

— Highway Performance Monitoring System

Procedural Manual For Data Submittal



System Condition



Safety



Vehicle Operating Cost



Comfort and Convenience





U.S. DEPARTMENT OF TRANSPORTATION Federal Highway Administration Program Management Division

Form FHWA 121 (Rev. 5-73)

UNITED STATES GOVERNMENT

Memorandum

DEPARTMENT OF TRANSPORTATION
FEDERAL HIGHWAY ADMINISTRATION

DATE: 2 4 AUG 1979

in reply refer to: HHP-12

ACTION: Distribution of Computer Software for the Highway Performance Monitoring

System (HPMS) Data Submittal

FROM: Director of Highway Planning Washington, D.C. 20590

to : All State Highway Agencies

THRU: Federal Highway Division Administrators

We appreciate the cooperative efforts of each State highway agency in implementing the Highway Performance Monitoring System. We fully recognize the magnitude of each State's efforts necessary to achieve this highly desirable goal. As a result, we have prepared software and guidelines for each State's use as an aid to develop the HPMS data submittal tape.

This memorandum transmits the "Procedural Manual for Data Submittal" and the associated battery of computer software that has been written to develop, edit and correct each State's section data that will be furnished to the FHWA on magnetic tape. The magnetic tape being distributed along with this memorandum and Procedural Manual contains the battery of programs as well as test data. All programs are written in COBOL.

Each State highway agency is encouraged to become familiar with the operation of this battery of programs through the use of the test data that have been furnished. Should problems occur when using the test data and/or in subsequent production runs, please contact:

Beverly Harrison

Special Studies Branch, HHP-12

Telephone: 202-426-0193

Kevin E. Heanue

K = E Hearne

Highway Performance Monitoring System

Procedural Manual For Data Submittal



U.S. DEPARTMENT OF TRANSPORTATION
Federal Highway Administration
Program Management Division
August 1979

Table of Contents

	Page
Introduction	1
Data Submittal Tape Specifications	2
STHPMS	3
Identification	3
Purpose	3
Components	3
Parameter Cards	3
ISTATE	3
Program Option Cards	4
SELDEV	4
SELMOD	5
SELEDT	- 6
SELTAB	7
Maximum Number Edit Errors (MAXERR)	8
Functional Class Curves/Grades Card	8
FUNCUR	8
FUNGRD	9
MFRS Option Card (OPMFRS)	9
Control Cards (Transactions)	9
Delete A Section Transaction Card	10
Update or Modify A Section Transaction Card	10
Add or Delete Bridge ID's Transaction Card	12
Add or Delete At-Grade Railroad Crossing ID's Card	13
Input/Output Datasets	14
Program Operation	17
DEVTAPE (SELDEV)	17
UPDATE (SELMOD)	18
EDITCK (SELEDT)	18
SUMTBLES (SELTAB)	19
Output	19
Dataset on Tape or Disk	19
Printed	19
Error Messages	20
STHPMS	20
DEVTAPE (SELDEV)	21
UPDATE	22
Core and Timing	24
Sample Run Setups	25
APPENDIX A - EDIT SPECIFICATIONS FOR HPMS SAMPLED DATA	
APPENDIX B - DATA ITEM NUMBERS	
APPENDIX C - HPMS RECORD FORMAT	
APPENDIX D - SAMPLE PRINTED OUTPUT	

Highway Performance Monitoring System (HPMS)

Procedural Manual for Developing the Data Submittal Tape

Introduction

The module of programs supplied for a State to use in preparing their HPMS data submittal tape will develop the database from cards or card images, edit the section data, correct errors in the data, and develop mileage, DVMT, and volume group summaries by functional class. The module consists of a main (calling) program, STHPMS, and four subprograms: DEVTAPE, EDITCK, UPDATE and SUMTBLES. (It should be noted that this module of programs has the capability of processing a mixed dataset consisting of both urban and rural section data.) The main program and four subprograms are written in COBOL and were designed and developed on an IBM 360/65 with full operating system (OS).

The module execution is controlled by user parameter cards through the main program, STHPMS. STHPMS calls the subprograms required by the options the user selected. The functions of the subprograms are as follows:

DEVTAPE reads the rural and urban section data on cards or card images in the FHWA worksheet format and creates the HPMS section record format on tape in sort by ID within county. The subprogram verifies that cards 1 and 2 and the optional cards specified by the user are present for each section. Only sections having valid card sets are added to the master dataset. A summary is produced for each volume group by functional class giving the number of sections added and rejected along with the sampled and expanded mileage. Lists of input cards, cards in error and a summary of sections for rural and urban areas are also produced.

EDITCK reads the HPMS dataset produced by DEVTAPE or UPDATE (or a State developed tape in the required format) and checks each data item for valid codes. Cross editing is also performed among data items. Each section ID is checked for uniqueness within a county. A listing is produced with errors and messages. 1/

UPDATE is used to correct section errors detected by the subprogram, EDITCK. Using transaction cards with the proper code, the user is able to delete or modify sections, and add or delete bridge and/or railroad crossing ID's. (Note: DEVTAPE is used to add a new section

 $[\]frac{1}{See}$ Appendix A for a complete listing of edit specifications.

to the existing dataset.) A summary is produced by section ID indicating the changes made to a section record. Also produced is a listing of input transaction cards and a listing of cards which have format errors.

SUMTBLES develops and produces two sets of summary tables. One table gives a summary of 1978 sampled and expanded mileage, 1978 DVMT, 2000 DVMT, average section length and the number of sections with lengths less than 0.3 for rural and 0.1 for urban for each functional class by area. The second table is a summary for each volume group within a functional class by area which contains the number of sections sampled and sampled and expanded mileage.

The module has been designed to enable a State to develop, edit and update their data for rural sections only or urban sections only if the State finds this easier for their particular work environment. However, the <u>final</u> edit and summaries <u>must</u> be run with only one dataset consisting of both the rural and urban section data in sort by ID within county.

Data Submittal Tape Specifications

1. The tape should have the following characteristics:

9 track EBCDIC Standard Labels 1600 BPI or 800 BPI

- 2. The rural and urban section data should be submitted on the same tape and in the same dataset in sort by section ID within county. The dataset name (DSNAME) should be URBRURXX, where XX is the twodigit State code (FIPS) listed in the "HPMS Field Implementation Manual."
- 3. The tape submitted should have a volume serial number of HPMSXX, where XX is the two-digit State code as listed in the "HPMS Field Implementation Manual."
- 4. The data control block (DCB) characteristics are to be as follows:

RECFM=VB LRECL=1823 BLKSIZE=9119

Each State is to submit the final edit run and the final two sets of summary tables with their data tape. Remaining errors in the data are to be explained on the edit listing. The tape and listings are to be provided to the FHWA division office for forwarding to the Special Studies Branch, HHP-12, by December 31, 1979.

STHPMS

A. Identification

Program Name: STHPMS Language: COBOL

Written By : Beverly Harrison

Special Studies Branch (HHP-12) Program Management Division, FHWA

Washington, D.C. 20590 Phone: 202-426-0193

Date : May-June 1979

B. Purpose

STHPMS processes the cards (or card images) punched from the HPMS rural and urban worksheets to develop a State's HPMS section database on tape, edits the database checking to see if each data item meets the specifications, updates the data items for each section found to be in error and developes and produces summary tables for 1978 mileage, 1978 DVMT, 2000 DVMT and volume groups by functional class for each area.

C. Components

STHPMS is the calling program in the module composed of four subprograms--DEVTAPE, EDITCK, UPDATE, and SUMTBLES.

D. Parameter Cards

There are several types of parameter cards the user may elect to use to execute STHPMS. The number and types of parameter cards required depends on the program option(s) selected. The parameter cards may be placed in the execution deck in any order.

1. State Name Card (ISTATE)

This card is required for <u>all</u> executions of the program. The keyword ISTATE is coded in columns 1-6 followed by an equal sign (=) in column 7. Starting in column 8, 1-25 characters and blanks may be used to code the State name. The State name is followed with the two-digit State code found in the "HPMS Field Implementation Manual." Both digits <u>must</u> be coded and must be coded as /xx/, where xx is the State code.

e.g., ISTATE=__TEST_HPMS_/99/

ISTATE=TEST HPMS/99/

2. Program Option Card (SELDEV, SELMOD, SELEDT, SELTAB)

The user must include at least one program option card and may include more than one of these cards in an execution.

a. SELDEV

This card enables the user to select the subprogram which processes the rural and/or urban cards (card images) punched from the HPMS worksheets and formats the cards into a record on tape for each sampled section. This card is also required when new sections are to be added to the existing database. SELDEV is punched in columns 1-6 followed by an equal sign (=) in column 7. The keywords for the options selected for the subprogram are then coded separated by a comma. The keywords may be coded in any order and are as follows:

Required Keywords

- -One keyword from this set must be selected.
- R Cards for rural sections only are being input.
- U Cards for urban sections only are being input.
- RU Cards for both rural and urban sections are being input.
- -One keyword from this set must be selected.
- REQONLY Only the required data are being submitted. (Cards 1 and 2 are being input.)
- REQOPT Required data plus some or all of the optional data are being submitted. (Cards 1-6 are being input.)

Optional Keywords

-If the keyword REQOPT is coded at least one of these keywords <u>must</u> be selected indicating which optional data is included.

CURVES Indicates curves are included for all sections for some or all functional classes, Card 3.

GRADES Indicates grades are included for all sections for some or all functional classes, Card 4.

BRIDID Indicates bridge ID's are included for some or all sections where applicable, Card 5.

CROSSID Indicates railroad crossing ID's are included for some or all sections where applicable, Card 6.

- -ADDSECT is coded if <u>new</u> sections are to be <u>added</u> to the existing database.
- -PUNERR is coded if the user wants the card sets in error punched as well as listed.

e.g., SELDEV=REQOPT, RU, GRADES, CROSSID Rural and urban sections
- optional grades
and railroad crossing
ID's coded.

SELDEV=PUNERR,R,REQONLY

Rural sections_required data only with card sets in error to be punched.

SELDEV=RU, ADDSECT, REQOPT, CURVES New rural and urban sections are being added to database with curves provided.

b. SELMOD

This card enables the user to select the subprogram which modifies (updates) or deletes a section in the database. This card is required if the user is correcting coding errors detected by the edit program. SELMOD is punched in columns 1-6 followed by an equal sign (=) in column 7. Each keyword selected for a subprogram option is then coded, followed by a comma. The keywords can be in any order. The keywords for SELMOD are as follows:

-One keyword from the following set must be coded.

- R Rural sections only are to be modified or deleted.
- U Urban sections only are to be modified or deleted.
- RU Rural and urban sections are to be modified or deleted.

-One keyword from the following set must be coded.

ADDMOD Indicates sections are to be <u>added</u> to the existing tape <u>and</u> the database is then to be <u>modified</u>. When this keyword is used, the program option card SELDEV with keyword ADDSECT <u>must</u> also be included.

MODONLY Coded when sections are to be modified or deleted and no new sections are being added.

e.g., SELMOD=RU, MODONLY

Rural and urban sections are to be modified or deleted.

No new sections are to be added.

c. SELEDT

This card enables the user to select the subprogram which checks each data item to see if it has been coded to specifications. In columns 1-6, punch SELEDT followed by an equal sign (=). Starting in column 8, code the keyword(s) for the subprogram option selected, each separated by a comma. The order of the placement of the keywords is not significant. Select options using the following keywords:

Required Keyword

-One of these keywords must be coded:

R Rural sections are to be edited.

U Urban sections are to be edited.

RU Rural and urban sections are to be edited.

Optional Keywords

-FINAL Indicates the final edit is to be made on the rural <u>and</u> urban sections in the HPMS database. The listing from this edit is to be submitted to FHWA with the data tape.

-ERRMESS Indicates the user wants a suppressed listing with section ID, item number in error and messages only. When this keyword is omitted, the listing includes the value coded for each data item for a section in error along with item number in error and message.

And the state of the Marian State of the Sta				

-FHWADESIGN Indicates the State has used the volume groups and ADT ranges contained in the "HPMS Field Implementation Manual" and that the volume group number coded is to be checked against the 1978 ADT. If this keyword is not coded, the volume group number is not verified with the 1978 ADT value.

-MFRS Indicates the State is not coding the items that could be reported via MFRS (* items in Manual).

e.g., SELEDT=R, FHWADESIGN Rural sections to be edited with volume group number and 1978 ADT verified.

SELEDT=FINAL, RU Final edit is to be made on all (rural and urban) HPMS sections.

d. SELTAB

This card enables the user to select the subprogram which developes and produces the summary tables for 1978 mileage, 1978 DVMT and 2000 ADT by functional class by area and the summary table for the volume groups by functional class, by area. SELTAB is coded in columns 1-6 followed by an equal sign (=). Starting in column 8, code the keyword(s) for the subprogram options selected with a comma separating each one. There is no required sequence for the keywords selected. The SELTAB keywords are:

-One keyword from the following set must be selected.

R Rural summary tables will be produced.

U Urban summary tables will be produced.

RU Rural and urban summary tables will be produced.

-One or both of the following keywords must be selected.

VOLGRP Indicates the summary tables for the volume groups are to be developed and printed.

DVMTMILE Indicates the summary table (s) for the mileage and DVMT are to be developed and printed.

-Optional Keyword

FINAL Indicates the final set of summary tables are to be produced for the HPMS database and are to be submitted to FHWA along with the final edit and submittal tape.

e.g., SELTAB=FINAL, DVMTMILE, VOLGRP, RU

Final set of both tables to be produced.

SELTAB=VOLGRP, RU

The tables for the volume group summaries are to be produced for use by the State.

3. Maximum Number Edit Errors (MAXERR)

This card is optional and is coded if the user wants the subprogram which edits the data to stop execution when a maximum number of sections with coding errors is reached. If MAXERR is included in the execution deck, the program option card, SELEDT, <u>must</u> be included. MAXERR is punched in columns 1-6 followed by an equal sign (=). Starting in column 8, code the numeric value for the maximum number of sections allowed to be in error. From 1 to 5 digits may be coded. The default value (card omitted) is for all sections in the database to be edited.

e.g., MAXERR=550 Execution for the edit subprogram will terminate when 550 sections with at least one data item in error had been detected.

4. Functional Class Optional Curves/Grades Card (FUNCUR, FUNGRD)

These cards are required if the optional data is being provided for curves and/or grades to indicate which functional class(es) will have the data coded. They are necessary since the optional grades and/or curves data must be provided for an entire functional class. Both cards may be included in the same execution.

a. FUNCUR

This card is required if the user has included the SELDEV card with the keywords, REQOPT and CURVES coded. In columns 1-6, punch FUNCUR followed by an equal sign (=). Starting in column 8, punch the functional class code for all classes (rural and/or urban) which will have curve data coded. Leading zeroes are optional for the rural functional class codes.

e.g., FUNCUR=2,11,14 Curves provided for rural functional classes 2 and urban functional classes 11 and 14.

FUNCUR=12,01,11 Curves provided for urban functional classes 11 and 12 and rural functional class 01.

b. FUNGRD

This card is required if the user has included the SELDEV card with the keywords, REQOPT and GRADES coded. FUNGRD is punched in columns 1-6 followed by an equal sign (=). Punch the functional class code for all classes (rural and/or urban) which will have grade data coded starting in column 8. The leading zero for the rural functional class codes is optional.

e.g., FUNGRD=17,11,01 Grades data will be provided for urban classes 17 and 11; rural, 01.

FUNGRD=2,12,06,16 Grades data will be provided for rural classes, 02 and 06; urban, 12 and 16.

5. MFRS Option Card (OPMFRS)

This card is optional and is used only by a State submitting part of their HPMS data items via MFRS (* items on the worksheet in the HPMS Implementation Manual). If all data items are being coded in the HPMS database, this card will not be included in the execution deck. In columns 1-6, punch OPMFRS followed by an equal sign (=). One of the following keywords must then be coded starting in column 8.

YFC Indicates all * items except functional class are coded via MFRS. The functional class code is being coded for all sections with the remaining * items coded zero.

NFC Indicates all * items including functional class are being submitted via MFRS and are coded zero.

e.g., OPMFRS=YFC Functional class is being coded and all remaining * items are coded zero.

OPMFRS=NFC All * items including functional class are being coded zero.

E. Control Cards (Transactions)

If the program option SELMOD has been selected by the user, control cards are required to indicate which transactions are to be performed by subprogram UPDATE. There are four kinds of transaction control cards used by UPDATE:

- -Delete a section
- -Modify or update a section
- -Add or delete bridge ID's
- -Add or delete at-grade railroad crossing ID's

Each transaction card must contain the county and section ID coded for the section which is to be altered. The delete card cannot be used with any of the other three transaction cards for the same section; however, the other three cards may be included for the same section. If a combination of transaction cards is used, all of one kind must be placed together in sequence. There may be only one delete card per section and from 1 to 10 each of the other three transaction cards per section.

The card format for each transaction control card will be discussed separately.

1. Delete a section transaction card.

This card enables the user to remove a section from the database. The card format is as follows:

Transaction card code"D"	column 1
Sequence numberalways "01"	columns 2-3
County code	columns 4-6
Section identification code	columns 7-18
Occurrence of section to be deleted	column 19
Blank	columns 20-80

The county code <u>must</u> be a three-digit numeric value. The section identification <u>must</u> be coded exactly as the one to be deleted (embedded blanks must be the same if the ID was placed in database with blanks as part of it). The occurrence of the section to be deleted must be numeric and tells which matching section is to be deleted if there is more than one in the database.

e.g., D01124__RT11__10212 Delete the second section with matching ID.

2. Update or modify a section transaction card.

This card enables the user to correct the coding errors in the data items. The update transaction card may be used in combination

with the bridge ID card and/or the at-grade railroad crossing ID card. The card must have the following format:

Transaction card code--"U"

column 1

Sequence number--"01-10"

columns 2-3

County code

columns 4-6

Section ID

columns 7-18

Data item number to be updated and data value in the following format:

columns 19-80

 $/N_1, D_1/N_2, D_2/N_3, D_3/.../N_i, D_i/$

where N_i = data item number to be updated*

 D_i = new data value

*The data item numbers are listed in Appendix B.

Several updates may be coded on one card providing that the last column coded contains a "/" thereby requiring both "N" and "D" values for a given update to be on the same card. The value coded for the data item <u>must</u> contain the same number of characters as the length of the data item, i.e., to update Item 43, 2000 ADT, one <u>must</u> code 6-digits. Leading zeroes <u>must</u> be coded for all numeric data items.

The data items which have a part a, b, or c (e.g., Item 18 or Item 27) must have the letter coded as part of the item number as indicated in Appendix B—that is, to correct the right shoulder width to "10" one would code /18-A,10/. The data items with more than one set of values (e.g., railroad crossing or bridge ID's) must have the position of the one to be corrected as part of the item number as indicated in Appendix B—that is, to correct the third railroad crossing ID, one would code /56-03,007631A/. The position for the item number must be coded as two digits with leading zero.

The sequence number always start with 01, must be two digits and indicates the location of the update card when there is more than one per section. The county code must have a three-digit numeric value and the section ID must be coded exactly as the ID for the section in the database. If all the data item corrections required for a section cannot be coded on 10 update cards, another execution will have to be made to correct any remaining data items. There cannot be more than 10 update cards with the same county and section ID code.

e.g., U01017____000011289/11,0110/27-B,03/ Item 11, section length is to be corrected to a value "0110"; Item 27-B, number at-grade intersections with stop signs is to be corrected to a value of "03".

U06020 _____286/53-E,02023/56-12,701936A/33,2/
Item 53-E, curves is changed to "02023"; Item 56, the 12th crossing ID is to be corrected to "701936A";
Item 33, terrain is changed to "2".

3. Add or delete Bridge ID's transaction card.

This card enables the user to add the optional bridge ID's to an existing section, add more bridge ID's to a section which already has ID's coded (<99) or delete one or more ID's from the existing set of ID's for a section. This card may be used in combination with the update card and/or at-grade crossing ID card. The bridge ID transaction card format is as follows:

Transaction card code"B"	column 1
Sequence number"01-10"	columns 2-3
County code	columns 4-6
Section ID	columns 7-18
Function performed on bridge ID"A" add ID's coded"D" delete ID's coded	column 19

Bridge ID's to be added or deleted columns 20-79 coded 15 characters each, 1 to 4 per card

Blank

column 80

The sequence number <u>must</u> begin with 01, be numeric and must have two digits coded. A three-digit numeric value must be coded for the county code and the section ID must be coded exactly as the existing section in the database. Only one function, "D" or "A", may be coded per card and all ID's coded on that card will be added or deleted; however, existing bridge ID's may be deleted for a section and new ID's added by coding one or more cards with a "D" and one or more with an "A". Each bridge ID <u>must</u> be 15 characters (blanks included) in length.

e.g., B01171 ___ RT07628D2243CTYRT1ORT25

B02171 ___ RT07628A_FED76982761072FED769871469352

Two bridge transaction cards for one section. First a bridge ID is to be deleted and then two new ID's are to be added for the section.

If more than 40 bridge ID's are to be deleted and/or added for a section, the subprogram UPDATE will need to be executed more than once since the maximum number of ID's that can be coded in one execution is 40 (4 per card, 10 cards maximum).

4. Add or delete at-grade railroad crossing ID's card.

The use of this card enables the user to add the optional crossing ID's to an existing section, add more crossing ID's to a section which already has ID's coded (<15) or delete one or more ID's from the existing set of ID's for a section. The crossing transaction card may be used in combination with the update and/or bridge ID transaction cards. The card format is as follows:

Transaction card code"C"	column 1
Sequence number"01-10"	columns 2-3
County code	columns 4-6
Section ID	columns 7-18
Function performed on Crossing ID	column 19

--"A" add ID's coded --"D" delete ID's coded

per card -

Crossing ID's to be added or deleted columns 20-75 coded as 7 characters each, 1 to 8

Blank

columns 76-80

The sequence number <u>must</u> be a two-digit numeric value and <u>must</u> start with O1. The county code must be a three-digit numeric value. The section ID coded must match the one in the database exactly. Crossing ID's may be deleted and added for the same section by using 2 or more crossing ID transaction cards, some with a function of "D" and some with "A". Each crossing ID coded <u>must</u> be 7 characters in length—six numeric digits and one alphabetic.

e.g., CO1273_____12854D724329B816629F CO2273_____12854A872131J923517D396424A157739H

Two crossing transaction cards for the same section. The first function says delete 2 crossing ID's; then add 4 crossing ID's to the section.

F. Input/Output Datasets

Several datasets are used during execution depending on the program option(s) selected. For a reference to see the datasets required for each program option, see Table 1.

1. SYSUDUMP/SYSABEND Standard "system output" dataset used if the program abnormally terminates during execution. Destined to the printer.

Required for all executions.

2. SYSOUT Standard "systems output" dataset for printing system messages. Required for all executions.

3. SYSIN Input dataset containing the program parameter cards. Consists of 80 - character records. Required for all executions.

4. PRINTOUT Output dataset destined to the printer for listing of parameter cards, error messages and summary tables. Required for all executions.

5. DATAIN

Input dataset containing the cards punched from the rural and/or urban worksheets or card images. Contains 80 - character records. Required for program option SELDEV.

The card set must be in sort by functional class within area.

Input/output dataset which contains the HPMS section data. The DCB parameters are defined by the subprogram when used as input or output. Required output dataset for program option SELDEV. If SELDEV is coded with keyword ADDSECT, then the DISP parameter must be coded - DISP=(MOD,...) - so the added sections may be placed at the end of the current HPMS section database. Required input dataset for the program option SELEDT and/or SELTAB if these program options are selected with SELDEV without the keyword ADDSECT.

7. CURDATA

SECTION TO

Input/output dataset which contains the HPMS section dataset. The DCB parameters are defined by the subprogram(s). Required output dataset for the program option SELDEV with keyword ADDSECT. Required input dataset for SELMOD. Required input dataset for SELTAB or SELEDT and SELTAB. Required input dataset for program option SELEDT and/or SELTAB and SELDEV with keyword ADDSECT.

8. NEWDATA

Input/output dataset which contains the HPMS section data. The DCB parameters are defined by the subprogram. Required output dataset for the program option SELMOD. Required input dataset for SELEDT and/or SELTAB if these program options are selected with (1) SELDEV with keyword ADDSECT and SELMOD with keyword ADDMOD or (2) SELMOD with keyword MODONLY.

9. ERRCARDS

Output dataset destined to the card punch. Contains 80 - character records. Required output for the program option SELDEV with keyword PUNERR.

10. ERRLIST

Output dataset destined to the printer.
Required output dataset for the program
option SELDEV and/or SELEDT and/or SELMOD.
Contains user supplied cards found to be
in error and/or error messages.

MODCARD

Input dataset destined to the card reader. Consists of the 80 - character transaction cards to modify and/or delete sections. Required dataset for program option SELMOD.

12. ALTFILE

Temporary input/output dataset required for the program option SELMOD. Contains the sorted valid transaction card sets to modify and/or delete HPMS sections. The DCB parameters are defined by the program.

13. SORTLIB

Dataset containing the sort routine. Required for program option SELDEV and/or SELTAB and/or SELMOD.

SORTWK01 SORTWK02 SORTWK03 Intermediate storage datasets for sorting applications. The sort program requires at least three work datasets. Additional work datasets may be defined with DD names beginning with SORTWK04 when larger amounts of data are to be sorted. Required datasets for program option SELDEV and/or SELTAB and/or SELMOD.

Table 1

Datasets Required for Each Program Option

	SELDEV	SELMOD	SELEDT	SELTAB
Datasets				
SYSUDUMP SYSOUT SYSIN PRINTOUT	0 0 1 0	0 0 I 0	0 0 I 0	0 0 I 0
DATAIN SECTDATA CURDATA NEWDATA	I O O(Keyword O(ADDSECT)	I O	I	I
ERRCARDS ERRLIST MODCARD ALTFILE	O(Keyword) OPUNERR	0 I 0/I	0	
SORTLIB SORTWK01 SORTWK02 SORTWK03	I I I I	I . I I		I I I

G. Program Operation

The parameter cards are read and processed to determine which program option cards have been included and which keywords were selected for these program options. Each card read is edited for general format—valid parameter card name with valid keywords and numeric value where required. Once a general error is detected, the remainder of the parameter cards are read and listed without being processed for selections along with the appropriate general error message. If the end of the parameter cards are reached without any general error being detected, a more detailed edit is performed on the set of cards with specific error message(s) listed for any error(s) detected. Some of the detailed edits are:

- 1. ISTATE card must be included in card set.
- 2. If SELMOD with keyword ADDMOD, then SELDEV card must be included in card set.
- 3. If MAXERR card is included, then SELEDT card must be present in card set.
- 4. If SELDEV with keywords REQOPT and CURVES, then FUNCUR must be included in card set.

If at least one error is detected—general or from the more detailed editing—the execution of STHPMS terminates with the parameter cards listed along with the appropriate error message(s).

Once the end of the parameter cards are reached with no errors, STHPMS proceeds to call the subprogram(s) required to perform the program option(s) selected by the user. Each subprogram operation will be discussed briefly in the order in which they are called.

DEVTAPE (SELDEV)

Each set of cards is checked to verify that required card 1 and card 2 with matching ID's are present; and, if curves (card 3) and/or grades (card 4) are to be provided the program verifies each is present for the functional classes coded on the FUNCUR or FUNGRD parameter cards. If cards 5 or 6 are provided, the ID's are verified with those on card 1. Any section with errors in the card set is not added to the dataset created by the program. Each valid section is added to the dataset in the HPMS record format (see Appendix C), added to the appropriate matrix for the volume group summary by functional class and added to the rural or urban section count. Upon reaching the end of the section punched cards, the output dataset is sorted by section ID within county; the volume group summary report is printed by functional class by area; cards in error are listed with error messages and a summary report for the data in the dataset is printed. Execution then returns to the main program, STHPMS, and the next subprogram selected is called.

UPDATE (SELMOD)

The transaction card sets are read and checked for general format errors with each valid set being placed in a temporary dataset, ALTFILE, with one record consisting of all cards (1-10) in a transaction set. When the end of the transaction cards is reached, ALTFILE is sorted by ID within county to match the ordering on the dataset from DEVTAPE used as input for this program. Next, the process of matching the section ID on the ALTFILE with the section to be modified or deleted begins. Once a match is found, the section record is not written on the new master dataset for a delete transaction or the section is written on the new master dataset with the corrected (update) data value, bridge ID's added and/or deleted or railroad crossing ID's added and/or deleted. This matching process continues until the end of the ALTFILE or the section dataset is reached. During this process, sections not being updated (unmatched) are copied to the new master dataset. A summary is written indicating the transactions by section ID for rural and urban. A listing is also given showing all transaction cards input, cards in error and error messages. Upon completion of all reports, execution control returns to STHPMS and the next subprogram selected is called.

EDITCK (SELEDT)

Each section record is read and the rural/urban code is checked to match the area with the user selection on the parameter card--R, U, or RU. All data items in the section record are then verified for valid codes with the data items which are coded for all sections being edited. Next, the urban only or rural only data items are verified. The program then checks to see if the MFRS option was selected and uses the appropriate edits with MFRS coding or non-MFRS. If the keyword FHWADESIGN was selected, each volume group number is checked with the 1978 ADT coded to verify the ADT falls within the range of ADT's for the volume group coded. Next, the program checks to see if the section has any optional data coded; if so, then, it checks to see which optional data and executes only the edits for the optional data coded. If no errors are detected, the next section record is read and the editing for that section is performed. If at least one data item was found to be in error, a check is made to see which print option was selected -- section ID's with error messages or section ID's, all coded values for data items and error messages. The appropriate listing is then printed along with calculations being made for the summary report. After the section with errors is printed, a check is made to see if the number of sections in error exceeds the maximum number of errors allowed, if not, a new section record is read and the editing is performed for that section. When the maximum number of errors allowed is exceeded or the end of the dataset is reached, the edit summary report is printed and execution returns to STHPMS and the next subprogram selected is called.

SUMTBLES (SELTAB)

The program reads each section record checking to see if the rural/ urban code matches the selection on the SELTAB parameter card--R, U, or RU. A work record is created containing the data items required for the calculations in the two summary tables -- mileage and DVMT summaries or volume group summaries. Upon reaching the end of the HPMS section dataset, the work file is sorted by urbanized code (Note the urbanized code for rural sections is coded "000"; small urban, "999"). Each sorted record is then returned with the appropriate checks for placement of the data in the proper matrices and calculations being performed for each table selected -- mileage and DVMT and/or volume group. When the end of an urbanized area or area is reached, the end calculations required for the mileage and DVMT table are performed if the user selected this summary. After all calculations are made, each table selected is printed with the mileage/DVMT table first; then, the volume group summary table for each functional class within the area. The above procedure continues until the end of the sorted file is reached. Execution then returns to STHPMS and execution stops.

· 新教育的基础的 · 斯克克斯斯斯斯 · 中原一个

H. Output

1. Dataset on Tape or Disk

The program option SELDEV creates a dataset with one record for each HPMS sampled section in the HPMS record format. The program option UPDATE creates a dataset with corrected values for the HPMS data items. Appendix C contains the HPMS record format.

2. Printed

- a. List of parameter cards provided by the user.
- b. Error messages if invalid parameter cards are used.
- c. Volume group summaries for data added to dataset.
- d. List of invalid cards when data is being added to dataset in card format with error message.
- e. Error messages and/or section data item values from editing of data.
- f. Update sumamries.
- g. Summary tables for mileage, DVMT and volume groups.

Appendix D contains samples of printed output.

I. Error Messages

The messages are listed below for STHPMS and each program option. (The edit messages for the data items in error will not be listed as the edit specifications are included in Appendix A.)

STHPMS

- 1. "INVALID KEYWORD ON PARAMETER CARD" Indicates the user has misspelled a keyword. Execution terminates.
- 2. "INVALID FORMAT ON PARAMETER CARD" Indicates the equal sign, required slashes, or comma has been omitted. Execution terminates.
- 3. "REQUIRED STATE NAME CARD MISSING" Indicates the ISTATE card is missing. Execution terminates.
- 4. "PROGRAM OPTION SELDEV SELECTED WITH REQOPT INDICATED. OPTIONAL DATA TO BE CODED WAS NOT INDICATED" Indicates the user needs to verify the type of data being provided in card format. Execution terminates.
- 5. "VALUE CODED FOR MAX NUMBER ERRORS ALLOWED (NUMERR) OR STATE CODE OR FUNCTIONAL CLASS IS NOT NUMERIC" Indicates a nonnumeric has been coded for a numeric. Execution terminates.
- 6. "FUNCTIONAL CLASS NOT INCLUDED FOR OPTIONAL CURVES AND/OR GRADES DATA" Indicates user has coded keyword CURVES and/or GRADES WITHOUT INCLUDING THE FUNCUR and/or FUNGRD card. Execution terminates.
- 7. "INVALID CARD NAME ON PARAMETER CARD" Indicates the user has miscoded the card name. Execution terminates.
- 8. "PROGRAM OPTION SELDEV SELECTED WITH REQONLY INDICATED. OPTIONAL DATA CODED ON SELDEV CARD. VERIFY " Indicates the user needs to verify which type of data is being provided in card format. Execution terminates.
- 9. "SELDEV CARD DOES NOT HAVE TYPE DATA KEYWORD CODED REQONLY OR REQOPT" Indicates the user has not coded what data are being provided in card format. Execution terminates.
- 10. "PARAMETER CARDS DO NOT CONTAIN AT LEAST ONE PROGRAM OPTION CARD--SELDEV, SELEDT, SELMOD, SELTAB" Indicates the user did not select a program option. Execution terminates.
- 11. "MAXIMUM NUMBER ERRORS CODED WITHOUT PROGRAM OPTION SELEDT CARD" Indicates the MAXERR card was included when the edit program was not selected. Execution terminates.

- 12. "SELDEV CODED REQONLY. CURVES AND/OR GRADES FUNCTIONAL CLASSES HAVE BEEN CODED. VERIFY CARDS" Indicates the user needs to check what data is being provided in card format. Execution terminates.
- 13. "ADDMOD CODED ON SELMOD CARD. REQUIRED SELDEV CARD MISSING FOR THIS SELECTION" Indicates new sections are to be added to the dataset, but the program which adds sections was not selected. Execution terminates.
- 14. "MODONLY CODED ON SELMOD CARD. SELDEV CARD CODED FOR THIS SELECTION IS IN ERROR. VERIFY SELECTIONS" Indicates the program to add sections to dataset was selected but the keyword on SELMOD indicated sections in existing dataset were to be modified only. Execution terminates.
- 15. "PARAMETER CARDS CONTAIN AT LEAST ONE ERROR. CHECK ALL CARDS. EXECUTION TERMINATED" Self-explanatory.

DEVTAPE (SELDEV)

- 1. "INVALID CARD NUM FOR REQUNLY" Required only data indicated but cards 3-6 are included or some other number is punched in column 80. Section is not added to dataset. Verify card number.
- 2. "ID's DON'T MATCH CARDS 1 & 2" The section ID has been miscoded on one of the cards. Section is not added to dataset.
- 3. "CARD 1 MISSING FOR SECTION" Each sampled section must have a card 1 & 2. Section is not added to dataset.
- 4. "CARD 2 MISSING FOR SECTION" See No. 3 above.
- 5. "REQUIRED CARD 1 & 2 MISSING" See No. 3 above.
- 6. "CARD 3 OR 4 MISSING FC LISTED" Indicates the functional class coded on card 1 is to have curve (card 3) or grade (card 4) data coded. Section is not added to dataset.
- 7. "TOO MANY CROSSING ID CODED" The section record format has been set up to allow for 1-15 railroad crossing ID's per section. Section is not added to dataset.
- 8. "ID's DON'T MATCH OPT CARD(S)" The section ID coded on cards 3-6 does not match the ID on cards 1 & 2. Section is not added to dataset.

- 9. "FC LISTED CARDS 3 & 4 NOT CODED" Functional class has been coded to have both curves and grade data. Both cards are not coded. Section is not added to dataset.
- 10. "INVALID CARD NUMBER NOT 1-6" Column 80 contains some other number or nonnumeric character. Section is not added to dataset.
- 11. "CHECK FC LIST FOR CUR/GRD" Curve (card 3) or grade (card 4) data has been coded for a functional class not listed on FUNCUR or FUNGRD card. Section is not added to dataset.
- 12. "TOO MANY BRID ID CODED" The section record format has been set up to allow for 1-99 bridge ID's per section. Section is not added to dataset.
- 13. "BRIDID (C5) NOT LISTED AS OPT" or "XINGID (C6) NOT LISTED AS OPT" or "CURVES (C3) NOT LISTED AS OPT" or "GRADES (C4) NOT LISTED AS OPT"-Optional data has been coded but was not indicated to be included. Section is not added to dataset.
- 14. "INVALID CODE CARD 1 COLUMN 79" Card 1 contains an invalid rural/ urban code. Must be coded 1 for an urban section; coded 2 for a rural section. Section is not added to dataset.
- 15. "RU CODE NOT = TYPERUN SELECT" Indicates the user coded R or U on the SELDEV card, but rural cards have been included when "U" was coded or urban cards have been included when "R" was coded. Section is not added to dataset.

UPDATE (SELMOD)

- 1. "UPDATE CARD IMPROPER FORM" Indicates the user has not coded the update transaction card correctly. This card is not used.
- 2. "SEQ NUM MUST BE NUMERIC > 0" Indicates the sequence number on the transaction card has been miscoded. The transaction is not used for the card set with matching ID.
- 3. "CK: SEQ NUM, ID or TRAN CODE" The ordering of the transaction set should be verified, section ID and county code checked. In some situations, the transaction code may be invalid. The set with matching ID's is not used.
- 4. "DELETE CARDS > 1 WITH SAME ID"-More than one delete card has been included for the same section. The deletion is not performed for either card. Verify ID's on cards.

- 5. "INVALID TRANSACTION CODE" The first column on the card does not contain a U, D, B, C. The transaction set with matching ID is not used.
- 6. "CARDS IN TRANSACTION SET > 10" The ID's on all cards should be verified to see if two different section modifications have been coded as one or the transaction code should be verified to see if two different codes should have been used. The set is not used.
- 7. "TRAN CODE NOT =; SEQ # > 1, ID =" Different transaction codes coded for same ID with a sequence number not equal O1. Verify ID, transaction code, and sequence number. The set is not used.
- 8. "TOO MANY BRID/XING ID FOR SECT" Indicates the addition of bridge or crossing ID's exceeded the maximum number bridge, 99; crossing, 15. Only the ID's beyond the maximum number were not added. Card with these ID's is listed.
- 9. "INVALID ITEM NUMBER" Indicates that particular update could not be performed. All valid updates on card are performed.
- 10. "ID TRANS NOT = ID FOR SECTION" Indicates the county code and section ID on the transaction card does not match any in the dataset. No transaction performed.
- 11. "OCCURRENCE OF DELETION INVALID" Indicates ID for deletion matched but there was only one section with that ID. Deletion is not performed.
- 12. "INVALID FORMAT FOR UPDATE CARD" Verify the coding of card. This particular card is not used but all valid cards in set are used and updates are performed.
- 13. "INVALID FORMAT FOR UPDATE" Indicates that particular update has a coding error--not of form /xx,xxxx/ or /xx-x, xx/. All valid coded updates on card are used.
- 14. "INVALID FORMAT FOR BRIDID CARD' Indicates that particular bridge transaction card is miscoded and is not used. Any valid cards in set are used with actions performed on section.
- 15. "INVALID FORMAT FOR XINGID CARD" Indicates that particular crossing transaction card is miscoded and is not used. Any valid cards in set are used with actions performed on section.
- 16. "INVALID FORMAT FOR DELETE CARD" Indicates the card is miscoded. The deletion is not performed.

- 17. "INVALID SUB-ITEM LETTER OR NUM" Indicates the letter coded for item number 18, 27, 37, 42, 53, or 54 is miscoded or the bridge ID referenced is > 99 or the crossing ID referenced is > 15. The update is not performed. Any other valid updates on card are performed.
- 18. "CODE NOT 'A' or 'D' FOR ID'S" Indicates the action to be performed on bridge or crossing ID is miscoded. This card is not used. Any other valid card in set is used.
- 19. "DEL BRID/XING ID DOESN'T MATCH" Indicates the ID coded to be deleted from section bridge ID's or crossing ID's is not on data record. Verify. Any other valid ID to delete on card is deleted for section.
- 20. "INVALID ITEM NUM WITH SUB-ITEM" Indicates a letter or number has been coded for an item number which has no subitems. See Appendix B to verify which data items have subitems. This particular update is not performed, but any valid update on card is performed.
- 21. "DEL CARD & OTHER TRAN CARD = ID" Indicates a delete for a section has been coded with an update, crossing ID action or bridge ID action for the same section. Verify transaction codes. Cards are not used.
- 22. "ITEM NUM MUST HAVE SUB-ITEM" Indicates the coded item number must have a letter or number subitem. This particular update is not made. Any other valid updates on card are performed.

J. Core and Timing

The amount of core and CPU time required depends on the program option selected or combination of program options selected. The amount of core for execution varies from approximately 100K bytes to 166K bytes. The approximate amount of core by program option is as follows:

DEVTAPE(SELDEV) 142K bytes
EDITCK(SELEDT) 100K bytes
*UPDATE(SELMOD) 134K bytes or 166K bytes
SUMTBLES(SELTAB)140K bytes

*SELMOD requires the larger amount of core for execution to sort the new master dataset if a county code or section ID is modified.

The amount of CPU time per 125 sections varies from 2.00 seconds to 8.70 seconds depending on the program option or combinations of program options being executed.

K. Sample Run Setups

EDIT SETUP WITH MAXIMUM NUMBER ERRORS SET PRINTED OUTPUT ERROR MESSAGES ONLY

```
//HPMS EXEC PGM=STHPMS, REGION=100K
//STEPLIB DD DSN=STATE.HPMS.LOADLIB, VOL=SER=SHP002, UNIT=SYSDA,
    DISP=OLD
//SYSOUT DD SYSOUT=A
//SYSUDUMP DD SYSOUT=A
//SYSIN
       DD DATA
ISTATE= TEST HPMS /99/
SELEDT=RU, FHWADESIGN, ERRMESS
MAXERR=100
/×
//PRINTOUT DD SYSOUT=A, DCB=(RECFM=FB, BLKSIZE=133)
//CURDATA DD UNIT=SYSDA, DISP=(OLD, KEEP),
     VOL=SER=SHPO02,DSNAME=HPMSTEST
11
//ERRLIST DD SYSOUT=A;DCB=(RECFM=FB;BLKSIZE=133)
14
11
```

SUMMARY TABLES SETUP RURAL DNLY

```
//HPMS EXEC PGM=STHPMS, REGION=240K
//STEPLIB DD DSN=STATE.HPMS.LOADLIB.VOL=SER=SHP002.UNIT=SYSDA,
    DISP=OLD
11
//SYSOUT DD SYSOUT=A
//SYSUDUMP DD SYSOUT=A
//SYSIN DD DATA
ISTATE= TEST HPMS /99/
SELTAB=VOLGRP, DVMTMILE, R
//PRINTOUT
           DD SYSOUT=A, DCB=(RECFM=FB, BLKSIZE=133)
//CURDATA DD UNIT=SYSDA, DISP=(OLD, KEEP),
    VOL=SER=SHPG@ 2.DSNAME=HPMSTEST
//SORTLIB DD DSNAME=SYS1.SORTLIB.DISP=SHR
//SORTWKO1 DD UNIT=SYSDA, SPACE=(CYL, (1,1))
//SORTWKO2 DD UNIT=SYSUA, SPACE=(CYL, (1,1))
//SORTWKO3 DD UNIT=SYSDA, SPACE=(CYL, (1,1))
//SORTWK04 DD UNIT=SYSDA, SPACE=(CYL, (1,1))
//SORTWK05 DD UNIT=SYSDA, SPACE=(CYL, (1,1))
/李
11
```

NOTE: Printed output requires 65 lines of print.

DEVELUP DATASET, m LIG SAMPLE SETUP SECTION DATA, D KURAL /URBAN DVMT ç., MILEAGE SUMMARY TABLE


```
//SORTWROD
//SORTWROD
//SORTWROD
//SORTWROD
                                                                                                                                                                                                                                                                                                  ISTATE= TEST HPMS /99/
SELDEV=RU,REQOPT,CURVES,GRADES,BRIDID,CROSSID
FUNCUR=@6,02,12,16
FUNGRD=@6,16,02
SELEDT=RU,FHWADESIGN
SELTAB=RU,DVMTMILE
                                                                                                                                                                                                                                                         //PRINTCUT
\
*
                                                                               //SORTLI
                                                                                                                                                                                                                                                                                                                                                                                                                                   //STEPLIB DD
                                                                                                                                                                                                                                                                                                                                                                                        //SYSUDUMP
                                                                                                                                                                                                              '/PRINTOUT DD SYSOUT=A,DCB=(RECFM=FB,BLKSIZE=133)
'/SECTDATA DD UNIT=SYSDA,DISP=(NEW,KEEP),SPACE=(TRK,(4,
'/ VOL=SER=SHP002,DSNAME=STATE.HPMS.TEST
'/ERFLIST DD SYSOUT=A,DCB=(RECFM=FB,BLKSIZE=133)
'/DATAIN DD DATA
                                                                                                                                                                                                                                                                                                                                                                                                                                                               /HPM
                                                                                                                                                                                                                                                                                                                                                                                                                   TUOSAS/
                                                                                                                                                                                                                                                                                                                                                                                                                                                                 EXEC
                                                                                  œ
                                                                                                                                                                                                                                                                                                                                                                                                                    O
                        00
                                                    000
                                                                                                                                                                                                                                                                                                                                                                                                        DD
                                                                                 \tilde{\sigma}
                                                                                                                                                                                                                                                                                                                                                                                        DATA
                                                                                                                                                                                                                                                                                                                                                                                                       SYSOUT=A
                                                                                                                                                                                                                                                                                                                                                                                                                                                PGM=STHPMS.REGION=150K
DSN=STATE.HPMS.LOADLIB.VOL=SER=SHP002.UNIT=SYSDA.
          DSNAME=SYS1.SORTLIB, DISP
UNIT=SYSDA, SPACE=(CYL, (
                                                                                                                                                         ECTION
                                                                                                                                                       DATA
                                                                                                                                                         S
                                                                                                                                                         CARDS
                                                                                                                                                         60
                                                                                    DII
                                                                                    SHR
                                                                                                                                                          7
                                         just fred ford
                                                                                                                                                         in Rin
```

NOTE: Printed output requires 65 lines of print

SAMPLE SETUP MODIFY SECTION DATASET & EDIT THE NEW MASTER DATASET ONLY ERROR MESSAGES PRINTED FROM EDIT

```
//HPMS EXEC PGM=STHPMS, REGION=140K
//STEPLIB DD DSN=STATE.HPMS.LOADLIB, VOL=SER=SHPQ02, UNIT=SYSDA,
     DISP=OLD
//SYSOUT DD SYSOUT=A
//SYSUDUMP
           DD SYSOUT=A
//SYSIN DD DATA
I STATE=
        TEST HPMS /99/
SEL MOD=RU, MODONLY
SELEDT=RU, FHWADESIGN, ERRMESS
//PRINTOUT DD SYSOUT=A, DCB=(RECFM=FB, BLKSIZE=133)
//CURDATA DD UNIT=SYSDA, DISP=(CLD, KEEP),
   VOL=SER=SHP@@2.DSNAME=STATE.HPMS.TEST
//MODCARD DD
              DATA
         CARUS TO MODIFY THE DATASET GO HERE
/*
//ALTFILE
           DD UNIT=SYSDA.SPACE=(TRK.(2,1)).DISP=(NEW.DELETE).
     DSNAME = & EWOF KUP
              UNI T=SYSDA, SPACE=(TRK, (4, 2), RLSE), DISP=(NEW, KEEP),
//NEWDATA
           DD
     VOL=SER=SHP@@Z.DSNAME=TEST.UPDATE.HPMS
//ERRLIST
           DD
               SYSOUT=A.DCB=(RECFM=FB.BLKSIZE=133)
//SOFTLIB
           00
               DSNAME=SYS1.SURTLIB, DISP=SHR
//SURTWK01
           DD UNIT=SYSDA, SPACE=(CYL, (3,2))
//SORTWK02
                UNIT=SYSDA, SPACE=(CYL, (1,1))
           DD
//SORTWKE3
            DD UNIT=SYSDA, SPACE=(CYL, (1,1))
//SORTWK04 DD UNIT=SYSDA, SPACE=(CYL, (1,1))
Y/SDRTWK⊕5
            DD UNIT=SYSDA.SPACE=(CYL.(1.1))
18
11
```

NOTE: Printed output requires 65 lines of print.



APPENDIX A

EDIT SPECIFICATIONS FOR HPMS SAMPLED DATA

The following specifications are to be met when editing the HPMS inventory data:

- 1. One asterisk (*) indicates items which may be optionally reported through the MFRS, as described in the HPMS/MFRS Coordination Section in Chapter I. The indicated items must contain zeroes, except for Functional Class (Item 8) and 1978 ADT (Item 36). We have requested that Items 8 and 36 be completed even if this option is selected, so that the edit and summary programs developed can be utilized to the maximum extent possible.
- 2. Two asterisks (**) indicate that when the MFRS option is selected, the following should be noted:
 - a. The edits for Items 22, 24, 25, 49, 50, 51, and 52 (Rural) will be limited due to Item 21, Surface Type, not being reported.
 - b. Items 15 and 52 (Urban) will be limited since Functional Class may not be reported.

DATA ITEM

EDIT TO BE PERFORMED

1 - Year	Must equal 78 for this submittal.
2 - State Code	Must match State code on edit program parameter control card.
3 - Type of Section ID	Must contain a value from 1 to 3.
4 - Section ID	Must be a nonzero alphanumeric and must be unique to this section on a countywide basis.
5 - Segment	Must be zero for this submittal.
6 - County Code	Must contain a nonzero numeric value.
7 - Urbanized Area Code (Urban Only)	Must contain a value from 001 to 291, 400-500, or "999".

* 8 - Functional Class	Rural: Must equal one of the following: "01", "02", "06", "07", "08".
	Urban: Must contain a value from 11 to 17
* 9 - Federal-Aid System	Must equal one of the following: Rural: "1", "2", "4", "8". Urban: "1", "2", "3", "8".
*10 - Jurisdictional Responsibility	Must contain a value from 1 to 4.
11 - Section Length	Must contain a nonzero numeric entry.
*12 - Access Control	Must contain a value from 1 to 3.
13 - Number of Through Lanes	Rural: Should contain a value from 01 to 10. Urban: Should contain a value from 01 to 14.
14 - Lane Width	Should contain a value from 07 to 15.
*15 - Approach Width	If Item 8 > 13, this item should contain a value from 007 to 100. Otherwise, it must contain "000".
16 - Median Width	Must contain a numeric value. If Item 13 < 2, this item should contain "00".
17 - Median Type	If Item 16 > 00, this item must contain a value from 1 to 3. Otherwise, it must contain "4".
18 - Shoulder Width a. Right b. Left	The right shoulder should contain a value from 00 to 12. If Item 16 = 00, left shoulder must be 00, otherwise left shoulder should contain a value from 00 to 12.

		
19 -	- Shoulder Type	If Item 18a > 0, this item must contain a value from 1 to 3. Otherwise, it must contain "4" or "5".
20 -	- Drainage Adequacy	Must contain a value from 1 to 3.
*21 -	- Surface Type	Must contain one of the following: "30", "40", a value from 51 to 53, "60", "70", "80". If Item 8 is "11" or "01", this item should contain a value from 60 to 79 (MFRS detailed codes will be accepted by the edit.)
**22 -	- Pavement Section	If Item 21 > 49, this item must contain a value from 1 to 5. Otherwise, it must contain "0".
23 -	- Structural Number or Slab Thickness	 a. If Item 22 contains "1", this item should contain a value from 10 to 60. b. If Item 22 contains "2", this item should contain a value from 06 to 12. c. If Item 22 does not contain "1" or "2", this item must contain "00".
**24 -	Pavement Condition	If Item 21 > 49, this item must contain a value from 01 to 50. Otherwise, it must contain "00".
**25 -	· Skid Resistance	Urban: Must be in the range 20-80 or "00" Rural: If Item 21 > 49, this item must be in the range 20-80 or "00". Otherwise, it must be "00".
26 -	Number of Grade- Separated Interchanges	Must contain a numeric value.
27 -	Number of At-Grade Intersections with Public Facilities with: a. Signals b. Stop Signs c. Other or No Controls	Must contain a numeric value. Must contain a numeric value. Must contain a numeric value.

28 - Prevailir Signali (Urban)	zation	If Item 27a > 00, this item must contain a value from 1 to 3. Otherwise, it must contain "4".
29 - Typical I Time (U		Must contain a numeric value and should be < 86. If Item 27a > 00, this item must not = 00.
	Major ial/Industrial/ ional Access	Must contain a numeric value or be coded with the range codes R1 - R6.
31 - Type of I (Rural Or	-	Must be coded 1 or 2.
32 - Urban Loc (Urban Or		Must contain a value from 1 to 5.
33 - Terrain (Rural Or	1y)	Must contain a value from 1 to 3.
*34 - Existing Width	Right-of-Way	Should contain a value \geq 15.
35 - Is Wideni	ng Feasible?	Must contain a value from 1 to 5.
*36 - 1978 ADT		Must contain a nonzero numeric value.
37 - Percent Ta. Peak b. Off I	Period	Must be numeric and should contain a value < 45. Must be numeric and should contain a value < 45.
38 - K Factor		Must be numeric and should contain a value from 01 to 24.

39 - Directional Factor	Urban: a. If Item 40 contains "1", "3", "5", or "7", this item must contain "100".
	b. If Item 40 contains "2", "4", "6", "8", "9", or "10", this
	item should contain a value from 050 to 075.
	Rural: Should contain a value from 050 to 075 or 100.
40 - Type of Operation (Urban Only)	Must contain a value from 1 to 10 ("0" code is changed to 10).
41 - Parking (Urban Only)	
a. Peak Period b. Off Peak	Must contain a value from 1 to 3. Must contain a value from 1 to 3.
42 - Capacity a. Peak Period	
	Must contain "000000" or must contain a
	nonzero numeric entry meeting the following conditions: (1) When item 13 = 3, it should contain
	<pre>a value < 4,000. (2) Otherwise, it should contain a value < Item 13 x 1,000.</pre>
Urban -	Must contain a nonzero numeric entry < Item 13 x 1,000.
b. Off Peak	Must contain a nonzero numeric entry < Item 13 x 1,000.
43 - 2000 ADT	Must contain a nonzero numeric entry.
44 - Number of Structures	Must contain a numeric value.
45 - Number of At-Grade Railroad Crossings	Must contain a numeric value.
46 - ADT Volume Group Identifier	Must contain a nonzero numeric value. For States using the FHWA developed approach, the number must be < 10. The 1978 ADT for this section must correspond to this volume group number for the ADT ranges outlined in the FHWA Manual.

47 - Expansion Factor	Must contain a value ≥ 0100 . Must contain a value from 15 to 56. If Item 21 > 49 and Item 13 = 2, this item should be in the range 010 to 100. Otherwise, it should contain "000". If Item 21 > 49 and Item 53 is omitted, this item must contain a value from 1 to 4. Otherwise, it must contain a numeric value ≤ 4 .						
48 - Speed Limit							
**49 - Percent of Length with Sight Distance > 1500 feet (Rural Only)							
**50 - Horizontal Alignment Adequacy (Rural Only)							
**51 - Vertical Alignment Adequacy (Rural Only)	If Item 21 > 49 and Item 54 is omitted, this item must contain a value from 1 to 4. Otherwise, it must contain a numeric value < 4.						
**52 - Average Highway Speed	Rural: a. If Item 8 > 6 and Item 21 > 49 and Item 31 = 1 and Item 53 is omitted, this item should contain a value from 35 to 70. b. If Item 8 > 6 and Item 21 > 49 and Item 31 = 2 and Item 53 is omitted, this item should contain a value from 35 to 70 or "00". c. If Item 8 < 7 and Item 21 > 49 and Item 53 is omitted, this item should contain a value from 35 to 70, otherwise, d. When Item 21 > 49, this item should be "00" or 35 to 70. Urban: If Item 8 = 11, 12, or 13, and Item 53 is omitted, this item must contain a numeric value which						

The following edits apply to optional data Items 53, 54, 55, and 56, which may or may not be provided.

53 - Curves by Class

The number of curves field and curve length field must contain a numeric value for each curvature class. If the number of curves is > 0, the corresponding curve length field must contain a nonzero numeric value. If the number of curves equal "00", the corresponding curve length field must contain "000". The sum of the curve length fields must be < section length.

54 - Grades by Class

The number of grades field and length field must contain a numeric value for each gradient class. If the number of grades is > 0, the corresponding length of grade field must contain a nonzero numeric value. If the number of grades equals 0, the corresponding length of grade field must contain "000". The sum of the grade lengths must approximately equal the section length.

55 - Bridge Identification Numbers

The number of ID's must equal the number of structures coded in Item 44.

56 - At-Grade Railroad Crossing Identification Numbers The first six positions of each crossing ID must be a numeric value. The seventh character must be alphabetic. The number of ID's must = number of crossings coded in Item 45.

CROSS EDITS

Items 57, 8

- If Rural/Urban Code = 1, then functional class is between 11 and < 17.
- If Rural/Urban Code = 2, then functional class = "01", "02", "06", "07", or "08".

Items 8, 9

If Federal-Aid = 1, then functional class = "01" or "11".

APPENDIX B

DATA ITEM NUMBERS

	REQUIRED	
NO.	FIELD LENGTH	<u>NAME</u>
1	2	Year
2	2	State Code
3	1	
4	12	Type of Section ID
5	1	Section ID
6	3	Segment
7	3	County Code
8		Urbanized Area Code
	2	Functional Class Code
9	1	Federal-Aid System
10	1	Jurisdictional Responsibility
11	4	Section Length
12	1	Access Control
13	2	Number of Through Lanes
14	2	Lane Width
15	3	Approach Width
16	2	Median Width
17	. 1	Median Type
18-A	2	Right Shoulder Width
18-B	2	Left Shoulder Width
19	1	Shoulder Type
20	1	Drainage Adequacy
21	2	Surface Type
22	1	Pavement Section
23	2	Structural Number
		or Slab Thickness
24	2	Pavement Condition
25	2	Skid Resistance
26	2	Number of Grade-Separated Interchanges
27-A	· · · · · · · · · · · · · · · · · · ·	Number of At-Grade Intersections
		with Signals
27-B	2	Number of At-Grade Intersections
		with Stop Signs
27-C	2	Number of At-Grade Intersections
		with Other or No Controls
28	1	Prevailing Type of Signalization
		(Urban Only)
29	2	Typical Percent Green Time (Urban Only)
30		Number of Major Commercial/Industrial/
		Recreational Access Points

	REQUIRED	
NO.	FIELD LENGTH	NAME
31	1	Type of Development (Rural Only)
32	1	Urban Location (Urban Only)
33	1	Terrain (Rural Only)
34	3	Existing Right-of-Way Width
35	1.	Is Widening Feasible?
36	. 6	1978 ADT
37-A	2	Peak Period Percent Trucks
37-B	2	Off Peak Percent Trucks
38	2	K Factor
39	3_,	Directional Factor
40	<u>2</u> 1/	Type of Operation (Urban Only)
41-A	1	Peak Period Parking (Urban Only)
41-B	1	Off Peak Parking (Urban Only)
42 - A	5	Peak Period Capacity
42-B	5	Off Peak Capacity (Urban Only)
43	6 .	2000 ADT
44	2	Number of Structures
45	2	Number of At-Grade Railroad Crossings
46	2	ADT Volume Group Identifier
47	4	Expansion Factor
48	2	Speed Limit
49	3,	Percent of Length with Sight Distance > 1500 feet (Rural Only)
50	1	Horizontal Alignment Adequacy (Rural Only)
51	1	Vertical Alignment Adequacy (Rural Only)
52	2	Average Highway Speed

^{1/}The data code of "0" is recoded to "10" on the data tape and therefore all other codes must be two digits.

NO.	СТ	NAME URVES BY CLA	-	cters requi	red)
53-A 53-B 53-C 53-D 53-E 53-F 53-G 53-H 53-I 53-J 53-K 53-L				rves from () 2 3 4 5 7 8 11 14	0.5° to 1.4° 1.5° to 2.4° 2.5° to 3.4° 3.5° to 4.4° 4.5° to 5.4° 5.5° to 6.9° 7.0° to 8.4° 3.5° to 10.9° 1.0° to 13.9° 1.0° to 19.4° 1.5° to 27.9° 1.5° to 27.9°
	GI	RADES BY CL	SS (<u>5 char</u> a	cters requi	red)
54-A 54-B 54-C 54-D 54-E	Nu	umber <u>and</u> Le	ength of Gra	0. 2. 4. 6.	0 to 0.4% 5 to 2.4% 5 to 4.4% 5 to 6.4% 5 to 8.4%

NO.				,	NAMI	<u> </u>					
	BRI	DGE ID	NUN	BERS	(<u>15</u>	cha	racters	requi	red)		
55-01 55-02	The	exact	ID	code	for	the	first second	Bridge l "	ID o	n the	file
										_	
55-23	11	TI .		Ħ			23rd	11	17 11	71	11
55-99	17	n	* 11	***	11	11	99th	¥Ť	17 \$1	***	11

At-GRADE RAILROAD CROSSING ID NOS. (7 characters required)

56-01 56-02	The	exact		Code "	for	**	first second	**	'ing	ID "	on	the	file	
(
56-11	* 11	11	11	11	11	11	11th	11	11	11	11	"	Ħ	
56-15	111	**	tt	11	11	ff ·	15th	21	1)	11	11	11	11	

APPENDIX C

HPMS Record Format

Part I: All Sections

			Rural Urban	
<u>Position</u>	<u>Item</u>	Length	Only Only	,
1	57	1	*Rural/Urban Code	
2-3	1	2	Year	
2-5 4-5	2	2	State Code	
4-5 6	3	1	Type of Section ID	
7-9	6	3	County Code	
10-21	4	12	Section ID	
22	5	1	Segment (Precoded: 0)	
23-25	7	3	Urban Area Code	
26-27	8	2	Functional Class	
28-29	46	2	Volume Group Identifier	
30	9	1	Federal-Aid System	
31	10	ī	Jurisdictional Responsibility	
32-35	11	4 (xx.xx)	Section Length	
36-39	47	4 (xx.xx)	Expansion Factor	
40	12	1	Access Control	
41-42	13	2	Number of Through Lanes	
43-44	14	2	Lane Width	
45-47	15	3	Approach Width	
48-49	16	2	Median Width	
50	17	1	Median Type	
51 - 54	18A&B	4	Shoulder Width (Right A, Left B)	
55	19	1	Shoulder Type	
56	20	ī	Drainage Adequacy	
57 - 58	21	2	Surface Type	
59	22	ī	Pavement Section	
60-61	23	2	Structural Number	
62-63	24	2 (x.x)	Pavement Condition	
64-65	25	2	Skid Resistance	
66-67	26	2	Number Grade-Separated Interchanges	
68-69	27A	2	At-Grade Intersections: Signals	
70-71	27B	2	Stop Signs	
72-73	27C	2	Other or None	
74	28	1	Prevailing Type of Signalization	
75-76	29	2	% Green Time	
77-78	30	2	Number Entrances/Exits	
79	31	ī	Type of Development	
80	32	1	Urban Location	
81	33	1	Terrain	
82-84	34	3	Existing Right-of-Way	
85	35	1	Is Widening Feasible?	
86-91	36	6	1978 ADT	
92-93	37 A	2	% Trucks: Peak	
94-95	37B	2	Off-Peak	
96-97	38	2	K-Factor	
98-100	39	3	Directional Factor	

^{*}Column 79 Card 1 on worksheets 1-Urban; 2-Rural

Position	Item	Length		Rural Urban Only Only
101-102	40	2	*Type of Operation	~
103	41A	1	Parking: Peak	· /
104	41B	1	. Off-Peak	~
105-109	42A	5	Capacity: Peak	
110-114	42B	5	Off-Peak	
115-120	43	6	2000 ADT	
121-122	44	2	Number Structures	
123-124	45	2	Number of At-Grade R.R. Crossings	
125-126	48	2	Speed Limit	
127-129	49	3	$PSD \ge 1500$	✓
130	50	1	Horizontal Alignment	_
131	51	1	Vertical Alignment	✓
132-133	52	2	Average Highway Speed	
134-139	_	6	Continuation Code for Optional Data	a ·
			(6-positions coded zero; No option	al data)

*Type of Operation coded "0" is coded "10" on the tape record.

A State not submitting \underline{any} of the optional data (cards 3-6) would submit data in the above 139 character record format with position 134-139 always coded "000000".

Part II - Sections with Optional Data Items Being Provided

A State submitting <u>any</u> of the optional data (cards 3-6) will have a variable record format determined on an individual section basis. The record would consist of the 133 characters formatted as in Part I plus the codes to indicate which optional data is being provided and any combination of the optional data. If none of the optional data being submitted exists for a section, the record would contain the 139 fixed characters only. The length of the variable record would have a minimum of 139 characters and a maximum of 1819 characters.

In the variable length record format, positions 134-139 are fixed with the remaining positions in the record depending on which optional data is being submitted and exists for a section. These fixed positions are coded as:

Position

134	Indicates	curve data provided for section (0-No; 1-Yes)
1 35	Indicates	grade data provided for section (0-No; 1-Yes)
136-137	Indicates	bridge ID data provided for section
	(00-None;	> 00 = # of ID's)
138-139	Indicates	crossing ID data provided for section
	(00-None;	> 00 = # of ID's)

The remaining part of the record will vary in the number of characters from 7-1680 depending on the combinations of the optional data and the number of bridge ID's and/or the number of at-grade crossing ID's. If all optional data are provided, the data will be in the following order:

Item 53, Curves by Class	60 characters
Item 54, Grades by Class	30 characters
*Item 55, Bridge ID's	15-1485 characters
*Item 56, At-Grade Crossing ID's	7-105 characters

*The record is designed to allow for 0-99 bridge ID's per section and/or 0-15 at-grade crossing ID's.

Any combination of the optional data would use the ordering given above for the placement of the data in the section record, e.g., Item 53, Item 56; Item 54, Item 55, Item 56; or Item 55, Item 56.

The following examples illustrate some of the different possibilities for a State submitting optional data:

A State is submitting curve data for Interstate only, rural and urban, and bridge ID's for all applicable sections.

a. The variable part of the record for an Interstate section with three bridges would be:

Position

134	Coded	"1"	
135	Coded	11011	
136-137	Coded	"03"	
138-139	Coded	"00"	
140-199	Curve	data	
200-244	Three	bridge	ID's

The record length for the section is 244 characters.

- b. The record for a minor collector section with no bridges would consist of the 139 fixed characters with zero coded in the 134-139th positions. The section record would not contain any of the optional information since the State is providing curve data for Interstate sections only and the section has no bridges.
- c. The variable part of the record for an Interstate section with no bridges would be:

Position

134	Coded	"1"
135	Coded	
136-137	Coded	"00"
138-139	Coded	"00"
140-199	Curve	data

The record length for the section is 199 characters.

d. The variable part of the record for a minor arterial section with 10 bridges would be:

Position

135	Coded "O"
136	Coded "0"
137	Coded "10"
138-139	Coded "00"
140-289	Ten bridge ID's

The record length for the section is 289. The section has no curve data since it is not an Interstate section.

APPENDIX D

SAMPLE PRINTED OUTPUT



STATE: 1FST HPMS DATE: C8/28/79

A REA:

GRUUP VOLUME H P M S

	AGE													
	EXPANDED MILEAGE	00.0	1951.02	2.00	00.0	00.0	176.80	00.0	00.0	00.0	00.0	44.20	00.00	2174.02
	SAMPLED MILEAGE	00.00	90.10	4.00	0.00	00.0	8.00	00.0	00.0	0.00	0.00	2.00	00.00	01 70
	SAMPLED		•											7.1
55 02	NUM SECTIONS	0	45		0	C	4	C	0	0	c	,1	0	ī
UNCTIONAL CLASS 02	NUM S													
NCTIC														
3	_													
	6 FCU	-	~	m	4	5	9	7	œ	6	10	10		
RURAL	VOLUME GECUP											^ *	**	TOTA

ALL VCLUME GROUP NUMBERS > 10. VERIFY FUNCTIONAL CLASS HAS >10 VOLUME GROUPS.

SECTIONS WHICH HAVE A NCHNUMERIC VOLUME GROUP NUMBER OR = 00.

NUMBER SECTIONS WITH SECTION LENGTH OR EXPANSION FACTOR NOT NUMERIC OR = ZERO:

FINAL SUMMARY SEND TO HHP-12 FHWA WITH HPMS DATA TAPE AND FINAL EDIT.

Sample Printout Volume Group Summary Table

USER SUPPLIED PARAMETER CARDS

ISTATE= TEST HPMS /99/
SELDEV=RU, REQOPT, CURVES, GRADES, BRIDID, CROSSID FUNCUR=06, 02, 12, 16
FUNGRD=06, 16, 02
SELEDT=RU, FHWADESIGN
SELTAB=RU, DVMT MILE

ALL USER SUPPLIED CARDS PROCESSED. NO ERRORS WERE DETECTED.

DATE: 28/30/79

STATE: TEST HPMS

HPMS VOLUME GROUP SUMMARY

DEVELOP TAPE

AREA:

RURAL

FUNCTIONAL CLASS 01

VOLUME GROUP	N U M B E REJECTED	R OF SEC	T I D N S	MILEAGE SEC SAMPLED	TIONS ADDED EXPANDED
1	0	. 0	0	0.30	0.00
2	o	. 1	1	4.10	86.10
3	C	0	0	0.001	0.00
4	0	0	5 .	0.00	0.00
5	· · · · · · · · · · · · · · · · · · ·	0	0 .	0.30	0.00
6	Ü	D ·	3	3.30	0.00.
7	0	0	Ö	0.00	0.00
8	Ü	0	D	3.30	0.00
9	o ·	Ŏ	Ŏ.	0.00	0.00
10	O.	Ď	Ŏ.	3.33	0.00
* >10	ò	ŏ	Ď	0.00	0.00
***	ň	ñ	ŏ	0.30	0.00
TOTAL	ő	ĭ	ĭ	4.10	86.10

^{*} ALL VOLUME GROUP NUMBERS > 10. VERIFY FUNCTIONAL CLASS HAS >10 VOLUME GROUPS.

^{***} SECTION HAS INVALID VOLUME GROUP NUM OR SECTION LENGTH OR EXP FACT OR CARD 2 MISSING.

NOTE: A SECTION REJECTED FOR AN INVALID CODE IN COLUMN 79, CARD 1, IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH DID NOT HAVE A REQUIRED CARD 1 IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH HAS AN INVALID CARD NUM FOR THE SPECIFIED TAPE FORMAT IS NOT COUNTED IN ANY VOL GRP SUMMARY TAB.

DATE:08/30/79

STATE: TEST HPMS

HPMS VOLUME GROUP SUMMARY

DEVELOP TAPE

AREA:

RURAL

FUNCTIONAL CLASS 02

VOLUME GROUP	N U M B E R REJECTED	DF SECTIONS ADDED TOTAL	MILEAGE Sample	SECTIONS ADDED D EXPANDED
1	0) 0	0.0	0.00.
2	v	o 0	0.0	0 0.00
3	C	1 1	4.3	3 2.00 /
4	0	o o	0.0	
5	C	0 0	0.0	0.00
6	0	1 1	2.0	
7	0	0 0	0.0	
8	C	0 0	0.0	
9	0	0 0.	0.0	
10	C ·	0	0.0	
* >10	0	0 0	0.0	
***	1	0 1	0.0	
TOTAL	1	2 3	6.3	0 46.20

^{*} ALL VOLUME GROUP NUMBERS > 10. VERIFY FUNCTIONAL CLASS HAS >10 VOLUME GROUPS.

^{***} SECTION HAS INVALID VOLUME GROUP NUM OR SECTION LENGTH OR EXP FACT OR CARD 2 MISSING.

NOTE: A SECTION REJECTED FOR AN INVALID CODE IN COLUMN 79, CARD 1, IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH DID NOT HAVE A REQUIRED CARD 1 IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH HAS AN INVALID CARD NUM FOR THE SPECIFIED TAPE FORMAT IS NOT COUNTED IN ANY VOL GRP SUMMARY TAB.

TEST HPMS STATE:

DATE: 08/30/79

> œ X I > S ۵ 200 c OLUME > S E d I

DEVELUP TAPE

VOLUME GROUP NUMBER OF SECTIONS REJECTED ADDED TOTAL SAMPLED SAMPLED 2 2 2 2 3 4 4 6 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	AREA:	RURAL	FUNCTIONAL	DNAL CLASS 03				
		VOLUME GROUP		N U M B E R REJECTED		T I O N S TOTAL	MILEAGE SE SAMPLED	MILEAGE SECTIONS ADDED SAMPLED EXPANDED
		-	. •	o	0	. 0	3 2 3 3 3	00.00
		~		0	-		2.00	44.20
		m		0	0	0	00.00	00.0
		4		0	0	0	00.0	00.00
		sr.		0	O	0	00.0	00.0
		•		0	0	0	0.00	00.00
		~		0	0	0	00.0	00.0
		80		0	•	0	00.0	00.00
		6		•	0	0	0.00	00.00
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		10		•	C	0	0.00	00.00
0 0 0		01< *			0	0	00.00	00.00
0 1 1 2 1		***		0	0	0	00.00	00.0
		TOTAL		0	-	-	2.00	44.20

A SECTION WHICH HAS AN INVALID CARD NUM FOR THE SPECIFIED TAPE FORMAT IS NOT COUNTED IN ANY VOL GRP SUMMARY TAB. A SECTION REJECTED FOR AN INVALID CODE IN COLUMN 79, CARD 1, IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE. A SECTION WHICH DID NOT HAVE A REQUIRED CARD 1 IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE. *** SECTION HAS INVALID VOLUME GROUP NUM OR SECTION LENGTH OR EXP FACT OR CARD 2 MISSING. * ALL VOLUME GROUP NUMBERS > 10. VERIFY FUNCTIONAL CLASS HAS > 10 VOLUME GROUPS. NOTE: NOTE: NOTE:

DATE: 08/30/79

STATL: TEST HPMS

HPMS VOLUME GROUP SUMMARY

DEVELOP TAPE

AREA:

RURAL

FUNCTIONAL CLASS 06

VOLUME GROUP	NUMBER	DF SECTI	ONS	MILEAGE SEC	TIONS ADDED
	REJECTED	ADDED TOT	AL	SAMPLED	EXPANDED
1	0	0	0	0.00	0.00
2	Ó	0	0). 00	0.00
3	Ď	0	0	3.33	0.00
4	Ö	0	Ŏ:	3.00	0.00
5	ō	Ö	Ď	3.30	0.00
6	i	ì	2	2.30	44.20
7	ō	Ō	D	2.30	0.00
8	Ŏ.	Ö	Ö	0.00	0.00
a a	Ŏ.	Ď	Ď	0.00	0.00
10	Č	Ō	Ď	0.00	0.00
* >10	Ď	Ŏ	0	0.00	0.00
***	ŏ	ã	o ·	0.30	0.00
TOTAL	ĭ	ī	2	2.00	44.20

^{*} ALL VOLUME GROUP NUMBERS > 10. VERIFY FUNCTIONAL CLASS HAS >10 VOLUME GROUPS.

^{***} SECTION HAS INVALID VOLUME GROUP NUM OR SECTION LENGTH OR EXP FACT OR CARD 2 MISSING.

NOTE: A SECTION REJECTED FOR AN INVALID CODE IN COLUMN 79, CARD 1, IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH DID NOT HAVE A REQUIRED CARD 1 IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH HAS AN INVALID CARD NUM FOR THE SPECIFIED TAPE FORMAT IS NOT COUNTED IN ANY VOL GRP SUMMARY TAB.

DATE: 08/30/79

STATE: TEST HPMS

HPMS VOLUME GROUP SUMMARY

DEVELOP TAPE

AREA:

RURAL

FUNCTIONAL CLASS 07

VOLUME	GROUP	N U N	B E R ECTED	OF SEC	T I O N S TOTAL		MILEAGE SEC SAMPLED	TIONS ADDED EXPANDED
1			0	o	O		3.33	0.00
• ;			ŏ	. 0	Ö		0.00	0.00
•			Ö	ĭ	ĭ		2.35	18.94
4			ŏ	ō	ō		0.00	0.00
5			ō ·	Ŏ	0		0.00	0.00
6			ō	0	Ŏ		0.00	0.00
7			Ď :	Ö	Ď		0.00	0.00
8			ŏ	ŏ	Ŏ		0.00	0.00
ä			ŏ ·	Ď	Ô	Control of the contro	0.30	0.00
10			õ	Ď	Ď		0.00	0.00
* >10			ŏ.	Ŏ	Õ		0.00	0.00
***			ō ·	Ď	0		3.00	0.00
TOTAL			Ö	ĭ	1		2.35	18.94

NOTE: A SECTION REJECTED FOR AN INVALID CODE IN COLUMN 79, CARD 1, IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH DID NOT HAVE A REQUIRED CARD 1 IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH HAS AN INVALID CARD NUM FOR THE SPECIFIED TAPE FORMAT IS NOT COUNTED IN ANY VOL GRP SUMMARY TAB.

^{*} ALL VOLUME GROUP NUMBERS > 10. VERIFY FUNCTIONAL CLASS HAS >10 VOLUME GROUPS.

^{***} SECTION HAS INVALID VOLUME GROUP NUM OR SECTION LENGTH OR EXP FACT OR CARD 2 MISSING.

HPMS VOLUME GROUP SUMMARY

DEVELOP TAPE

AREA: URBANIZED 070

FUNCTIONAL CLASS 11

VOLUME GR	OUP	NUMBER REJECTED	OF S E C	T I O N S		MILEAGE SECT Sampled	IONS ADDED
1		0	0,-	0		0.00	0.00
2		0	0	0		0.00	0.00
3		0	1	1	`	0.95	21.89
4		0	0	0.		0.00	0.00
5		0	- 0	0		0.00	0.00
6		0	0	0		0.00	0.00
7		0	0	0		0.00	0.00
8		. 0	0	0		0.00	0.00
. 9	•	0	0	0		0.00	0.00
10		o i	9	0		0.00	0.00
• >10		0	0	.0		0.00	0.00
***		O	0	0		0.00	0.00
TOTAL		0	1	1		0.95	21.89

NOTE: A SECTION REJECTED FOR AN INVALID CODE IN COLUMN 79, CARD 1, IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH DID NOT HAVE A REQUIRED CARD 1 IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH HAS AN INVALID CARD NUM FOR THE SPECIFIED TAPE FORMAT IS NOT COUNTED IN ANY VOL GRP SUMMARY TAB.

^{*} ALL VOLUME GROUP NUMBERS > 10. VERIFY FUNCTIONAL CLASS HAS >10 VOLUME GROUPS.

^{***} SECTION HAS INVALID VOLUME GROUP NUM OR SECTION LENGTH OR EXP FACT OR CARD 2 MISSING.

HPMS VOLUME GROUP SUMMARY

DEVELOP TAPE

AREA: URBANIZED 074

FUNCTIONAL CLASS 11

VOLUME GROUP	N U I	B E R	DF S E C ADDED	T I O N S TOTAL	MILEAGE SEC	TIONS ADDED
1		0	O		3.30	0.00
2		0	0	0	0.00	0.00
3		C	0	0	0.35	0.00
.e		0	Q .	0	0.00	0.00
5		0	0	0	0.00	0.00
6		0	0	0	0.00	0.00
7		0	0 .	0	0.00	0.00
8		0	. 0	0	0.30	0.00
· 9		0 .	0	0	0.00	0.00
10		C	0	0	0.00	0.00
* >10		0	0	0	0.00	0.00
***		0	1	1	0.30	0.00
TOTAL		0	1	1	0.00	0.00

^{*} ALL VOLUME GROUP NUMBERS > 10. VERIFY FUNCTIONAL CLASS HAS >10 VOLUME GROUPS.

^{***} SECTION HAS INVALID VOLUME GROUP NUM OR SECTION LENGTH OR EXP FACT OR CARD 2 MISSING.

NOTE: A SECTION REJECTED FOR AN INVALID CODE IN COLUMN 79, CARD 1, IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH DID NOT HAVE A REQUIRED CARD 1 IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH HAS AN INVALID CARD NUM FOR THE SPECIFIED TAPE FORMAT IS NOT COUNTED IN ANY VOL GRP SUMMARY TAB.

AREA: 1

	S E G I	S VOLUME GROUP SUMMARY	6 R O U P	N N N	≻		
		DEVEL	DEVELOP TAPE				
URBANIZED 070	FUNCT I ONAL	CLASS 12					
VOLUME GROUP		N U M B E R REJECTED	OF SEC	T I O N S TOTAL		MILEAGE SEC SAMPLED	MILEAGE SECTIONS ADDED SAMPLED EXPANDED
-		0	C	0		3.00	00.00
7		-	0			00.0	00.0
m		0	C	0		0.00	00.00
4		0	0	0		0.30	00.0
ស		6	0	٥		00.00	00.0
•		0	0	•		00.0	0.00
~		C	0	0		0.00	0.00
€		• •	0	0		00.0	00.00
6		0	٥	0		0.00	00.00
10		0	0	0		00.00	00.0
01< *			0	0		00.00	00.0
***		0	0	0		00.0	00.00
TOTAL			0			00.00	0000

SECTION HAS INVALID VOLUME GROUP NUM OR SECTION LENGTH OR EXP FACT OR CARD 2 MISSING. * ALL VOLUME GROUP NUMBERS > 10. VERIFY FUNCTIONAL CLASS HAS >10 VOLUME GROUPS.

A SECTION WHICH DID NOT HAVE A REQUIRED CARD 1 IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE. NOTE:

A SECTION REJECTED FOR AN INVALID CODE IN COLUMN 79, CARD 1, IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE:

A SECTION WHICH HAS AN INVALID CARD NUM FOR THE SPECIFIED TAPE FORMAT IS NOT COUNTED IN ANY VOL GRP SUMMARY TAB. NOTE:

DATE: C8/35/79

STATE: TEST HPMS

HPMS VOLUME GROUP SUMMARY

DEVELOP TAPE

AREA: URBANIZED 070

FUNCTIONAL CLASS 14

VOLUME	GROUP	N	U M B E R REJECTED	OF S	E C	TION	S		CTIONS ADDED
			KEJEUTEU	ADDED	,	TOTAL		SAMPLED	EXPANDED
1			0	0		o		0.00	0.00
2			0	0		0		0.00	0.00
. 3			Ü	. 0		0		0.00	0.00
4			0	9		0		0.00	0.00
5			0	0		0		0.00	0.00
- 6			0	Ŏ		Ö		0.00	0.00
7			0	1		1		0.95	21.89
8			. 0	Ō		ō		3.00	0.00
9			. 0	0		0		0.00	0.00
10			0	0		o o		0.00	0.00
* >10			0	0		0		0.00	0.00
***			C	. 0		Ō		0.00	0.00
TOTAL			Ö	1		i		0.95	21.89

*** SECTION HAS INVALID VOLUME GROUP NUM OR SECTION LENGTH OR EXP FACT OR CARD 2 MISSING.

NOTE: A SECTION REJECTED FOR AN INVALID CODE IN COLUMN 79, CARD 1, IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH DID NOT HAVE A REQUIRED CARD 1 IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH HAS AN INVALID CARD NUM FOR THE SPECIFIED TAPE FORMAT IS NOT COUNTED IN ANY VOL GRP SUMMARY TAB.

^{*} ALL VOLUME GROUP NUMBERS > 10. VERIFY FUNCTIONAL CLASS HAS >10 VOLUME GROUPS.

DATE: 08/30/79 STATE: TEST HPMS

HPMS VOLUME GROUP SUMMARY

DEVELOP TAPE

AREA: URBANIZED 070

FUNCTIONAL CLASS 13

VOLUME GROUP	N U M B E R REJECTED	OF SE	C T I O N S TOTAL	MILEAGE SEC Sampled	TIONS ADDED EXPANDED
1	O	0	0	3.33 .	0.00
2	1	0	1	0.00	0.00
3	0	. 0	0	0.00	0.00
4	0	0	0	0.00	0.00
5	0	0	0	0.00	0.00
6	. 0	0	0 .	0.00	0.00
7	0	0	0	0.00	0.00
8	0	0	0	0.00	0.00
9	0	9	. 0	0.00	0.00
10	0	3	0	0.00	0.00
* >10	0	0	0	0.00	0.00
***	0	0	0	0.00	0.00
TOTAL	1	0	1	0.00	0.00

^{*} ALL VOLUME GROUP NUMBERS > 10. VERIFY FUNCTIONAL CLASS HAS >10 VOLUME GROUPS.

^{***} SECTION HAS INVALID VOLUME GROUP NUM OR SECTION LENGTH OR EXP FACT OR CARD 2 MISSING.

NOTE: A SECTION REJECTED FOR AN INVALID CODE IN COLUMN 79, CARD 1, IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH DID NOT HAVE A REQUIRED CARD 1 IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH HAS AN INVALID CARD NUM FOR THE SPECIFIED TAPE FORMAT IS NOT COUNTED IN ANY VOL GRP SUMMARY TAB.

DATE: 08/20 /79 STATE:

TEST HPMS

HPMS VOLUME GROUP SUMMARY

DEVELOP TAPE

AREA: URBANIZED 070 FUNCTIONAL CLASS 17

	4 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -
MILEAGE SECTIONS ADDED SAMPLED EXPANDED	7.000000000000000000000000000000000000
MILEAGE SE	
r i o n s rotal	H000000000
OF SECTIONS ADDED TOTAL	H000000000
N U M B E R REJECTED	000000000000
ROUP	
VCLUME GROUP	10 4 * 10 10 10 10 10 10 10 10 10 10

A SECTION WHICH HAS AN INVALID CARD NUM FOR THE SPECIFIED TAPE FORMAT IS NOT COUNTED IN ANY VOL GRP SUMMARY TAB. NOTE: A SECTION REJECTED FOR AN INVALID CODE IN COLUMN 79, CARD 1, IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE. A SECTION WHICH DID NOT HAVE A REQUIRED CARD 1 IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE. *** SECTION HAS INVALID VOLUME GROUP NUM DR SECTION LENGTH OR EXP FACT DR CARD 2 MISSING. * ALL VOLUME GROUP NUMBERS > 10. VERIFY FUNCTIONAL CLASS HAS >10 VOLUME GROUPS. NOTE: NOTE:

DATE: J8/30/79 STATE: TEST HPMS

HPMS VOLUME GROUP SUMMARY

DEVELOP TAPE

AREA: SMALL URBAN

FUNCTIONAL CLASS 12

VOLUME	GROUP		NUMBER		CTIONS		TIONS ADDED
			REJECTED	ADDED	TOTAL	SAMPLED	EXPANDED
1			0	1	1	0.85	22.95
2			Ö	Ď :	Õ	0.00	0.00
3			6	Ö	Ó	3.30	0.00
4			.0	0	0 .	0.00	0.00
5			0	9	0	0.00	0.00
6			. 0	0	0	0.00	0.00
7			0	Ö	0	0.00	0.00
8			0	0 0	0	0.00	0.00
9			0	0	0	0.00	0.00
10			Ü	0	0.	0.30	0.00
* >10			0	0	0	0.00	0.00
***			Ö	0	0 .	0.00	0.00
TOTAL			0	1	1	0.85	22.95

NOTE: A SECTION REJECTED FOR AN INVALID CODE IN COLUMN 79, CARD 1, IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH DID NOT HAVE A REQUIRED CARD 1 IS NOT COUNTED IN ANY VOL GRP SUMMARY TABLE.

NOTE: A SECTION WHICH HAS AN INVALID CARD NUM FOR THE SPECIFIED TAPE FORMAT IS NOT COUNTED IN ANY VOL GRP SUMMARY TAB.

^{*} ALL VOLUME GROUP NUMBERS > 10. VERIFY FUNCTIONAL CLASS HAS >10 VOLUME GROUPS.

^{***} SECTION HAS INVALID VOLUME GROUP NUM OR SECTION LENGTH OR EXP FACT OR CARD 2 MISSING.

STATE: TEST HPMS

HPMS DATA TAPE SUMMARY

DEVELOP TAPE

RURAL /URBAN

WRONG RUCODE GRADES BRIDGES XINGS RURAL RURAL OPTIONAL DATA INCLUDEDICARDS 3-6): CURVES URBAN URBAN NUMBER SECTIONS REJECTED: RECORD FORMAT: REQUPT NUMBER SECTIONS ADDED:

0

NUMBER SECTIONS WITH CARDI MISSING:

NUMBER CARDS WITH INVALID CARD NUMBER:

\$3

DATE:08/33/79 STATE: TEST HPMS

RURAL

AREA:

HPMS MILEAGE AND DVMT SUMMARY TABLE

BY FUNCTIONAL CLASS

# SECT LGTH < .3	0	0	0	0	0	0	0
AVG SECT LGTH	4.13	3.00	2.00	2.35	0.00	2.33	2.74
2000 DVMT (100+S)	26260.5	15366.0	14586.0	1079.5	0.0	14586.0	71878.0
1978 DVMT (100°S)	23247.0	14000.0	13260.0	1041.7	0.0	13260.0	64808.7
EXPANDED MILEAGE	86.10	46.20	44.20	18.94	00.00	44.20	239.64
SAMPLED MILEAGE	4.10	60.0	2.00	2,35	0.00	2.00	16.45
NUM SECTIONS	a	N		_	0	-	•
	ō	05	90	0	80	*	TOTALS

*** SECTIONS WHICH HAVE AN INVALID FUNCTIONAL CLASS CODE.

NUMBER SECTIONS WITH NON-NUMERIC OR ZERO SECTION LENGTH, EXPANSION FACTOR, 1978 ADT OR 2000 ADT:

WORK SUMMARY FOR STATE

DATE:08/30/79 STATE: TEST HPMS

HPNS MILEAGE AND DVMT SUMMARY

ABLE

BY FUNCTIONAL CLASS

SECT LGTH < .1

AVG SECT LGTH

00000000

URBANIZED 070

AREA:

NUM SECTIONS	SAMPLED MILEAGE	EXPANDED MILEAGE	1978 DVMT (100*S)	2000 DVMT (100'S)
	0.95	21.89	5691.4	6567.0
• C	0000	00.0	0.0	0.0
, c	0000	00.00	0.0	0.0
, ,	0.95	21.89	5691.4	6567.0
. 0	00.00	00.0	0.0	0.0
. c	00*0	00.0	0.0	0.0
, c	00.0	00.3	0.0	0
•	00.0	00.0	0.0	0
~	1.90	43.78	11382.8	13134.0

*** SECTIONS WHICH HAVE AN INVALID FUNCTIONAL CLASS CODE.

R.

NUMBER SECTIONS WITH NON-NUMERIC OR ZERO SECTION LENGTH, EXPANSION FACTOR, 1978 ADT OR 2030 ADT:

WORK SUMMARY FOR STATE

DATE: 38/30/79 STATE: TEST HPMS

HPMS NILEAGE AND DVMT SUMMARY TABLE

BY FUNCTIONAL CLASS

AREA: URBANIZED 074

# SECT LGTH < .1	C		•	· ·	· c) c		. 0	00
AVG SECT LGTH	0,00	00.00				0000	00.0	0.00	00.00
2000 DVMT (100°S)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1978 DVMT (100°S)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
EXPANDED MILEAGE	00.00	00.0	00.0	00.0	00.00	00.00	00*0	00*0	00.0
SAMPLED MILEAGE	0.00	00.0	00.0	00.0	00.0	0.00	00.0	0.00	00.0
NUM SECTIONS	0	0	0	0	0	0	0	O :	0
en manufacture.	#4 (#4 ;	21	c T	4	٠	9	17		UTALS

*** SECTIONS WHICH HAVE AN INVALID FUNCTIONAL CLASS CODE.

NUMBER SECTIONS WITH NON-NUMERIC OR ZERO SECTION LENGTH, EXPANSION FACTOR, 1978 ADT OR 2000 ADT:

WORK SUMMARY FOR STATE

STATE: TEST HPMS DATE: 38/30 /79

SUMMARY ANDOVMT MILEAGE NOH

8 L E

BY FUNCTIONAL CLASS

AREA: SMALL URBAN

# SECT LGTH < .1	0	0	0	0	0	• :	0	0	0
AVG SECT LGTH	0.00	0.85	00.00	0.33	0.00	0.03	0.00	0.00	0.85
2000 DVMT (10015)	0.0	2049.0	0.0	0.0	0.0	0.0	0.0	0.0	5049.0
1978 DVMT (100'S)	0.0	4131.0	0.0	0.0	0.0	0.0	0.00	0.0	4131.0
EXPANDED MILEAGE	00.0	22.95	00.0	00.0	00*0	20*0	00.0	00.0	22.95
SAMPLED MILEAGE	00.0	0.85	00.00	00.0	00.00	03.0	00.00	00.0	0.85
NUM SECTIONS	0		•	0	0	•	0		
J.	=======================================	12	13	**	15	16	17	***	TOTALS

*

SECTIONS WHICH MAYE AN INVALID FUNCTIONAL CLASS CODE. ***

NUMBER SECTIONS WITH NON-NUMERIC OR ZERO SECTION LENGTH, EXPANSION FACTOR, 1978 ADT OR 2000 ADT:

WORK SUMMARY FOR STATE

CARD NUM	NON	CODED DATA	LOCATION ERROR
•	78991	720 204050070022300E0214221616666116036633650000BB000211180300000334121	
•		8001706210200204123410808116046031400160000100111604030001019421	48 CARD3 OR 4 MISSING FC LISTED
•	78991	8012056 039600330000150622105600005000000000000000000000	6*
ı ∢	78991	8001015615050000000000000000000000000000	50
	78991	21099907012210095104120004030606117030032300100000040000322040011	59 CHECK FC LIST FOR CUR/GRD
• ^	78991	2100260000600413055233037600384033000010002230556500000030003	. 09
1 (*	78991	210536690000000000000000000000000000000000	61
•	78991	210000000000000000000000000000000000000	62
	78991		63
· ~	78991SHD	78991SHDRT SEC502002600006041305523303760038400360600000323055555000000000000	64 CARD 1 MISSING FOR SECTION
	78991	31099907013210095104120004630666117630032000100000040030322040011	68 CHECK FC LIST FOR CUR/GRD
•	78991	3100260000604130552333376058846030000000022305556500000000000000	69
1 60	78991	310030100000000000000000000000000000000	70
*	16682	310100000000000000000000000000000000000	7.7

LISTING OF REJECTED SECTIONS OR CARD RURAL/URBAN

STATE: TEST HPMS

DATE: 08/30/79

CODED VALUES FUR SECTION IN ERROR & ERROR MESSAGES RURAL/UKBAN

COUNTY(ITEM 6): 001 SECTION ID(ITEM 4): _555 777 2 SEGMENT(ITEM5): 0

ITEM ITEM NAME	CODED VALUE		ITEM NAME	CODED	ITEM NUM	ITEM NAME	VALUE
						and the state of t	
57 RURAL/URBAN CODE	1	1 19	SHOULDER TYPE	1	1 36	1978 ADT	018000
1 YEAR	78	1 20	DRAINAGE ADEQUACY	2	1 37-A	% TRUCKS: PEAK	02
2 STATE CODE	35	1 21	SURFACE TYPE	60	1 37-B	OFF PEAK	04
3 TYPE SECTION ID	1	22	PAVEMENT SECTION	4	38	K-FACTOR	25
7 URBAN AREA CODE	070	23	STRUCTURAL NUMBER	92	39	DIRECTIONAL FACTOR	055
8 FUNCTIONAL CLASS	17	1 24	PAVEMENT CONDITION	51	1 40	TYPE OPERATION	02
46 VOLUME GROUP IDENTIF	IER 01	25	SKID RESISTANCE	00	1 41-A	PARKING: PEAK	3 .
9 FEDERAL-AID SYSTEM	3	1 26	NUM GRADE-SEPARATED INTERCH	00	1 41-B	OFF PEAK	O I
10 JURISDICTIONAL RESPO	DNSIBILITY 1	1 27-A	AT-GRADE INTERSECT: SIGNALS	02	1 42-A	CAPACITY: PEAK	00800
11 SECTION LENGTH	0030	1 27-B	STOP SIGNS	. 00	1 42-B	OFF PEAK	00750
47 EXPANSION FACTOR	0800	1 27-C	OTHER/NONE	01	43	2000 ADT	000000
12 ACCESS CONTROL	0	28	PREVAILING TYPE SIGNALIZATION	1	44	NUMBER STRUCTURES	00
13 NUMBER OF THROUGH LA	INES 02	1 29	% GREEN TIME	50	45	NUMBER AT-GRADE RR CROSSINGS	01
14 LANE WIDTH	09	1 30	NUMBER ENTRANCES/EXITS	00	48	SPEED LIMIT	40
15 APPROACH WIDTH	015	31	TYPE OF DEVELOPMENT	. 0	49	PSD > OR = 1500	000
16 MEDIAN WIDTH	00	32	URBAN LOCATION	0	1 50	HORIZONTAL ALIGNMENT	0
17 MEDIAN TYPE	4	1 33	TERRAIN	-0	51	VERTICAL ALIGNMENT	0
18-A SHOULDER WIDTH: RIGH	1T 00	34	EXISTING RIGHT-DF-WAY	060	52	AVERAGE HIGHWAY SPEED	40 .
18-B LEFT	r oo	35	IS WIDENING FEASIBLE?	1	! .	CONTINUATION CODE	000001

OPTIONAL DATA: 56-XING ID:1234567

ERRORS AND MESSAGES:

STATE CODE DOES NOT MATCH STATE CODE ON PARAMETER CARD ITEM 2 ITEM 12 ACCESS CONTROL MUST CONTAIN A 1, 2, OR 3 SHOULDER TYPE CODE MUST BE 4 OR 5 WHEN ITEM 18-RIGHT SHOULDER- = 0 ITEM 19, 18 STRUCTURAL NUMBER MUST BE ZERO WHEN ITEM 22 NOT = 1 OR 2 ITEM 23, 22 PAVEMENT CONDITION MUST BE IN RANGE 01 TO 50 WHEN ITEM 21 > 49 ITEM 24. 21 URBAN LOCATION CODE MUST BE IN RANGE 1-5 ITEM 32 URBAN ITEM 38 K FACTOR MUST BE NUMERIC AND SHOULD CONTAIN A VALUE IN THE RANGE 01-24. VERIFY PARKING PEAK AND OFF-PEAK MUST BE 1, 2, OR 3 ITEM 41 URBAN 2000 ADT MUST BE NON-ZERO NUMERIC 1TEM 43 ADT VOLUME GROUP(FOR FHWA APPROACH) IDENTIFIER IS INVALID FOR 1978 ADT VALUE CODED. VERIFY ITEM 46, 36 ITEN 52.8 AHS SHOULD BE OD WHEN ITEM 8 > 13. VERIFY AT-GRADE RR CROSSING ID MUST BE 6-DIGITS AND 1 ALPHABETIC ITEM 56

DATE: 08/30/79

0

Q

 \bigcirc

0

0

0

0

0

٥

STATE: TEST HPMS

CODED VALUES FOR SECTION IN ERROR & ERROR MESSAGES RURAL/URBAN

COUNTY(ITEM 6):	AAE	CECTION ISSITE	M 41. 1	2 22456	SEGMENT(ITEM5):	^
LUUNIILLIEM DJ:	003	SECTION IDIALE	7 414 4	2 44420	OCUMENTATION DIA	•

ITEM NUM	ITEM NAME	CODED	ITEM NUM	ITEM NAME	CODED	ITEM NUM	ITEM NAME	CODED
57	RURAL/URBAN CODE	•	19	SHOUL DER TYPE		1 24	1978 ADT	010000
21.							The state of the s	018000
ř	YEAR	78		DRAINAGE ADEQUACY	- 2	•	# TRUCKS: PEAK	04
2	STATE CODE	99		SURFACE TYPE		1 37-B		05
-3	TYPE SECTION ID	1	22	PAVEMENT SECTION	1	38	K-FACTOR	14
7	URBAN AREA CODE	999	23	STRUCTURAL NUMBER	47	39	DIRECTIONAL FACTOR	050
8	FUNCTIONAL CLASS	12	24	PAVEMENT CONDITION	34	1 40	TYPE OPERATION	02
46	VOLUME GROUP IDENTIFIER	01	25	SKID RESISTANCE	00	41-A	PARKING: PEAK	3
9	FEDERAL-AID SYSTEM	•	26	NUM GRADE-SEPARATED INTERCH	00			3
10	JURISDICTIONAL RESPONSIBILITY	ī		AT-GRADE INTERSECT: SIGNALS	01		CAPACITY: PEAK	02880
11	SECTION LENGTH	- ,	27-8	STOP SIGNS	00	-		02850
4.7			27-C			• –		
47	EXPANSION FACTOR			OTHER/NONE		1.43	2000 ADT	022000
12	ACCESS CONTROL	2		PREVAILING TYPE SIGNALIZATION		•	NUMBER STRUCTURES	00
13	NUMBER OF THROUGH LANES	04	29	% GREEN TIME	. 77	45	NUMBER AT-GRADE RR CROSSINGS	00
14	LANE WIDTH	12	30	NUMBER ENTRANCES/EXITS	90	48	SPEED LIMIT	55
15	APPROACH WIDTH	000	31	TYPE OF DEVELOPMENT	0	1 49	PSD > OR = 1500	000
16	MEDIAN WIDTH	24	32	URBAN LOCATION	4	1 50	HORIZONTAL ALIGNMENT	a
17	MEDIAN TYPE	3	33	TERRAIN	0	51	VERTICAL ALIGNMENT	ŏ
_	SHOULDER WIDTH: RICHT	C8		EXISTING RIGHT-DF-WAY		52	AVERAGE HIGHWAY SPEED	60
18-B	LEFT	06		IS WIDENING FEASIBLE?				
T 0_D	LEFI	VO)	22	19 MINEMING LEMPIDEEL	4	,	CONTINUATION CODE	100000

OPTIONAL DATA:

ERRORS AND MESSAGES:

ITEM 46, 36

ADT VOLUME GROUP(FOR FHWA APPROACH) IDENTIFIER IS INVALID FOR 1978 ADT VALUE CODED. VERIFY

CODED VALUES FOR SECTION IN ERROR & ERROR MESSAGES RURAL/URBAN

CO	UNTY (ITEM 6): 017 SECTION ID(1	TEM 4):	41 SEGMENT	(ITEM5): O			
IT NU	=	CODED ITEM		DED CODED VALUE	ITEM NUM	ITEM NAME	CODED VALUE
27	DUDAL ALIDDAN FOOE	2 19	CHOW DED TYPE		1 24	1978 ADT	030000
57	RURAL/URBAN CODE		SHOULDER TYPE			TRUCKS: PEAK	030000
ī	YEAR STATE CODE	78 20 99 21	DRAINAGE ADEQUACY SURFACE TYPE			OFF PEAK	34
2	TYPE SECTION ID	1 22	PAVEMENT SECTION	· •		K-FACTUR	12
7	URBAN AREA CODE	000 23	STRUCTURAL NUMBER	The state of the s		DIRECTIONAL FACTOR	050
8		03 24	PAVEMENT CONDITIO			TYPE OPERATION	00
46		02 25				PARKING: PEAK	ő
9		2 26				OFF PEAK	ň
10	JURISDICTIONAL RESPONSIBILITY	•	A AT-GRADE INTERSEC			CAPACITY: PEAK	03690
11	SECTION LENGTH	0200 27-		STOP SIGNS OF		OFF PEAK	00000
47	EXPANSION FACTOR	2210 27-		OTHER/NONE OI		2000 ADT	033000
12	ACCESS CONTROL	2 28			1 44	NUMBER STRUCTURES	02
13	NUMBER OF THROUGH LANES	04 1 29	% GREEN TIME) 45	NUMBER AT-GRADE RR CROSSINGS	00
14	LANE WIDTH	12 30	NUMBER ENTRANCES/) 48	SPEED LIMIT	50
15	APPROACH WIDTH	000 31	TYPE OF DEVELOPME		l 49	PSD > OR = 1500	000
16	MEDIAN WIDTH	36 32	URBAN LOCATION		5 1 50	HORIZONTAL ALIGNMENT	0.0
17	MEDIAN TYPE	1 33	TERRAIN		51	VERTICAL ALIGNMENT	a
	-A SHOULDER WIDTH: RIGHT	08 34	EXISTING RIGHT-OF	-WAY 160	–	AVERAGE HIGHWAY SPEED	50
18		08 35	IS WIDENING FEASI		1 32	CONTINUATION CODE	000000

ERRORS AND MESSAGES:

7

ITEM 8	FUNCTIONAL CLASS CODE IS INVALID
ITEM 50,21,53 RURAL	HORIZONTAL ALIGNMENT MUST BE IN RANGE 1-4 WHEN ITEM 21 > 49 AND ITEM 53 IS NOT PROVIDED
ITEM 51,21,54 RURAL	VERTICAL ALIGNMENT MUST BE IN RANGE 1 TO 4 WHEN ITEM 21 > 49 AND ITEM 54 IS NOT PROVIDED.
ITEM 52,8,21,31 RUR	VERIFY VALUE CODED ITEM 52; ITEM 8, 21 OR 31 IS IN ERROR
ITEM 57.8	RUR-URB CODE = 2; FUNCTIONAL CLASS CODE MUST BE 01.02.06.07 OR 08

STATE: TEST HPMS

CODED VALUES FOR SECTION IN ERROR & ERROR MESSAGES RURAL/URBAN

COUNTY(ITEM 61:	104	SECTION	ID(ITEM 4):	CROSS FOITO1	SEGMENTITEMS1: 0

ITEM NUM	ITEM NAME	CODED	ITEM NUM	ITEM NAME	CODED	ITEM NUM	ITEM NAME	CODED VALUE
57	RURAL/URBAN CODE	2	1 19	SHOULDER TYPE	4	36	1978 ADT	005500
1	YEAR	78	20	DRAINAGE ADEQUACY	. 2	1 37-A	% TRUCKS: PEAK	30
2	STATE CODE	99	1 21	SURFACE TYPE	54	37-8	OFF PEAK	35
-3	TYPE SECTION ID	1	22	PAVEMENT SECTION	0	38	K-FACTOR	15
7	URBAN AREA CODE	000	23	STRUCTURAL NUMBER	10	1 39	DIRECTIONAL FACTOR	100
8	FUNCTIONAL CLASS	0.7	24	PAVEMENT CONDITION	. 00	1 40	TYPE OPERATION	00
46	VOLUME GROUP IDENTIFIER	03	25	SKID RESISTANCE	10	41-A	PARKING: PEAK	Ö
9	FEDERAL-AID SYSTEM	4	1 26	NUM GRADE-SEPARATED INTERCH	00	1 41-8	OFF PEAK	ŏ
10	JURISDICTIONAL RESPONSIBILITY	1	1 27-A	AT-GRADE INTERSECT: SIGNALS	02	42-A	CAPACITY: PEAK	03000
11	SECTION LENGTH	0235	1 27-B	STOP SIGNS	01			00000
47	EXPANSION FACTOR	0806	1 27-C	OTHER/NDNE	00	43	2000 ADT	005700
12	ACCESS CONTROL	. 3	28	PREVAILING TYPE SIGNALIZATION	0	44	NUMBER STRUCTURES	03
13	NUMBER OF THROUGH LANES	02	29	% GREEN TIME	00	1 45	NUMBER AT-GRADE RR CROSSINGS	
14	LANE WIDTH	11	1 30	NUMBER ENTRANCES/EXITS	10	48	SPEED LIMIT	50
15	APPROACH WIDTH	000	31	TYPE OF DEVELOPMENT	2	1 49	PSD > OR = 1500	000
16	MEDIAN WIDTH	00	1 32	URBAN LOCATION	0	50	HORIZONTAL ALIGNMENT	2
17	MEDIAN TYPE	2	33	TERRAIN	1	51	VERTICAL ALIGNMENT	2
18-A	SHOULDER WIDTH: RIGHT	10	34	EXISTING RIGHT-OF-WAY	042	52	AVERAGE HIGHWAY SPEED	30
18-8	LEFT	04	35	IS WIDENING FEASIBLE?			CONTINUATION CODE	000401
						•	THE PROPERTY OF THE PROPERTY O	2007JL

OPTIONAL DATA:

55-STRUC ID: BRIDGE 31 BRIDGE 32 BRIDGE 33 BRIDGE 3

56-XING ID:495644R

ERRORS AND MESSAGES:

ITEM 17, 16	MED TYPE CODE MUST BE 4 WHEN ITEM 16 = 0
ITEM 18, 16	LEFT SHOULDER WIDTH MUST BE ZERG WHEN ITEM 16 = 00
ITEM 19, 18	SHOULDER TYPE CODE MUST BE IN RANGE 1-3 WHEN ITEM 18-RIGHT SHOULDER- > 0:
ITEM 21	SURFACE TYPE CODE IS INVALID
ITEM 22, 21	VERIFY VALUE CODED FOR ITEM 22; ITEM 21 IS IN ERROR
ITEM 23, 22	STRUCTURAL NUMBER MUST BE ZERO WHEN ITEM 22 NOT = 1 OR 2
ITEM 24, 21	VERIFY VALUE CODED FOR ITEM 24; ITEM 21 IS IN ERROR
ITEM 25, 21 RURAL	VERIFY VALUE CODED FOR ITEM 25: ITEM 21 IS IN ERROR
ITEM 42, 13 RURAL	CAPACITY SHOULD BE < OR = NUMBER LANES TIMES 1000 OR ZERO
ITEM 49, 21, 13	VERIFY VALUE CODED FOR ITEM 49; ITEM 21 OR 13 IN ERROR
ITEM 50, 21 RURAL	VERIFY VALUE CODED FOR ITEM 59; ITEM 21 IS IN ERROR
ITEM 51, 21 RURAL	VERIFY VALUE CODED FOR ITEM 51; ITEM 21 IS IN ERROR
ITEM 52,8,21,31 RUR	VERIFY VALUE CODED ITEM 52; ITEM 8, 21 OR 31 IS IN ERROR
ITEM 55:44	BRIDGE ID NUMBER OF ID'S MUST # NUMBER OF STRUCTURES, ITEM 44
ITEM 56,45	AT-GRADE RR CROSSING ID NUMBER OF ID'S MUST = NUMBER OF RR CROSSINGS, ITEM 45

CODED VALUES FOR SECTION IN ERROR & ERROR MESSAGES RURAL/URBAN

DPTIONAL DATA: 55-STRUC ID: 217369728452083 432198765432109

ERRORS AND MESSAGES:

ITEM 46. 36 ADT VOLUME GROUP(FOR FHWA APPROACH) IDENTIFIER IS INVALID FOR 1978 ADT VALUE CODED. VERIFY

CODED VALUES FOR SECTION IN ERROR & ERROR MESSAGES RURAL/URBAN

COUN	TY(ITEM 6): 700 SECTION ID(I	TEM 4):	3	54 2172C SEGMENT(ITEM5): 0				
ITEM NUM	ITEM NAME	CODED VALUE	ITEM NUM	ITEM NAME	CODED	ITEM NUM	ITEM NAME	CODED VALUE
57	RURAL/URBAN CODE	2 1	19	SHOULDER TYPE		36	1978 ADT	037000
1	YEAR	78	20	DRAINAGE ADEQUACY	1	1 37-1	TRUCKS: PEAK	C1
2	STATE CODE	99	21	SURFACE TYPE	70	1 37-8	DFF PEAK	04
3	TYPE SECTION ID	1	22	PAVEMENT SECTION	. 2	38	K-FACTOR	25
7	URBAN AREA CODE	000	23	STRUCTURAL NUMBER	00	39	DIRECTIONAL FACTOR	050
8	FUNCTIONAL CLASS	02	24	PAVEMENT CONDITION	40	40	TYPE OPERATION	00
46	VOLUME GROUP IDENTIFIER	03		SKID RESISTANCE	. 60	41-1	PARKING: PEAK	0
9	FEDERAL-AID SYSTEM	2 !	26	NUM GRADE-SEPARATED INTERCH	01	41-8	OFF PEAK	0:
10	JURISDICTIONAL RESPONSIBILITY	1	.27-A	AT-GRADE INTERSECT: SIGNALS	. 00	42-1	CAPACITY: PEAK	00000
11	SECTION LENGTH	0400	27 - 8	SPDIS ACTS			OFF PEAK	00000
47	EXPANSION FACTOR	0050					2000 ADT	039000
12	ACCESS CONTROL	1 1		PREVAILING TYPE SIGNALIZATION	_	44	NUMBER STRUCTURES	01
13	NUMBER OF THROUGH LANES	04		\$ GREEN TIME		45	NUMBER AT-GRADE RR CROSSINGS	
14	LANE WIDTH	12		NUMBER ENTRANCES/EXITS		48	SPEED LIMIT	10
15	APPROACH WIDTH	000 j		TYPE OF DEVELOPMENT		1 49	PSD > DR = 1500	090
16	MEDIAN WIDTH	16		URBAN LUCATION		50	HORIZONTAL ALIGNMENT	0
17	MEDIAN TYPE	2		TERRAIN	_	51	VERTICAL ALIGNMENT	0.
18-A		08 1		EXISTING RIGHT-DF-WAY		52	AVERAGE HIGHWAY SPEED	60.
18-B	LEFT	08	35	IS WIDENING FEASIBLE?	3.		CONTINUATION CODE	110000

OPTIONAL DATA:

54-GRADES: 02030 01007 01005 00000 03000 00000

ERRORS AND MESSAGES:

ITEM 23, 22	STRUCTURAL NUMBER SHOULD BE IN RANGE 06-12 WHEN ITEM 22 = 2
ITEM 33 RURAL	TERRAIN CODE MUST BE IN RANGE 1-3
ITEM 38	K FACTOR MUST BE NUMERIC AND SHOULD CONTAIN A VALUE IN THE RANGE 01-24. VERIFY
ITEM 46, 36	ADT VOLUME GROUP(FOR FHWA APPRUACH) IDENTIFIER IS INVALID FOR 1978 ADT VALUE CODED. VERIFY
ITEM 47	EXPANSION FACTOR MUST BE IN THE RANGE 0100 TO 9999
ITEM 48	SPEED LIMIT MUST BE IN THE RANGE 15 TO 56
ITEM 49, 13 RURAL	PSD > OR = 1500 SHOULD BE 000 WHEN ITEM 13 > 2 OR ITEM 21 < 49
ITEM 53	CURVES BY CLASS NUM OF CURVES > 00 MUST HAVE LENGTH > 000
1TEM 54,11	GRADES BY CLASS SUM OF GRADES LENGTHS MUST = ITE4 11

CODED VALUES FOR SECTION IN ERROR & ERROR MESSAGES RURAL/URBAN

COUN	TY(ITEM 6): 999 SECTION ID(I	TEM 41:	- 1 <u>- 1</u>	41 SEGMENT(ITEM5): 0					*
ITEM	ITEM NAME	CODED	ITEM NUM	ITEM NAME	CODED VALUE	ITEM NUM	ITEM NAME		CODED VALUE
57	RURAL/URBAN CODE	1	19	SHOULDER TYPE	1	36	1978 ADT		026000
1	YEAR	78		DRAINAGE ADEQUACY	1.	•	% TRUCKS: PEAK		06
2	STATE CODE	99		SURFACE TYPE	70			- ,	04
3	TYPE SECTION ID		22	PAVEMENT SECTION	. 3	•	K-FACTOR		13
7	URBAN AREA CODE	070		STRUCTURAL NUMBER	00		DIRECTIONAL FACTOR		055
. 8	FUNCTIONAL CLASS		24	PAVEMENT CONDITION	32		TYPE OPERATION		02
46	VOLUME GROUP IDENTIFIER	07		SKID RESISTANCE	00		PARKING: PEAK		3
9		2	-	NUM GRADE-SEPARATED INTERCH	01	• . –			3
10	JURISDICTIONAL RESPONSIBILITY			AT-GRADE INTERSECT: SIGNALS	00	-	CAPACITY: PEAK		03760
11	SECTION LENGTH	0095				•		A	03840
47	EXPANSION FACTOR	2305					2000 ADT		030000
12	ACCESS CONTROL	1	28	PREVAILING TYPE SIGNALIZATION			NUMBER STRUCTURES		01
13	NUMBER OF THROUGH LANES	04	•	% GREEN TIME	. 00	-	NUMBER AT-GRADE RR C	ROSSINGS	00:
14	LANE WIDTH	12		NUMBER ENTRANCES/EXITS	0.0		SPEED LIMIT		55
15	APPROACH WIDTH	000	•	TYPE OF DEVELOPMENT	0	•	PSD > OR = 1500	100 100 100	000
16	MEDIAN WIDTH	40		URBAN LOCATION	3		HORIZONTAL ALIGNMENT		0
17	MEDIAN TYPE	3		TERRAIN	0		VERTICAL ALIGNMENT		0
	SHOULDER WIDTH: RIGHT	06		EXISTING RIGHT-OF-WAY	220	52	AVERAGE HIGHWAY SPEE	D	65
18-B	LEFT	06	35	IS WIDENING FEASIBLE?	4		CONTINUATION CODE	•	000100

OPTIONAL DATA:

55-STRUC ID: BRIDGE

1

ERRORS AND MESSAGES:

ITEM 15, 8 URBAN APPROACH WIDTH SHOULD BE IN RANGE 007-100 WHEN ITEM 8 > 13. VERIFY

1TEM 52,8 URBAN AHS SHOULD BE 00 WHEN ITEM 8 > 13. VERIFY

CODED VALUES FOR SECTION IN ERROR & ERROR MESSAGES RURAL/URBAN

COUN	TY(ITEM 6): 999 SECTION ID(ITEM 4):	~~~~	501 SEGMENT (ITEM5)	: 0				
ITEM	ITEM NAME	CODED	ITEM NUM	ITEM NAME		CODED	ITEM NUM	ITEM NAME	CODED VALUE
57	RURAL/URBAN CODE	1 1	19	SHOULDER TYPE		1	1 36	1978 ADT	026000
i	YEAR	78 1		DRAINAGE ADEQUACY		ī	•	% TRUCKS: PEAK	06
2	STATE CODE	99 1		SURFACE TYPE		70	•	OFF PEAK	04
3	TYPE SECTION ID	i i		PAVEMENT SECTION		3		K-FACTOR	13
7	URBAN AREA CODE	075	23	STRUCTURAL NUMBER		0.0	39	DIRECTIONAL FACTOR	055
8	FUNCTIONAL CLASS	11	24	PAVEMENT CONDITION		32	1 40	TYPE OPERATION	02
46	VOLUME GROUP IDENTIFIER	03	25	SKID RESISTANCE		00	41-A	PARKING: PEAK	3
9	FEDERAL-AID SYSTEM	1	26	NUM GRADE-SEPARATED INTE	RCH	01	41-B	OFF PEAK	- 3
10	JURISDICTIONAL RESPONSIBILITY	1 1	27-A	AT-GRADE INTERSECT: SIGN	AL S	00	1 42-A	CAPACITY: PEAK	03760
11	SECTION LENGTH	0095	27-B	STOP	SIGNS	5 00	1 42-B	OFF PEAK	03840
47	EXPANSION FACTOR	2305	27-C				43	2000 ADT	030000
12	ACCESS CONTROL	1 1	28	PREVAILING TYPE SIGNALIZ	ATION	1 4	44	NUMBER STRUCTURES	00
13.	NUMBER OF THROUGH LANES	04 1		% GREEN TIME		00	45	NUMBER AT-GRADE RR CROSSINGS	00
14	LANE WIDTH	12		NUMBER ENTRANCES/EXITS		00	7.	SPEED LIMIT	55
15	APPROACH WIDTH	000		TYPE OF DEVELOPMENT		. 0	•	PSD > OR = 1500	000
16	MEDIAN WIDTH	40	32	URBAN LOCATION		3	•	HORIZONTAL ALIGNMENT	o
17	MEDIAN TYPE	3		TERRAIN		0		VERTICAL ALIGNMENT	Õ
_	SHOULDER WIDTH: RIGHT	06		EXISTING RIGHT-OF-WAY			52	AVERAGE HIGHWAY SPEED	65
18-B	LEFT	06	35	IS WIDENING FEASIBLE?		4		CONTINUATION CODE	000000

ERRORS AND MESSAGES:

ITEM 46, 36 ADT VOLUME GROUP(FOR FHWA APPROACH) IDENTIFIER IS INVALID FOR 1978 ADT VALUE CODED. VERIFY

CODED VALUES FOR SECTION IN ERROR & ERROR MESSAGES RURAL/URBAN

CC	DUNTY (ITEM 61: 999 SECTION ID	ITEM 4):	506 SEGMENT(ITEM5): D			As.
	TEM NAME	CODED ITE		E CODED VALUE	ITEM NUM	ITEM NAME	CODED
57	7 RURAL∕URBAN CODE	1 1 19	SHOULDER TYPE	1	1 36	1978 ADT	026000
21	YEAR	8 1 20				% TRUCKS: PEAK	96
	STATE CODE	99 21) 37-B		04
	TYPE SECTION ID	1 22					13
	URBAN AREA CODE	074 23			39	DIRECTIONAL FACTOR	055
Š	FUNCTIONAL CLASS	11 24			40	TYPE OPERATION	őź
46		03 25				PARKING: PEAK	3
7.	FEDERAL-AID SYSTEM	1 26					. 3
10			-A AT-GRADE INTERSECT	·		CAPACITY: PEAK	03760
ii			-B	STOP SIGNS 00			03840
47		-	- c	OTHER/NONE 00	•	2000 ADT	030000
i		1 1 28			1 44	NUMBER STRUCTURES	30
13		04 1 29			1 45	NUMBER AT-GRADE RR CROSSINGS	
14		12 30	· · · · · · · · · · · · · · · ·		1 48	SPEED LIMIT	55
ī:		000 i 31			49	PSD > OR = 1500	000
16		40 32			1 50	HORIZONTAL ALIGNMENT	0
17	· · · · · · · · · · · · · · · · · · ·	3 1 33) 51	VERTICAL ALIGNMENT	Ö
	B-A SHOULDER WIDTH: RIGHT	06 34		-		AVERAGE HIGHWAY SPEED	65
	3-B LEFT	06 35				CONTINUATION CODE	000000

ERRORS AND MESSAGES:

ITEM 1 YEAR MUST BE 78
ITEM 11 SECTION LENGTH MUST BE A NON-ZERO NUMERIC
ITEM 46, 36 ADT VOLUME GROUP(FOR FHWA APPROACH) IDENTIFIER

ADT VOLUME GROUP(FOR FHWA APPROACH) IDENTIFIER IS INVALID FOR 1978 ADT VALUE CODED. VERIFY

EDIT SUMMARY RURAL/URBAN

NUMBER SECTIONS EDITED: RURAL: 6 URBAN: 5
NUMBER SECTIONS IN ERROR: RURAL: 4 URBAN: 5

END OF DATASET WAS REACHED BEFORE MAXIMUM NUMBER ERRORS FOR EDIT RUN WORK EDIT FOR STATE.

USER SUPPLIED PARAMETEK CARDS

ISTATE TEST HPMS /99/ SELMUDENU, MCJUNLY SELEUT=RU, FHHADESIGN, ERLMFSS

ALL USER SUPPLIED CARDS PROCESSED, NO ERRURS WENE DETECTED.

THANSACTION CARDS SUPPLIED KURAL/URBAN

	CARD LOC	COUNTY	SECTION TO	CARD
	1	001	555771_2	Ubland 555 777 2/2,99/12,2/56-1,9997218/
	2	001	555_777_2	U01.01 555 777 2/44,02/45,3/
	. 3	001	555171_2	CC140 14 555 1777 2A77777X666666Y
	4	001	<u> 555 777 2</u>	BCLCCL 555 777 2ATEST ADD BRIDGITEST ADD BRIDG2
	5	193	95 87675	001193 95 876751
,	5	170	0 354 21720	B/11700 354 21720UND MATCH DEL ID
	1	170	0 354 2) 720	802.700 354 21720ATEST ADD BRIDDLITEST ADD BRIDD2TEST ADD BRIDD3
	. 8	170	J 354 21720	U01170C 354 21720/44:03/48:45/
	9	999	<u>F91</u>	U(1599 501/33,1/27,01/
	10	999	501	U02999 50145,06/18-C,10/37-A,25/
	11	999	5.01	CO1999 501AADD TEST BRIDD1
	3.2	999	501	5011999 501111111A22222B333333C
	13	999	501	802999 5 01A444 4440555555E666666F
	14	193	72183	0/11/93 721832
	15	193	721.83	D02193 721831
	16	617	40	801347 40AADD TEST BRIDD1
	17	017	<u>40</u>	CO1(17 40999999Z
	18	017	40	U01017 40/6,018/
	19	999	921 768	001999 921 768/10,1/38,22/
	20	.999	<u>501</u>	U01999 501/37-A,10-1,78-47,2215/
	21	999	50:	U02999 501/7,007/14,10/51,1/
	22	999	<u> </u>	801999 561ABRIDO1 TEST ADDBRIDO2 TEST ADD
	23	760	<u> 354 21721</u>	D01799 354 217211
	24	01.7		U01(17 41/8,32/
	25	018	44	COIC18 44A887766X
	26	01.8		UD2018 44/6,019/
	27	005	3 22450	UE19051 3 22450746,02752,45745,017
	28	0C 5	1 3 22450	U12U051 3 22450/53-C,01002/44,02/
	29.	00.5	3 2245)	BD10051 3 22459AADD BRIDOL TEST
	30	005	1 3 22450	C010U51 3 22450A623457Z
	31	104	CROSS EDITOR	-UJ\$104CR0\$5 EDIT01/17,4/18-8,00/19,2/
	32	104	CRUSS EDITOR	U02104CROSS EDIT01/45,01/44,04/23,00/

FILES OPENCO. MENCE PROCESS STAFTED TO UPDATE SECTIATA AND CREATE DATASET NEWDATA--THE NEW MASTER FILE. VALI) THANSACTION SETS WORL PROCESSED. UPDATE PROCESS STARTED. HEW MASTER DATASET TO BE DEVELOPED.

))))))

		SECTION DELETED	
	O V I D VEW MASTER DATABASE	CRUSSING 10	A - 1 0 - 0 A - 1 0 - 0 A - 1 0 - 0 A - 1 0 - 0 A - 0 0 - 0 A - 0 0 - 0
	BY SECTION ID DN	BRIDGE ID	A A A A A A B B B B B B B B B B B B B B
STATE: TEST HPMS	TRAMS ACTIONS BY SECTION ID N I D (SUMMARY IS BY CUUNTY CUDE AND SECTION ID ON NEW MASTER DATABASE)	NUMBEL TEMS UPDATED	අගකරනුද
		SECTION 10	LESS 177.2 1 3 22457 CESS EULICE 95 97615
DATE:: 5/3: /79		COUNTY	0001 0005 104 104 193

(

STATE: TEST HPMS PATE : 18/36 /79 HP HS UP DATESUAMARY REPORT

で記述

* SECTIONS	*SECTIONS MODIFIED: RUPAL:	RUPAL:		URBAIII	ι.J	
SECTIONS	SECTIONS DELCTED: RURAL:	RURAL:	 and I	URBAN:	S	
THOUL PART FOR	Trion	RURAL		URBAN:	'n	

* INCLUDES SECTION WITH UPDATED DATA ITEM AND/OR BRIDGE 13'S ADDED OR DELETED AND/OR CROSSING 10'S ADDED OR DELETED.

END OF SECTION DATABASE REACHED BEFORE ALL TRANSACTIONS WERE PROCESSED. TRANSACTION BEING PROCESSED: 999 921 768 U

SECTIONS WERE MODIFIED OR DELETED CHLY IN THIS EXECUTION. NO NGW SECTIONS WERE ADDED TO THE DATABASE.

STATE: TEST HPMS UATC: 18/54/79

TRANSACTION SETS WERE NOT ADDED TO ALTER FILE AND NONE WERE USED IN DEVELOPING UPDATED DATABASE)

TRAN CODE NOT #; SEQ# >1, ID = DELETE CARDS > 1 WITH SAME ID ERROR MESSAGE CCUED CARD 44A887765X 44/6,019/ 721832 001193 002193 CO1018 UP 2F.18 CARU LOC 4 5 252

ERRORS DETECTED DURING MERGE PROCESS

C	INPUT	CARD	PUS IT I	IN SE	u NUM	CCUNTY	SECTION ID	TKANS	S CODE	CODED ERROR OR VERIFY		ERROR MESSAGE
<u></u>		1	t 8		1 16	001 017	555777_2		U	56-1 CK CNTY & SECT ID CODED		SUB-ITEM LETTER OR NUM IS NOT = ID FOR SECTION
a		1	7 6 8		16 16 2	017 017 170	354 2172U		C U	CK CNTY & SECT ID CODED CK CNTY & SECT ID CODED CK CNTY & SECT ID CODED	ID TRAN	IS NOT = ID FOR SECTION IS NOT = ID FOR SECTION IS NOT = ID FOR SECTION
		2	6 3		2 2	170 700	C 354 21720 354 21721		D .	CK CNTY & SECT ID CODED CK CNTY & SECT ID CODED	ID TRAN	IS NOT = ID FOR SECTION S NOT = ID FOR SECTION
67		20) 9		1	999 999	501		U	CHECK /'S AND ,'S	ITEM NU	FORMAT FOR UPDATE CARD IM MUST HAVE SUB-ITEM
0		1.	9·. 2		2	999 999	501 501		U B	CHECK /'S AND 'S		FORMAT FOR UPDATE CARD OF 'A' OR 'D' FOR ID'S

ITEM NUMBERS AND ERROR MESSAGES BY SECTION ID RURAL/URBAN

```
SECTION ID(ITEM 4): __555__777_2 SEGMENT(ITEM5): S
     COUNTY(ITEM 6): 601 -
     TREUES AND MESSAGES:
                              SHOULDER TYPE CODE MUST BIT OF BR 5 WHEN ITEM 18-RIGHT SHOULDER- = 0
       ITEM 19, 18
                              STRUCTURAL NUMBER MUST BE ZERO WHEN ITEM 22 NOT = 1 OR 2
       ITEM 23, 22
                             PAYEMENT CONDITION MUST BE IN RANGE OF TO 50 WHEN ITEM 21 > 49
       ITEM 24, 21
                             URBAN LOCATION CODE MUST BE IN RANGE 1-5
       ITEM DZ URBAN
                             R FACTOR MUST BE HUMBRIG AND SHOULD CENTAIN A VALUE IN THE RANGE 01-24. VERIFY
       1TEM 38
                             PARKING PEAK AND OFF-PEAK MUST BE 1, 2, UR 3
       ITEM 41 URBAN
                             2300 ADT MUST BE NON-ZERG NUMERIC
       ITEM 43
                              NUMBER OF AT-GRADE CRUSSINGS MUST BE NUMERIC
       ITEM 45
                             ADT VOLUME GROUP (FOR FIMA APPROACH) IDENTIFIER IS INVALID FOR 1978 ADT VALUE CODED. VERIFY
      ITEM 46. 36
                        URB AHS SHOULD BE OF WHEN ITEM 3 > 13. VERIFY
       ITEN 52.8
                             AT-GRADE RK CHOSSING ID MUST BE 6-DIGITS AND 1 ALPHABETIC
       ITEM 56
                             AT-GPADE RK CROSSING ID NUMBER OF ID'S MUST = NUMBER OF RR CROSSINGS, ITEM 45
       ITEM 56,45
     COUNTY(ITEM 6): (C5 SECTION ID(ITEM 4): 1 3 22452 SEGMENT(ITEM5): 0
     EFRUES AND MESSAGES:
(*
                             BRIDGE ID
                                           NUMBER OF ID'S MUST = NUMBER OF STRUCTURES, ITEM 44
      ITEM 55,44
                           SECTION ID(ITEM 4): 41 SEGMENT(ITEM5): 9
     COUNTY (ITEM 6): 017
(")
     ERRORS AND MESSAGES:
       ITFM 46, 36
                              ADT VOLUME GROUP (FOR FHWA APPROACH) IDENTIFIER IS INVALID FOR 1978 ADT VALUE CODED. VERIFY
                             HORIZONTAL ALIGNMENT MUST BE IN KANGE 1-4 WHEN ITEM 21 > 49 AND ITEM 53 IS NOT PROVIDED
       ITEM 50 .21 .53 RUFAL
(2
                             VERTICAL ALIGNMENT MUST BE IN RANGE 1 TO 4 WHEN ITEM 21 > 49 AND ITEM 54 IS NOT PROVIDED
       ITEM 51,21,54 RURAL
                           SECTION ID(ITEM 4): CRUSS EDITE SEGMENT(ITEM5): 3
     COUNTY(ITEM 6): 1.4
     FREGES AND MESSAGES:
       11EM 21
                              SURFACE TYPE CODE IS INVALID
       ITEM 22, 21
                              VERIFY VALUE CODED FOR ITEM 22; ITEM 23 IS IN ERROR
       ITEM 24, 21
                              VERIFY VALUE CODED FOR ITEM 24: ITEM 21 IS IN ERROR
       ITEM 25, 21 RURAL
                              VERIFY VALUE CODED FOR ITEM 25; ITEM 2% IS IN ERROR
       ITEM 42, 13 RURAL
                              CAPACITY SHOULD BE < OR = NUMBER LANES TIMES 1000 OR ZERO
                              VERIFY VALUE CODED FOR ITEM 49; ITEM 21 OR 13 IN ERROR
       ITEM 49, 21, 13
       ITEM 50, 21 FURAL
                              VERILY VALUE CODED FOR ITEM 50; ITEM 21 IS IN ERROR
       ITEM 51, 21 RURAL
                              VERIFY VALUE CODED FOR ITEM 52: ITEM 22 IS IN ERROR
       1TEM 52,8,21,31 RUR
                              VERIFY VALUE CODED ITEM 52; ITEM 8: 2% OR 3% IS IN ERROR
                           SECTION ID(ITEM 4): 354 21720 SEGMENT(ITEM5): 0
     COUNTY (ITEM 6): 700
     EEFORS AND NESSAGES:
       1TEM 23, 22
                              STRUCTURAL NUMBER SHOULD BE IN RANGE 06+12 WHEN ITEM 22 = 2
                              TERRAIN CODE MUST BE IN RANGE 1-3
       ITEM 33 RURAL
                              K FACTOR MUST BE NUMERIC AND SHOULD CONTAIN A VALUE IN THE RANGE 01-24. VERIFY
       ITEM 38
                              ADT VOLUME GROUP (FOR FHWA APPROACH) IDENTIFIER IS INVALID FOR 1978 ADT VALUE CODED. VERIFY
       ITEM 46, 36
                              EXPANSION FACTOR MUST BE IN THE RANGE 0100 TO 9999
       ITEM 47
       ITEM 48
                              SPEED LIMIT MUST BE IN THE RANGE 15 TO 56
       ITEM 49, 13
                     RULAI
                             PSD > 0k = 1500 SHOULD BE COTE WHEN ITEM 13 > 2 OR ITEM 21 < 49
       ITEM 53
                              CURVES BY CLASS
                                                NUM OF CURVES > 00 MUST HAVE LENGTH > 000
       ITEM 54.11
                              GRADES BY CLASS SUM OF GRADES LENGTHS MUST = ITEM 11
     COUNTY(ITEM 6): 999
                          SECTION ID(IT_M 4): 41 SEGMENT(ITEM5): 0
     FREDES AND MESSAGES:
       ITEM 15, 8 URBAN
                              APPROACH WIDTH SHOULD BE IN RANGE 007-100 WHEN ITEM 8 > 13. VERIFY
                        URB AHS SHOULD BE DO WHEN ITEM 5 > 13. VERIFY
       ITEM 52,8
     COUNTY ( ETEM 6 ): 999
                           SECTION ID(1TEM 4): 51 SEGMENT(ITEM5): 7
     ERRORS AND MESSAGES:
                              ADT VOLUME GROUP (FOR FHWA APPRIACH) IDENTIFIER IS INVALID FOR 1978 ADT VALUE CODED. VERIFY
       ITEM 46, 36
       ITEM 55,44
                              BRIDGE ID GUMBER OF ID'S MUST = NUMBER OF STRUCTURES. ITEM 44
       ITEM 55
                              AT-GRADE RE CROSSING ID MUST BE 6-DIGITS AND 1 ALPHABETIC
                              AT-GRADE AR CRUSSING ID NUMBER OF ID'S MUST = NUMBER OF RR CROSSINGS. ITEM 45
       ITEM 56,45
```

YEAR MUST BE 78 SECTION LENGTH MUST BE A NEW-ZORD NUMBRIC ADT VOLUME GROUPLEGE FHWA APPROACH) IDENTIFIER IS INVALID FOR 1978 ADT VALUE CODED. VERIFY AN UNBAN SECTION HAS A VALUE CODED FOR A RURAL ONLY DATA LIEM. CHECK ALL RURAL LIEMS SEGMENTITEMS): 0 SECTION IDUITEM 413 COUNTY(ITEM 6): 590 EREURS AND MESSAGES: ITEM 1 ITEM 11 ITEM 11 UKBAP:

(

0

)

E D I T S U M M A R Y RURAL/URBAN

STATE: TEST HPMS

141E: 38/39/75

UF BAN: **KUEAL:** NUMBER SECTIONS EDITED:

3 URBAN: RURAL: NUMBER SECTIONS IN ERROR:

END OF DATASET WAS REACHED BEFURE MAXIAUM WOMBER ERRORS FOR EDIT RUN

WURK EDIT FOR STATE.

D. C. School Co.

