Coast Guard, DHS § 120.376

§120.354 Battery installations.

- (a) Large batteries. Each large battery installation must be located in a locker, room or enclosed box solely dedicated to the storage of batteries. Ventilation must be provided in accordance with §111.15-10 in subchapter J of this chapter. Electrical equipment located within the battery enclosure must be approved by an independent laboratory for Class I, Division 1, Group B hazardous locations and meet §111.105 in subchapter J of this chapter.
- (b) *Small batteries.* Each small battery installation must be located in a well ventilated space and protected from falling objects. A small battery installation must not be in a closet, storeroom, or similar space.

§ 120.360 Semiconductor rectifier systems.

- (a) Each semiconductor rectifier system must have an adequate heat removal system that prevents overheating.
- (b) Where a semiconductor rectifier system is used in a propulsion system or in other vital systems it must:
 - (1) Have a current limiting circuit;
- (2) Have external overcurrent protection; and
- (3) Meet Sections 35.84.2 and 35.84.4 of the American Bureau of Shipping (ABS), "Rules for Building and Classing Steel Vessels," or other standard specified by the Commandant.

§ 120.370 General grounding requirements.

- (a) A vessel's hull must not carry current as a conductor except for the following systems:
- (1) Impressed current cathodic protection systems; or
- (2) Battery systems for engine starting.
- (b) Receptacle outlets and attachment plugs for portable lamps, tools, and similar apparatus operating at 100 volts or more, must have a grounding pole and a grounding conductor in the portable cord.
- (c) Each nonmetallic mast and top mast must have a lightning ground conductor.

§120.372 Equipment and conductor grounding.

- (a) All metallic enclosures and frames of electrical equipment must be permanently grounded to the hull on a metallic vessel. On a nonmetallic vessel, the enclosures and frames of electrical equipment must be bonded together to a common ground by a normally non-current carrying conductor. Metallic cases of instruments and secondary windings of instrument transformers must be grounded.
- (b) On a nonmetallic vessel, where a ground plate is provided for radio equipment, it must be connected to the common ground.
- (c) Equipment grounding conductors must be sized in accordance with Section 250-95 of the NEC (NFPA 70), or other standard specified by the Commandant.
- (d) Each insulated grounding conductor of a cable must be identified by one of the following means.
- (1) A green braid or green insulation;
- (2) Stripping the insulation from the entire exposed length of the grounding conductor; or
- (3) Marking the exposed insulation of the grounding conductor with green tape or green adhesive labels.
- (e) Cable armor must not be used to ground electrical equipment of systems.

§ 120.376 Grounded distribution systems (Neutral grounded).

- (a) If a grounded distribution system is provided, there must be only one connection to ground, regardless of the number of power sources. This ground connection must be at the switchboard or at the common ground plate, which must be accessible.
- (b) Each propulsion, power, lighting, or distribution system having a neutral bus or conductor must have the neutral grounded.
- (c) The neutral or each grounded generation and distribution system must be grounded at the generator switchboard and have the ground connection accessible for checking insulation resistance of the generator to ground before the generator is connected to the bus, except the neutral of an emergency power generation system must be grounded with:

§ 120.378

- (1) No direct ground connection at the emergency switchboard;
- (2) The neutral bus permanently connected to the neutral bus on the main switchboard; and
- (3) No switch, circuit breaker, or fuse in the neutral conductor of the bus-tie feeder connecting the emergency switchboard to the main switchboard.
- (d) On a metallic vessel, a grounded alternating current system must be grounded to the hull. On a nonmetallic vessel, the neutral must be connected to the common ground, except that aluminum grounding conductors must not be used.

§ 120.378 Ungrounded systems.

Each ungrounded system must be provided with a suitably sensitive ground detection system, located at the respective switchboard, that provides continuous indication of circuit status to ground with a provision to momentarily remove the indicating device from the reference ground.

[CGD 85-080, 62 FR 51352, Sept. 30, 1997]

§ 120.380 Overcurrent protection.

- (a) Overcurrent protection must be provided for each ungrounded conductor for the purpose of opening the electric circuit if the current reaches a value that causes an excessive or dangerous temperature in the conductor or conductor insulation.
- (b) The grounded conductor of a circuit must not be disconnected by a switch or circuit breaker, unless the ungrounded conductors are simultaneously disconnected.
- (c) A conductor of a control, interlock, or indicator circuit, such as a conductor for an instrument, pilot light, ground detector light, or potential transformer, must be protected by an overcurrent device.
- (d) Conductors must be protected in accordance with their current carrying capacities. If the allowable current carrying capacity does not correspond to a standard device size, the next larger overcurrent device may be used provided it does not exceed 150 per cent of the conductor current carrying capacity.
- (e) Steering gear control system circuits must be protected against short circuit.

- (f) Each steering gear feeder circuit must be protected by a circuit breaker that meets the requirements of §58.25–55 in subchapter F of this chapter.
- (g) Each lighting branch circuit must be protected against overcurrent either by fuses or circuit breakers rated at not more than 30 amperes.
- (h) Overcurrent devices capable of carrying the starting current of the motor must be installed to protect motors, motor conductors, and control apparatus against:
- (1) Overcurrent due to short circuits or ground faults; and
- (2) Overload due to motor running overcurrent, in accordance with §111.70-1 in subchapter J of this chapter. A protective device integral with the motor, which is responsive to both motor current and temperature, may be used.
- (i) An emergency switch must be provided in the normally ungrounded main supply conductor from a battery. The switch must be accessible and located as close to the battery as practicable.
- (j) Disconnect means must be provided on the supply side of and adjacent to all fuses for the purpose of deenergizing the fuses for inspection and maintenance purposes.
- (k) If the disconnect means is not within sight of the equipment that the circuit supplies, means must be provided for locking the disconnect device in the open position.
- (l) Fuses must be of the cartridge type only and be listed by Underwriters Laboratories or another independent laboratory recognized by the Commandant.
- (m) Each circuit breaker must meet UL 489, "Molded-Case Circuit Breakers and Circuit Breaker Enclosures," or other standard specified by the Commandant, and be of the manually reset type designed for:
 - (1) Inverse time delay;
- (2) Instantaneous short circuit protection: and
- (3) Switching duty if the breaker is used as a switch.