§ 129.380

- (d) On each nonmetallic vessel with a ground plate provided for radio equipment, the plate must be connected to the common ground plate.
- (e) Each insulated grounding-conductor of a cable must be identified by one of the following means:
- (1) Wrapping of the cable with green braid or green insulation.
- (2) Stripping of the insulation from the entire exposed length of the grounding-conductor.
- (3) Marking of the exposed insulation of the grounding-conductor with green tape or green adhesive labels.
- (f) No vessel's hull may carry current as a conductor except for—
- (1) An impressed-current cathodic-protection system; or
- (2) A battery system to start an engine.
- (g) No cable armor may be used to ground electrical equipment or systems.
- (h) Each receptacle outlet and attachment plug, for a portable lamp, tool, or similar apparatus operating at 100 or more volts, must have a grounding-pole and a grounding-conductor in the portable cord.

§ 129.380 Overcurrent protection.

- (a) Overcurrent protection must be provided for each ungrounded conductor, to open the electric circuit if the current reaches a value that causes an excessive or dangerous temperature in the conductor or its insulation.
- (b) Each conductor of a control, interlock, or indicator circuit, such as a conductor for an instrument, pilot light, ground-detector light, or potential transformer, must be protected by an overcurrent device.
- (c) Each generator must be protected by an overcurrent device set at a value not exceeding 115 percent of the generator's full-load rating.
- (d) Circuits of control systems for steering gear must be protected against short circuit.
- (e) Each feeder circuit for steering gear must be protected by a circuit breaker that complies with §\$58.25–55(a) and (b) of this chapter.
- (f) Each branch circuit for lighting must be protected against overcurrent by either fuses or circuit breakers. Nei-

ther the fuses nor the circuit breakers may be rated at more than 30 amperes.

- (g) Each conductor must be protected in accordance with its current-carrying capacity. If the allowable current-carrying capacity does not correspond to a standard size of device, the next larger overcurrent device may be used, provided it is less than 150 percent of the conductor's current-carrying capacity.
- (h) An overcurrent device must be installed to protect each motor conductor and control apparatus against overcurrent due to short circuit or ground fault. Each overcurrent device must be capable of carrying the starting current of the motor.
- (i) An emergency switch must be provided in each normally ungrounded main supply conductor from a battery. The switch must be accessible from the battery and located as close as practicable to it.
- (j) No grounded conductor of a circuit may be disconnected by a switch or circuit breaker unless the ungrounded conductors are all simultaneously disconnected.
- (k) A means of disconnect must be provided on the supply side of and adjacent to each fuse, to de-energize the fuse for inspection and maintenance.
- (1) A way for locking the means of disconnect open must be provided unless the means of disconnect for a fused circuit is within sight of the equipment that the circuit supplies.
- (m) Each fuse must be of the cartridge type and be listed by Underwriters Laboratories (UL) or another independent laboratory recognized by the Commandant.
- (n) Each circuit breaker must meet UL 489 and be of the manually-reset type designed for—
 - (1) Inverse delay;
- (2) Instantaneous short-circuit protection; and
- (3) Switching duty if the breaker is used as a switch.
- (o) Each circuit breaker must indicate whether it is open or closed.

§ 129.390 Shore power.

Each vessel that has an electrical system operating at more than 50 volts and has provisions for receiving shore power must meet the requirements of this section:

- (a) A shore-power-connection box or receptacle must be permanently installed at a convenient location.
- (b) A cable connecting the shorepower-connection box or receptacle to the switchboard or main distribution panel must be permanently installed.
- (c) A circuit breaker must be provided at the switchboard or main distribution panel for the shore-power connection.
- (d) The circuit breaker, required by paragraph (c) of this section, must be interlocked with the feeder circuit breakers for the vessel's power sources to preclude the vessel's power sources and shore power from energizing the vessel's switchboard simultaneously, except in cases where system devices permit safe momentary paralleling of OSV power with shore power.

§ 129.395 Radio installations.

A separate circuit, with overcurrent protection at the switchboard, must be provided for at least one radio installation. Additional radios, if installed, may be powered from a local lighting power source, such as the pilothouse lighting panel, provided each radio power source has a separate overcurrent protection device.

Subpart D—Lighting Systems

§129.410 Lighting fixtures.

- (a) Each globe, lens, or diffuser of a lighting fixture must have a high-strength guard or be made of high-strength material, except in accommodations, the pilothouse, the galley, or similar locations where the fixture is not subject to damage.
- (b) No lighting fixture may be used as a connection box for a circuit other than the branch circuit supplying the fixture.
- (c) Each lighting fixture must be installed as follows:
- (1) Each lighting fixture and lampholder must be fixed. No fixture may be supported by the screw shell of a lampholder.
- (2) Each pendant-type lighting fixture must be suspended by and supplied through a threaded rigid-conduit stem.
- (3) Each tablelamp, desklamp, floorlamp, or similar equipment must be so secured in place that it cannot be

displaced by the roll, pitch, or heave or by the vibration of the vessel.

(d) Each lighting fixture in an electrical system operating at more than 50 volts must comply with UL 595, "Marine Type Electric Lighting Fixtures." A lighting fixture in an accommodation space, radio room, galley, or similar interior space may comply with UL 57. "Electric Lighting Fixtures," UL 1570, "Fluorescent Lighting Fixtures," UL 1571, "Incandescent Lighting Fixtures," UL 1572, "High Intensity Discharge Lighting Fixtures," UL 1573, "Stage and Studio Lighting Units," or UL 1574, "Track Lighting Systems," as long as the general marine requirements of UL 595 are satisfied.

§ 129.420 Branch circuits for lighting on OSVs of 100 or more gross tons.

On each vessel of 100 or more gross tons, each branch circuit for lighting must comply with §111.75-5 of this chapter, except that—

- (a) Appliance loads, electric-heater loads, and isolated small-motor loads may be connected to a lighting-distribution panelboard; and
- (b) Branch circuits, other than for lighting, connected to the lighting-distribution panelboard permitted by paragraph (a) of this section may have fuses or circuit breakers rated at more than 30 amperes.

$\S 129.430$ Navigational lighting.

- (a) Each vessel of less than 100 gross tons and less than 19.8 meters (65 feet) in length must have navigational lighting in compliance with the applicable navigation rules.
- (b) Each vessel of 100 or more gross tons, or 19.8 meters (65 feet) or more in length, must have navigational lighting in compliance with the applicable navigation rules and with §111.75–17(d) of this chapter.

§ 129.440 Emergency lighting.

- (a) A vessel of less than 100 gross tons must have adequate emergency lighting fitted along the line of escape to the main deck from accommodations and working (machinery) spaces below the main deck.
- (b) The emergency lighting required by paragraph (a) of this section must