

# DEFENDER CLASS OPERATOR'S HANDBOOK

U.S. Department of  
Homeland Security  
United States  
Coast Guard



COMDTINST M16114.37B



DEFENDER "A" CLASS (RB-HS)  
AND  
DEFENDER "B" CLASS (RB-S)







Commandant  
United States Coast Guard

2100 Second Street SW  
Washington, DC 20593-0001  
Staff Symbol: G-RCB  
Phone: (202) 267-2193  
Fax: (202) 267-4593

COMDTINST M16114.37B  
JUN 27 2006

COMMANDANT INSTRUCTION M16114.37B

Subj: DEFENDER CLASS OPERATOR'S HANDBOOK

1. PURPOSE. This Manual provides technical orientation, performance characteristics, basic operating procedures, and standard boat outfitting for Defender Class boats. The Defender Class is comprised of the Defender "A" Class (formerly known as Response Boat-Homeland Security or RB-HS), and the Defender "B" Class (formerly known as the Response Boat-Small or RB-S).
2. ACTION. Area and district commanders, commanders of maintenance and logistics commands, commanding officers of headquarters units, assistant commandants for directorates, Judge Advocate General, and special staff offices at Headquarters shall ensure adherence to the contents of this Manual at all units which operate and/or maintain Defender Class boats. To ensure standardization, there is no command requirement with regard to the type or location of equipment carried except as noted. All design or structural alterations are prohibited unless specifically authorized in accordance with this Manual. Internet release authorized.
3. DIRECTIVES EFFECTED. Defender Class Operator's Handbook, COMDTINST M16114.37A is cancelled.
4. DISCUSSION. This Manual contains the information necessary to safely and efficiently operate Defender Class boats. The operational capabilities, limitations, and emergency procedures are clearly stipulated. The fittings, outfit list, and physical characteristics of the boats are pictured and described in detail. This Manual is directive in nature and applies to all Defender Class crews, and operational and supervisory commands.

DISTRIBUTION - SDL No. 145

	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o	p	q	r	s	t	u	v	w	x	y	z
A																										
B		8	10		*			2	5					50												
C	2	2						20		2				5	10									1	5	
D			5					10					*									*				
E			1					1										5	5	2						
F																										
G																										
H																										

NON-STANDARD DISTRIBUTION: Be: Academy; LDC (2); OIC/XPO (2); Dm: PACAREA TRATEAM (5); Dv: RB-S Project Resident Office (5)


COMDTINST M16114.37B

JUN 27 2006

5. SUMMARY OF CHANGES. This revision provides new policies and procedures, makes modification and clarification to other existing policies, and makes several minor clerical changes. The majority of these changes originated from feedback received from the field. In addition to several illustrations that were replaced throughout the Manual, the following major areas of change were made:
- a. Chapter 1: RB-HS and RB-S are now referred to as “Defender A Class” and “Defender B Class” boats (respectively) throughout the Manual.
  - b. Chapter 2: Sections 2.A.4.a. and 2.A.4.b. provide corrected physical and operational characteristics.
  - c. Chapter 3:
    - (1) Section 3.B. provides guidance on preventing galvanic corrosion of the aluminum hull.
    - (2) Section 3.C. provides health precautions to take when making repairs to the collar system.
    - (3) Sections 3.F. and 3.G. provide guidance on the use and reliability of electronic navigation systems and magnetic compass.
    - (4) Section 3.K.1. allows the use of Kerosene as an alternate fuel for the cabin heater when diesel fuel jelling occurs in cold temperatures.
    - (5) Section 3.L. is updated with new trailering hardware requirements and procedures. Section 3.L. allows MSSTs to use a pintle hook and ring in lieu of the ball and coupler assembly.
    - (6) Section 3.M. denotes authorized machine gun stands for use aboard Defender Class boats and provides guidelines for setting machine gun train and elevation stops.
  - d. Chapter 4: Section 4.E.2. provides Commanding Officers and Officers In Charge guidance on establishing seat belt and helmet wearing policy.
  - e. Chapter 5: Tables 5-1 and 5-2 provide corrected speed for 4500 RPM.
  - f. Chapter 6:
    - (1) Sections 6.D. and 6.H. provide recommended precautions when going alongside other vessels.
    - (2) Section 6.E.1. provides general boat handling guidance with regard to the importance of proper engine trim.
    - (3) Section 6.F. establishes restrictions on conducting helicopter hoisting for training purposes.
  - g. Chapter 7: Section 7.A. provides guidance on egress from a capsized Defender Class boat.
  - h. Appendices:
    - (1) Appendix A contains several updated boat outfit requirements, including the addition of an anchor line.

JUN 27 2006

- (2) Appendix B lists all approved engineering and configuration changes approved by the Configuration Control Board.
  - (3) Appendix C provides an updated material inspection checklist.
  - (4) Appendices D and E contain updated Disabling Casualty and Restrictive and Major Discrepancies.
  - (5) Appendix F contains procedures for conducting underway power trials.
6. PROCEDURE. District, operational, and unit commanders for all units with Defender Class boats shall ensure the procedures and limitations detailed within this Manual are followed. Boat crews shall become familiar with the changes made within this Manual, but are not required to recertify solely based on changes within this revision. Forward any comments, corrections, recommendations, and questions regarding this handbook to the Defender Class Facility Manager in accordance with Section 1.C. of this Manual. Design and structural change requests shall be submitted as outlined in the Naval Engineering Manual, COMDTINST M9000.6 (series).
7. ENVIRONMENTAL ASPECT AND IMPACT CONSIDERATIONS. Environmental considerations were examined in the development of this directive and have been determined to be not applicable.
8. FORMS AVAILABILITY. None.



WAYNE E. JUSTICE  
Acting Assistant Commandant for Response









## Defender Class Operator's Handbook



# Table of Contents

---

<b>CHAPTER 1 INTRODUCTION.....</b>	<b>1-1</b>
Section A.    Warnings, Cautions, and Notes .....	1-3
A.1. Warning .....	1-3
A.2. Caution.....	1-3
A.3. Note .....	1-3
Section B.    Facility Manager.....	1-5
Section C.    Changes .....	1-7
C.1. Engineering Changes .....	1-7
Section D.    Action .....	1-9
D.1. Configuration Control.....	1-9
<b>CHAPTER 2 BOAT CHARACTERISTICS.....</b>	<b>2-1</b>
Section A.    General Description.....	2-3
A.1. Design.....	2-3
A.2. Manufacturer.....	2-3
A.3. Missions.....	2-4
A.4. Boat Specifications .....	2-4
A.5. Hull Reference Points .....	2-6
Section B.    Compartments.....	2-9
B.1. Anchor/ Ammunition Locker.....	2-9
B.2. Cabin.....	2-9
B.3. Cuddy Cabin .....	2-18
B.4. Port and Starboard Lockers.....	2-18
B.5. Cabin Dewatering Pump .....	2-19
Section C.    Main Deck Equipment.....	2-21
C.1. Bow Eye.....	2-21
C.2. Standard Cleats .....	2-22
C.3. Tow Bitts.....	2-22
C.4. Handrails.....	2-24
C.5. Transom Eyes.....	2-25
C.6. Non-Skid.....	2-25
C.7. Deck Lighting .....	2-26
C.8. Lifting Eyes.....	2-28
C.9. Navigation Lights.....	2-29
C.10. Ring Buoy and Strobe Light.....	2-30
C.11. Towline Reel.....	2-30
Section D.    Main Deck Stowage.....	2-33
D.1. Anchor/ Ammunition Locker.....	2-33
D.2. Port Aft Deck Locker.....	2-33
D.3. Starboard Aft Deck Locker.....	2-34
D.4. Pump Stowage .....	2-34
<b>CHAPTER 3 BOAT SYSTEMS.....</b>	<b>3-1</b>
Section A.    Propulsion System .....	3-3
A.1. Engine.....	3-4
A.2. Lubrication Systems .....	3-6
A.3. Engine Cooling System .....	3-6
A.4. Engine Fuel System .....	3-7
A.5. Ignition System.....	3-8
A.6. Starter .....	3-8
A.7. Engine Controls .....	3-9
A.8. Engine Key Switch Panels .....	3-10



A.9. Power Tilt Switch .....	3-12
A.10. Manual Relief Valve.....	3-13
A.11. Tilt Lock Lever.....	3-14
A.12. Sacrificial Anodes.....	3-14
A.13. Engine Exhaust Port.....	3-14
A.14. Fuse Panels .....	3-15
A.15. Propellers .....	3-16
A.16. Flo-Torq Assembly .....	3-16
<b>Section B. Hull System .....</b>	<b>3-17</b>
B.1. Draft.....	3-17
B.2. Sound Insulation .....	3-17
B.3. Performance Fins .....	3-17
B.4. Lifting Strakes.....	3-17
B.5. Beaching Plate .....	3-17
B.6. Inspection Access.....	3-19
B.7. Diagonal Stiffeners .....	3-19
B.8. Rig Tubes.....	3-19
B.9. Hull Access Plug.....	3-19
B.10. Deck Drains and Scuppers .....	3-21
<b>Section C. Collar System .....</b>	<b>3-25</b>
C.1. Attachment.....	3-25
C.2. Repair and Removal.....	3-27
<b>Section D. Steering System .....</b>	<b>3-29</b>
D.1. Hydraulic Steering Cylinder .....	3-29
D.2. Tie Bar Assembly .....	3-29
D.3. Helm Pump Assembly .....	3-29
D.4. Hoses .....	3-32
<b>Section E. Propulsion Fuel System.....</b>	<b>3-33</b>
E.1. Fuel Tank .....	3-33
E.2. Fuel Tank Vent (Defender A Class).....	3-33
E.3. Fuel Tank Vent (Defender B Class).....	3-34
E.4. Fuel Tank Fill (Gasoline) .....	3-34
E.5. Fuel Filters/Water Separators .....	3-36
E.6. Primer Bulbs.....	3-37
E.7. Fuel Tank Level Sensor.....	3-38
<b>Section F. Communications/Navigation System (Defender A Class).....</b>	<b>3-39</b>
F.1. Motorola VHF-FM Astro Spectra W9 Transceiver and Control Head .....	3-39
F.2. Raymarine 215 VHF Transceiver .....	3-40
F.3. Raymarine 430 Loudhailer .....	3-41
F.4. Raytheon RL80CRC Radar .....	3-41
F.5. Depth Sounder Display.....	3-42
F.6. ST60 Digital Compass.....	3-43
F.7. Magnetic Compass .....	3-44
F.8. Antennas.....	3-45
<b>Section G. Communications/Navigation System (Defender B Class).....</b>	<b>3-47</b>
G.1. Raymarine 430 Loudhailer .....	3-47
G.2. Motorola VHF-FM Astro Spectra W9 Transceiver and Control Head.....	3-48
G.3. Raymarine 215 VHF Transceiver .....	3-49
G.4. Furuno 1933C/NT Radar Display .....	3-50
G.5. Radome Antenna .....	3-51
G.6. WAAS/DGPS Receiver/ Antenna.....	3-51
G.7. RD-30 Multi-Display .....	3-52
G.8. GP-37 WAAS/DGPS Receiver and Navigator .....	3-52
G.9. Magnetic Compass.....	3-53
G.10. PG-1000 Heading Sensor.....	3-54
G.11. 235DT-SSE Depth and Temperature Sensor.....	3-55
G.12. Antennas .....	3-56



Section H. Electrical System .....	3-57
H.1. Alternators .....	3-57
H.2. Batteries .....	3-58
H.3. Battery Switches .....	3-60
H.4. 12-VDC Distribution Panels .....	3-62
H.5. Ground .....	3-63
Section I. Seating System (Defender A Class).....	3-65
I.1. Seats .....	3-65
Section J. Seating System (Defender B Class).....	3-67
J.1. Forward Cabin Seats .....	3-67
J.2. Aft Cabin Seats .....	3-68
Section K. Heating System.....	3-71
K.1. Heater .....	3-71
K.2. 30-Amp Breaker .....	3-71
K.3. Thermostat .....	3-72
K.4. Diesel Fuel Tank.....	3-73
K.5. Window Defrosters .....	3-75
Section L. Trailering .....	3-77
L.1. General .....	3-77
L.2. Tow Vehicle .....	3-78
L.3. Hitch.....	3-79
L.4. Ball Mount and Ball .....	3-79
L.5. Trailer Coupler, Safety Chains and Hydraulic Brake Actuator .....	3-80
L.6. Pintle Hook and Lunette Eye Configuration for MSSTs .....	3-81
L.7. Trailer Construction and Equipment .....	3-81
L.8. Hooking up the Trailer .....	3-82
L.9. Securing the Boat to the Trailer.....	3-83
L.10. Towing Precautions.....	3-86
L.11. Trailering Checklist.....	3-87
L.12. Launching the Boat .....	3-89
L.13. Recovering the Boat.....	3-90
Section M. Weapons Mounting/Stowage.....	3-91
M.1. Pedestal Stands.....	3-91
M.2. Machine Gun Elevation and Train Stop Limits .....	3-91
M.3. Ammunition Stowage.....	3-91
M.4. Weapon Locks/Mounts .....	3-93
Section N. Hull Exterior Lighting (Defender A Class) .....	3-95
N.1. Searchlight.....	3-95
N.2. Light Switch Panel.....	3-96
Section O. Hull Exterior Lighting (Defender B Class).....	3-99
O.1. Searchlight .....	3-99
O.2. Light Switch Panel.....	3-100
O.3. Towlight Mast.....	3-104
Section P. Ancillary Systems and Furnishings .....	3-107
P.1. Windshield Wipers and Washer .....	3-107
P.2. Cabin Fans.....	3-107
P.3. Fire Extinguisher(s).....	3-109
P.4. First Aid Kit .....	3-109
P.5. Cabin Dome Lights.....	3-110
P.6. Horn.....	3-111
P.7. Miscellaneous Stowage .....	3-111
P.8. Emergency Position Indicating Radio Beacon.....	3-111
P.9. Deck Matting.....	3-112
<b>CHAPTER 4 CREW REQUIREMENTS.....</b>	<b>4-1</b>
Section A. Minimum Crew .....	4-3
A.1. Certified Crew .....	4-3



Section B. Coxswain .....	4-5
B.1. Authority and Responsibility .....	4-5
B.2. Relief of Responsibility .....	4-5
Section C. Crew Members .....	4-7
C.1. Certified Crew Member .....	4-7
C.2. Additional Crewmembers .....	4-7
Section D. Passengers.....	4-9
Section E. Safety Equipment .....	4-11
E.1. Personal Protective Equipment.....	4-11
E.2. Seat Belts and Helmets.....	4-11
<b>CHAPTER 5 OPERATIONAL GUIDELINES .....</b>	<b>5-1</b>
Section A. Operating Parameters .....	5-3
A.1. Disabling Casualties .....	5-3
A.2. Restrictive Discrepancies.....	5-3
A.3. Major Discrepancies .....	5-4
A.4. Minor Discrepancies .....	5-4
A.5. Responsibilities.....	5-4
A.6. Environmental Limits .....	5-6
Section B. Performance Data .....	5-7
B.1. Fuel Consumption.....	5-7
B.2. Seakeeping.....	5-8
B.3. Stability.....	5-9
B.4. Speed.....	5-9
Section C. Performance Monitoring.....	5-10
C.1. Performance Monitoring .....	5-10
C.2. Control Panel Indicators.....	5-10
C.3. Helm Dash Panel.....	5-12
C.4. Voltmeters.....	5-13
<b>CHAPTER 6 MISSION PERFORMANCE .....</b>	<b>6-1</b>
Section A. Boat Davit Operations .....	6-3
Section B. Starting Procedures.....	6-5
B.1. Pre-Start .....	6-5
B.2. Engine Starting.....	6-6
B.3. Energizing Equipment.....	6-6
Section C. Underway .....	6-7
C.1. Personal Protective Gear .....	6-7
C.2. Communications .....	6-7
Section D. Going Alongside Boats and Vessels of Interest.....	6-9
Section E. Handling Characteristics.....	6-13
General Boat Handling .....	6-14
E.1. Characteristics .....	6-14
Turning and Pivoting .....	6-15
E.2. Characteristics .....	6-15
Head Seas .....	6-16
E.3. Buoyancy .....	6-16
E.4. Over-Acceleration .....	6-16
Beam Seas, Following Seas, and Quartering the Seas .....	6-17
E.5. Beam Seas .....	6-17
E.6. Following Seas.....	6-17
E.7. Quartering the Seas .....	6-17
Effects of Wind.....	6-18
E.8. Maneuverability .....	6-18
Station Keeping .....	6-19
E.9. Stern-To .....	6-19
Section F. Operating with Helicopters.....	6-20
Section G. Anchoring.....	6-21





Section H. Towing.....	6-22
H.1. Angular Momentum.....	6-22
H.2. Alongside Towing.....	6-22
Section I. Securing Procedures.....	6-23
Section J. Loading and Unloading Boat for Air Transport.....	6-24
J.1. Prior to Loading.....	6-24
J.2. Loading and Unloading.....	6-26
<b>CHAPTER 7 EMERGENCY PROCEDURES.....</b>	<b>7-1</b>
Section A. Capsizing.....	7-3
A.1. Introduction.....	7-3
A.2. Prevention.....	7-3
A.3. Potential Causes.....	7-3
A.4. Precautions.....	7-4
A.5. Egress Hazards for Defender Class Boat Crews.....	7-4
A.6. Egress Procedures.....	7-5
A.7. Post Egress Procedures.....	7-8
Section B. Steering Casualty.....	7-9
B.1. Symptom(s).....	7-9
B.2. Actions.....	7-9
Section C. Loss of Control of Engine RPM.....	7-11
C.1. Symptom(s).....	7-11
C.2. Actions.....	7-11
Section D. Loss of Fuel Pressure.....	7-13
D.1. Symptom(s).....	7-13
D.2. Actions.....	7-13
Section E. Loss of Lube Oil Pressure.....	7-15
E.1. Symptom(s).....	7-15
E.2. Actions.....	7-15
Section F. Overheated Engine.....	7-17
F.1. Symptom(s).....	7-17
F.2. Actions.....	7-17
Section G. Damage to Collar.....	7-19
G.1. Symptom(s).....	7-19
G.2. Actions.....	7-19
Section H. No Power/Insufficient Power to Communications/Navigation Equipment.....	7-21
H.1. Symptom(s).....	7-21
H.2. Actions.....	7-21
<b>APPENDIX A. OUTFIT LIST AND STOWAGE PLAN.....</b>	<b>A-1</b>
<b>APPENDIX B. ENGINEERING AND CONFIGURATION CHANGES.....</b>	<b>B-1</b>
<b>APPENDIX C. MATERIAL INSPECTION CHECKLIST.....</b>	<b>C-1</b>
<b>APPENDIX D. DISABLING CASUALTIES.....</b>	<b>D-1</b>
<b>APPENDIX E. RESTRICTIVE AND MAJOR DISCREPANCIES.....</b>	<b>E-1</b>
<b>APPENDIX F. DEFENDER CLASS UNDERWAY TRIAL.....</b>	<b>E-1</b>
<b>APPENDIX G. LIST OF ACRONYMS.....</b>	<b>G-1</b>
<b>INDEX.....</b>	<b>INDEX – 1</b>



## List of Figures

Figure 2-1 Defender Class Boat Hull Construction.....	2-7
Figure 2-2 Outboard Profile (Defender A Class).....	2-10
Figure 2-3 Outboard Profile (Defender B Class).....	2-11
Figure 2-4 Inboard Profile.....	2-12
Figure 2-5 Anchor/Ammunition Locker.....	2-13
Figure 2-6 Cabin (Defender A Class).....	2-13
Figure 2-7 Forward Cabin Window with Windshield Wiper.....	2-14
Figure 2-8 Sliding Cabin Door.....	2-15
Figure 2-9 Aft Cabin Windows and Weather-Tight Door (Defender A Class).....	2-16
Figure 2-10 Aft Cabin Windows and Weather-Tight Door (Defender B Class).....	2-16
Figure 2-11 Spotter Windows (Defender A Class).....	2-17
Figure 2-12 Cuddy Cabin.....	2-18
Figure 2-13 Electric Cabin Dewatering Pump (Defender B Class).....	2-19
Figure 2-14 Bow Eye.....	2-21
Figure 2-15 Standard Cleat.....	2-22
Figure 2-16 Aft Tow Bitt (Defender A Class).....	2-23
Figure 2-17 Aft Tow Bitt (Defender B Class).....	2-23
Figure 2-18 Handrails.....	2-24
Figure 2-19 Transom Eye.....	2-25
Figure 2-20 Deck Lighting.....	2-26
Figure 2-21 Foredeck LEDs (Defender B Class).....	2-27
Figure 2-22 Aft Deck LEDs (Defender B Class).....	2-27
Figure 2-23 Lifting Eye.....	2-28
Figure 2-24 Navigation Light (Port).....	2-29
Figure 2-25 Ring Buoy and Strobe Light.....	2-30
Figure 2-26 Towline Reel (Defender A Class).....	2-31
Figure 2-27 Towline Reel (Defender B Class).....	2-31
Figure 2-28 Tow Reel Brake (Defender B Class).....	2-32
Figure 2-29 Port Aft Deck Locker (Defender A Class).....	2-33
Figure 2-30 Port Aft Deck Locker (Defender B Class).....	2-34
Figure 2-31 Starboard Aft Deck Locker (Defender A Class).....	2-35
Figure 2-32 Starboard Aft Deck Locker (Defender B Class).....	2-35
Figure 2-33 Pump Container Stowage.....	2-36
Figure 2-34 Pump Container Stowage.....	2-36
Figure 3-1 Outboard Engine.....	3-3
Figure 3-2 Outboard Engine (Starboard Side).....	3-4
Figure 3-3 Outboard Engine (Port Side).....	3-5
Figure 3-4 Cooling System Indicator.....	3-6
Figure 3-5 Fuel Priming Bulb.....	3-7
Figure 3-6 Water Separator.....	3-8
Figure 3-7 Gearshift and Throttle Control.....	3-9
Figure 3-8 Key Switch Panels (Defender A Class).....	3-10
Figure 3-9 Key Switch Panel (Defender B Class).....	3-11
Figure 3-10 Power Tilt Switch.....	3-12
Figure 3-11 Manual Relief Valve.....	3-13
Figure 3-12 Tilt Lock Lever.....	3-14
Figure 3-13 Fuse Panels.....	3-15
Figure 3-14 Flo-Torq II System.....	3-16



Figure 3-15 Performance Fin and Lifting Strakes ..... 3-18

Figure 3-16 Beaching Plate ..... 3-18

Figure 3-17 Hull Construction Top View ..... 3-20

Figure 3-18 Forward Cabin Deck Drain ..... 3-21

Figure 3-19 Forward Cabin Deck Scupper ..... 3-22

Figure 3-20 Aft Weather Deck Drain ..... 3-22

Figure 3-21 Aft Weather Deck Scupper/Water Sock ..... 3-23

Figure 3-22 Aft Locker Drain Plug ..... 3-24

Figure 3-23 Side Collar Attaching Bolt ..... 3-25

Figure 3-24 Collar (Bow Section) ..... 3-26

Figure 3-25 Bow Cover, Defender B Class ..... 3-26

Figure 3-26 Steering System ..... 3-30

Figure 3-27 Steering Cylinder and Tie Bar ..... 3-31

Figure 3-28 Helm and Helm Pump (Defender A Class) ..... 3-31

Figure 3-29 Helm, Helm Pump, and Vent/Fill Cap (Defender B Class) ..... 3-32

Figure 3-30 Fuel System (Defender A Class) ..... 3-33

Figure 3-31 Fuel Tank (Gasoline) Vent System (Defender B Class) ..... 3-34

Figure 3-32 Fuel Tank Fill (Gasoline) (Defender A Class) ..... 3-35

Figure 3-33 Fuel Tank Fill (Gasoline) (Defender B Class) ..... 3-35

Figure 3-34 Fuel Filters/Water Separators ..... 3-36

Figure 3-35 Primer Bulbs ..... 3-37

Figure 3-36 Fuel Tank Level Sensor ..... 3-38

Figure 3-37 Motorola VHF-FM Astro Spectra W9 Control Head ..... 3-39

Figure 3-38 Raymarine 215 VHF Transceiver ..... 3-40

Figure 3-39 Loudhailer ..... 3-41

Figure 3-40 Radar/GPS ..... 3-42

Figure 3-41 Depth Sounder and Digital Compass ..... 3-43

Figure 3-42 Standby/Magnetic Compass ..... 3-45

Figure 3-43 Antennas ..... 3-45

Figure 3-44 Raymarine 430 Loudhailer and Motorola VHF-FM Astro Spectra W9 Control Head ..... 3-48

Figure 3-45 Raymarine 215 VHF Transceiver ..... 3-49

Figure 3-46 Radar Display ..... 3-50

Figure 3-47 Radar Antenna and WAAS/DGPS Receiver/Antenna ..... 3-51

Figure 3-48 Coxswain Console ..... 3-54

Figure 3-49 Heading Sensor ..... 3-54

Figure 3-50 Depth and Temperature Sensor ..... 3-55

Figure 3-51 Antennas (Defender B Class) ..... 3-56

Figure 3-52 Voltmeters ..... 3-57

Figure 3-53 Batteries (Defender A Class) ..... 3-58

Figure 3-54 Batteries (Defender B Class) ..... 3-59

Figure 3-55 Battery Box Vent (Defender A Class) ..... 3-59

Figure 3-56 Forward Battery Vent (Defender B Class) ..... 3-60

Figure 3-57 12-VDC Main Power Panel ..... 3-61

Figure 3-58 12-VDC Distribution Panels ..... 3-63

Figure 3-59 Forward Cabin Seat (Defender A Class) ..... 3-66

Figure 3-60 Forward Cabin Seats (Defender B Class) ..... 3-67

Figure 3-61 Aft Cabin Seat (Defender B Class) ..... 3-68

Figure 3-62 Rear Seat Back Tension Adjustment ..... 3-69

Figure 3-63 Heater Intake and Exhaust ..... 3-71

Figure 3-64 Heater Thermostat ..... 3-72

Figure 3-65 Heater Diesel Fuel Tank (Defender A Class) ..... 3-73

Figure 3-66 Heater Diesel Fuel Tank (Defender B Class) ..... 3-74

Figure 3-67 Window Defroster ..... 3-75

Figure 3-68 Boat Trailer ..... 3-77



Figure 3-69 Defender A Class and Trailer..... 3-78

Figure 3-70 Defender B Class and Trailer..... 3-78

Figure 3-71 Hitch, Ball Mount, and Ball Assembly ..... 3-79

Figure 3-72 Trailer Coupling Assembly..... 3-80

Figure 3-73 Pintle Hook ..... 3-81

Figure 3-74 Trailer Hook-Up..... 3-83

Figure 3-75 Trailer to Transom Tie Down ..... 3-84

Figure 3-76 Boat Trailer, Bow Tie Down..... 3-84

Figure 3-77 Boat Trailer, Forward Tie Down..... 3-85

Figure 3-78 Spacing Between Bow and Bow Stops ..... 3-85

Figure 3-79 Ammunition Stowage ..... 3-92

Figure 3-80 Weapon Lock/Mount (Defender A Class) ..... 3-93

Figure 3-81 Weapon Locks/Mounts (Defender B Class)..... 3-93

Figure 3-82 Searchlight (Defender A Class) ..... 3-95

Figure 3-83 Searchlight Control (Defender A Class) ..... 3-96

Figure 3-84 Light Switch Panel (Defender A Class) ..... 3-97

Figure 3-85 Navigation Light (Defender A Class) ..... 3-97

Figure 3-86 Floodlights (Defender A Class) ..... 3-98

Figure 3-87 Exterior (Deck Edge) Light (Defender A Class)..... 3-98

Figure 3-88 Cabin Roof Lights (Defender B Class) ..... 3-99

Figure 3-89 Searchlight Control (Defender B Class) ..... 3-100

Figure 3-90 Light Switch Panel (Defender B Class) ..... 3-101

Figure 3-91 Port Navigation Light (Defender B Class)..... 3-102

Figure 3-92 Starboard Navigation Light and Deck Edge Lights (Defender B Class)..... 3-103

Figure 3-93 Floodlights and Law Enforcement Lights (Defender B Class) ..... 3-103

Figure 3-94 Towlight Mast Stowed (Defender B Class) ..... 3-104

Figure 3-95 Towlight Mast..... 3-105

Figure 3-96 Windshield Wiper Motor and Cabin Fan ..... 3-108

Figure 3-97 Windshield Wiper Switches..... 3-108

Figure 3-98 B-1 Type Fire Extinguisher..... 3-109

Figure 3-99 Cabin Dome Light..... 3-110

Figure 3-100 Horn ..... 3-111

Figure 3-101 EPIRB ..... 3-112

Figure 5-1 Control Panel Indicators (Defender A Class)..... 5-10

Figure 5-2 Control Panel Indicators (Defender B Class)..... 5-11

Figure 5-3 Helm Dash Panel (Defender A Class)..... 5-12

Figure 5-4 Helm Dash Panel (Defender B Class)..... 5-13

Figure 5-5 Voltmeters..... 5-13

Figure 6-1 Searchlight Removal..... 6-25

Figure 6-2 C-130 Loading Ramp and Cargo Bay ..... 6-27

Figure 6-3 Loading Boat (Bow First) ..... 6-28

Figure 6-4 Loading Boat (Stern First) ..... 6-31

Figure 7-1 Primary and Secondary Egress Routes ..... 7-7

## List of Tables

---

Table 5-1 Fuel Consumption Information (Defender A Class) ..... 5-7

Table 5-2 Fuel Consumption Information (Defender B Class)..... 5-8



# Chapter 1 Introduction

**Introduction**

This handbook contains specific information necessary for the safe and efficient operation of Defender Class boats, which includes the 25' Defender A Class (formerly known as Response Boat—Homeland Security (RB-HS)), and Defender B Class (formerly known as Response Boat—Small (RB-S)). This handbook defines the operational capabilities, limitations, and emergency procedures, describes the fittings, outfit lists, and physical characteristics of each boat.

**In this Chapter**

This chapter contains the following sections:

Section	Topic	See Page
A	Warnings, Cautions, and Notes	1-3
B	Facility Manager	1-5
C	Changes	1-7
D	Action	1-9








## Section A. Warnings, Cautions, and Notes

---

**Introduction** The following definitions apply to Warnings, Cautions, and Notes found throughout the handbook.


---

**A.1. Warning** **WARNING**  Operating procedures or techniques that must be carefully followed to avoid personal injury or loss of life.

---

**A.2. Caution** **CAUTION !** Operating procedures or techniques that must be carefully followed to avoid equipment damage.

---

**A.3. Note** **NOTE**  An operating procedure or technique essential to emphasize.

---





## Section B. Facility Manager

---

### Introduction

Commandant (G-RCB-2) is the facility manager for Defender Class boats. The Defender Class is comprised of standard boats as defined in the *Boat Management Manual*, COMDTINST M16114.4 (series); and the *Naval Engineering Manual*, COMDTINST M9000.6 (series).

Commandant (G-AWP) is the project manager for Defender Class boats.

---







## Section C. Changes

---

### **Introduction**

Commandant (G-RCB-2) promulgates this handbook and its changes. Submit recommendations for changes to Commandant (G-RCB-2) via standard memo or electronic mail. For more information, contact Commandant (G-RCB-2), Defender Class Facility Manager.

The address for Commandant (G-RCB-2) is:

Commandant (G-RCB-2)  
U.S. Coast Guard Headquarters  
2100 Second Street, SW  
Washington, DC 20593-0001

Attn: Defender Class Facility Manager

---

### **C.1. Engineering Changes**

All engineering changes (ECs) issued since the Defender A Class and Defender B Class have been in service are provided in *Appendix B*. ECs issued after the date of this revision supersede information in this handbook where applicable.

---






## Section D. Action


---

**Introduction** Operating and supervisory commands and boat crews will comply with the procedures and limitations specified in this publication and any duly issued changes.

---

**D.1. Configuration Control** Configuration control for the Defender Class is critical for standardization of equipment and safety of operations. Configuration control authority for the Defender Class boat resides with Commandant (G-AWP) while the Defender Class boat is in the acquisition phase, and will be transferred to Commandant (G-RCB) upon sustainment.

**NOTE**  To maintain fleet-wide standardization, unit commanders shall not change or vary the type or location of equipment carried except where noted. Design or structural alterations are prohibited unless specifically promulgated in accordance with the Naval Engineering Manual, COMDTINST M9000.6 (series).

**NOTE**  Prototype testing of Defender Class configuration changes may only be carried out with the specific authorization of Commandant (G-AWP) during acquisitions or Commandant (G-RCB) during sustainment.

---





## Chapter 2 Boat Characteristics

---

**Introduction** This chapter describes standard features for Defender Class boats. The general location of the major hull and system components is presented in this chapter. Detailed information about hull and system components is provided in *Chapter 3, Boat Systems*.

**NOTE** All illustrations and photographs in this operator's handbook are for familiarization only. The location of hull fittings and system components in these illustrations may not accurately reflect proper placement and installation on all hulls.

**NOTE** Where differences exist between the Defender A Class and the Defender B Class, they are specifically identified in the text by hull designation.

---

**In this Chapter** This chapter contains the following sections:

Section	Topic	See Page
A	General Description	2-3
B	Compartments	2-9
C	Main Deck Equipment	2-21
D	Main Deck Stowage	2-33

---





## Section A. General Description

---

<b>A.1. Design</b>	Each Defender Class boat has a deep-V, rigid mono-hull with a stabilizing closed cell polyethylene foam collar.
A.1.a. Hull and Deck	The hull and deck structures are constructed of marine grade aluminum and are welded using Metal Inert Gas (MIG) or Tungsten Inert Gas (TIG) welding techniques as required.
A.1.b. Walking Surfaces	Non-skid material is installed on the deck areas except that a 1-inch “no non-skid” area is provided around fittings, between non-skid pads, and around deck drains.
A.1.c. Cabin	The cabin is constructed of 5052 marine grade aluminum and is welded to the hull. The cabin provides seating for the four crewmembers. All boat systems operating controls are contained in the cabin. A small cuddy cabin, forward of the main cabin area, provides access to electronics, the heater, and the forward deck area. A hinged radar pod and the VHF antennas atop the cabin can be lowered for transport on a C-130 aircraft.
A.1.d. Collar	The collar is manufactured from closed cell polyethylene foam with an ultraviolet (UV) stable polyurethane coating. The collar is bolted directly to the outside of the hull and cannot lose buoyancy or absorb water.
A.1.e. Bow Post and Tow Post	An integral bow post and tow post are welded to the hull structure. Both posts may be used as gun mounting points.
<b>A.2. Manufacturer</b>	Defender Class boats are designed and manufactured by: SAFE™ Boats International 8800 SW Barney White Road Port Orchard, WA 98367

---



---

### **A.3. Missions**

Defender Class boats are intended to operate from Boat Forces Units with the following missions:

- Defense Operations (DO)
- Port Safety and Security (PSS)
- Recreational Boating Safety (RBS)
- Marine Environmental Protection (MEP)
- Enforcement of Laws and Treaties (ELT)
- Maritime Safety and Security (MSS)
- Search and Rescue (SAR)

---

### **A.4. Boat Specifications**

The following provides a list of all physical and operational characteristics of Defender Class boats.

---





A.4.a. Physical Characteristics	Design Length of Hull (Defender B Class measurement includes bow cover)	25' (7.6 meters) (Defender A Class) 25' 2½" (7.7 meters) (Defender B Class)
	Length Overall (bow to lowered taffrail)	29' 4" (8.9 meters) (Defender A Class) 29' 6½" (9.0 meters) (Defender B Class)
	Length at Waterline	22' 6" (6.8 meters) (Defender A Class) 22' 8½" (6.9 meters) (Defender B Class)
	Beam Overall	8' 6" including collar (2.6 meters)
	Operational Draft (DIW with engines vertical)	39" (.98 meters)
	Draft, Engines Tilted Up (waterline to keel)	23 ¼" (.6 meters)
	Height of Navigation Light Mast When on Trailer	12'8" (3.9 meters)
	Height of Radar Dome When on Trailer	11' ½" (3.5 meters))
	Height of Search Light When on Trailer	9'7" (2.9 meters)
	Highest Fixed Point When on Trailer (Radar Pod Cofferdam, with the tow reel removed, radar pod folded down, and search light removed)	9' ½" (2.7 meters)

**NOTE**

Trailer heights were measured from ground on a properly loaded (cabin top level) boat.

Crew Capacity (cabin seats)	4
Passenger Capacity (sitting on aft boxes and gunwales)	6
Seating Total	10
Fuel Tank Capacity	125 gallons (Defender A Class) 105 gallons (Defender B Class)
Propulsion Machinery	Twin Honda 225-HP, 4-stroke outboards
Propellers	14x19 Mercury Offshore or Vensura Series

**NOTE**

Defender Class boats can operate with a minimum complement of two, a coxswain and crewmember. Crew and passenger weights shall be 180 pounds per person when calculating weights for other loading configurations.

Boat Weight (fully outfitted, no crew)	7400
Boat Maximum Weight (fully outfitted, four crew, six passengers)	9200
Weight (fully outfit, fuel, trailer, no crew)	9450



A.4.b.  
Operational  
Characteristics

---

Maximum Speed	46 knots at 6000 RPM
Cruise Speed	35 knots at 4500 RPM
Maximum Range at Cruise Speed	175 NM (Defender A Class)
Maximum Range at Cruise Speed	150 NM (Defender B Class)
Maximum Operating Winds	25 knots
Maximum Operating Seas	6' (no surf)
Maximum Towing Capacity	10 displacement tons
Maximum Operating Distance Offshore	10 NM
Outside Air Temperature	0 to 105 °F
Outside Water Temperature	28 to 95 °F
Operation in Ice	None

**WARNING**

Operating the Defender Class Boat in ice conditions (including slush) may result in damage to the outboard engine, lower units and propellers, transducer, hull, and collar system. To avoid damage, do not operate the Defender Class Boat in any type of ice, including slush. If operating in or near ice becomes unavoidable, slow down to bare steerage and carefully reassess the need to continue the mission.

**A.5. Hull  
Reference  
Points**

---

The following reference points on Defender Class boats are frequently used (Figure 2-1):

- Non-Watertight bulkhead 7½
- Non-Watertight bulkhead 13½
- Watertight bulkhead 16

Frames are numbered aft to forward.

---




Figure 2-1  
Defender Class Boat Hull Construction





## Section B. Compartments

---

### Introduction

The hull of Defender Class boats (**Figure 2-2**, **Figure 2-3**, and **Figure 2-4**) is comprised of a single pressure-tested, airtight, welded compartment. A fuel tank (125 gallons, Defender A Class and 105 gallons, Defender B Class), fabricated from ¼-inch 5086 aluminum and supported by rubber isolation mounts, is part of the hull's structure.

---

### B.1. Anchor/ Ammunition Locker

An anchor locker, with fabricated door (**Figure 2-5**), anchor tie-downs, and drain, is located at the bow, forward of the bitt. The locker has drain holes that empty onto the foredeck and out through the shell discharge tubes. Storage shelves are built into the locker door to accommodate four boxes of ammunition.

---

### B.2. Cabin

The full width cabin (**Figure 2-6**) has seating for four crew with additional seating in the cuddy cabin. The Defender A Class has two pneumatic suspension seats forward and two bolster seats aft. The Defender B Class has two pneumatic suspension seats forward and two shock mitigating seats aft. Port and starboard sliding glass windows allow for air circulation and overhead tinted spotter windows allow for greater visibility. A hinged weather-tight door is built into the aft bulkhead. There is one sliding door located on each side of the main cabin. Welded handrails provide a minimum of two handholds for every seated crewmember. An overhead hinged instrument panel (OHIP) holds secondary "Contura" switches for navigation and deck lighting. Two 12-volt fans are mounted on the OHIP.

---




Figure 2-2  
Outboard Profile (Defender A Class)




Figure 2-3  
Outboard Profile (Defender B Class)




Figure 2-4  
Inboard Profile





**Figure 2-5**  
**Anchor/Ammunition Locker**



**Figure 2-6**  
**Cabin (Defender A Class)**



---

B.2.a. Windows      The Defender A Class cabin has 12 windows and the Defender B Class cabin has 14 windows.

---

B.2.a.1. Forward Facing Windows      The two forward facing windows incorporate windshield wipers (**Figure 2-7**).

---



**Figure 2-7**  
**Forward Cabin Window with Windshield Wiper**

---

B.2.a.2. Sliding Door Windows      Two windows (port and starboard) (**Figure 2-8**) are built into the sliding doors abeam of the helm chairs. The doors lock in the *open* position using an internal auto lock and slide mechanism that latches automatically when closed.

---



**Figure 2-8**  
**Sliding Cabin Door**

B.2.a.3.  
Combination  
Windows

---

Two combination (fixed/opening) windows are aft of the sliding doors (**Figure 2-9** (Defender A Class)).

---

B.2.a.4. Aft  
Bulkhead  
Windows

---

Two aft facing windows (port and starboard) are on the aft bulkhead (**Figure 2-9** (Defender A Class), **Figure 2-10** (Defender B Class)).

---

B.2.a.5.  
Weather-Tight  
Door Window

---

An aft facing window is built into the weather-tight door in the aft bulkhead (**Figure 2-9** (Defender A Class), **Figure 2-10** (Defender B Class)).

---



**Figure 2-9**  
**Aft Cabin Windows and Weather-Tight Door (Defender A Class)**



**Figure 2-10**  
**Aft Cabin Windows and Weather-Tight Door (Defender B Class)**



---

B.2.a.6. Tinted Spotter Windows    The Defender A Class has four tinted spotter windows on the cabin roof. The Defender B Class has six tinted spotter windows on the cabin roof:

- Two forward port and starboard of centerline (one port and one starboard)
  - One port forward
  - One port aft (Defender B Class only)
  - One starboard forward
  - One starboard aft (Defender B Class only)
- 



**Figure 2-11  
Spotter Windows (Defender A Class)**



**CAUTION !**

The weather-tight door in the forward bulkhead of the cuddy cabin shall be secured after each use to prevent water intrusion.

**B.3. Cuddy Cabin**

A weather-tight door is located in the forward bulkhead of the cuddy cabin (**Figure 2-12**) leading to the foredeck. A bench seat is provided on the starboard side. The Webasto® diesel-burning, forced air heater for cabin and window defrosting is located on the port side of the cuddy cabin behind an aluminum access cover. A B-1 fire extinguisher is mounted on the aluminum access cover for the cabin heater.



**Figure 2-12**  
**Cuddy Cabin**

**B.4. Port and Starboard Lockers**

Port and starboard lockers are located astern of the weather deck. The port locker contains access to the fuel management system that includes the tank information plate, fuel filters, fuel pickup, vent tubing, primer bulbs, and Wema™ fuel-sending unit. The starboard locker accesses the rig tube for the outboard engines and houses the diesel fuel tank for the heater (Defender B Class only). A portable B-1 fire extinguisher is also mounted in the starboard locker.



### **B.5. Cabin Dewatering Pump**

The electric cabin dewatering pump on the Defender A Class is located inside the cabin on the cabin floor, aft bulkhead on the centerline under the cabin step.

On the Defender B Class, an electric cabin dewatering pump having the identical performance characteristics as that of the Defender A Class is located inside the cabin, starboard side aft, under the starboard aft passenger seat (**Figure 2-13**).

The pump is rated at 1100 gallons per hour and has a built-in float switch for automatic operation. The pump will turn *on* when the water level reaches  $2\frac{1}{8}$  inches and *off* when no load is sensed by the pump's impeller. The discharge for the electric cabin dewatering pump is located on the aft, starboard exterior cabin bulkhead, above the deck edge walkway. The pump requires 12 VDC for operation and draws 3.3 amps at 12 volts. The boat is outfitted with a portable, manual bilge pump rated at 10 strokes per gallon and 6 gallons per minute.



**Figure 2-13**  
**Electric Cabin Dewatering Pump (Defender B Class)**








## Section C. Main Deck Equipment

---

### C.1. Bow Eye

A stainless steel bow eye (**Figure 2-14**) is through-bolted to the stem below the collar and above the waterline, and is secured with backing plate and two ½-inch stainless steel nuts.

---



**Figure 2-14**  
**Bow Eye**



---

### C.2. Standard Cleats

Six 10-inch aluminum standard cleats (**Figure 2-15**) located port, starboard, forward, aft, and amidship are fully welded to the gunwhale.

---


### C.3. Tow Bitts

Two tow bitts with stainless steel Norman (cross) pins (**Figure 2-16** (Defender A Class) and **Figure 2-17** (Defender B Class)) are located forward and aft on centerline. Each bitt accommodates the MK16 light machine gun stand. The aft tow bitt on the Defender B Class incorporates an additional handhold welded between the vertical tow bitt member and the equipment locker.


---



**Figure 2-15**  
Standard Cleat



**Figure 2-16**  
**Aft Tow Bitt (Defender A Class)**



**Figure 2-17**  
**Aft Tow Bitt (Defender B Class)**



#### C.4. Handrails

A single horizontal handrail (**Figure 2-18**) runs continuously port and starboard and around the front of the cabin. Two additional port and starboard handrails lead aft then vertically midway down the transom. A single horizontal handrail runs the width of the radar pod. Two vertical handrails are located port and starboard on the aft exterior cabin bulkhead (**Figure 2-18**).



**Figure 2-18**  
**Handrails**



---

**C.5. Transom Eyes**

Two stainless steel transom eyes (**Figure 2-19**), suitable for securing the Defender Class Boat to the trailer, are located port and starboard on the transom, above the waterline.

---



**Figure 2-19  
Transom Eye**

---

**C.6. Non-Skid**

The exterior decks are covered with non-skid pads. All non-skid edges are treated with edge seal. A 1-inch clearance is provided between the non-skid pads and deck fixtures, accesses, and openings.


---




### C.7. Deck Lighting

Both the Defender A Class and Defender B Class superstructures have four dimmable light emitting diode (LED) deck lights (**Figure 2-20**) mounted low on the port and starboard sides of the cabin exterior, to allow safe crew movements during night operations. The Defender B Class incorporates four additional LEDs installed for deck lighting. Two LEDs provide illumination for the foredeck and are mounted port and starboard on the exterior bulkhead of the cuddy cabin hatch (**Figure 2-21**). Two are mounted on the exterior aft cabin bulkhead port and starboard of the cabin door (**Figure 2-22**).

Controls for all deck lights are located on the OHIP.



**Figure 2-20**  
**Deck Lighting**



**Figure 2-21**  
**Foredeck LEDs (Defender B Class)**



**Figure 2-22**  
**Aft Deck LEDs (Defender B Class)**



### C.8. Lifting Eyes

Defender Class boats have four lifting eyes (**Figure 2-23**). Two are located above the anchor locker and two are located in the forward bulkhead of the aft lockers. Each eye is rated at 9500 pounds. Special slings, available for purchase through SAFE™ Boats International, should be used to lift the boat.



**Figure 2-23**  
**Lifting Eye**





**C.9. Navigation Lights**

Port and starboard navigation lights (**Figure 2-24**) are mounted on the cabin above the forward windows. Incandescent lamps are installed in the Defender A Class navigation lights and LEDs in the Defender B Class.



**Figure 2-24  
Navigation Light (Port)**




---

**C.10. Ring Buoy and Strobe Light**

A 24-inch ring buoy and strobe light (**Figure 2-25**) are mounted at the stern on the port side. The ring buoy is required to have 2” SOLAS grade retro reflective tape at four points equally spaced around the perimeter. Stencil “U.S. COAST GUARD” on the ring buoy’s lower semi-circle and the boat number or station name (upper case) on the buoy’s upper semi-circle (ref. COMDTINST 10470.10E).

---



**Figure 2-25**  
**Ring Buoy and Strobe Light**

---

**C.11. Towline Reel**


A fabricated towline reel (**Figure 2-26** (Defender A Class) and **Figure 2-27** (Defender B Class)) is mounted on the aft face of the radar pod. The working end of the line is fitted with an eye splice to attach to the anchor line chain. The towline reel has a ball-lock pin to keep the reel from rotating in the frame.

---

C.11.a.  
Defender A  
Class Towline  
Reel

On the Defender A Class, the reel is outfitted with 150 feet of 2¼” circumference double-braided nylon line, which can be used for towing or anchoring (**Figure 2-26**).

---



**Figure 2-26**  
**Towline Reel (Defender A Class)**




**Figure 2-27**  
**Towline Reel (Defender B Class)**

C.11.b.  
Defender B  
Class Towline  
Reel

---

On the Defender B Class, the reel is equipped with a manual, adjustable brake and 300 feet of 2 ¼ ” circumference double-braided nylon line, which can be used for towing or anchoring (**Figure 2-28**).

---



**Figure 2-28**  
**Tow Reel Brake (Defender B Class)**



## Section D. Main Deck Stowage

### D.1. Anchor/ Ammunition Locker

An anchor/ammunition locker (**Figure 2-5**) with fabricated door, anchor tie-downs, and drain is located at the bow, forward of the bitt. The locker has drain holes that empty onto the foredeck and out through the shell discharge tubes. Storage shelves are built into the locker door to accommodate four cans of ammunition.

### CAUTION !

The port aft deck locker is not to be used for storage due to risk of damage to the fuel system components.

### D.2. Port Aft Deck Locker

The port aft deck locker (**Figure 2-29** (Defender A Class) and **Figure 2-30** (Defender B Class)) contains access to the fuel tank and Wema™ fuel-sending unit. It contains the fuel management system, including the fuel filters, fuel pickup, vent tubing, and primer bulbs. The port locker provides accesses to the port side rig tube. On the B-Class, an in-line diesel fuel filter and pump for the cabin heater is located inside the port aft deck locker.



**Figure 2-29**  
**Port Aft Deck Locker (Defender A Class)**



**Figure 2-30**  
**Port Aft Deck Locker (Defender B Class)**

---

**D.3. Starboard Aft Deck Locker**

The starboard aft deck locker (**Figure 2-31** (Defender A Class) and **Figure 2-32** (Defender B Class)) provides access to the rig tube for the outboard engines and a portable B-1 fire extinguisher. The boat's 12-VDC electrical system negative bus bar is located under a plastic cover on the forward bulkhead in the starboard aft deck locker. On the Defender B Class, the diesel fuel tank for the cabin heater is located in the starboard aft deck locker.

---

**D.4. Pump Stowage**

A portable pump container may be strapped forward of the aft deck locker using the tie down straps attached to the boat's lifting eyes. The ratcheting tie-down straps provided with the boat are 1 inch wide by 7 feet long. When carried aboard the boat, the pump container should be located on the port side to allow unrestricted access to the fire extinguisher located in the starboard aft deck box. Failure to adequately secure the pump container to the deck may result in injury and loss of the pump (**Figures 2-33, 2-34**).

---



**Figure 2-31**  
**Starboard Aft Deck Locker (Defender A Class)**



**Figure 2-32**  
**Starboard Aft Deck Locker (Defender B Class)**



**Figure 2-33**  
**Pump Container Stowage**



**Figure 2-34**  
**Pump Container Stowage**





## Chapter 3 Boat Systems

**Introduction** This chapter discusses the boat's mechanical, electrical, and manual operating systems. It describes basic characteristics and provides information to allow the boat's crew to operate effectively.

**In this Chapter** This chapter contains the following sections:

Section	Topic	See Page
A	Propulsion System	3-3
B	Hull System	3-17
C	Collar System	3-25
D	Steering System	3-29
E	Propulsion Fuel System	3-33
F	Communications/Navigation System (Defender A Class)	3-39
G	Communications/Navigation System (Defender B Class)	3-47
H	Electrical System	3-57
I	Seating System (Defender A Class)	3-65
J	Seating System (Defender B Class)	3-67
K	Heating System	3-71
L	Trailing	3-77
M	Weapons Mounting/Stowage	3-91
N	Hull Exterior Lighting (Defender A Class)	3-95
O	Hull Exterior Lighting (Defender B Class)	3-99
P	Ancillary Systems and Furnishings	3-107





## Section A. Propulsion System

---

### Introduction

The propulsion system for Defender Class boats consists of two Honda outboard engines (**Figure 3-1**) mounted on the transom.

### NOTE

All references to engine locations are taken standing behind the engine propeller looking forward.

### NOTE

When differences exist between the Defender A Class and Defender B Class, they will be specifically identified in the text by hull designation.




**Figure 3-1**  
**Outboard Engine**




### A.1. Engine

Each engine, rated 225 HP at 5500 RPM, is a four-stroke, V6, water-cooled engine with a single overhead cam. Engine displacement is 212 cubic inches (3741 cubic centimeters) with a 3½-inch bore and 3.66-inch stroke (89 by 93 millimeters). The operating weight of each engine is approximately 633 pounds. (see **Figure 3-2** and **Figure 3-3**)



- |                              |                             |
|------------------------------|-----------------------------|
| 1. Oil dipstick              | 7. Anode                    |
| 2. Power tilt switch         | 8. Engine oil drain plug    |
| 3. Tilt lock lever           | 9. Cooling system indicator |
| 4. Frame serial number       | 10. Spark plug              |
| 5. Flush plug connector      |                             |
| 6. Cooling water intake port |                             |

**Figure 3-2**  
**Outboard Engine (Starboard Side)**



- |                           |                         |
|---------------------------|-------------------------|
| 1. Oil filler cap         | 7. Gear oil drain plug  |
| 2. Engine cover           | 8. Gear oil level plug  |
| 3. Anode                  | 9. Anode                |
| 4. Anti-ventilation plate | 10. Manual relief valve |
| 5. Exhaust port           | 11. Stern bracket       |
| 6. Propeller              | 12. Engine cover latch  |

**Figure 3-3**  
**Outboard Engine (Port Side)**




## A.2. Lubrication Systems

The engine oil system is a trochoid pump pressure system with a capacity of 8 U.S. quarts (7.6 liters) of SAE 10W-30, API standard (SG, SH, SJ). The engine oil dipstick (**Figure 3-2, 1**) is located under the engine cover on the starboard side of each engine. The oil filler cap (**Figure 3-3, 1**) is located under the engine cover on the forward port side of the engine. The oil drain plug (**Figure 3-2, 8**) is located on the starboard side of the engine behind a small rectangular cover, which is retained in place by a screw. A spin-on type, disposable oil filter is mounted on the front of the engine above the Low-Pressure Fuel Filter.

The gear case requires 1.24 U.S. quarts (1.17 liter) of SAE 90 outboard motor gear oil, API standard (GL-4/5). The gear case utilizes a splash-type lubrication system. A gear oil level plug (**Figure 3-3, 8**) is located on the forward port side of the engine directly above the anti-ventilation plate. The gear oil drain plug (**Figure 3-3, 7**) is located on the port side of the horizontal propeller shaft fairing.

## A.3. Engine Cooling System

The engine cooling system consists of an impeller type pump and thermostat mounted on the engine. Two cooling water intake ports (**Figure 3-2, 6**) are located on the port and starboard sides of the lower outboard fairing directly above the horizontal propeller shaft. A cooling system indicator (**Figure 3-4**) on the starboard side of the engine cover shows that water is circulating through the engine cooling system.



**Figure 3-4**  
**Cooling System Indicator**

**CAUTION !**


The fuel system requires unleaded 86-octane gasoline or higher.

**A.4. Engine Fuel System**


An electric-powered mechanical fuel pump provides fuel to each cylinder as metered by an electronic fuel injection system. A priming bulb (**Figure 3-5**), located in the inlet line to the outboard engine, primes and pressurizes the outboard engine fuel system for starting. A water separator (**Figure 3-6**) is located beside the oil dipstick and provides a visual indication of the presence of water in the fuel. The separator should be cleaned when excessive water is present.

A fuel pump filter is located directly below the engine oil filter. The filter is mounted in a translucent cup to provide a visual indication of sediment or water. The filter is disposable and should be replaced periodically or when excessive sediment or water is observed.

Fuel for the outboard engines is stored in a hull-mounted fuel system.



**Figure 3-5**  
**Fuel Priming Bulb**



**Figure 3-6**  
**Water Separator**

---

**A.5. Ignition System**

The ignition system is a fully transistorized battery ignition system with six spark plugs and six ignition coils (**Figure 3-2, 10**). The left and right engine undercovers must be removed to gain access to the plugs and coils.

---

**A.6. Starter**

A direct cranking starter is mounted on each outboard engine. The starter requires a battery rated for 12 VDC and 110 amp hours.


---





### A.7. Engine Controls

The gearshift and throttle control (**Figure 3-7**) for both engines is located on the starboard dash panel. Each lever controls engine RPM and ahead or astern movement. Moving the throttle lever 35 degrees from neutral selects the gear, forward or reverse, and further movement increases engine speed. The port throttle lever contains the power trim/tilt switches for both engines. These rocker-type switches, labeled UP and DN, change the angle of the outboard motor to trim the boat for normal operation, shallow water operation, beaching, launching, and mooring.



**Figure 3-7**  
**Gearshift and Throttle Control**




**A.8. Engine Key Switch Panels**

On the Defender A Class, there are two engine key switch panels (**Figure 3-8**) and on the Defender B Class there is one engine key switch panel (**Figure 3-9**) mounted below the gearshift and throttle control. Each panel has an ignition key switch for starting labeled OFF-ON-START. The key switch is interlocked to allow engine starting only with the throttle lever in *neutral*.

**A.8.a. Defender A Class Panels**

One engine kill switch is installed next to the ignition key switch for each of the engines. The engine kill switch clip must be inserted in the engine kill switch in order for the engine to start and run. The kill switch clip is attached to an 18-inch lanyard, which is attached to the operator’s PFD or boat crew survival vest. Should the operator/coxswain fall away from the controls, the engine(s) will immediately stop.

Engine warning lights are mounted above the key switches on the switch panels.




**Figure 3-8**  
**Key Switch Panels (Defender A Class)**



A.8.b. Defender B  
Class Panel

One engine kill switch is installed between the ignition key switches for both of the engines. The engine kill switch clip must be inserted in the engine kill switch in order for the engines to start and run. The kill switch is attached to an 18-inch lanyard that is attached to the operator's PFD or boat crew survival vest. Should the operator/coxswain fall away from the controls, the engines will immediately stop.

Engine warning lights are mounted above the key switches on the switch panel.



**Figure 3-9**  
**Key Switch Panel (Defender B Class)**




**CAUTION !**

The engines must be up and locked for all trailering evolutions.

**A.9. Power Tilt Switch**

The power tilt switch (**Figure 3-10**) is mounted on the starboard side of the engine cover. The power tilt switch will operate without turning the ignition *on*. The switch is used when the engine is stopped to raise the engine for mooring, trailering, or maintenance.




**Figure 3-10**  
**Power Tilt Switch**



### A.10. Manual Relief Valve

The manual relief valve (**Figure 3-11**) is located on the port side of the engine's stern bracket and is used in conjunction with the tilt lock lever. By inserting a screwdriver in the manual release valve and turning the screw, the engine can be manually tilted and locked.



**Figure 3-11**  
**Manual Relief Valve**




---

**A.11. Tilt Lock Lever**

The tilt lock lever (**Figure 3-12**) is used to support the engine in the *fully raised* position. The lever is located between the engine housing and the frame of the engine.

---



**Figure 3-12**  
**Tilt Lock Lever**

---

**A.12. Sacrificial Anodes**

Sacrificial anodes (**Figure 3-2, 7** and **Figure 3-3, 3, 9**) are used to protect the outboard motor from corrosion. Two of the anodes are located on the gear case, one on the stern bracket, and two small anodes are located in the water passages of the engine block.

---

**A.13. Engine Exhaust Port**


The engine exhaust gases are discharged around the propeller shaft (**Figure 3-3, 5**) and through the hub of the propeller.

---



**A.14. Fuse Panels**

Two fuse panels are located under the outboard engine cover (**Figure 3-13**). The side-mounted fuse panel houses 10-amp, 15-amp, and 30-amp fuses for the ignition switch circuit, power trim/tilt switch circuit, and electric starter circuit. The top-mounted fuse panel houses the 150-amp alternator/charging circuit fuse.



**Figure 3-13  
Fuse Panels**




---

**CAUTION !** The left- and right-hand propellers ARE NOT interchangeable.

**CAUTION !** Changing the propeller configuration will change the operating characteristics of the boat. Any recommended changes must be submitted in accordance with the *Naval Engineering Manual*, COMDTINST M9000.6 (series).

**A.15. Propellers** Defender Class boats utilize a stainless steel, four-blade propeller, with a 14-inch diameter and 19-inch pitch.

**A.16. Flo-Torq Assembly** To protect the propeller, engine, and lower gear unit gears, Defender Class boats have the Mercury Marine Flo-Torq II propeller cushion hub kit (**Figure 3-14**) on the installed propellers. The hub kit reduces the shock on the lower unit gears and engine when shifting gears, and also absorbs shock if the propeller hits an object. The hub kit is a safety device designed to break down and slip under excessive torque loading. The cost of the sacrificial cushion hub replacement is relatively inexpensive when compared with expensive engine damage.



**Figure 3-14**  
**Flo-Torq II System**





## Section B. Hull System

### Introduction

The boat's hull is fabricated from 5086 marine grade aluminum. The hull's design is a deep-V mono-hull with a pointed bow and flat transom. The deadrise is 25 degrees at the transom; defined as the angle between the baseline plane and the hull bottom when measured perpendicular to the boat's centerline.

The hull consists of 1/4-inch 5086 marine grade aluminum bottom plating. The decks and side plating are 3/16-inch 5086 marine grade aluminum. The boat has a fixed fender system to protect the exterior of the hull during alongside work. The boat's hull has sufficient buoyancy and stability to float upright with the fendering system removed.

### NOTE

To prevent galvanic corrosion of the aluminum hull, the outboard engines should be raised out of the water when the boat is moored for prolonged periods of time.

### CAUTION !

With the engines trimmed to the maximum depth and the boat making no headway, the draft is 39 inches.

### B.1. Draft

The hull's deepest draft with the engines raised is at the step, which is on the keel at bulkhead 1, forward of the transom (**Figure 2-1**).

### B.2. Sound Insulation

A layer of two-part, maintenance free, polyurethane foam covers the bottom 4 inches of the hull. The foam is flame retardant and complies with ASTM flame spread requirements. The foam's main purpose is to provide sound insulation. No polyurethane foam is installed directly below the fuel tank in the bilge area on the Defender B Class.

### B.3. Performance Fins


The performance fins (**Figure 3-15**) are located port and starboard below the aft portion of the collar. They provide lift upon acceleration and create a vacuum for stabilization during turning.

### B.4. Lifting Strakes


The hull contains three custom lifting strakes (**Figure 3-15**) on each side of the V bottom hull to improve seakeeping, directional stability, and planing performance.

### B.5. Beaching Plate

A 3/16-inch 5086 marine grade aluminum beaching plate (**Figure 3-16**) is welded to the keel along the forefoot to provide additional protection to the hull.



**Figure 3-15**  
**Performance Fin and Lifting Strakes**




**Figure 3-16**  
**Beaching Plate**



---

<b>B.6. Inspection Access</b>	Two ½-inch inspection plugs are located inside the cabin near frames 7½ and 13½. A borescope is required for internal inspection.
<b>B.7. Diagonal Stiffeners</b>	The ¼- by 3-inch diagonal stiffeners ( <b>Figure 3-17</b> ), spaced 12 inches apart, are designed to efficiently disperse impact energy. This unique herringbone framing directs impact energy along its natural course of flow.
<b>B.8. Rig Tubes</b>	Rig tubes are located directly below the main deck on the port and starboard sides and terminate at watertight bulkhead 13½, where they interconnect with the transverse rig tube. There are multiple access points to the rig tubes.
<b>B.9. Hull Access Plug</b>	The hull access plug is located forward of the depth and temperature sensor in the step. This can be used for hull draining and borescope access.

---



**Figure 3-17**  
**Hull Construction Top View**



---

### **B.10. Deck Drains and Scuppers**


There are six deck drains and four scuppers on the Defender A Class and Defender B Class as follows:

- 2 Forward Cabin Deck Drains
- 2 Forward Cabin Deck Scuppers
- 2 Aft Weather Deck Drains
- 2 Aft Well Deck Drains
- 2 Aft Weather Deck Scuppers

---

#### **B.10.a. Forward Cabin Deck Drains**

Two 2½-inch diameter drains are located in the aft, outboard corners of the forward cabin deck, just forward of the cuddy cabin door (**Figure 3-18**).



**Figure 3-18**  
**Forward Cabin Deck Drain**

---

#### **B.10.b. Forward Cabin Deck Scuppers**

The forward cabin deck drains interface with scoop type scuppers (**Figure 3-19**) under the hull to allow water taken over the side to drain from the boat.


---




**Figure 3-19**  
**Forward Cabin Deck Scupper**

B.10.c. Aft  
Weather Deck  
Drains

Two 2½-inch diameter drains are located in the lower outboard corners on the forward bulkhead of the aft storage lockers (**Figure 3-20**). These drains allow water to drain through the scupper/water socks (**Figure 3-21**) mounted on the transom.



**Figure 3-20**  
**Aft Weather Deck Drain**



**Figure 3-21**  
**Aft Weather Deck Scupper/Water Sock**

---

B.10.d. Aft Well Deck Drains    The aft well deck is drained using two oblong openings in the transom, outboard of the engines, just above the deck level.

---



B.10.e. Aft Locker Drain Plugs

Two drain plugs located on the transom just inboard of the aft well deck scuppers (water socks) can be removed to drain the aft lockers (**Figure 3-22**).



**Figure 3-22**  
**Aft Locker Drain Plug**





## Section C. Collar System

---

### Introduction

The patented SAFE™ (Secured Around Flotation Equipped) collar system is designed to provide flotation, fendering, and stability. The collar core is constructed of solid, closed-cell, polyethylene foam. The coating is exceptionally tough, scuff-resistant, UV stable polyurethane. If damage to the collar occurs, it is easily repaired at the unit level. The collar is capable of absorbing major impact and returning to its original shape. Damaged sections can be easily repaired or replaced as necessary.

The water-contacting surface of the collar is protected by an aluminum flange, which protects it from damage.

---

### C.1. Attachment

The two side collar sections are bolted using stainless steel lag bolts (**Figure 3-23**) to aluminum collar blocks that are welded to the side of the hull. On the Defender B Class, the collar attachment bolts thread into ultra high molecular weight (UHMW) plastic blocks located at the collar attaching gussets.

The bow section on the Defender A Class (**Figure 3-24**) is bolted through the hull and the bow collar reinforcement bracket (BCRB) for improved impact resistance. On the Defender B Class only, the collar bow section is outfitted with a protective cover (**Figure 3-25**) equipped with a rub strake.

---



**Figure 3-23**  
**Side Collar Attaching Bolt**



**Figure 3-24**  
**Collar (Bow Section)**



**Figure 3-25**  
**Bow Cover (Defender B Class)**




---

**CAUTION !** The daily checkoff sheet requires a thorough inspection of the collar. Immediately repairing any damage that penetrates the polyurethane coating (skin) is critical. Failure to do so may result in further damage to the area requiring extensive repair.

**CAUTION !** In accordance with ALCOAST 543-04, sanding of collars puts personnel at risk to airborne lead particle exposure. To minimize risk, PSX-700 shall be applied to collars without abrading the existing surface coating.

---

**C.2. Repair and Removal** Minor repairs are easily completed within 24 hours. Repair procedures for both repair and removal can be found in the most current SAFET<sup>™</sup> Boats International RB-S/RB-HS Tech manual.

**NOTE**  The closed-cell polyethylene foam does not absorb water. However, if the polyurethane coating is damaged, water may collect between the foam and the coating. If damaged, a water “bubble” may appear under the surface of the polyurethane coating. If not repaired, accumulated water will cause the coating to rupture, necessitating the complete replacement of the collar.

---





## Section D. Steering System

---

**Introduction** The steering system (**Figure 3-26**) is an integrated system made up of three major components as follows:

- Hydraulic steering cylinder
- Tie bar assembly
- Helm pump assembly

**CAUTION !** Never use brake fluid in the steering system. Use of non-specified fluids may cause irreparable damage and steering system failure.

The hydraulic system operates on standard hydraulic fluid. The recommended fluid for the steering system is Sea Star Hydraulic Fluid HA5430 or any hydraulic fluid meeting MIL-H-5606 specifications. Automatic transmission fluid (ATF) could also be used in an emergency. The system is filled with fluid and then bled free of any air bubbles.

---

**D.1. Hydraulic Steering Cylinder** The Sea Star steering cylinder (**Figure 3-27**) is a front-mount system that is compatible with twin-engine, independent tilt. It allows for easy hydraulics and has a five-turn lock-to-lock response. It is a general purpose cylinder rated for up to 600 HP on a counter-rotating, twin-engine application.


---

**D.2. Tie Bar Assembly** The tie bar (**Figure 3-27**) is a ½-inch solid, stainless steel rod. It has an adjustable ball joint on one end and a rod end connector on the other. The rod is protected by a stainless steel stringer tube, which provides added stability and acts as a stop for the rod end fittings. The purpose of the tie bar is to provide equal, uniform directional control of the engines, but does not interfere with independent trim, tilt, and throttle.

---

**D.3. Helm Pump Assembly** The Helm Pump Assembly (HPA) is mounted in the console and is a multiple position tilt system. The Momo<sup>®</sup> wheel (**Figure 3-28** (Defender A Class) and **Figure 3-29**, (Defender B Class)) is attached to the 5/8-inch shaft on the HPA. The hydraulic lines from the steering cylinder connect into the rear of the HPA.

---




**Figure 3-26**  
**Steering System**



**Figure 3-27**  
**Steering Cylinder and Tie Bar**



**Figure 3-28**  
**Helm and Helm Pump (Defender A Class)**



**Figure 3-29**  
**Helm, Helm Pump, and Vent/Fill Cap (Defender B Class)**

#### **D.4. Hoses**

Hydraulic hoses, compatible with fluids that meet MIL-H-5606 specifications, connect the helm with the twin, front-mounted steering cylinders mounted on the transom. The hoses are routed through conduit to prevent chaffing or contact and interference with equipment or the hull structure.





## Section E. Propulsion Fuel System

### CAUTION !

A separate diesel fuel system is installed for the cabin heater. Great care must be taken to ensure that the correct fuel is provided to each system during re-fueling operations, or serious engine or heater damage may result.


### Introduction

On the Defender A Class, the propulsion fuel system provides 118 gallons of burnable gasoline (95% of total tank capacity) for operating the two outboard engines.

On the Defender B Class, the propulsion fuel system provides 100 gallons of burnable gasoline (95% of total tank capacity) for operating the two outboard engines.

### E.1. Fuel Tank

The fuel tank (**Figure 3-30**) is constructed of 1/4-inch welded 5086 marine grade aluminum. Transverse baffles restrict free surface movement of the fuel. The bottom is rolled (no seams) with doublers on either end, welded to flanges that are mounted on shock absorbent rubber isolation pads. Doubler plates isolate the tank from mounting brackets. Rubber mounts isolate the tank from the hull.



**Figure 3-30**  
**Fuel System (Defender A Class)**


### E.2. Fuel Tank Vent (Defender A Class)

The fuel tank vent line is accessed through a removable deck plate located in the center of the aft well deck, aft of frame 7 on hulls 255001 through 255086. The last thirteen Defender A Class boats have the same fuel tank vent system as that for the Defender B Class (see *E.3*).



**E.3. Fuel Tank Vent (Defender B Class)**

The fuel tank vent (**Figure 3-31**) is integral to the fuel tank and connects to the vent.




**Figure 3-31**  
**Fuel Tank (Gasoline) Vent System (Defender B Class)**

**E.4. Fuel Tank Fill (Gasoline)**

The propulsion fuel tank (gasoline) fill cap for both the Defender A Class and Defender B Class (**Figure 3-32** and **Figure 3-33**) is located between the port and starboard aft equipment lockers. The vent (**Figure 3-32**) for the Defender A Class propulsion fuel tank is located directly above and forward of the fill cap. On the Defender B Class (**Figure 3-33**), the propulsion fuel tank and diesel fuel tank vents are located above and forward of the fill cap.



**Figure 3-32**  
**Fuel Tank Fill (Gasoline) (Defender A Class)**



**Figure 3-33**  
**Fuel Tank Fill (Gasoline) (Defender B Class)**



### E.5. Fuel Filters/Water Separators

Each outboard engine has a separate fuel filter/water separator (**Figure 3-34**) mounted in the aft port storage box. The filters have a translucent bowl that allows for visually determining the presence of water in the fuel. Each filter is rated at 60 gallons per hour (GPH) and has a 10-micron, disposable filter element.



**Figure 3-34**  
**Fuel Filters/Water Separators**



**E.6. Primer Bulbs**

Two primer bulbs (**Figure 3-35**), one for each engine, are located in the port aft storage box.



**Figure 3-35  
Primer Bulbs**



### E.7. Fuel Tank Level Sensor

The fuel tank level sensor (**Figure 3-36**) is located in the aft port storage box adjacent to the fuel tank fill hose. The tank sensor transmits the known fuel tank quantity to the fuel tank indicator on the starboard instrument panel.



**Figure 3-36**  
**Fuel Tank Level Sensor**



## Section F. Communications/Navigation System (Defender A Class)

### Introduction

All of the standard marine communications and navigation equipment is mounted in the cabin of the Defender A Class.

### NOTE

Frequent operations and position reports between the boat and its operational control (OPCON) are critical to crew safety and timely mishap follow-up. Every boat must have the capability for communicating by radio to the station and other vessels. For radio protocol, channel selection, and additional radio communication information, refer to *Chapter 11* in the *Boat Crew Seamanship Manual*, COMDTINST M16114.5 (series); the *Telecommunications Manual*, COMDTINST M2000.3 (series); and the *Radiotelephone Handbook*, COMDTINST 2300.7 (series).

### F.1. Motorola VHF-FM Astro Spectra W9 Transceiver and Control Head

The Motorola VHF-FM Astro Spectra W9 control head (**Figure 3-37**) is mounted in the cabin on top of the port dash panel. The transceiver is located forward of the coxswain console and is accessible through the cuddy cabin. The transceiver is used for communicating on VHF marine band frequencies, 146 to 174 MHz. The transceiver meets the digital encryption standard (DES) requirements for APCO 25. The radio requires a 12-VDC power input. The radio antenna is located atop the cabin, starboard side.

The Astro Spectra W9 is no longer available through Motorola. The Motorola XTL-5000 provides similar operating characteristics, including AES encryption capability, and is the replacement radio for the Astro Spectra W9.



**Figure 3-37**  
Motorola VHF-FM Astro Spectra W9 Control Head



**F.2. Raymarine  
215 VHF  
Transceiver**

The Raymarine 215 VHF transceiver (**Figure 3-38**) is a microprocessor controlled, digitally synthesized VHF transceiver. The transceiver provides two-way communications on marine channels and monitoring of 10 separate weather channels. The transceiver has built-in digital select calling (DSC) for sending and receiving DSC distress, all ships, individual ship, and group call communications. The radio requires 12-VDC input and has a 25- or 1-watt power setting. The antenna is located atop the cabin, port side. The transceiver can transmit on frequencies 156.025 to 157.425 MHz and receive on frequencies 156.050 to 163.275 MHz. The transceiver is located on the OHIP, port side.



**Figure 3-38**  
**Raymarine 215 VHF Transceiver**





### F.3. Raymarine 430 Loudhailer

The Raymarine 430 loudhailer (**Figure 3-39**) requires a 12-VDC input and provides 30 watts of output power to the loudhailer speaker on the forward face of the radar pod. The loudhailer has eight programmable foghorn signals to be used when operating in conditions of low visibility. The loudhailer and microphone are mounted on the port side of the dash panel.



**Figure 3-39**  
**Loudhailer**

### F.4. Raytheon RL80CRC Radar

The Raytheon RL80CRC radar display (**Figure 3-40**) is mounted on top of the dash panel on the centerline. This surface radar/chart plotter can display various input and exchange this information simultaneously in full screen, split screen, or overlay screen modes. The RL80CRC has a 10.4-inch daylight viewable, color display and is GPS compatible. The RL80CRC contains a ten-target mini automatic radar plotting aid (MARPA) for tracking radar targets and providing risk assessment and tracked target data that includes range, bearing, speed, course, closest point of approach, and time to closest point of approach. A man overboard (MOB) mode provides a readout that shows range, bearing, latitude, and longitude of MOB, and time elapsed since MOB.

#### F.4.a. Radome Antenna

The radar antenna is a compact Raymarine 2-kW radome antenna that has a maximum range of 24 nautical miles (NM). The radome can operate with an input voltage of 10.7 to 32 VDC.



**F.4.b. GPS Receiver/Antenna**

The 12-channel Raystar 120 Sea Talk GPS receiver/antenna is mounted on the radar pod. The receiver/antenna provides GPS correction signals to the RL80CRC radar.



**Figure 3-40  
Radar/GPS**

**F.5. Depth Sounder Display**

The Raytheon CRP-ST-60 depth sounder display (**Figure 3-41**) is mounted on the centerline of the OHIP. The depth sounder transducer is located forward of the transom. When first turned *on*, the depth sounder will show the current depth. The depth sounder memorizes the minimum and maximum depth while it is turned *on*, and these quantities can be recalled and displayed.

The depth sounder also employs a depth trend indicator to indicate a rising or lowering seabed. Deep and shallow threshold limits can be programmed into the depth sounder to activate deep and shallow depth alarms.



**F.6. ST60  
Digital  
Compass**

The ST60 digital compass (**Figure 3-41**) is mounted on the OHIP at centerline. The compass can display true/magnetic course headings, current or locked heading, course over ground, average heading, and a man overboard function. The compass is a stand-alone unit requiring a 10- to 16-VDC input. The heading sensor is located under the coxswain seat box.

**CAUTION !**


The ST60 digital compass has proven to be accurate and shall be considered the primary navigation compass. In addition, the Course Over Ground feature on the GPS/Chart Plotter is unaffected by Electro Magnetic Interference and therefore can also be used in combination with the digital compass.

**CAUTION !**

Do not stow metallic objects near the heading sensor as it may cause inaccurate compass readings.

**NOTE**

The accuracy of the digital compass should be frequently checked by steering a known range and calibrated in accordance with the manufacturer’s instructions. If the boat experiences electronic problems, operates in a new geographic region, or requires recalibration for some other reason, record the results of the accuracy check in Part 1 of the Boat Record.



**Figure 3-41  
Depth Sounder and Digital Compass**



### F.7. Magnetic Compass

A Nexus magnetic compass (**Figure 3-42**) is mounted on the centerline between the cabin windshields. The magnetic compass shall only be used as an emergency backup compass if the electronic compass and/or Raystar 120 Sea Talk GPS receiver fails. It is of the utmost importance that coxswains remain aware of the affects of Electro Magnetic Interference (EMI) caused by various energized electronic accessories and engine RPMs when using the magnetic compass. In the event of an electronic navigation system failure, coxswains and operational commanders must consider all available options, including anchoring to await an escort, during the risk assessment process.

The compass contains an internal gimbal system for maximum stability during adverse weather conditions. Built-in compensators provide for easy compass deviation adjustments. The blue dial is calibrated in white 5-degree increment markings. Lubber lines are provided at 45 degrees.

The magnetic compass must be calibrated on an annual basis. Compass calibration should be performed with all non essential accessories (heater, wipers, fans, flood lights, etc) secured, and at low engine RPM. With the non essential accessories secured, units should be able to calibrate the magnetic compass within 5 degrees. However, deviation greater than 5 degrees is not considered a restrictive discrepancy when accessories are energized or while traveling at higher RPM. A waiver to operate the Defender Class boat with excessive deviation when accessories are energized is not required. Multiple deviation tables that record deviation levels with various electronic accessories energized or under various engine RPM loads are also not required. The only requirement is to have a current deviation table on board. Units should document the fact that that the compass was adjusted with non essential accessories secured (windshield wipers, fans, heater, and flood lights).

### CAUTION!

Magnetic compass deviation may occur when cabin electrical equipment (windshield wiper motors, cabin fan motors, heater, or flood lights) is energized creating Electro Magnetic Interference (EMI). EMI may also affect the magnetic compass at various engine RPMs.



**Figure 3-42**  
**Standby/Magnetic Compass**

**F.8. Antennas**

All of the communications and navigation antennas (**Figure 3-43**) are mounted on the radar pod or on top of the cabin. The antennas and the radar pod can be lowered to allow for overhead clearance when the Defender A Class is loaded on the trailer for air transport.



**Figure 3-43**  
**Antennas**





## Section G. Communications/Navigation System (Defender B Class)

---

### Introduction

All of the standard marine communications and navigation equipment is mounted in the cabin of the Defender B Class. The Defender B Class utilizes a Scalable Integrated Navigation System (SINS) that is built around the Furuno NavNet radar/chart plotter system. The SINS system on the Defender B Class includes the following:

- 1833C/NT Radar/Video Plotter
- PG1000 Heading Sensor
- GP-37 WAAS/DGPS Navigator
- RD-30 Multi-Display Unit
- 235DT-SSE Depth Sensor

### NOTE

Frequent operations and position reports between the boat and its operational control (OPCON) are critical to crew safety and timely mishap follow-up. Every boat must have the capability for communicating by radio to the station and other vessels. For radio protocol, channel selection, and additional radio communication information, refer to *Chapter 11* in the *Boat Crew Seamanship Manual*, COMDTINST M16114.5 (series); the *Telecommunications Manual*, COMDTINST M2000.3 (series); and the *Radiotelephone Handbook*, COMDTINST 2300.7 (series).

### G.1. Raymarine 430 Loudhailer

The Raymarine 430 loudhailer (**Figure 3-44**) requires a 12-VDC input and provides 30 watts of output power to the loudhailer speaker on the forward face of the radar pod. The loudhailer has eight programmable foghorn signals to be used when operating in conditions of low visibility. The loudhailer and microphone are mounted on the port side of the dash panel.

The FURUNO LH 3000 loudhailer replaced the Raymarine 430 loudhailer beginning with hull 25575.


---



**G.2. Motorola VHF-FM Astro Spectra W9 Transceiver and Control Head**

The Motorola VHF-FM Astro Spectra W9 transceiver and control head (**Figure 3-44**) is mounted in the cabin on top of the port dash panel. The transceiver is located on the portside behind the 12-VDC main power panel. The transceiver is used for communicating on VHF marine band frequencies, 146 to 174 MHz. The transceiver meets the digital encryption standard (DES) requirements for APCO 25. The radio requires a 12-VDC power input. The radio antenna is located atop the cabin, starboard side.

The Astro Spectra W9 is no longer available through Motorola. The Motorola XTL-5000 provides similar operating characteristics, including AES encryption capability, and is the replacement radio for the Astro Spectra W9.



**Figure 3-44**  
**Raymarine 430 Loudhailer and Motorola VHF-FM Astro Spectra W9 Control Head**





**G.3.**  
**Raymarine 215**  
**VHF**  
**Transceiver**

The Raymarine 215 VHF transceiver (**Figure 3-45**) is a microprocessor controlled digitally synthesized VHF transceiver. The transceiver provides two-way communications on marine channels and monitoring of 10 separate weather channels. The transceiver has built-in digital select calling (DSC) for sending and receiving DSC distress, all ships, individual ship, and group call communications. The radio requires 12-VDC input and has a 25- or 1-watt power setting. The antenna is located atop the cabin, port side. The transceiver can transmit on frequencies 156.025 to 157.425 MHz and receive on frequencies 156.050 to 163.275 MHz. The transceiver is located on the OHIP, port side.



**Figure 3-45**  
**Raymarine 215 VHF Transceiver**



#### G.4. Furuno 1933C/NT Radar Display

The Furuno 1833C/NT radar display (**Figure 3-46**) is mounted on top of the dash panel on the centerline. This surface radar/chart plotter has a 10.4-inch color LC display and utilizes a powerful X-band transmitter for reliable operation in all types of weather. This true color radar displays six levels of target density and is capable of tracking storms. The radar incorporates head-up, course-up, north-up, and true motion display modes. The range scales are from 0.125 to 48 NM, 16-step increments. The Echo Trail intervals available are 15 seconds; 30 seconds; 1, 3, 6, 15, and 30 minutes; or continuous.

The plotter has a memory capacity of up to 8000 points for the boat's track and marks, 1000 waypoints, and 200 planned routes. Display modes include course plot, navigation data, steering display, and highway. Plot interval is adjustable from 1 second to 59 minutes, 59 seconds or 0.01 to 9.99 NM. Alarms available are guard zone, arrival/anchor watch, proximity alert, ships speed, water depth and temperature, and cross track error (XTE). A SAVE MOB function will immediately mark the MOB position and display the range and bearing of the man overboard location on the display.



**Figure 3-46**  
**Radar Display**



---

**G.5. Radome Antenna**


The radar antenna (**Figure 3-47**) is a compact Furuno 4-kW radome antenna that has a maximum range of 36 NM. The radome requires a 12-VDC input.

---

**G.6. WAAS/DGPS Receiver/Antenna**

The Furuno Wide Area Augmentation System (WAAS)/differential global positioning system (DGPS) receiver/antenna (**Figure 3-47**) is mounted on the radar pod. The antenna has 12 DGPS receiving channels and 1 WAAS receiving channel. The receiver/antenna can decode correction signals from WAAS/DGPS and provide these signals to the 1833C/NT radar display and the GP-37 WAAS/DGPS navigator. The position accuracy for the DGPS is 10 meters; the DGPS, 5 meters; and the WAAS, 3 meters. The receiver/antenna requires a 12-VDC input.

---



**Figure 3-47**  
**Radar Antenna and WAAS/DGPS Receiver/Antenna**



### G.7. RD-30 Multi-Display

The RD-30 multi-display and data repeater (**Figure 3-48**) is mounted on the starboard face of the coxswain’s operating console. The RD-30 utilizes a wide variety of navigation data and displays it in digital and analog (graphic) formats. The multi-display uses input from the depth/temperature sensor, radar, WAAS/DGPS receiver/antenna, and the PG 1000 heading sensor to provide essential navigational information. The unit features a 4½-inch backlit LCD and has five user programmable displays. The RD-30 has ten conditions that can trigger audio and visual alarms:

- Speed
- Water temperature
- Depth
- Arrival/anchor watch
- XTE
- Trip distance (two alarms)
- Countdown timer
- Alarm clock
- No position fixing
- No position data

The RD-30 requires 12-VDC input.

#### CAUTION !

The PG-1000 Fluxgate heading sensor (displayed on the RD-30 Multi-Display) has proven to be accurate and shall be considered the primary navigation compass. In addition, the Course Over Ground feature on the GP-37 WAAS/DGPS Receiver and Navigator is unaffected by Electro Magnetic Interference and therefore can also be used in combination with the digital compass.

#### NOTE

The accuracy of the digital compass should be frequently checked by steering a known range and calibrated in accordance with the manufacturer’s instructions. If the boat experiences electronic problems, operates in a new geographic region, or requires recalibration for some other reason, record the results of the accuracy check in Part 1 of the Boat Record.

#### NOTE

WAAS is not currently approved for use by Coast Guard vessels. In the AUTO mode, the GP-37 runs with DGPS as the default setting. If the DGPS signal is lost for any reason, the WAAS mode is automatically selected. Consult the Furuno Operator’s Manual for the GP-37 DGPS Navigator to enable the AUTO mode from the Menu selection.

### G.8. GP-37 WAAS/DGPS Receiver and Navigator

The GP-37 WAAS/DGPS receiver and navigator (**Figure 3-48**) is mounted on the port face of the coxswain’s operating console. The GP-37 is totally integrated DGPS receiver and video plotter. The GP-37 can track up to 13 satellites (12 DGPS, 1 WAAS) simultaneously using the WAAS/DGPS receiver/antenna mounted on the radar pod.

Display modes available are: plotter, NavData (position indication in latitude, longitude or LORAN), steering (vessel course, position, speed), and highway. The GP-37 has five available alarm functions and a memory capacity of 1000 points of vessel track, 999 waypoints or marks, and 50 routes comprised of up to 30 waypoints. The GP-37 has an accuracy of 5 meters or better with DGPS and 3



---

meters or better with WAAS. The GP-37 requires a 12-VDC power source.

## CAUTION !

Magnetic compass deviation may occur when cabin electrical equipment (windshield wiper motors, cabin fan motors, heater, or flood lights) is energized creating energized creating Electro Magnetic Interference (EMI). EMI may also affect the magnetic compass at various engine RPMs.

### G.9. Magnetic Compass

A Ritchie magnetic compass (**Figure 3-48**) is mounted on the starboard dash panel, centered over the coxswain console. The magnetic compass shall only be used as an emergency backup compass if the PG-1000 Fluxgate compass and/or GP-37 WAAS/DGPS Receiver and Navigator fail. It is of the utmost importance that coxswains remain aware of the affects of Electro Magnetic Interference (EMI) caused by various energized electronic accessories and engine RPMs when using the magnetic compass. In the event of an electronic navigation system failure, coxswains and operational commanders must consider all available options, including anchoring to await an escort, during the risk assessment process.

The compass contains an internal gimbal system for maximum stability during adverse weather conditions. Built-in compensators provide for easy compass deviation adjustments. The blue dial is calibrated in white 5-degree increment markings. Lubber lines are provided at 45 degrees.


The magnetic compass must be calibrated on an annual basis. Compass calibration should be performed with all non essential accessories (heater, wipers, fans, flood lights, etc) secured, and at low engine RPM. With the non essential accessories secured, units should be able to calibrate the magnetic compass within 5 degrees. However, deviation greater than 5 degrees is not considered a restrictive discrepancy when accessories are energized or while traveling at higher RPM. A waiver to operate the Defender Class boat with excessive deviation when accessories are energized is not required. Multiple deviation tables that record deviation levels with various electronic accessories energized or under various engine RPM loads are also not required. The only requirement is to have a current deviation table on board. Units should document the fact that that the compass was adjusted with non essential accessories secured (windshield wipers, fans, heater, and flood lights).



**Figure 3-48**  
**Coxswain Console**

**G.10. PG-1000**  
**Heading Sensor**

The heading sensor (**Figure 3-49**) is mounted horizontally inside the cabin on the centerline, aft bulkhead under the step. The sensor detects terrestrial magnetism and produces heading data, which can be utilized by navigation system components that need accurate and stable heading input. The heading accuracy of the sensor is  $\pm 1$  degree. The compass sensor requires a 12-VDC power source.




**Figure 3-49**  
**Heading Sensor**



**G.11. 235DT-SSE Depth and Temperature Sensor**


The 235DT-SSE depth and temperature sensor (**Figure 3-50**) is mounted under the transom, on the centerline, aft of the step. The RD-30 multi-display has programmable alarm set-points and menu selectable displays for water temperature and depth that require input from the 235DT-SSE sensor.



**Figure 3-50**  
**Depth and Temperature Sensor**



**G.12. Antennas** All of the communications and navigation antennas (**Figure 3-51**) are mounted on the radar pod or on top of the cabin. The antennas and the radar pod can be lowered to allow for overhead clearance when the boat is loaded on the trailer for air transport.



**Figure 3-51**  
**Antennas (Defender B Class)**






## Section H. Electrical System

### Introduction

The electrical system consists primarily of two engine-driven alternators, two starting batteries, one accessory battery, and control devices and indicators.

### H.1. Alternators

Two alternators provide the charging power for the boats' batteries. Each 12 volt alternator is rated at 60 amps at 2300 RPM, and 48 amps at 1000 RPM. Each alternator is belt-driven and mounted on the outboard engine driveshaft. An indicator light, located on the engine switch key panel, will illuminate if the charging system is faulty. Each engine has a voltmeter (**Figure 3-52**) on the OHIP to indicate alternator output.



**Figure 3-52**  
**Voltmeters**



**CAUTION !**


If the 12-VDC power supplies trip off-line, secure the electronics and allow power supplies to cool. Visually check the individual or the main 75-amp breaker to see if it has tripped. Isolate the circuit (breaker off/open) until the system can be serviced.

**H.2. Batteries**


The boats' batteries (**Figure 3-53** (Defender A Class), **Figure 3-54** (Defender B Class)) consist of three 12-V gel-cell type batteries mounted on the port side under the forward crew seat. On the Defender B Class, a sliding battery tray (**Figure 3-54**) has been incorporated to provide battery accessibility for maintenance. On both boats, the batteries are vented (**Figure 3-55** (Defender A Class), **Figure 3-56** (Defender B Class)) to the exterior, port aft cabin bulkhead to prevent accumulation of charging gases. One additional battery vent is installed on the Defender B Class on the forward port cabin exterior bulkhead just aft of the heater exhaust.



**Figure 3-53**  
**Batteries (Defender A Class)**



**Figure 3-54**  
**Batteries (Defender B Class)**



**Figure 3-55**  
**Battery Box Vent (Defender A Class)**




**Figure 3-56**  
**Forward Battery Vent (Defender B Class)**

### **H.3. Battery Switches**

The battery disconnect switches and battery interconnect switch are mounted on the 12-VDC main power panel (**Figure 3-57**) located inside the cuddy cabin, port side. The panel has switches labeled as follows:

- PORT BATTERY
- STARBOARD BATTERY
- ELECTRONICS BATTERY
- INTERCONNECT FOR EMERGENCY USE ONLY

Under normal circumstances, the port and starboard batteries are operated independently for engine starting. However, if the individual battery fails to start the engine, the interconnect switch will parallel the two starting batteries.



**Figure 3-57**  
**12-VDC Main Power Panel**

H.3.a. Battery Isolator

The electronics battery is protected from over-charging by the use of an installed battery isolator.

H.3.b. Circuit Overload Protection

The 12-VDC main power panel (**Figure 3-57**) also incorporates a 75-amp breaker for circuit overload protection and a breaker for the electric cabin dewatering pump/breaker.




**H.4. 12-VDC  
Distribution  
Panels**

Three 12-VDC distribution panels (**Figure 3-58**) are located on the inboard side of the starboard cabin console. The panels provide circuit protection for shipboard electrical and electronic equipment. Listed below are the components served by each console on the Defender A Class and Defender B Class:

<b>Defender A Class</b>		
<b>Top Panel</b>	<b>Middle Panel</b>	<b>Bottom Panel</b>
Radar VHF radio (Raymarine) VHF radio (Motorola) Loudhailer <i>Four spare breakers</i>	Navigation lights Instruments lights Floodlights Strobe light Searchlights Deck lights Cabin lights <i>One spare breaker</i>	Heater Cabin fans Windshield wipers Horn 12-VDC outlets <i>Three spare breakers</i>

<b>Defender B Class</b>		
<b>Top Panel</b>	<b>Middle Panel</b>	<b>Bottom Panel</b>
Radar DGPS Depth sounder VHF 1 VHF 2 Loudhailer <i>Two spare breakers</i>	Navigation lights Instrument lights Floodlights Strobe light Searchlights Deck lights Cabin lights <i>One spare breaker</i>	Heater Cabin fans Windshield wipers Horn 12-VDC outlets Gunlocks <i>Two spare breakers</i>



**Figure 3-58**  
**12-VDC Distribution Panels**

---

**H.5. Ground**

A two-wire insulated return (ungrounded) 12-VDC system is used so that all grounds from electronic equipment are run back to the battery and are not grounded to the hull.

---







## Section I. Seating System (Defender A Class)

---

**Introduction** Two suspension-mounted seats are located at the port and starboard console. Bench seating is provided in the aft portion of the main cabin as well as in the cuddy cabin. All interior seats are equipped with seat belts.

---

**I.1. Seats** The two suspension-mounted seats (**Figure 3-59**) have an overall width of 24 inches and a height adjustment of 3 inches. There is a 6-inch forward and aft double-locking slide adjustment via a handle on the lower left portion of the seat. The backrest is adjustable and the armrests fold up to allow easy access. The seat back is contoured for lumbar support. The base is made of mild steel with steel fasteners. The base is equipped with a heavy-duty adjustable shock absorber designed for severe duty.

The bench seats are marine grade vinyl covered foam. The removable cushions are fastened with heavy-duty Velcro and the permanent cushions have a marine grade plastic incorporated to accommodate fastening screws.

**NOTE** 

Regular maintenance of the seats must be performed in accordance with PMS to ensure proper operation.

---



**Figure 3-59**  
**Forward Cabin Seat (Defender A Class)**



## Section J. Seating System (Defender B Class)

---

### Introduction

Two shock mitigating, suspension-mounted seats are located forward in the cabin just aft of the port and starboard operating consoles. Two shock mitigating seats are located inside the cabin, aft, port and starboard side. A padded bench seat is also located in the cabin. All interior cabin seats are equipped with seat belts.

---

### J.1. Forward Cabin Seats

The two forward cabin seats (**Figure 3-60**) have an overall width of 24 inches and a height adjustment of three inches. There is a six-inch forward and aft double locking slide adjustment via a handle on the lower left portion of the seat. The backrest is adjustable and the armrests fold up for easy access. The seat back is contoured for lumbar support. The base is made of mild steel with steel fasteners. The base is equipped with a heavy-duty adjustable shock absorber and is designed for severe duty.

---



**Figure 3-60**  
**Forward Cabin Seats (Defender B Class)**



## J.2. Aft Cabin Seats


The two aft cabin seats (**Figure 3-61**) are marine grade vinyl covered foam with mechanical, spring-loaded, shock mitigating adjustments (**Figure 3-62**) for the back of the seats. A stowage bag for the inboard seat belt section is provided on both aft seats.

### NOTE

Regular maintenance of the seats must be performed in accordance with PMS to ensure proper operation.



**Figure 3-61**  
**Aft Cabin Seat (Defender B Class)**



**Figure 3-62**  
**Rear Seat Back Tension Adjustment**





## Section K. Heating System

### Introduction

The cabin of Defender Class boats is heated by a 12,000-BTU combustion heater. The heated air is also used for defrosting or defogging the windshield.

### K.1. Heater

A 12,000-BTU combustion heater that utilizes diesel fuel is located inside the cabin, port side behind an access panel. The heater draws air from outside combustion (25%) and mixes it with cabin air (75%). The heater intake (**Figure 3-63**) is located on the port cabin exterior bulkhead, below the windshield. The heater incorporates a self-contained ignition system and a remote fuel pump.

Heater exhaust air is discharged from an opening on the port exterior cabin bulkhead (**Figure 3-63**).

### NOTE

Extreme cold temperatures may cause the diesel fuel to jell. Kerosene may be used when diesel fuel jelling occurs in the heating system.



**Figure 3-63**  
**Heater Intake and Exhaust**

### K.2. 30-Amp Breaker

A 30-amp breaker connects the heater to the 12-VDC electrical system.




**K.3.  
Thermostat**

The thermostat and ON-OFF switch (**Figure 3-64**) for the heater is located on the starboard dash panel, inboard and below the steering wheel.

**NOTE** 

To shut down the heater, turn temperature control to minimum, operate for two minutes, depress ON-OFF rocker switch in the *off* position.




**Figure 3-64  
Heater Thermostat**






**K.4. Diesel Fuel Tank**

On the Defender A Class, a six-gallon diesel fuel tank (**Figure 3-65**) is located on the aft weather deck, just aft of the port cabin bulkhead. On the Defender B Class, the diesel fuel tank (**Figure 3-66**) is located inside the starboard aft deck locker. On both boats there is a Delevan sediment filter between the fuel tank and dosing pump. On the Defender B Class, there is also a water guard filter downstream of the pump.



**Figure 3-65  
Heater Diesel Fuel Tank (Defender A Class)**



**Figure 3-66**  
**Heater Diesel Fuel Tank (Defender B Class)**




---

**K.5. Window Defrosters**

Window defrosters (**Figure 3-67**) are located atop the dash panel in the forward outboard corners.

---



**Figure 3-67**  
**Window Defroster**





## Section L. Trailing

---

### Introduction

The trailer (**Figure 3-68**) that accompanies Defender Class boats is custom built by E-Z Loader. It is designed to transport the Defender A Class (**Figure 3-69**) and Defender B Class (**Figure 3-70**) on roadways and allows the trailer and boat to be loaded onto a HC-130 aircraft for worldwide deployment.



**Figure 3-68**  
**Boat Trailer**

### L.1. General

The boat trailer and associated equipment are an important part of your boat's readiness. All too often, the trailer and tow vehicle do not receive the attention required to ensure proper operation. Proper maintenance and continual care of all trailering equipment is necessary.

### NOTE

The only trailer authorized for the Defender Class Boat is the EZ Loader Trailer designed for this class of boat.



**WARNING**

Lack of preventative maintenance contributes to a significant amount of trailering mishaps each year. Defender Class PMS requirements for the boat's trailer is contained in the Response Boat Small (Defender B Class) Preventative Maintenance Manual, TECH Pub 3909A. It is imperative that PMS is completed in accordance with this manual. If care and maintenance of the trailer is neglected, you may be endangering the safety of your boat, your crew, yourself, and the public.



**Figure 3-69**  
**Defender A Class and Trailer**



**Figure 3-70**  
**Defender B Class and Trailer**

**L.2. Tow Vehicle**

The tow vehicle must be capable of handling the weight of the trailer (with boat and equipment), as well as the weight of the passengers and equipment carried inside the vehicle. This may require that the tow vehicle be specially equipped with the following:

- Engine of adequate power.
- Transmission and rear-end designed for towing.
- Larger cooling systems for the engine and transmission.
- Heavy-duty brakes.
- Load bearing hitch attached to the frame, not the bumper.
- Heavy duty suspension

**NOTE**

The towing vehicle must be rated at the combined weight of the boat and trailer. The vehicle's towing limitations can be found in the owner's manual.

**NOTE**

If the combined weight of the boat, trailer, personnel, and equipment is too close to the tow vehicle's rating, consider using a second vehicle to transport some of the personnel and equipment to provide an additional safety margin.



### L.3. Hitch

The trailer hitch is attached to the tow vehicle's frame providing a secure fitting from which to attach the receiver and ball mount.

The Hitch shall be at a minimum a Class V hitch capable of carrying 10,000 lbs or greater. The hitch **must** be stamped (by the manufacturer) or have a sticker affixed from the manufacturer stating the class and the rated towing capacity (10,000 lbs. or greater).

### L.4. Ball Mount and Ball

The ball mount attaches to the trailer hitch providing a secure fitting to mount the trailer ball.

The ball mount must be capable of carrying trailer weight of 10,000 lbs or greater. The ball mount **must** be stamped (by the manufacture) or have a sticker affixed from the manufacture stating the rated towing capacity (10,000 lbs. or greater). If using a ball mount that requires the hardware (bolts and nuts), hardware must have a rating of 10,000 lbs. or greater.

The ball **must** be a 2 5/16", and have a rating of 10,000 lbs. or greater. It shall be stamped and **clearly** legible. The ball should be inspected often for cracks, abnormal wear, and proper lubrication. **(Figure 3-71)**

The height of the ball mount should be positioned so that the trailer will be pulled level. The tongue weight should be 800 lbs or less when the trailer is level. Adjusting the height of the ball mount is critical to ensure this condition is met.



**Figure 3-71**  
**Hitch, Ball Mount, and Ball Assembly**



### L.5. Trailer Coupler, Safety Chains and Hydraulic Brake Actuator

The trailer coupler attaches to the ball of the tow vehicle. The coupler engages the ball and provides a positive mechanical lock between the trailer and the tow vehicle. The coupler **must** be a 2 5/16" and have a rating of 10,000 lbs. or greater.

Two safety chains attached to the trailer provide trailer retention to the vehicle should the coupler disengage from the ball. The safety chains **must** be ½" galvanized steel. One end of the safety chains are bolted directly to the trailer. The bitter ends are to be attached to the tow vehicle's hitch with ½ inch galvanized screw pin shackles that are rated at 2 tons.

The breakaway lever actuating chain (Hydraulic Brake Actuator) is attached to the vehicle during towing operations. Should the coupler disengage from the ball, the breakaway lever actuating chain will be pulled forward actuating the breakaway lever automatically applying the trailer's brakes. The hydraulic brake actuator safety chain **must** be attached to the hitch using ¼" shackle and an additional ½" shackle. The breakaway level actuating chain is a standard length and should not be altered in any way. (Figure 3-72)




Figure 3-72  
Trailer Coupling Assembly



**NOTE** 

Always use a designated “spotter” when hooking up the trailer. The spotter can provide detailed instructions to the tow vehicle operator when backing up which will prevent damage to both the tow vehicle and trailer.

### L.6. Pintle Hook and Lunette Eye Configuration for MSSTs

Because of their unique operating requirements, MSSTs are authorized to use a pintle hook and lunette eye hitch system when deploying with Department of Defense, aviation units, or at the discretion of the unit’s commanding officer. The pintle hook and lunette eye components must have a rating of 10,000 lbs or greater, and be installed in accordance with the manufacturer’s instructions. It shall be stamped and **clearly** legible. The pintle hook and lunette eye should be inspected often for cracks and abnormal wear. When the pintle hook is in use, the ball and coupler assembly must be carried in the outfit kit. **(Figure 3-73)**



**Figure 3-73**  
**Pintle Hook**

### L.7. Trailer Construction and Equipment

The primary frame of the trailer is made up of 4 X 6-inch aluminum “I”-beams. The suspension is a torsion axle system. The trailer is a six-wheel configuration (three on each side) with one spare and an E-Z Jack. The wheels are attached to the hub system.

The Defender A Class uses conventional incandescent bulbs for trailer brake, tail, and clearance lights. The Defender B Class uses LEDs for trailer brake, tail, and clearance lights.

The E-Z Jack was designed as an easy-to-use, safe, and reliable device for changing tires on tandem axle trailers. Its unique rocker shape allows trailer operators to simply drive the trailer onto the E-Z Jack to elevate entire trailer side of the tire to be changed.



### L.8. Hooking up the Trailer

When hooking the tow vehicle up to the trailer, the same procedures should be done every time. Whether your transiting to a local boat ramp just down the road or going on a long trip, the trailer should always be completely attached to the tow vehicle. **(Figure 3-74)**

Follow these steps for attaching the trailer to the tow vehicle:

Step	Procedure
1	Using a spotter, carefully back the tow vehicle so that the trailer ball is aligned under the trailer’s coupler.
2	Using the hand-crank jack, lower the trailer coupler until it is completely seated on the trailer ball.
3	Engage the coupler latch and insert the coupler latch pin to ensure it does not come undone during transit. NOTE: The coupler latch pin should have a lanyard long enough to facilitate insertion and removal.
4	Attach the safety chains. They shall be crisscrossed and have enough slack to allow for sharp turns in both directions yet short enough to not drag on the ground.
5	Attach the breakaway level actuating chain ensuring there is enough slack to allow for sharp turns in both directions.
6	Connect the wiring harness to the tow vehicle. The wiring harness (pig tail) should have enough slack to allow sharp turns in both directions and short enough as to not drag on the ground.
7	Check trailer lights to ensure they are operating properly.

**NOTE**


The wiring on the trailer’s wiring harness should be a 7-4-2 configuration.

**CAUTION !**

Once connected to the tow vehicle, ensure the trailer is being towed level to the ground. If the trailer is not level to the ground, a drop bar/ball mount of a different height may be necessary and/or the trailer coupler may need adjustment.

**WARNING** 

Do not exceed the maximum weight rating on the trailer. Exceeding the maximum rating voids the manufacturer's warranty and may lead to failure of the trailer causing damage to the boat and creating an unsafe towing condition.



**Figure 3-74**  
**Trailer Hook-Up**

### L.9. Securing the Boat to the Trailer

Before taking the trailer and boat into tow, you must first ensure that the boat is properly secured to the trailer. **Damage to the boat and trailer could result if the two are not connected.**

Tie-down straps must be attached and tightened between the pad-eyes found on the boat and trailer prior to transporting the boat. Placement is as follows:

- One on each side of the transom (**Figure 3-75**),
- One on each side forward (**Figure 3-76**),
- Belly strap and
- A strap attaching the trailer eyebolt to the trailer (**Figure 3-77**).

**Tie-downs shall be rated for at least 6,000 lbs.,** and be the same style and model as the issued tie-downs that came with the EZ Loader Trailer.

The bow of the Defender B Class / HS should remain 1 to 2 inches away from the bow stops when properly trailered. (**Figure 3-78**)

The winch strap shall not be used as a tie down and not exceed light strain.

The Defender B Class is outfitted with a window guard/screen, and should be in place for highway traveling.



**NOTE** 


Trailer chaffing skids or “Bunk” must be kept in good condition to prevent scratching and gouging of the hull.



**Figure 3-75**  
**Trailer to Transom Tie Down**



**Figure 3-76**  
**Boat Trailer, Bow Tie Down**



**Figure 3-77**  
**Boat Trailer, Forward Tie Down**



**Figure 3-78**  
**Spacing Between Bow and Bow Stops**



---

### L.10. Towing Precautions

Pulling a trailer presents several problems: more time is required to brake, accelerate, pass, and stop. The presence of the boat on the trailer will increase the size of the vehicle's blind spots, especially when using rear view mirrors for backing. The turning radius is also much greater; curbs and roadside barriers must be given a wide berth when negotiating corners.

Prior to operating on the open road, the vehicle operator should practice turning, backing up, and other maneuvers on a level, non-congested parking area. Backing a trailer is a challenge even to the most experienced drivers and requires considerable practice.

### CAUTION!

Use a spotter when backing or maneuvering in tight quarters. The boat and trailer will hinder the driver's ability to judge distances and negotiate turns.

The Defender Class boat and trailer is closely matched to the minimum trailer-truck-hitch requirements. Safe trailering requires that the trailer be properly balanced and loaded. Overloading a trailer on the highway is as dangerous as overloading your boat on the water. Carrying additional equipment (beyond the boat outfit) or personal gear on the boat may add substantially to the trailer's gross weight and play havoc with the load distribution.

### WARNING

Do not overload the trailer by carrying additional equipment or personal gear in the boat.

### NOTE

Many units require tow vehicle operators to complete a unit generated Performance Qualification Standard (PQS) before they tow a trailer.

---



### L.11. Trailering Checklist

Before your trip, ensure the following items have been checked:

- Check intended routes for restrictions on bridges and tunnels, and low overhead clearances. All antennas and the anchor light mast should be rotated to the down position. With the antennas and the anchor light mast in the down position, the highest point of the trailered boat becomes the top of the radar dome, at 11' 1/2".
- Lower the taff rail to the horizontal position to provide additional protection to the outboard engines.
- Ensure the tow ball and coupler are the same size and bolts with washers are tightly secured. (The vibration of road travel can loosen them.)
- Confirm the coupler is completely over the ball and the latching mechanism is locked down and secured with locking pin. If using a pintle/lunette eye, ensure the pintle is properly engaged.
- Ensure the safety chains are securely attached, crisscrossing under the coupler, to the hitch of the tow vehicle. If the ball were to break, the trailer's tongue would be held up by the chains allowing the trailer to follow in a straight line and prevent the coupler from dragging on the road.
- Ensure the hydraulic brake actuator safety chain is attached to the hitch.
- Ensure the jack is fully cranked up.
- The side-view mirrors of towing vehicles should be large enough and adjusted to provide an unobstructed rear view on both sides of the vehicle.
- Check that the wiring is properly connected - not touching the road, but loose enough to make turns without disconnecting or damaging the wires. Make sure all trailer running lights, brake lights, turn signals, and hazard lights are working on both the tow vehicle and trailer. When trailer lights are submerged during launching/recovery they have a greater chance of failure and should be serviced more frequently. Always disconnect the trailer-wiring harness from tow vehicle before submerging the trailers lights.
- Check the brakes. Lightly test before getting on a major road. On a level parking area, roll forward and apply the brakes several times at increased speeds to determine a safe stopping distance.
- Check tires, including the trailer's spare tire and towing vehicle tires for condition and proper inflation. Improper inflation may cause difficulty in steering. Read the tire sidewall to determine tire pressure required. Also check for tire wear, cracks, bubbles, or foreign objects imbedded in the tire. When trailer wheels are immersed in water (especially salt water) the bearings should be inspected and greased on a regular basis in accordance with PMS procedures. Make sure the wheel lug nuts/bolts on the tow vehicle and trailer are tightened to the correct torque.



- Check all spaces for standing water (rainwater or water from cleaning). Standing water is undesirable for many reasons, but mainly because a collection of it can rapidly increase weight on the trailer, often beyond its capacity. Furthermore, the extra weight may shift with the movement of the trailer and cause a dangerous situation.
- Check load distribution to make sure the tow vehicle and trailer are properly balanced front and back and side to side. Too much weight on the hitch will cause the rear of the tow vehicle to sag and may make steering more difficult. This can also cause your headlights to shine into the eyes of oncoming traffic.
- Use wheel chocks when parking the trailer.
- Double check all connections, safety chains, breakaway lever actuating chain, wiring harness, and tie down straps are properly secured/connected.

**WARNING** 

In accordance with COMDTINST M16114.28 do not tow any trailer faster than 55 MPH – some states 45 MPH.

---





## L.12. Launching the Boat

Once at the boat ramp, use the following procedures to launch the boat:

Step	Procedure
1	Using a spotter, carefully back the trailer down the boat ramp to the water's edge. Set parking break.
2	Remove all of the tie-down straps that secure the boat to the trailer. <b>DO NOT disconnect the trailer winch connection.</b>
3	Disconnect trailer-wiring harness from tow vehicle.
4	Visually inspect the boat's hull and engines for any damage that may have occurred during transit.
5	Place crew onboard the boat and have crew member stand-by to release the trailer winch connection.
6	Carefully back the trailer into the water until approximately three-quarters of the boat is floating free of the trailer. Set the towing vehicle's parking break.
7	Check spaces for flooding.
8	Lower engines into the water and start. Ensure the water level in the vicinity of the outboards is sufficient for operation and clear of hazards.
9	If crew is satisfied with condition of boat/engines and is ready to get underway, release the trailer winch connection and carefully push/power the boat back off the trailer.
10	Carefully pull tow vehicle forward clear of boat ramp.

### NOTE

After launching or recovering the boat, always rinse down the trailer with fresh water and check the trailer lights for proper operation.

### CAUTION !

During recovery, ensure 1 to 2 inches of space remains between the bow and the bow stops. This will ensure proper loading and weight distribution.

### CAUTION !

**Always use a spotter when backing a trailer!** Windows should be open and radio should be off.



**L.13.  
Recovering the  
Boat**

When finished with boat operations, use the following procedures to recover the boat:

<b>Step</b>	<b>Procedure</b>
1	Disconnect trailer-wiring harness from tow vehicle. Set parking brake.
2	Using a spotter, carefully back trailer down the ramp until approximately three-quarters of the trailer is submerged.
3	Align the center of the boat with the center of the trailer and carefully maneuver the boat onto the trailer. <b>Check water level in the vicinity of the trailer and trim engines up or secure as needed.</b>
4	Attach trailer winch to bow of boat and pull boat forward onto the trailer until 1 to 2 inches of space remains between the bow and the bow stops. <b>Always ensure boat stays centered on trailer.</b>
5	Secure engines on boat (if still running).
6	Slowly pull the tow vehicle forward until the trailer is clear of the water.
7	Attach all tie-down straps securing the boat to the trailer. Lower antennas and anchor light mast before transporting on roadways.
8	Ensure trailer lighting is operating properly.
9	Do a complete visual inspection of the tow vehicle, trailer, and boat before transiting on highway.



## Section M. Weapons Mounting/Stowage

---

**Introduction** The fore and aft tow bits on Defender Class boats are designed to provide the foundation for and accommodate the MK 16 MOD 8 stand for a weapons system to be determined by Commandant (G-R).

**NOTE** 

Weapons allowances for Coast Guard boats are established by G-RPC.

---

**M.1. Pedestal Stands**

The MK 16 MOD 8 stands may be mounted on the forward and aft tow bits. The stands can receive various weapons and are equipped with stops to prevent discharging the weapon toward the hull.

---

**CAUTION !**

The MK-16 MOD 8 stand is the only stand authorized for use aboard Defender Class Boats. The MK-16 MOD 8 stand shall be used with the MK-97 mount (for the M-240 machine gun) or the MK-82 mount (for the M-60 machine gun). Under no circumstances shall the UTB M-60 mount be used aboard Defender Class Boats, as these mounts are one-of-a-kind design, specifically made to work only on UTBs. Units should contact their servicing armory if in doubt as to the appropriate weapon or weapon mount configuration.

---

**M.2. Machine Gun Elevation and Train Stop Limits**

The bow mount setting for train should be set to 060 degrees to starboard and 300 degrees to port. This setting allows for 120 degrees of train on the bow mount. The bow mount setting for depression should stay at the stock depression setting with the depression stop bolt in its lowest position. In this manner the weapon will not engage any of the boat's structure and will allow for approximately 050 degrees elevation and -015 degrees depression.

The stern mount setting for train should be set to 045 degrees to starboard and 315 degrees to port. This setting allows for 270 degrees of train on the stern mount. The stern mount settings for depression should be set at approximately -005 degrees. At this setting, the elevation will be approximately 050 degrees. When employed, the taffrail must be lowered to its intermediate position to provide an unobstructed field of fire.

---

**CAUTION !**

When the aft machine gun is mounted, the taffrail must be lowered to its intermediate position to provide an unobstructed field of fire.

---

**M.3. Ammunition Stowage**

Ready service ammunition for the forward gunner is stowed in the anchor locker depicted in **Figure 3-79**. Ready service ammunition for the aft gunner is stowed in the cabin.

---



**Figure 3-79**  
**Ammunition Stowage**



**M.4. Weapon Locks/Mounts**

On the Defender A Class, secure, lockable mounts (**Figure 3-80**) for the Coast Guard modified 12-gauge shotgun and M16 rifle are provided on bulkheads inside the aft cabin. The Defender B Class utilizes Santa Cruz electrically-operated weapon locks/mounts (**Figure 3-81**) with backup key override.



**Figure 3-80**  
**Weapon Lock/Mount (Defender A Class)**



**Figure 3-81**  
**Weapon Locks/Mounts (Defender B Class)**





## Section N. Hull Exterior Lighting (Defender A Class)

---

**Introduction** The Defender A Class is equipped with exterior lighting to comply with international marine operating requirements for specific mission operations and crew safety.

---

**N.1. Searchlight** The searchlight (**Figure 3-82**) is mounted on the centerline atop the cabin and is controlled by a remote control panel (**Figure 3-83**) mounted on the OHIP. The searchlight is rated at 200,000 candlepower and can be rotated 360 degrees. The beam can be elevated 9 degrees up and 17 degrees down.

---



**Figure 3-82**  
**Searchlight (Defender A Class)**




**Figure 3-83**  
**Searchlight Control (Defender A Class)**

**N.2. Light Switch Panel**

The light switch panel (**Figure 3-84**) is located on the approximate centerline of the OHIP. The following lights are controlled from the light switch panel:

Port (red) navigation light <b>(Figure 3-85)</b>	Port forward on upper cabin bulkhead
Starboard (green) navigation light	Starboard forward on upper cabin bulkhead
Anchor light (white) <b>(Figure 3-82)</b>	Atop the flag mast
Port and starboard floodlights <b>(Figure 3-86)</b>	Port and starboard on the side of radar pod
Aft floodlights <b>(Figure 3-86)</b>	Aft port and starboard on the aft frame of radar pod
Exterior (deck edge) lights <b>(Figure 3-87)</b>	Exterior cabin bulkhead, port and starboard, outboard along the deck edge
Law enforcement lights (2) (blue)	Atop the radar pod, port and starboard






**Figure 3-84**  
**Light Switch Panel (Defender A Class)**



**Figure 3-85**  
**Navigation Light (Defender A Class)**



**Figure 3-86**  
**Floodlights (Defender A Class)**



**Figure 3-87**  
**Exterior (Deck Edge) Light (Defender A Class)**




## Section O. Hull Exterior Lighting (Defender B Class)

### Introduction

The Defender B Class is equipped with exterior lighting to comply with collision regulations (COLREGS) for specific missions.

### O.1. Searchlight

The searchlight (**Figure 3-88**) is mounted on the centerline atop the cabin and is controlled by a remote control panel (**Figure 3-89**) mounted on the OHIP. The searchlight is rated at approximately 180,000 candlepower and can be rotated 360 degrees.



**Figure 3-88**  
**Cabin Roof Lights (Defender B Class)**




**Figure 3-89**  
**Searchlight Control (Defender B Class)**

**O.2. Light Switch Panel**

The light switch panel (**Figure 3-90**) is located on the starboard side of the OHIP above the coxswain. The following lights are controlled from the light switch panel:

Port (red) navigation light ( <b>Figure 3-91</b> )	Port forward on upper cabin bulkhead
Starboard (green) navigation light ( <b>Figure 3-92</b> )	Starboard forward on upper cabin bulkhead
Anchor light (white) ( <b>Figure 3-88</b> )	Atop the flag mast
Port and starboard floodlights ( <b>Figure 3-93</b> )	Port and starboard on the side of radar pod
Aft floodlights ( <b>Figure 3-93</b> )	Aft port and starboard on the aft frame of radar pod
Exterior (deck edge) lights ( <b>Figure 3-92</b> )	Exterior cabin bulkhead, port and starboard, outboard along the deck edge
Law enforcement lights (2) (blue) ( <b>Figure 3-93</b> )	Atop the radar pod, port and starboard




**Figure 3-90**  
**Light Switch Panel (Defender B Class)**



**Figure 3-91**  
**Port Navigation Light (Defender B Class)**



**Figure 3-92**  
**Starboard Navigation Light and Deck Edge Lights (Defender B Class)**



**Figure 3-93**  
**Floodlights and Law Enforcement Lights (Defender B Class)**




### O.3. Towlight Mast

A collapsible towlight (Figure 3-94) mast is stowed inside the cabin on the aft bulkhead, above the cabin door. When required, it can be quickly erected on the port aft side of the radar pod (Figure 3-95) and extended and locked into place using a ball-lock pin. Two electrical connectors labeled Tow #1 and Tow #2 (astern and alongside towing) mate with a 12-VDC utility receptacle located on the horizontal aft port surface of the radar pod.



**Figure 3-94**  
**Towlight Mast Stowed (Defender B Class)**





**Figure 3-95  
Towlight Mast**





## Section P. Ancillary Systems and Furnishings

---

**Introduction** This section discusses ancillary systems and furnishings that are installed on or furnished with Defender Class boats.

---

**P.1. Windshield Wipers and Washer** Defender Class boats utilize two 12-VDC dynamic park windshield wiper motors (**Figure 3-96**) mounted in the cabin, port and starboard, adjacent to and outboard of the windshields. Two microprocessor controlled, wiper switches (**Figure 3-97**), mounted on the OHIP starboard side, control the wiper motor and washer operation. The switch has six positions:

- Off/Park
- Long Delay
- Intermittent Delay
- Short Delay
- Low Speed/High Speed

Depressing the switch will actuate the wipers for three cycles and inject the windshield wash solution. A 4-liter windshield wash reservoir is mounted in the cabin.

---

**P.2. Cabin Fans** Defender Class boats have cabin fans (**Figure 3-96**) mounted on the OHIP, outboard port and starboard. The fans can be adjusted stationary or 120 degrees oscillation. The fans require 12 VDC and utilize an ON-OFF switch mounted on the base of the fan.

---



**Figure 3-96**  
**Windshield Wiper Motor and Cabin Fan**



**Figure 3-97**  
**Windshield Wiper Switches**



---

**P.3. Fire Extinguisher(s)**

Defender Class boats have two B-1 type fire extinguishers (**Figure 3-98**) installed. One is mounted in the cabin, port side on the heater access panel, and one is mounted in the starboard aft deck locker. Each extinguisher contains approximately two pounds of dry chemical agent (ammonium phosphate) that will discharge in 9 to 10 seconds once the handle is activated. This type of extinguisher is designed to be used on Class A, B, and C fires.

---



**Figure 3-98**  
**B-1 Type Fire Extinguisher**

---

**P.4. First Aid Kit**

One first aid kit is provided with each Defender Class boat and is stowed inside the cabin. The first aid kit contains four modules equipped to treat injuries normally encountered during craft underway evolutions. Each module contains specific supplies to treat common first aid problems, cuts and splinters, sprains and fractures, CPR, and burns. The kit also contains a place to store personal over-the-counter medications and prescription drugs.

---



### **P.5. Cabin Dome Lights**

Two cabin dome lights (**Figure 3-99**) are installed on the overhead at the centerline, fore and aft inside the cabin. The dome lights operate on 12 VDC and have a base mounted switch for red or white illumination.



**Figure 3-99**  
**Cabin Dome Light**



---

**P.6. Horn**

A 12-VDC diaphragm type horn (**Figure 3-100**) is mounted on the forward port face of the radar pod. The horn is actuated by a switch on the OHIP in the cabin and produces a 106-decibel blast.

---



**Figure 3-100**  
**Horn**

---

**P.7. Miscellaneous Stowage**

Areas to stow approved deck gear and mission essential equipment are located under the aft cabin seats on the Defender A Class and Defender B Class. On the Defender A Class and Defender B Class, the boat hook is stowed inside, on the aft cabin door. The Defender A Class has a holder for fenders on the starboard aft exterior cabin bulkhead.

---

**P.8. Emergency Position Indicating Radio Beacon**

Defender Class boats are outfitted with a Category II, 406 MHz EPIRB (**Figure 3-101**). These EPIRBs are manually deployable, self-buoyant units equipped with a self-test feature that confirms operation as well as battery condition and GPS position data. The EPIRBs use GEOSAR satellites that are in geostationary high-earth orbit and can instantly relay emergency transmissions. The EPIRB provides location accuracy to 0.05 NM and can provide data to search and rescue (SAR) units within 5 minutes after activation and signal detection. A monthly inspection shall be conducted in accordance with the Rescue and Survival Systems Manual, COMDTINST M10470.10 (series).

---



**Figure 3-101**  
**EPIRB**

**P.9. Deck  
Matting**

---

Defender Class boats are outfitted with a sound and fatigue mitigating deck matting. Replacement matting can be procured through SAFE Boats International.

---





## Chapter 4 Crew Requirements

---

### Introduction

The *U.S. Coast Guard Boat Operations and Training (BOAT) Manual, Vol. I*, COMDTINST M16114.32 (series), provides minimum standards and guidelines for competence onboard Defender Class boats. Each crewmember should be familiar with the duties of the other crewmembers in addition to his/her own duties. It is important for a crewmember to know and commit to memory all important characteristics of the boat and its equipment, and which procedures to follow in the event of a casualty. Each crewmember should mentally rehearse the procedures each member of the crew would follow during any operational casualty. Teamwork is the common thread that allows the crew to succeed. Whenever the opportunity is available, the crew should get the boat underway to practice operational and emergency procedures.

---

### In this Chapter

This chapter contains the following sections:

Section	Topic	See Page
A	Minimum Crew	4-3
B	Coxswain	4-5
C	Crew Members	4-7
D	Passengers	4-9
E	Safety Equipment	4-11

---





## Section A. Minimum Crew

---

### **Introduction**

Units shall comply with the minimum boat crew requirements prescribed in the *U.S. Coast Guard Boat Operations and Training (BOAT) Manual, Volume I, COMDTINST M16114.32 (series)*.

---

### **A.1. Certified Crew**

The minimum crew of two shall be a coxswain and a crew member. All crewmembers shall meet the qualification requirements prescribed in the *U.S. Coast Guard Boat Operations and Training (BOAT) Manual, Vol. II, COMDTINST M16114.33 (series)*.

---





## Section B. Coxswain

---

### Introduction

The U.S. Coast Guard places great trust in each coxswain and his or her ability to accomplish the assigned missions in a safe and professional manner even under adverse conditions. The position of coxswain is one of high regard and great responsibility.

The coxswain is responsible for the boat, its crew, and passengers during every mission. The coxswain assigns and directs all onboard functions during each operation.

---

### B.1. Authority and Responsibility

The extent of the authority and responsibility of the coxswain is specified in *U.S. Coast Guard Regulations*, COMDTINST M5000.3 (series), as follows:

*“The coxswain shall be responsible, in order of precedence, for the safety and conduct of passengers and crew; the safe operation and navigation of the boat assigned; and the completion of the sortie or mission(s) assigned or undertaken pursuant to USCG policy and regulations. An underway coxswain will at all times respond, within the limits of capabilities and legal authority, to observed hazards to life or property, and violations of law or regulations.”*

The coxswain is the direct representative of the Commanding Officer (CO) or Officer-in-Charge (OIC) and as such, (subject to *Articles 88-89* of the *UCMJ*) has the authority and responsibilities that are independent of rank or seniority in relation to other personnel embarked. The authority and responsibility of the coxswain exist only when the boat is engaged on a specific sortie or mission.

---

### B.2. Relief of Responsibility

The only person embarked in the boat who may relieve the coxswain of the responsibility as described above is:

- The CO, OIC, Executive Officer (XO), or Executive Petty Officer (XPO).
  - A senior officer at the scene of a distress emergency or other abnormal situation, who exercises authority under the provisions of *U.S. Coast Guard Regulations*, COMDTINST M5000.3 (series), whether or not other units are involved.
-



## Chapter 4 – Crew Requirements



## Section C. Crew Members

---

**Introduction** Under direct supervision of the coxswain, the crew is responsible for line handling, acting as lookout, and assisting the coxswain as required during all evolutions or maneuvers.

---

**C.1. Certified Crew Member** The crew member must be certified in accordance with the *U.S. Coast Guard Boat Operations and Training (BOAT) Manual, Vol. I*, COMDTINST M16114.32 (series) and *U.S. Coast Guard Boat Operations and Training (BOAT) Manual, Vol. II*, COMDTINST M16114.33 (series).

Additionally, the crew member may be responsible for operating the communications/navigation equipment as directed by the coxswain.

---

**C.2. Additional Crewmembers** Additional crewmembers are assigned by the coxswain and certified by the CO/OIC based upon mission requirements.

---



## Chapter 4 – Crew Requirements





## Section D. Passengers

---

### **Introduction**

Defender Class boats are designed to carry up to four crew in the cabin. Six additional crew or passengers can be carried in support of various missions not to exceed designed weight capacity. Crew and passengers shall be seated as directed by the coxswain.

---





## Section E. Safety Equipment

### E.1. Personal Protective Equipment

During all boat operations, crewmembers shall wear PPE as required by the *Rescue and Survival Systems Manual*, COMDTINST M10470.10 (series).

#### WARNING

The use of the engine kill switch is required whenever the boat is started or is underway. The engine kill switch/s is located beside the start switch. The activation clip for the kill switch **MUST** be inserted into the switch body to start the engine. The lanyards (**Figure 3-8** (Defender A Class), **Figure 3-9** (Defender B Class)) **MUST** be properly attached to the coxswain at all times during boat operation. A second kill switch lanyard with activation clip **MUST** be carried onboard to enable remaining crewmembers to operate the boat in the event the coxswain is ejected.

#### NOTE

The Defender A Class utilizes two control panels with warning indicators for starting and stopping the outboard engines. Each control panel has an engine kill switch. The Defender B Class has a single control panel with warning indicators for starting and stopping the outboard engines. The Defender B Class control panel has only one engine kill switch, which if removed, will stop both engines.

#### NOTE

The coxswain is responsible for ensuring that all required personal safety equipment is worn, and worn correctly.

### E.2. Seat Belts and Helmets

Since Defender Class boats carry out a wide array of missions in an ever changing environment, the decision of when to wear seat belts and/or helmets remains at the unit level.

Commanding Officers and Officers in Charge shall routinely discuss seat belt and helmet use with their crews and establish unit policy. Sector Ready For Operations teams shall ensure units have adequate seat belt and helmet policies in place.


Prior to getting underway, as well as throughout the mission, boat crews shall continuously assess and manage risks in accordance with Team Coordination Training, COMDTINST 1541.1 (series) and Operational Risk Management, COMDTINST 3500.3 (series). During these assessments the crew should consider whether or not seat belts and/or helmets should be worn. Factors for the crew to consider are:


- Sea State
- Time of day
- Mission
- Anticipated boat speed and maneuvering.



---

As always, the coxswain is ultimately responsible and accountable for the safety of the crew and the boat, as well as the mission. Adherence to unit seat belt and/or helmet policies and safe boat operations are expected at all times.

**NOTE**  No single piece of Personal Protective Equipment (PPE) will completely eliminate the risk of personal injury that can result when operating a boat irresponsibly. A combination of PPE and prudent, responsible boat handling is required to prevent injury. Seat belts, helmets, and other protective equipment work only to reduce injury. The best way to prevent injuries is to operate the boat responsibly and follow the operational risk management process.

**NOTE**  Crews are encouraged to “buckle up” regardless of speed, sea state, or mission. Groundings, collisions, and the need to make sudden, unannounced maneuvers can occur at any time. Using seat belts is your best defense from injury. Wearing seatbelts at all times is a good habit to learn and practice.

---



## Chapter 5

# Operational Guidelines

---

### Introduction

This chapter describes how to use Defender Class boats in the safest and most efficient manner. These policies and performance criteria should be used as guidelines for boat operations. Within these guidelines, consider *Navigation Rules, International-Inland*, COMDTINST M16672.2 (series), local operating conditions, and the skill of the crew to determine how Defender Class boating capabilities are to be used. These factors must be considered prior to each sortie or mission.

---

### In this Chapter

This chapter contains the following sections:

Section	Topic	See Page
A	Operating Parameters	5-3
B	Performance Data	5-7
C	Performance Monitoring	5-10

---





## Section A. Operating Parameters

---

### Introduction

The readiness of Defender Class boats shall be continuously monitored to ensure that they are capable of unrestricted operations. This monitoring is accomplished through a variety of programs, including daily boat checks, the boat preventive maintenance system (PMS) schedule, engineering inspections, and ready for operation (RFO) evaluations.

Operating parameters for Defender Class boat crewmembers include the following areas:

- Disabling Casualties
  - Restrictive Discrepancies
  - Major Discrepancies
  - Minor Discrepancies
  - Responsibilities
  - Environmental Limits
- 

### A.1. Disabling Casualties

Disabling casualties are those that make the boat not serviceable. *Appendix D* contains a listing of disabling casualties. If a disabling casualty is identified, the boat shall not get underway until the casualty is corrected, and command notifications are made.

Disabling casualties shall be reported immediately to the CO/OIC. The boat shall be immediately placed in “Charlie” status and repaired. If the casualties cannot be repaired within 48 hours, a casualty report (CASREP) shall be sent within 24 hours of the casualty.

---

### A.2. Restrictive Discrepancies

Restrictive discrepancies are those that restrict the operations of the boat such that it can perform some, but not all, missions safely. *Appendix E* contains a listing of restrictive discrepancies.

---

#### A.2.a. Reporting Restrictive Discrepancies

Restrictive discrepancies shall be reported to the CO/OIC if the discrepancy cannot be repaired within 1 hour. The boat shall be immediately placed in “Charlie” status and shall not get underway until the discrepancy is corrected, or a waiver has been received. If the discrepancy cannot be repaired within 48 hours, a CASREP shall be sent within 24 hours of the discrepancy. The CO/OIC is responsible for monitoring the progress of repairs to these discrepancies.

---



Step	Procedure
1	The coxswain shall immediately notify the CO/OIC with all pertinent information and a recommendation as to whether to continue or abort the mission.
2	The CO/OIC shall notify the coxswain as to whether or not continuing the mission is authorized and the conditions under which the boat may be operated.

**A.3. Major Discrepancies**

Major discrepancies are those that degrade the effectiveness of the boat to perform one or more missions. *Appendix E* contains a listing of major discrepancies.

**A.4. Minor Discrepancies**

Minor discrepancies do not affect the operational readiness of the boat. However, a boat with minor discrepancies does not meet the standardization criteria established for the boat.

In the event that the addition of portable equipment, not part of the standard boat outfit, is necessary to meet mission needs, units are authorized to temporarily carry this extra equipment. This authorization is on a case-by-case basis only, and care must be taken to properly secure any extra gear and to ensure it does not interfere with safe egress or the boat's standard outfit/systems. Under no circumstances shall permanent alterations be made to power, stow or in any way accommodate extra equipment.

**A.5. Responsibilities**

The coxswain is always responsible for the safe operation of the boat. The coxswain must decide if the mission warrants subjecting the crew and boat to the danger defined by the mission, weather, and sea conditions anticipated.

**A.5.a. Disabling Casualty - Underway**

In the event that the boat sustains a disabling casualty while underway, the boat crew shall inform the coxswain who will immediately contact the CO/OIC or Operational Commander.





A.5.b.  
Restrictive  
Discrepancy -  
Underway

In the event the boat sustains a restrictive discrepancy while underway, the coxswain should not normally proceed without authorization, unless aborting the mission would increase the level of risk. The situation and recommendations must be effectively communicated to the Operational Commander to allow for prudent risk assessment by all levels. The following is the procedure for communicating the discrepancy while underway:

Step	Procedure
1	The coxswain shall immediately notify the CO/OIC with all pertinent information and a recommendation as to whether to continue or abort the mission.
2	The CO/OIC shall notify the coxswain as to whether or not continuing the mission is authorized, and the conditions under which the boat may be operated.

A.5.c. Major  
Discrepancy

The occurrence of major discrepancies shall be documented. A plan to correct these discrepancies shall be formulated and carried out. The Operational Commander is responsible for monitoring the status of repairs to these discrepancies.

A.5.d. Minor  
Discrepancy

The occurrence and repair of minor discrepancies shall be documented and monitored at the unit level.



<b>Casualty/Discrepancy</b>	<b>Consequence</b>	<b>Required Action</b>
<p><b><u>Disabling Casualty</u></b></p> <p>“Boat is not serviceable.”</p>	<p>Not authorized to get underway.</p> <p>Notify the CO/OIC immediately.</p>	<p>Assign “Charlie” status to the boat, and commence repairs immediately. Submit CASREP if applicable.</p>
<p><b><u>Restrictive Discrepancy</u></b></p> <p>“Boat and crew cannot perform <u>all</u> missions safely.”</p>	<p>Operations restricted.</p> <p>Notify CO/OIC if repairs cannot be made in 1 hour.</p>	<p>Create repair plan and set deadline for completion of repairs. CO/OIC shall monitor progress of repairs. Any operations before restrictive discrepancies are repaired require written waiver by the Operational Commander. Submit CASREP if applicable.</p>
<p><b><u>Major Discrepancy</u></b></p> <p>“Boat and crew can perform all missions but <u>some</u> degradation in effectiveness or readiness should be expected.”</p>	<p>Operations unrestricted.</p> <p>Discrepancy occurrence and repair is documented.</p>	<p>Maintenance plan is carried out. CO/OIC shall monitor status of repairs to the discrepancies.</p>
<p><b><u>Minor Discrepancy</u></b></p> <p>“Boat and crew readiness not affected nor impaired. Boat does not meet standards.”</p>	<p>Operations unrestricted.</p> <p>Discrepancy occurrence and repair is documented.</p>	<p>Maintenance plan is carried out. CO/OIC monitors completion of maintenance/repair.</p>

**A.6. Environmental Limits**

**WARNING** 

The following is a critical operational and environmental limitation:

- maximum sea state for transiting (6 feet, no surf)
- maximum operating winds 25 knots
- maximum towing capacity 10 displacement tons
- maximum operating distance from shore 10 NM
- outside air temperature 0-105 degrees F
- outside water temperature 28 – 95 degrees F
- no ice

**WARNING** 

Do not operate in breaking seas or surf conditions.



## Section B. Performance Data

### B.1. Fuel Consumption

Fuel consumption and operating range are affected by engine tuning, weather conditions, trim, type of evolution, and operating area. The Defender A Class is capable of operating a maximum of 175 NM at 35 knots and the Defender B Class 150 NM at 35 knots, with a normal load (full load of fuel, liquids in machinery at normal levels, crew of two). Fuel consumption information may be found in Table 5-2 (Defender A Class) and Table 5-2 (Defender B Class).

**Table 5-1  
Fuel Consumption Information (Defender A Class)**

Engines: BF225 Honda, 4-Stroke, RH-LH		
<ul style="list-style-type: none"> <li>Fuel tank capacity: 125 gallons</li> <li>Propellers: Mercury Offshore 14 by19 P, RH-LH</li> </ul>		
RPM	KNOTS	GPH
6000	46	40
5500	42	32
4500	35	28
4000	34	20
3500	26	16
3000	22	12
2500	16	10
2000	10	8
1500	8	6
1000	7	4
700	4	2



**Table 5-2  
Fuel Consumption Information (Defender B Class)**

Engines: BF225 Honda, 4-Stroke, RH-LH		
• Fuel tank capacity: 105 gallons		
• Propellers: Mercury Offshore 14 by19 P, RH-LH		
RPM	KNOTS	GPH
6000	46	44
5500	42	32
4500	35	20
4000	34	16
3500	26	14
3000	22	11
2500	16	7
2000	10	6
1500	8	5
1000	7	4
700	4	1

**WARNING**

The coxswain is responsible for ensuring that all required personal safety equipment is worn, and worn correctly.

**B.2. Seakeeping**

Positioning the vessel with respect to the wind, seas, and other craft is essential to prevent damage to the hull or injuries to the crew.

**B.2.a. Operating in Beam Seas**

Operating with the seas on the beam is more uncomfortable than dangerous when following basic boat handling guidelines. Use the following techniques to minimize danger:

- Tacking - With large seas on your beam, tack across the seas at a slight angle in a zigzag fashion. This prevents exposure of the beam to heavy swells.
- Changing Course - To change course heading, allow the boat to lose headway, turn the wheel hard over, and apply power to come smartly to the new heading.



**B.2.b. Operating in Following Seas**

Following seas present the greatest dangers to Defender Class boats. The boat does not have the balanced buoyancy or ability to lay-to in a following sea. The operational limitations are the controlling guideline and must be followed at all times. Consider the following point and technique when operating under these conditions:

- Do not power the boat over the crest of a wave and into the trough of the next wave or bury the bow into the back of the next wave.

**B.3. Stability**

By virtue of hull design and equipment placement, Defender Class boats provide for stable maneuvering through all operating speeds. Ensuring the deck areas are always free of water and eliminating the free surface affect of liquids are essential to maintaining stability of the boats.

**B.4. Speed**

Defender Class boats achieve a top speed of approximately 46 knots at 6000 RPM.

**NOTE** 

Do not use rapid accelerations from dead-in-the-water (DIW) to full speed except when necessary. This conserves fuel and helps prolong engine life.

**NOTE** 

Avoid rapid acceleration unless absolutely necessary to prolong engine life and conserve fuel. Maximum speed/power should only be used when operationally necessary. Under non-urgent conditions, operate the boat at cruise speed.



## Section C. Performance Monitoring

### C.1. Performance Monitoring

It is essential that the coxswain and crewmembers be aware of installed monitoring equipment, gauges, and warning indicators, to ensure safe and efficient operation of the Defender A Class and Defender B Class propulsion and ancillary systems. Crewmembers should be aware of the “normal range” or indication of all gauges and indicators, and report and react accordingly when changes occur.

### C.2. Control Panel Indicators

The control panel (**Figure 5-1** (Defender A Class) and **Figure 5-2** (Defender B Class)) is attached to the dash panel, starboard side of the helm below the throttle controls. The panel contains the following:


- Ignition switch
- Engine kill switch
- Alternator (ACG) indicator
- Programmed fuel injection (PGM-FI) indicator
- Oil pressure indicator
- Overheating indicator

#### NOTE

The Defender A Class utilizes two separate control panels for engine start, stop, and monitoring. The Defender B Class uses one control panel for both engines. Panel indicators and functions are identical.



**Figure 5-1**  
**Control Panel Indicators (Defender A Class)**



**Figure 5-2**  
**Control Panel Indicators (Defender B Class)**

C.2.a.  
Overheating  
Indicator

If the engine overheats, the RED indicator light will come on, engine speed will be gradually reduced to approximately 1800 RPM and the engine will stop after 20 seconds. The overheating indicator is activated via the engine control module (ECM) by two overheat sensors mounted on the engine. The Honda 225-HP engines require approximately 12 PSI water pressure with a minimum water pressure of 5 PSI to maintain adequate engine cooling and prevent engine damage.

C.2.b. Oil  
Pressure Indicator

If oil pressure becomes low, less than 23 PSI at 1800 RPM, the GREEN oil pressure light will go off. If at cruising speed, the ECM will gradually decrease engine speed. Stop the engine and check and service the oil level. Restart the engine. The GREEN indicator light should come on within 30 seconds and throttle operation should be normal. If the engine protection system remains activated, oil indicator light *off*, engine RPM will not increase with throttle movement. Stop the engine and repair as required.

C.2.c. Alternator  
Indicator

The RED indicator light will come on if there is a malfunction in the charging system. Each 12 volt alternator is rated at 60 amp at 2300 RPM, and 48 amps at 1000 RPM. The alternators are belt driven by the engines and protected by a 150-amp fuse installed in the fuse case mounted on the engine.




C.2.d.  
Programmed Fuel  
Injection Indicator

The RED indicator light will come on when the ECM senses an abnormality from one of the nine engine-mounted sensors. Continue to carefully monitor engine performance and stop engine if performance deteriorates or becomes erratic.

**C.3. Helm Dash Panel**

The helm dash panel (Figure 5-3 (Defender A Class) and **Figure 5-4** (Defender B Class)) mounts the following:

- Trim tilt indicators
- Tachometers
- Fuel totalizer



**Figure 5-3  
Helm Dash Panel (Defender A Class)**

C.3.a. Trim Tilt  
Indicators

The trim tilt indicators indicate the trim angle of the outboard motors and have a range of -4 to 16 degrees. Use the trim tilt indicators when operating the power tilt/trim switch to achieve best performance from the boat.


C.3.b.  
Tachometer

The tachometer shows engine speed in RPM. The Honda 225 engine is designed to idle at 650±50 RPM. The tachometer also has a display for engine operating hours.

C.3.c. Fuel  
Totalizer

The fuel totalizer is a single gauge that provides an indication of fuel consumption and rate in GPH for each engine.






**Figure 5-4**  
**Helm Dash Panel (Defender B Class)**

---

**C.4. Voltmeters** Two voltmeters (Figure 5-5), one for each engine, are located on the OHIP. The voltmeters provide a visual indication of the voltage output of each engine's alternator. During operation, the minimum voltage indicated should be 12.7 volts.

---



**Figure 5-5**  
**Voltmeters**





## Chapter 6

# Mission Performance

---

### Introduction

The actions and techniques described in this chapter are products of field experience. They are intended to give boat crewmembers information on how Defender Class boats perform and react in various mission scenarios. The information is not intended to provide the “only way” to perform an action or complete a mission. Boat crews should use effective communications and teamwork skills along with this general information to adapt their actions to each unique mission scenario.

Information in this section alone does not qualify a crewmember. Observe these procedures and apply skills developed through practice to effectively use Defender Class boats to perform missions.

---

### In this Chapter

This chapter contains the following sections:

Section	Topic	See Page
A	Boat Davit Operations	6-3
B	Starting Procedures	6-5
C	Underway	6-7
D	Going Alongside Boats and Vessels of Interest	6-9
E	Handling Characteristics	6-14
F	Operating with Helicopters	6-20
G	Anchoring	6-21
H	Towing	6-22
I	Securing Procedures	6-23
J	Loading and Unloading Boat for Air Transport	6-24

---





## Section A. Boat Davit Operations

---

### **Introduction**

Although Defender Class boats are fitted with lifting points for hoisting the boat with a single point davit, they were not designed to be deployed on a large vessel.

---





## Section B. Starting Procedures

**Introduction** The following procedures must be followed before starting a cold engine.

**B.1. Pre-Start** The following pre-start checks must be accomplished before the first mission of the day and prior to engine start:

Step	Action
1	Ensure hull fuel tank is full. Use fuel level gauge as required.
2	Check fuel filter sediment/water bowl for presence of contamination. Drain sediment/water bowl as required.
3	Ensure the port and starboard cooling water intakes on the lower engine shaft housing are free of debris.
4	Check outboard engine cover gasket for damage. Check that outboards are secure to the transom and all mounting hardware is tight.
5	Trim engines down until lower unit is submerged (ensure full tilt/trim travel on each engine).
6	Ensure engine oil level is filled to 'FULL' mark.
7	Check hydraulic steering system for leaks at helm and at steering ram by outboards.
8	Squeeze primer bulbs until firm.
9	Ensure the engine kill switch clips are installed and lanyards attached.
10	Install start keys and turn key to <i>on</i> position. Ensure the engine alarm system is operating.



**B.2. Engine Starting**

The following procedures must be followed for starting the engines:

Step	Action
1	Set throttle levers to <i>neutral</i> position at all operating stations.
2	Ensure electronics, antennas, and speakers are secured.
3	Ensure the engine kill switch clips are installed and lanyards attached. One spare clip and lanyard must be onboard and stored inside the cabin.
4	Turn key to <i>start</i> position until engine starts.
5	Check outboards for nominal or adequate cooling water output at telltale discharge on each engine.
<p><b>CAUTION !</b> If cooling water output is not evident, immediately secure engine and investigate.</p>	
6	Check crew and passengers for appropriate PPE including helmets (if required).

**B.3. Energizing Equipment**

The following steps must be completed prior to getting underway:

Step	Action
1	Close (turn <i>on</i> ) all of the remaining breakers on the 12-VDC power panels.
2	Energize and test all installed electronic components.
3	Conduct a test of the hydraulic steering ensuring that motors respond appropriately.
4	Test throttle operation in <i>forward</i> and <i>reverse</i> .
5	Ensure gear is properly stowed and watertight integrity is set.
6	Inform coxswain on the status of all engineering and electronic systems and that the boat is ready to get underway.





## Section C. Underway

---

### Introduction

It is the responsibility of the coxswain and crewmembers to ensure that once the vessel is underway the boat and its systems are operated in a safe and efficient manner. The safety of the crew and any embarked personnel is also incumbent on all crewmembers.

After getting underway, observe all appropriate machinery gauges. If an abnormal condition develops, take corrective action to prevent further damage, in accordance with the *U.S. Coast Guard Boat Operations and Training (BOAT) Manual, Vol. I*, COMDTINST M16114.32 (series). Report any abnormal conditions to the coxswain.

---

### C.1. Personal Protective Gear

Always observe requirements of this manual, the *Rescue and Survival Systems Manual*, COMDTINST M10470.10 (series), and the *Boat Crew Seamanship Manual*, COMDTINST M16114.5 (series), for wearing protective clothing, personal flotation devices, and boat crew signal kits.

---

### C.2. Communications

Crew communications and coordination is the key to safe operations. Crewmembers should inform the coxswain of their location when moving about the deck. Engine noise can make crew communications difficult on Defender Class boats. Speak loudly and clearly repeat as necessary until acknowledged.

#### NOTE

When operating the boat with minimal crew, effective crew communications are critical. Speak loud enough to be heard over the background noise. Ensure the receiver hears and understands the message being passed. A common strategy is to have the receiver repeat back the message that was sent.

#### NOTE

The enclosed steering station can create a sense of isolation from the elements and other marine traffic. Crewmembers should use all available means to maintain awareness of wave action, winds, currents, and traffic.

---







## Section D. Going Alongside Boats and Vessels of Interest

### Introduction







The following is a generic procedure for going alongside. Defender Class boat crews must be familiar with the applicable U.S. Coast Guard instructions and Standard Operating Procedures (SOP) for going alongside a vessel of interest and shall be accomplished in accordance with the *Boat Crew Seamanship Manual*, COMDTINST M16114.5 (series), *Chapter 10*.

The height of the cabin and the narrow side deck makes the Defender Class boat's cabin, door, and windows vulnerable to damage when coming alongside another vessel. Sea state, location of installed rub rails and the flare of the other vessel's hull increases the likelihood of damage if the two vessels roll towards each other. A thorough risk assessment, including asset selection is essential to reduce the potential of personnel injury and property damage. Rigging fenders along the cabin's handrail may further reduce damage.



**WARNING**  When going along side a vessel with a high freeboard, rig fenders along the cabin's handrail to prevent damage to the cabin.

Step	Action
1	Ensure that communications between the Defender Class boat and the Operational Commander are established and reliable.
2	Attempt to make and establish contact with the vessel of interest on designated marine band frequencies.
3	Make approach preparations and inform the crew. The coxswain should determine where to make contact with the vessel.
<p><b>WARNING</b>  Pick a contact point well clear of a larger vessel's propeller (including in the area of suction screw current), rudder, and quarter wave. Forces from these could cause loss of control.</p>	
4	Conditions permitting, match your speed to the other vessel, and then start closing in from the side.
5	Close at a 15- to 30-degree angle to the other vessel's heading. This should provide a safe rate of lateral closure at no more than one-half the forward speed.



<p><b>NOTE</b> </p>	<p>If your initial heading was parallel to the other vessel, you will have to increase speed slightly when you start to close at an angle.</p>
<p><b>WARNING</b> </p>	<p>Applicable U.S. Coast Guard instructions and SOP must be strictly adhered to when/if the Defender Class boat is in close proximity to any vessel that fails to identify itself.</p>
<p>6</p>	<p>If contact has been made with the vessel of interest, determine if a sea painter has been provided for going alongside. Also, determine if a boarding ladder (if necessary) is available and rigged.</p>
<p><b>NOTE</b> </p>	<p>In some instances, a sea painter may be used in going alongside a larger vessel underway. The sea painter is a line used to sheer a boat clear of a ship's side, when underway or at anchor, to hold a boat in position under shipboard hoisting davits, and occasionally to hold the boat alongside a ship in order to embark or disembark personnel. It leads from the larger vessel's deck, well forward of where the boat will come alongside.</p>
<p><b>WARNING</b> </p>	<p>Never secure the sea painter to the boat's stem nor to the side of the boat away from the vessel of interest. If secured to the "outboard" side of the boat, capsizing could result.</p>
<p><b>NOTE</b> </p>	<p>As both the Defender Class boat and vessel of interest have headway, the pressure of the water on the boat's bow will cause it to sheer away from the vessel of interest. Use this force by touching on the helm to control sheer, in or out, by catching the current on one side of the bow or the other side. Riding the sea painter will help maintain the position and control of your boat while alongside.</p>
<p><b>NOTE</b> </p>	<p>When sheering in or out, apply rudder slowly and be prepared to counteract the tendency of the boat to close or open quickly.</p>
<p>7</p>	<p>Come alongside of the vessel, matching its course and speed. When close to the larger vessel, and forward of the desired contact point, ask the vessel to pass the sea painter.</p>
<p>8</p>	<p>Receive the sea painter and secure it inboard just aft of the bow.</p>
<p>9</p>	<p>The sea painter is usually passed by use of a heaving line. Quickly haul in the heaving line and adjust the boat's heading and speed to control slack in the sea painter so that these lines do not get into the boat's propeller or mast.</p>
<p>10</p>	<p>Reduce your speed slowly and drift back on the painter (ride the painter).</p>



11	Use helm to hold the boat at the desired position alongside or at some distance off the vessel.
12	If set toward the vessel, apply rudder to sheer the bow out. If too far away, apply rudder to sheer the bow in. The forward strain on the painter will pull the boat and provide steeringway.
<p><b>NOTE</b>  If approaching a vessel anchored in a strong current, the sea painter provides a means to lay alongside. Procedures are the same as if the vessel is making way. Approach from leeward, against the current.</p>	
<p><b>CAUTION !</b> Use care when going alongside a vessel of interest so as not to damage the collar.</p>	
13	Make contact with the forward sections of your boat (about halfway between the bow and amidships). Use helm and power (if not on a sea painter) to hold the bow into the other vessel at the same forward speed. Do not use so much helm or power that you cause the other vessel to change course.
14	Ensure that communication with the Operational Commander is established to update the status of the assigned mission. If personnel are to be embarked/disembarked on the vessel of interest, utilize a boarding ladder as provided. Minimize the time alongside. If necessary and following U.S. Coast Guard instructions and SOP, “make-up” to the other vessel rather than relying on helm and power to maintain contact.
15	When the mission is complete, embark all personnel. Sheer the stern in with the helm to get the bow out. Avoid getting set toward the side or stern of the vessel.
<p><b>NOTE</b>  If on a sea painter, its strain sheers the boat clear.</p>	
16	If on a sea painter, use enough speed to get slack in the line, then cast off when clear. Ensure the sea painter is hauled back aboard the larger vessel immediately to keep it from getting caught in the outdrive or mast.
<p><b>CAUTION !</b> Never back down when clearing alongside, parallel to another vessel that is making way. Outboard powered vessels with a large portion of weight aft are susceptible for shipping water while backing, particularly in a chop.</p>	
17	Apply gradual power to gain slight relative speed. Maneuver the boat away from the vessel of interest. Continue to update position and status of the mission with the Operational Commander.





## Section E. Handling Characteristics

---

**Introduction** Boat handling is a complex skill that requires knowledge and practical, underway experience to build confidence and skill level. Always use forethought and finesse when handling the boat. Know the boat's handling features, monitor weather conditions, and be aware of the operating limitations of the boat.

---

**In this section** This section contains the following information:

Topic	See Page
General Boat Handling	6-14
Turning and Pivoting	6-15
Head Seas	6-16
Beam Seas, Following Seas, and Quartering the Seas	6-17
Effects of Wind	6-18
Station Keeping	6-19

---



## General Boat Handling

### E.1. Characteristics

The Defender Class boat is a powerful, highly maneuverable platform, which requires a solid understanding of boat handling concepts, particularly the effects of trim on hull efficiency, engine performance, and reduction of impact stress and injuries to boat crews. In addition, coxswains and crews should be familiar with the capabilities, limitations, and handling characteristics of the boat, as well as their own personal training and experience levels.

When operating at high speed, it is critical that the engines be trimmed down (in) before making hard turns or maneuvers. Trimming the engines down (in) causes the bow of the boat to be pushed down by the thrust of the engines and is considered the safest position when accelerating, performing hard maneuvers, and heading into wind and waves.

Performing high speed turns and maneuvers with the engines trimmed out (up) or level can result in hooking a chine, where the chine of the boat abruptly catches the water. The result can be violent in nature, the physical forces of which may cause personnel in the boat to be thrown in the direction of momentum.

#### **WARNING**

High speed turns while “trimmed out” (up) or “trimmed level” can result in “hooking a chine”, causing a violent reaction which may create immediate loss of control of the boat and sufficient force to pitch crewmembers overboard.

#### **CAUTION !**

The Defender Class boat is sensitive to changes to the Longitudinal Center of Gravity (LCG). These changes can occur by adding or subtracting weight, or through simple crew movements. These changes will change the boat handles in any given situation. The coxswain must assess any LCG change and may have to make many trim adjustments during a sortie.

Prior to making a high speed or tactical turn, crews and passengers must be forewarned and given the opportunity to prepare themselves for the maneuver. The forces created as the boat turns at high speeds will result in injury and ejection if crews are not properly restrained.





## Turning and Pivoting

---

### E.2. Characteristics

Each Defender Class boat turns or pivots, for steering purposes, on its vertical axis, at approximately the aft cabin bulkhead when fully trimmed in. Because of this characteristic (which provides other benefits such as straight-line tracking and planning), coxswains must be aware of the boat's turning capabilities.

### WARNING

High-speed turns while improperly trimmed, may result in injury to crew or damage to the boat.

### E.2.a. Turning on Plane

Avoid making sharp, high-speed turns while improperly trimmed. Due to the reduced amount of wetted surface (hull in water), sharp, high-speed turns may result in “hooking a chine”. This can be hazardous and may result in injury to the crew or damage to the boat. If a sharp turn is required, trim the engines in before turning.

---



## Head Seas

---

**E.3. Buoyancy** The primary consideration when advancing in head seas is to maintain forward momentum and keep the bow into the swell. The buoyant construction of the boat allows it to ride up over oncoming seas.

---

**E.4. Over-Acceleration** When heading into the wind and up the face of large waves, care must be taken to avoid over-accelerating, which can result in the bow being caught and creating a pitch-pole situation where the boat is inverted end-over-end.

---



## Beam Seas, Following Seas, and Quartering the Seas

---

**E.5. Beam Seas** Whenever possible, the coxswain should avoid steering a course parallel (broadside) to heavy swells. Tack across the swells at a 30- to 40-degree angle. If necessary, steer a zigzag course, making each leg as long as possible, and adjust the boat speed for a safe and comfortable ride. Seas directly off the beam of the boat can cause adverse rolling conditions.

When transiting parallel to the seas, the boat will tend to ride the contour of the wave surface. This means that the boat's vertical axis will remain perpendicular to the surface on which the boat is operated. A wave face of 20 degrees will cause a 20-degree heel.

---

**E.6. Following Seas** Following open swells up to 6 feet can be safely negotiated as long as the boat remains stable as it travels down the front of the swell. Powering over the crest of a wave can cause the bow to bury into the back of the next wave and cause extensive damage. In bad weather, Defender Class boats are relatively safe running before the sea due to their speed. If caught in breaking seas, this advantage is used to ride the back of the waves while adjusting speed as required.

### NOTE

Extreme caution should be exercised when operating in following swells (Refer: Section 5.B.2.b Operating in Following Seas).

---

**E.7. Quartering the Seas** Taking larger head seas slightly off of either bow can create a more comfortable ride, as the boat may proceed more gently off the back of the wave instead of slamming violently. The speed and angle of approach will have to be adjusted as needed for the optimum ride. This is sometimes referred to as quartering the seas, which is not to be confused with taking a following sea on the quarter.

---



## Effects of Wind

---

### **E.8. Maneuverability**

In calm or negligible wind and seas, Defender Class boats respond well using standard twin-screw operating practices. In stiff winds, several design features combine to make handling this boat challenging. With the majority of weight and the deepest draft aft, the bow is very susceptible to the effects of the wind. Moderate winds may have an effect on maneuverability and can often be the predominant environmental factor in maneuvering situations. In some cases, it can be difficult to recover and turn the bow into the wind at slow speeds.

---



## Station Keeping

---

**E.9. Stern-To** Station keeping requires concentration to maintain a constant heading and position. The boat tends to work well with its stern to the wind as the bow tends to “weathervane” downwind. If stern-to station keeping is not an option, the operator must use extra care to counteract environmental factors.

---



## Section F. Operating with Helicopters

---

### Introduction

The Defender Class boat was not designed to conduct helicopter hoisting operations and presents many safety obstacles. The boat's limited deck space and close proximity of the tow bit, taffrail, and other appendages requires careful consideration when conducting hoist operations.

Conducting helicopter training on this platform is **limited to rescue strop with trail line only**. Conducting live hoists and delivery of any other device other than the rescue strop for training purposes is prohibited.

### NOTE

Crewmembers on boats less than 30 feet in length are only required to possess a knowledge of helicopter operations for qualification purposes. Always refer to the U.S. Coast Guard Boat Operations and Training Manual - Volume II, COMDTINST M16114.33 (series) for current qualification requirements.

In the event of an operational requirement to conduct live hoists or delivery of other rescue devices and equipment from a Defender Class boat, crewmembers shall rely on knowledge gained from qualification tasks associated with boat crew member training and appropriate operational risk management.

In all situations, the on-scene helicopter pilot shall provide appropriate instruction for a safe hoisting evolution.

### NOTE

Air operation procedures are described in the *Boat Crew Seamanship Manual*, COMDTINST M16114.5 (series).



## Section G. Anchoring

**WARNING** 

If the anchor line fairlead is from any point other than the bow, there is the potential for a tripping hazard and possible capsizes. Never anchor from the stern.

**Introduction**

Care must be taken when anchoring to ensure that the anchor line fairlead is over the bow.

**NOTE** 

Anchoring procedures are described in the *Boat Crew Seamanship Manual*, COMDTINST M16114.5 (series).



## Section H. Towing

---

### Introduction

Towing a disabled vessel requires a high degree of awareness of all potential hazards, as well as full knowledge of the capabilities and limitations of the particular components within the towing operation. The safety of your crew and the crew of the towed vessel is more important than property.

### NOTE

Towing procedures are described in the *Boat Crew Seamanship Manual*, COMDTINST M16114.5 (series).

### WARNING

Due to their limited size and hull design, Defender Class boats are more susceptible to tripping. A boat is said to be tripping when it is towed sideways by an opposing force on its own towline. There is imminent danger that a boat will capsize when in a tripping situation. If your vessel is caught in a tripping situation, the coxswain must attempt to maneuver to position the stern back under the towline; or sever the towline at the bitt.

### H.1. Angular Momentum

Overcoming angular momentum can be far more hazardous on smaller non-displacement hulls such as the Defender A Class and Defender B Class. When changing the direction of the tow, the towed vessel will develop angular momentum; the vessel's heading begins to change and it wants to keep changing in that same direction. Attempts to correct angular momentum can create a tripping hazard. Coxswains need to anticipate how the momentum will affect the towed vessel's motion and apply an offsetting force early and gradually.

### H.2. Alongside Towing

The height of the cabin and the narrow side deck makes the Defender Class boat's cabin, door, and windows vulnerable to damage when coming alongside another vessel. Sea state, location of installed rub rails and the flare of the other vessel's hull increases the likelihood of damage if the two vessels roll towards each other. A thorough risk assessment, including asset selection is essential to reduce the potential of personnel injury and property damage. Rigging fenders along the cabin's handrail may further reduce damage.

### WARNING

When going alongside a vessel with a high freeboard, rig fenders along the cabin's handrail to prevent damage to the cabin.





## Section I. Securing Procedures

**Introduction** Once a mission is complete, it is essential that boat equipment be correctly secured to enhance subsequent equipment performance and equipment longevity.

**I.1. Procedure** The following procedure should be completed after each mission:

Step	Action
1	Secure all non-essential electrical and electronic gear.
2	If operated, ensure heater is “cooled down” prior to securing.
3	Ensure all equipment necessary to moor the boat is available on deck.
4	If necessary, lower the extendable tow light mast, folding light arch, and VHF antennas.
5	Idle and stop engines.
6	Secure all non-essential breakers and switches on the 12-VDC power panels.
7	Turn the battery and accessory battery switches to the <i>off</i> position.
8	Secure all pyrotechnics, weapons and ammunition as directed by U.S. Coast Guard instruction or station operating requirements.
9	Check and refill all machinery fluid levels.
10	Refuel the boat and refill the heater fuel tank.
11	Raise the engines out of the water when the boat is moored for prolonged periods of time.

**NOTE**

Keeping the boat clean and neat is very important to control corrosion. Having aluminum in contact with dissimilar metal, particularly a copper alloy, can cause major corrosion problems. Something as small as a penny left in the bilge can cause serious damage. Maintaining corrosion control is the responsibility of everyone in the crew.

**NOTE**

The mission is not complete until the boat is ready for the next mission.



## Section J. Loading and Unloading Boat for Air Transport

### Introduction

The following is a generic procedure for loading and unloading the Defender A Class or Defender B Class for air transport on a C-130 aircraft.

### J.1. Prior to Loading

Step	Action
1	Ensure battery switches on the 12-VDC main power panel are off.
2	Ensure that no additional pilferable gear is stowed on the deck areas or inside the cabin, anchor/ammunition locker, or aft deck lockers.
3	Ensure both VHF radio antennas atop the cabin are lowered and secured.
4	Remove the searchlight atop the cabin as follows: <ul style="list-style-type: none"> <li>• Remove the ¼x1½-inch Phillips screws holding the searchlight base to the hull (<b>Figure 6-1</b>).</li> <li>• Using a ³⁄₁₆-inch Allen wrench, remove the six ⁵⁄₁₆x1-inch bolts that secure the OHIP to the interior cabin overhead. Locate, mark, and carefully disconnect the searchlight wiring.</li> <li>• Reposition OHIP and reinstall and tighten remaining bolts.</li> <li>• Remove the searchlight from atop the cabin. Reinstall the Phillips screws in the exterior cabin overhead. Carefully stow the searchlight to prevent damage.</li> </ul>
5	Tilt engines up to port and set engine tilt locks.
6	Contact Air Station Commander, Aircraft (AC) Commander, or Aircrew Member (Loadmaster) for: <ul style="list-style-type: none"> <li>• Instructions on fuel removal (gasoline and diesel) and verification of fuel tank status.</li> <li>• Dunnage required to distribute boat trailer weight (wheels and tongue jack) equally over the aircraft cargo area floor.</li> </ul>
7	Weigh the boat and trailer as configured for air shipment. Provide this information to the Air Station Commander, AC Commander, or Aircrew Member (Loadmaster) to ensure aircraft weight and balance restrictions are not compromised.



8	<p>Upon arrival at the air station:</p> <ul style="list-style-type: none"> <li>• Ensure all hatches and doors are securely closed, dogged down, but UNLOCKED (aircrew may need access to the boat during flight for inspection).</li> </ul>
<b>NOTE</b>	<p>If additional clearance between the lowered radar pod and C-130 cargo area overhead is needed, the top dog of the aft cabin door may be removed.</p>
	<p>Lower the radar pod as follows:</p> <ul style="list-style-type: none"> <li>▪ Remove the ½-inch lock-pins on the port and starboard side of the radar pod.</li> <li>▪ Loosen and release the stainless steel latches on the forward side of the radar pod.</li> <li>▪ Using two people, slowly rotate the radar pod aft until the pod's restraining strap supports the weight of the pod.</li> </ul>



**Figure 6-1  
Searchlight Removal**





**J.2. Loading and Unloading**

**NOTE** 

The Defender A Class or Defender B Class can be loaded either bow or stern first into the C-130 cargo area. The bow first technique is preferred.

J.2.a. Loading Boat Bow First

Step	Action
1	Ensure the aircraft cargo ramp is fully lowered and the aircraft cabin/cargo area door is fully retracted (open) ( <b>Figure 6-2</b> ).
2	Position two USCG fabricated extended auxiliary ramps adjacent to the aircraft cargo ramp. This will facilitate rolling wheeled vehicles up the aircraft loading ramp.
3	Ensure all boat trailer straps are secure.
4	Attach the tongue jack wheel.
5	Position a third ramp adjacent to the aircraft cargo ramp to accommodate the tongue jack wheel. This ramp may be fabricated from wood or other material.
6	Position the trailer under the C-130 tail section, bow to the open cargo area door.
<p><b>CAUTION !</b> </p>	
<p>Do not attach the winch to any lateral members of the trailer's frame or the surge brake assembly.</p>	
7	Attach the C-130 cargo winch to both of the trailer safety chains.
8	Ensure spotters are positioned to determine top, bottom, and side clearances of the boat, trailer, and aircraft fuselage components.
9	Slowly winch the boat and trailer into the cargo bay ( <b>Figure 6-3</b> ) of the aircraft and secure as directed by the Aircraft Commander or aircrew.
10	Ensure all doors and hatches on the boat are closed, dogged down, but UNLOCKED.




**Figure 6-2**  
**C-130 Loading Ramp and Cargo Bay**



**Figure 6-3**  
**Loading Boat (Bow First)**



J.2.b.  
Unloading Boat  
Bow First

Step	Action
1	Ensure that the aircraft cargo ramp is fully lowered and the aircraft cabin/cargo area door is fully retracted (open) ( <b>Figure 6-2</b> ).
2	Position two USCG fabricated extended auxiliary ramps adjacent to the aircraft cargo ramp. This will facilitate rolling wheeled vehicles down the aircraft loading ramp.
3	Ensure all boat trailer straps are secure.
4	Ensure C-130 cargo winch is securely attached to the boat trailer safety chains.
5	Remove tie-downs that secure boat trailer to the cargo area floor.
<p><b>NOTE</b> </p>	<div style="border: 1px solid black; padding: 5px;">                     It maybe necessary to attach the boat's towline to the aft tow bitt, transom tie-down points, or trailer tie-down points to assist in pulling the boat and trailer out of the cargo area.                 </div>
6	Ensure spotters are positioned to determine top, bottom, and side clearances of the boat, trailer, and aircraft fuselage components.
7	Using the C-130 cargo winch brake and if required, applying a slight aft pull with the attached towline, slowly move the boat and trailer from the cabin area and down the cargo ramps.
8	When there is sufficient clearance under and around the aircraft fuselage, attach a vehicle with an approved hitch to the trailer and tow the trailer as directed.
9	When directed, reinstall the searchlight, raise the radar pod and other antennas, and prepare the boat for operations.



J.2.c. Loading  
Boat Stern First

<b>CAUTION !</b>		Do not attempt to use the C-130 cargo winch to load the boat stern first into the cargo area.
<b>Step</b>	<b>Action</b>	
1	Ensure that the aircraft cargo ramp is fully lowered and the aircraft cabin/cargo area door is fully retracted (open) ( <b>Figure 6-4</b> ).	
2	Position two USCG fabricated, extended auxiliary ramps adjacent to the aircraft cargo ramp. This will facilitate rolling wheeled vehicles up the aircraft cargo ramp.	
3	Ensure all boat trailer straps are secure.	
4	Ensure spotters are positioned to determine top, bottom, and side clearances of the boat, trailer, and aircraft fuselage components.	
<b>CAUTION !</b>		The right combination of tow vehicles, tow-bars, or drawbars is necessary during stern first loading to prevent the tongue of the trailer from becoming too low, thereby raising the aft edge of the boat's cabin and striking the inside overhead of the C-130 cargo area. If this situation cannot be corrected, load the boat and trailer bow first.
5	Slowly back the boat trailer up the C-130 ramp and into the cargo area.	
6	When directed by the aircrew, stop the vehicle.	
7	After the trailer is secured in the cargo area and when directed by the aircrew, disconnect the vehicle from the boat trailer.	





**Figure 6-4**  
**Loading Boat (Stern First)**



J.2.d.  
Unloading Boat  
Stern First

<b>CAUTION !</b>		Do not attempt to use the C-130 cargo winch to unload the boat stern first from the cargo area.
<b>Step</b>	<b>Action</b>	
1	Ensure that the aircraft cargo ramp is fully lowered and the aircraft cabin/cargo area door is fully retracted (open).	
2	Position two USCG fabricated, extended auxiliary ramps adjacent to the aircraft cargo ramp. This will facilitate rolling wheeled vehicles up the aircraft cargo ramp.	
3	Ensure all boat trailer straps are secure.	
4	Ensure spotters are positioned to determine top, bottom, and side clearances of the boat, trailer, and aircraft fuselage components.	
<b>CAUTION !</b>		The right combination of tow vehicles, tow-bars, or drawbars is necessary during stern first unloading to prevent the tongue of the trailer from becoming too low, thereby raising the aft edge of the boat's cabin and striking the inside overhead of the C-130 cargo area.
5	Back the tow vehicle up and engage the tow vehicle ball with the trailer hitch. Ensure the safety chains and breakaway lever chain are connected to the tow vehicle.	
6	Disconnect all tie-downs between the cabin area floor and boat trailer.	
7	When all tie-downs have been disconnected and only when directed by aircrew, slowly pull the boat and trailer from the cargo area.	
8	Tow the boat and trailer away from the vicinity of the aircraft.	
9	When directed, reinstall the searchlight, raise the radar pod and other antennas, and prepare the boat for operations.	



## Chapter 7

# Emergency Procedures

---

### Introduction

Responding to equipment casualties and emergencies aboard Defender Class boats should be second nature to all members of the crew. The ability of crewmembers to take immediate action to control emergency situations is critical, to prevent a bad situation from getting worse. While every event is different, step-by-step procedures help gain control of the casualty and aid in troubleshooting.

The first step in responding to all casualties is to protect the immediate safety of all crewmembers and to communicate the nature of the casualty to the crewmembers. It is the coxswain's responsibility to keep the Operational Commander informed of all emergencies encountered during the operation of the boat.

The coxswain and crew should work together to determine if equipment casualties can be safely repaired while underway. The coxswain must decide whether a casualty has impacted the ability of the boat and crew to complete the mission. The coxswain should not make the decision in a vacuum; input from other crewmembers, as well as communication with the Operational Commander, should be used to determine whether to continue with the mission. The following factors should be considered:

	<b>Factors</b>
1	The safety and physical condition of the crew and vessel.
2	Equipment limitations due to the casualty.
3	Current and forecasted weather and sea conditions.
4	The urgency of the mission.

---



---

**In this Chapter** This chapter contains the following sections:

<b>Section</b>	<b>Topic</b>	<b>Page</b>
A	Capsizing	7-3
B	Steering Casualty	7-9
C	Loss of Control of Engine RPM	7-11
D	Loss of Fuel Pressure	7-13
E	Loss of Lube Oil Pressure	7-15
F	Overheated Engine	7-17
G	Damage to Collar	7-19
H	No Power/Insufficient Power to Communications/Navigation Equipment	7-21

---



## Section A. Capsizing

### A.1. Introduction

The Coast Guard Defender Class of boats is a fast, highly maneuverable platform, capable of performing a variety of missions in 6 foot seas and 25 knot winds. The protective cabin on this vessel provides ample protection in a maritime environment; however, it also raises concerns of crew safety and egress in the unlikely event of capsizing.

### A.2. Prevention

The best way to survive a capsizing is to never place your self in a position that can lead to a capsizing. The Boat Crew Seamanship Manual, COMDTINST M16114.5(series) provides excellent recommendations on how to prevent a capsizing situation.

### NOTE

Boat crew personnel should be familiar with the *Boat Crew Seamanship Manual*, COMDTINST M16114.5 (series), *Chapter 16, Water Survival Skills*.

### A.3. Potential Causes

Four scenarios are likely for a Defender Class boat to become capsized. They are:

- High Speed Maneuver: The vessel, operating in a high speed/high maneuver environment may result in loss of control leading to capsizing. High speed hard turns while “trimmed out” or “trimmed level” can also result in “hooking a chine,” causing a violent reaction which may lead to capsizing;
- Boarding Operations: The vessel, along side another vessel may capsize as a result of rolling motion of the adjacent craft. Outlying gear, including fishing apparatus, accommodation ladders, and rigging, may also entangle with the boat, causing it to capsize;
- Extreme Seas/Surf: A Defender Class boat may also capsize as a result in the loss of maneuverability or power when operating in extreme seas or surf condition; and
- Towing: The Defender Class boat towing another vessel can experience “tripping.” Tripping occurs when the tow line becomes sideways or perpendicular to the towing vessel and subsequently pulls it over.



#### **A.4. Precautions**

---

If the hull is intact after capsizing, the Defender Class boat will not sink for some time, even in rough seas. The crew will have time to escape if panic is avoided. Precautions ahead of time include:

- Learn the boat’s interior. Initially the crew will be disoriented due to being upside down with a lack of lighting.
  - Stow all loose gear and have all equipment and doors operating properly for ease in escaping.
  - Know the location and use of all survival equipment. Check it regularly to be sure that it is adequate, in good repair, and that all signaling devices work.
  - Be ready to grab a sturdy support to prevent being thrown about and to provide a point of reference.
- 

#### **A.5. Egress Hazards for Defender Class Boat Crews**

Boat crews must be thoroughly familiar with capsize and egress hazards specific to Defender Class boats. These hazards differ depending on door/window configuration at the time of capsizing.

- The air pocket in the cabin when inverted may be useful, however, the motion of the boat due to surrounding seas may make it difficult to rely on this air pocket for long, and may disorient the crew.
- Once inverted, doors, windows, and hatches are oriented completely opposite from normal. Crews must realize that opening devices that are instinctively operated will be located on the opposing sides. For example, instead of using a downward pull on the cabin’s side door handle, an upward pull on the handle is needed to release the door’s catch when the boat is inverted.
- Visibility may be hindered due to low or no lighting. Egress may have to be accomplished in low or no lighting conditions.
- The sliding side doors were relatively easy to open during the egress testing. However, it should be noted that this may not be the case for a boat that has been in service for a long time, or has suffered damage during the capsizing event. Crews should keep this in mind when selecting an egress route.
- Egress through the forward cabin door is not recommended. Gear adrift tends to collect in the cuddy cabin, and once through the door the crew would then have to further egress from the underside of the forward deck. A weapon mounted forward would be an additional impediment.
- Egress through the aft door is also less than ideal. Once through the aft door the crew would then have to further egress from the underside of the aft deck. The towing bitt and towline may endanger the crew, and with the fuel fill and vent located aft, the likelihood of fuel entrapped in this area is high.
- Increased buoyancy from your Type III PFD, anti-exposure coveralls, air trapped inside the dry suit, and inflated PFDs will make it difficult (but not impossible) to egress safely from the cabin of a capsized Defender Class boat.



**NOTE** *↪*

The preferred method of egress from a Defender Class boat is through the port/starboard sliding doors. Attempt egress from the aft or forward cabin door only as a last resort.

**CAUTION !**

Do not lock the weather tight doors while operating the boat!

With the weather tight windows and doors closed, a capsized Defender Class boat’s cabin will provide considerable buoyancy, which will cause the boat to take on a “bow up” profile with much of the cabin remaining above water.

- Releasing restraints while suspended may result in head injuries.
- Opening windows/doors will allow incoming water to fill the cabin quickly, dislodge occupants, and interfere with egress.
- In rough seas, the water level and rate of fill in the cabin may change dramatically and quickly.
- Fuel and fuel vapors may exist in the cabin and on the water’s surface in areas surrounding the boat following capsizing. Crewmembers must be cognizant of the smell of fuel and egress immediately if vapor or the appearance of oil is evident on the surface within the cabin.

In situations where the doors/windows are open and the cabin floods quickly:

- Releasing restraints while inverted may result in confusion and loss of reference points.
- Occupants attempting to get upright and breathe in the remaining air pocket (this pocket will vary in width from none to approximately two feet) may suffer head/body injuries and swallow water in rough seas.

**A.6. Egress Procedures**

---

Boat crews must be thoroughly familiar with capsize and egress procedures specific to the Defender Class boat. These procedures will differ depending on door/window configuration at the time of capsizing.

**A.6.a Egress Procedures with Doors/Windows Closed**


---

During a capsizing event where the cabin does not sustain significant damage and the windows and doors remain secured and in tact, the Defender Class cabin does not immediately flood. It will likely assume a “bow-up” profile with much of the cabin out of the water. In this position, there is a possibility that the boat may roll back over with subsequent wave action. If it does not roll back over to its upright position, the weather proof windows and doors will eventually leak and flood the cabin, at which point the hull will come to rest inverted and level at the flotation collars. In situations where the cabin does not immediately flood:



1. Prepare and brace for impact.
2. Remain strapped in and hold onto a reference point until the violent motion subsides.
3. Remain strapped in and quickly perform crew coordination. Assess the situation and condition of all occupants. Plan your egress route prior to opening exit doors. The preferred way to escape from a capsized Defender Class Boat is to egress through either of the sliding side cabin doors. If the sliding doors appear to be damaged or do not open, egress from the aft cabin door. Water pressure against the closed aft cabin door may be difficult to overcome. When egressing through the aft cabin door, you must swim under and away from the main deck area. Egress through the forward hatch is the least preferred route and should be used as a last resort. Egress through the forward hatch requires swimming through the cuddy cabin and away from the foredeck area (see Figure 7-1).
4. While remaining strapped in, grab a reference point with one hand and open the side door with the other to allow water to flood the compartment. Remaining strapped in will prevent occupants from being thrown about with the in-rushing water.
5. Continue to hold onto the reference point with one hand. When in-rushing water slows, release restraint while maintaining hold of the reference point and pull hand-over-hand to a pre-determined exit (see Figure 7-1). Open exit if necessary and pull sharply through exit.
6. Swim clear of the boat and inflate personal flotation device if applicable. Muster as directed.





**Figure 7-1**  
**Primary and Secondary Egress Routes**

**WARNING** 

Automatic inflatable PFDs will activate inside the cabin of a capsized Defender Class boat.

A.6.b Egress  
Procedures with  
Doors/ Windows  
Open

With the windows/doors open, water will immediately fill the cabin and the boat will come to rest inverted and level at the flotation collars. In situations where the cabin floods immediately:

1. Prepare and brace for impact.
2. Keep your seat belt fastened and maintain hold a suitable reference point.
3. When in-rushing water slows and all violent motion subsides, forward-seated occupants egress from nearest side door exit.
4. Rear-seated occupants follow immediately by pulling hand-over-hand forward and out of the side cabin doors.

**WARNING** 

Do not attempt egress through the aft window area.

5. Swim clear of the boat and inflate personal flotation device if applicable. Muster as directed.



**CAUTION !**

Below the waterline, the inverted cabin MAY create a limited air pocket in the forward section of the cabin. Use of this air pocket is a crew decision at the time of the mishap; however, violent motion of the boat may cause the air pocket shift severely causing inhalation of water.

**A.7. Post Egress Procedures**

Every effort should be made to escape from a capsized boat. Following egress, crewmembers should take the following action:

1. Muster the crew and passengers and account for any missing occupants.
2. Remain upwind/up current to prevent ingestion of gasoline that may be present.
3. Attempt to climb aboard the inverted hull.
4. Check for injuries and administer first aid to the best of your abilities.
5. Conduct an inventory of signaling equipment. Activate Personal Locator Beacon (PLB).
6. Check for the presence of gasoline in the water before activating pyrotechnic signaling devices.
7. Stay with the boat and do not swim for shore. Distances to the beach can be deceiving, and strenuous activities such as swimming in cold water can hasten the onset of hypothermia.

**NOTE** *GS*

After capsizing, if possible, climb atop the hull. The boat is inherently buoyant even after capsizing. The boat is designed to remain afloat with crewmembers on it in capsized position.



## Section B. Steering Casualty

**B.1. Symptom(s)**

- Sluggish response or no response when wheel is turned to port or starboard.

**B.2. Actions**

When partial or complete steering loss occurs, take the following actions:

Step	Action
1	Coxswain notify and direct the crew to investigate the casualty, and reports status, cause and, if applicable, estimated time to repair.
2	Notify the Operational Commander of the casualty.
3	Check for steering fluid in the starboard aft compartment and well deck, around the helm pump, and adjacent to the transom near the steering actuator.
<p><b>WARNING</b>  Do not turn the wheel while crewmembers are inspecting the steering system linkage.</p>	
4	Ensure that all lines and fittings in the steering system are installed and tight.
5	Report all findings to the coxswain.





## Section C. Loss of Control of Engine RPM

### C.1. Symptom(s)

- Throttle position changed with no apparent change in engine RPMs.
- No ahead or astern movement of the boat.

### C.2. Actions

When the engine fails to respond to throttle commands, take the following actions:

Step	Action
1	Coxswain notify and direct the crew to investigate the casualty, and reports status, cause and, if applicable, estimated time to repair.
2	Crewmembers should: <ul style="list-style-type: none"> <li>• Check throttle and shift control cables.</li> <li>• Check throttle arm on engine.</li> <li>• Report all findings to the coxswain.</li> </ul>
3	If required, secure engine while in gear.
4	Coxswain report status of casualty to the Operational Commander.





## Section D. Loss of Fuel Pressure

### D.1. Symptom(s)

- Erratic or unstable engine RPMs.
- Engine stops completely.

### D.2. Actions

When it appears that the engine has sustained a loss of fuel pressure, take the following actions:

Step	Action
1	Coxswain notify and direct the crew to investigate the casualty, and reports status, cause and, if applicable, estimated time to repair.
2	Verify the fuel tank level at the gauge on the coxswain's console. Sound the fuel tank to ascertain tank level.
3	Crewmembers should: <ul style="list-style-type: none"> <li>• Check the aft compartments and the well deck for fuel.</li> <li>• Check for the presence of fuel around the engine cover.</li> <li>• Check the condition of the secondary (Racor) fuel filters.</li> <li>• Check engine fuel lines for holes or loose connections.</li> <li>• Check engine fuel filter and water separator for visual contamination as applicable.</li> <li>• Report all findings to the coxswain.</li> </ul>
4	Coxswain report status of casualty to the Operational Commander.







## Section E. Loss of Lube Oil Pressure

### E.1. Symptom(s)

- Loss of engine power when throttle is increased.
- Green light extinguishes on ignition panel indicating low oil pressure.

### E.2. Actions

If the engine experiences a loss of oil pressure and shuts down, take the following action:

Step	Action
1	Coxswain notify and direct the crew to investigate the casualty, and reports status, cause and, if applicable, estimated time to repair.
2	Coxswain secure the engine if this has not already occurred.
3	Crewmembers should: <ul style="list-style-type: none"> <li>• Check the outboard engine area for oil.</li> <li>• Verify oil level on dipstick.</li> <li>• Check that spin-on oil filter is tightly installed.</li> <li>• Check oil drain fitting for security.</li> <li>• Report all findings to the coxswain.</li> </ul>
4	Coxswain report status of casualty to the Operational Commander.





## Section F. Overheated Engine

**F.1. Symptom(s)**

- Loss of engine power when throttle is increased.
- Red light (overheating indicator) illuminates on ignition control panel.

**NOTE** *↪*

When the red overheat light illuminates, the engine speed is reduced automatically to 1800 RPM. If the condition persists another 20 seconds, the engine shuts down.

- Steam escapes from the engine cover.

**F.2. Actions**

If the engine experiences high water temperature, take the following actions:

Step	Action
1	Coxswain notify and direct the crew to investigate the casualty, and reports status, cause and, if applicable, estimated time to repair.
2	Coxswain bring engine to idle and stop the engine.
3	Crewmembers should: <ul style="list-style-type: none"> <li>• Check engine cover with the back of the hand to ascertain any abnormal temperature.</li> <li>• Check around engine cover for evidence of steam.</li> <li>• If possible, tilt engine forward and check cooling water intake screen for obstructions.</li> <li>• Report all findings to the coxswain.</li> </ul>
4	Coxswain report status of casualty to the Operational Commander.





## Section G. Damage to Collar

**G.1. Symptom(s)**

- Obvious rips and tears to collar.

**G.2. Actions**

If damage to the collar occurs, take the following actions:

Step	Action
1	Coxswain notify and direct the crew to investigate the casualty, and reports status, cause and, if applicable, estimated time to repair.
2	Crewmembers should: <ul style="list-style-type: none"> <li>• Check the physical condition of the collar.</li> <li>• Report all findings to the coxswain.</li> </ul>
3	Coxswain report status of casualty, disabling or restrictive, to the Operational Commander. Return home as directed by extent of casualty and direction of Operational Commander.



## Chapter 7 – Emergency Procedures



## Section H. No Power/Insufficient Power to Communications/Navigation Equipment

### H.1. Symptom(s)

- VHF, radar, GPS, or DGPS system(s) fail to operate properly.

### H.2. Actions

If there is no power to operate the communications/navigation equipment, take the following actions:

Step	Action
1	Coxswain notify and direct the crew to investigate the casualty, and reports status, cause and, if applicable, estimated time to repair.
2	Verify alternator output on voltmeter for each engine.
3	Check the position on power panels of all breakers and switches for the affected equipment.
4	Crewmembers report all findings to the coxswain.
5	Coxswain report status of casualty to the Operational Commander.







## Appendix A. Outfit List and Stowage Plan

---

**Introduction** This appendix contains the standard stowage plan for Defender Class boat outfitting. No deviation from this list is authorized, except in the event that the addition of portable equipment, not part of the standard boat outfit, is necessary to meet mission needs; units are authorized to temporarily carry this extra equipment on a per sortie basis.

Defender Class boat Management Information, Configuration, and Allowances (MICA) provides national stock numbers (NSNs) and ordering information for all outfit list items.

**WARNING** 

Any time the boat is started or has way on, the coxswain **MUST** have the lanyard of the engine kill switch clipped to his/her survival vest or PFD. A second kill switch activation clip and lanyard **MUST** be carried onboard to enable remaining crewmembers to operate the boat in the event the coxswain is ejected.

**In this appendix** This appendix contains the following information:

Topic	See Page
Defender A Class Outfit List and Stowage Plan	A-3
Defender B Class Outfit List and Stowage Plan	A-8

---





## Defender A Class Outfit List and Stowage Plan

Item	Part Number	Quantity
<b>Anchor/Ammunition Locker</b>		
Fortress 7-Pound Anchor	FX11	1 each
3/8" Galvanized Anchor Shackle WWL-2000 lbs.	147610	3 each
1/4"x4' PVC Coated Anchor Chain (secured w/Bungee Cord)	3112944	1 each
Mooring Lines 2" or 2 1/4" x 25' circumference DBN x 25'	Samson 618040202561	2 each
Fenders (5 1/2"x20")	Polyform G3	2 each
Anchor Line (1 3/4" circumference DBN x 100 feet) stowed in mesh bag		1 each
Anchor Line Thimble (spliced in eye)	Sea Dog PN 172012	1 each
Shackle, screw pin, 3/8" galvanized (attached to thimble)	4030-00-185-0482	1 each
Swivel, 3/8" Galvanized Eye to Eye	Sea Dog PN 181110)	1 each
Shackle, screw pin, 5/8" galvanized (attached to swivel)	4030-00-149-5574	1 each
<b>Main Cabin</b>		
<b>Forward Compartment (Cuddy Cabin)</b>		
Fire Extinguisher (Type B-1)	Kidde 91203	1 each
<b>Starboard Seats – Forward Section of Storage Compartment</b>		





## Defender A Class Outfit List and Stowage Plan

Item	Part Number	Quantity
<b>Spare Parts kit/Tool Bag</b> Containing Lube Oil (10w/30) Phillips and Slotted Screwdriver Metric Wrench Set (10mm -20mm) Pliers Rags Hub Kit Spare Kill Switch Lanyard 3/16" T-Allen Wrench 90 Degree Phillips Screwdriver Spark Plug Wrench with 4" extension Prop Nut Wrench	2010-01-523-1008 Honda 36182-ZV4-000AH	1 each 2 quarts 1 each 1 each 1 each Misc 1 each 2 each 1 each 1 each
<b>Port Seats – Aft Section of Storage Compartment</b>		
<b>Gear Bag</b> Containing 1½" circumference DBN Skiff hook line 9' SS Shackles (3/8" and ½") Mousing Wire Ties Flashlight (No larger than 2D cell in size) Dewatering Pump Tie Down Strap Binoculars		1 each 1 each 1 each 4 min. 1 each 1 each 1 each
Fenders (5 ½" x 20")	Polyform G3	2 each
Mooring Lines (2" or 2 ¼" (Cir.) DBN x 25')	Samson 6180032202561	2 each
Along Side/Mooring Lines (2" or 2 1/4" (Cir.) DBN x 35')	Samson 6180032202561	2 each
<b>Seat backs or Bottom Cushions (4)</b>		
Boat Crew Survival Vest		4 each
<b>Aft Cabin Door</b>		
Garelick Delux Telescoping Boat Hook 8'	55170	1 each
<b>Main Deck</b>		
24" Throwable Life Ring	Jim Buoy GO-X-24T	1 each
Life Ring Strobe Light	ACR SM-2	1 each
National Ensign	8345-00-245-2040	1 each



## Defender A Class Outfit List and Stowage Plan

Item	Part Number	Quantity
CG Ensign	8345-00-242-0275	1 each
Tow Line 2 ¼” circumference DBN (with cover)	Samson 472032006030	150
406 MHz Category II EPIRB with GPS	ACR Model 2744	1 each
Throw Line Bag (Aft of Port Deck Locker)		1 each
<b>Miscellaneous</b>		
Tow Mast		1 each
Sound and Fatigue Mitigating Deck Matting		1 set
<p><b>MSST Pintle Hook/Lunette Eye</b> (Pintle hooks/lunette eyes are authorized when deploying with Department of Defense, aviation units, or at the discretion of the unit’s Commanding Officer. When using a pintle hook/lunette eye, the ball, ball mount, and coupler must be kept in serviceable condition.</p>		
Buyers ( <a href="http://www.buyersproducts.com">http://www.buyersproducts.com</a> )  8 ton Buyers Pintle Hook 15 ton Buyers Pintle Hook 6 ton Buyers Pintle Eye Pintle Receiver Adapter 8 ton Buyers Ball Combination Hitch Valley Pintle Mount  Putnam Hitches ( <a href="http://www.putnamhitch.com">http://www.putnamhitch.com</a> ) Putnam Mounting Plate	PH-8 PH-15 B16137PKGD 10033 BH82516 69992  14003	
<b>Aft Cabin Door Port Deck Locker</b>		
No stowage, (Potential for damage to fuel system)		
<b>Starboard Deck Locker</b>		
Fire Extinguisher (Type B-1)	Kiddie 91203	1 each



## Defender A Class Outfit List and Stowage Plan

Item	Part Number	Quantity
12 VDC Negative Bus Bar Cover	Blue Sea 4028	1 each



## Defender B Class Outfit List and Stowage Plan

Item	Part Number	Quantity
<b>Anchor/ Ammunition Locker</b>		
Fortress 7-Pound Anchor	FX11	1 each
3/8" Galvanized Anchor Shackle WWL-2000 lbs.	147610	3 each
1/4"x4' PVC Coated Anchor Chain (secured w/Bungee Cord)	3112944	1 each
Mooring Lines 2" or 2 1/4" x 25' circumference DBN	Samson 618032202561	2 each
Fenders (5 1/2"x20")	Polyform G3	2 each
Anchor Line (1 3/4" circumference DBN x 100 feet) stowed in mesh bag		1 each
Anchor Line Thimble (spliced in eye)	Sea Dog PN 172012	1 each
Shackle, screw pin, 3/8" galvanized (attached to thimble)	4030-00-185-0482	1 each
Swivel, 3/8" Galvanized Eye to Eye	Sea Dog PN 181110	1 each
Shackle, screw pin, 5/8" galvanized (attached to swivel)	4030-00-149-5574	1 each
<b>Main Cabin</b>		
<b>Forward Compartment (Cuddy Cabin)</b>		
Spare Kill Switch Lanyard (stowed in Pouch)	Honda 36155-ZW7-000AH	1 each
3/16" T-Allen Wrench (stowed in Pouch)		1 each
90 Degree Phillips Screwdriver (stowed in Pouch)		1 each
Fire Extinguisher (Type B-1)	Kidde 91203	1 each
<b>Starboard Seats – Forward Section of Storage Compartment</b>		







## Defender B Class Outfit List and Stowage Plan

Item	Part Number	Quantity
<b>Spare Parts kit/Tool Bag</b> Containing: Lube Oil (10w/30) Phillips and Slotted Screwdriver Metric Wrench Set (10mm -20mm) Pliers Rags Hub Kit Spark Plug Wrench with 4” extension Prop Nut Wrench	2010-01-523-1008	1 each 2 quarts 1 each 1each 1 each Misc 1 each
<b>Port Seats – Aft Section of Storage Compartment</b>		
<b>Gear Bag</b> Containing: 1½" circumference DBN skiff hook line 9’ SS Shackles (3/8” and ½”) Mousing Wire Ties Flashlight (No larger than 2D cell in size) Dewatering Pump Tie Down Strap		1 each 1 each 4 min. 1 each 1 each
Fenders (5 ½” x 20”)	Polyform G3	2 each
Mooring Lines (2” or 2 ¼“ circumference)	Samson 618032202561	2 each
Along Side/Mooring Lines (2" or 2 1/4" (Cir.) DBN x 35')	Samson 618032202561	2 each
<b>Seat backs or Bottom Cushions (4)</b>		
Boat Crew Survival Vest		4 each
<b>Main Cabin Above Aft Cabin Door</b>		
Towing Mast		1 each
Lightening Rod		1 each
<b>Aft Cabin Door</b>		
Garelick Delux Telescoping Boat Hook to 8’	55170	1 each
<b>Main Deck</b>		
24" Throwable Life Ring	Jim Buoy GO-X-24T	1 each



## Defender B Class Outfit List and Stowage Plan

Item	Part Number	Quantity
Life Ring Strobe Light	ACR SM-2	1 each
National Ensign	8345-00-245-2040	1 each
CG Ensign	8345-00-242-0275	1 each
Tow Line 2 ¼" (Cir.) DBN (with cover)	Samson 472032006030	300 ft
406 MHz Category II EPIRB with GPS	ACR Model 2744	1 each
Throw Line Bag (Aft of Port Deck Locker)		1 each
<b>Miscellaneous</b>		
Trailer Screen (Windshield Guard) (S-WCS)		1 each
Sound and Fatigue Mitigating Deck Matting		1 set
<b>MSST Pintle Hook/Lunette Eye</b> (Pintle hooks/lunette eyes are authorized when deploying with Department of Defense, aviation units, or at the discretion of the unit's Commanding Officer. When using a pintle hook/lunette eye, the ball, ball mount, and coupler must be kept in serviceable condition)		
Buyers ( <a href="http://www.buyersproducts.com">http://www.buyersproducts.com</a> )  8 ton Buyers Pintle Hook 15 ton Buyers Pintle Hook 6 ton Buyers Pintle Eye Pintle Receiver Adapter 8 ton Buyers Ball Combination Hitch Valley Pintle Mount  Putnam Hitches ( <a href="http://www.putnamhitch.com">http://www.putnamhitch.com</a> ) Putnam Mounting Plate	PH-8 PH-15 B16137PKGD 10033 BH82516 69992       14003	
<b>Aft Cabin Door Port Deck Locker</b>		
No stowage, (Potential for damage to fuel system)		
<b>Starboard Deck Locker</b>		
Fire Extinguisher (Type B-1)	Kiddie 91203	1 each



## Defender B Class Outfit List and Stowage Plan


Item	Part Number	Quantity
12 VDC Negative Bus Bar Cover	Blue Sea 4028	1 each



## Appendix B. Engineering and Configuration Changes

---

**Introduction** This appendix contains a list of authorized engineering changes (EC) and configuration changes (CC) for Defender Class boats.

**NOTE**  For a complete breakdown of the Engineering Change Request, see the *Naval Engineering Manual*, COMDTINST M9000.6 (series), *Chapter 41*.

**In this appendix** This appendix contains the following information:

Topic	See Page
Engineering Changes (ECs)	B-2
Configuration Changes (CCs)	B-3

---





## Configuration Changes (CCs)

<b>CC Number</b>	<b>Subject</b>	<b>Date</b>
CC-001	Clam Shell Intake	14 May 04
CC-002	Replacement of Cabin Dewatering Pump Breaker	14 May 04
CC-003	Egress Arrows and Placard	14 May 04
CC-004	Honda Rig Tube Sleeves	14 May 04
CC-005	Additional Kill Switch Lanyard	14 May 04
CC-006	Flag Mount	14 May 04
CC-007	Trailer Safety Sticker	14 May 04
CC-008	Flat Four/Two to Round Seven Trailer Light Conversion Pigtail	14 May 04
CC-009	Honda Water Intake Scoop Change Out	14 May 04
CC-010	Pigtail for ESD Routine Loading of W9 Radio Codes	14 May 04
CC-011	EZ Loader Axle Bracket Mounting and Tire Renewal	11 May 05
CC-012	Installation of Front Seat Belts on Defender A Class	12 Nov 04
CC-013	Installation of Defender A Class Life Ring Strobe Light Bracket	12 Nov 04
CC-014	Replacement of Helm Vent	15 Feb 05
CC-015	Tow Light Switch Retrofit	16 May 05
CC-016	Taff Rail Modification	22 Nov 05
CC-017	Installation of Anti-Reflective Tape to Reduce Nav Light Reflection	30 Oct 05
CC-018	Installation of Lifting Point Labels for Defender A Class	30 Nov 05



Appendix B – Engineering Changes (ECs)

CC-019	Transom Gusset Upgrade	30 Nov 05
CC-020	Installation of Rear Seat Belts on Defender A Class	13 Feb 05





## Appendix C. Material Inspection Checklist

---

**Introduction** This appendix is meant to be a systematic means to inspect ANY Defender Class boat and to ensure the entire boat is prepared to meet mission demands.

This checklist may be locally reproduced.

---

**In this appendix** This appendix contains the following information:

No.	Area	See Page
I	Hull	C-3
II	Deck	C-4
III	Bilge	C-6
IV	Aft Port and Starboard Storage Lockers	C-7
V	Outboard Engines and Steering Actuator	C-8
VI	Cabin (Interior)	C-10

---



# Material Inspection Checklist

**Boat Number:** \_\_\_\_\_  
**Station:** \_\_\_\_\_  
**Date:** \_\_\_\_\_

- References:**
- *Defender Class Operator’s Handbook*, COMDTINST M16114.37 (series)
  - *Naval Engineering Manual*, COMDTINST M9000.6 (series)
  - *Coatings and Color Manual*, COMDTINST M10360.3 (series)
  - *Coast Guard Rescue and Survival Systems Manual*, COMDTINST M10470.10 (series)

**WARNING**

The engine kill switch lanyard and activation clip **MUST** be inspected daily. Damaged, deteriorated or frayed lanyards must be replaced prior to engine start. Engine kill switch operation must be tested weekly.

- Inspection Standards:**
- The following inspection standards apply to Defender Class boat hull, machinery, equipment, outfit, and all installed systems and accessories:
- Operates smoothly and correctly.
  - Free of grease, oil, rust, corrosion, and marine growth.
  - All fluid levels and pressure readings are within tolerances.
  - Protective coatings applied correctly and neatly.
  - Free of rips, tears, abrasions, and cracks.
  - Outfit and equipment correctly installed, adjusted, and stowed to specifications and design (see *Appendix A*).
  - Labels, test dates, and placards properly displayed.
  - Free of non-standard/unapproved installations or equipment.
  - Maintained according to current manufacturer’s guidelines and Commandant Directives.

**Inspection Guidelines:**

Inspections require a minimum of *two* experienced personnel, preferably one Boatswain’s Mate and one Machinery Technician, who have a strong working knowledge of the contents of all references listed above. Each item on the checklist should be judged against applicable standards and references. Additional discrepancies, uninstalled engineering changes (ECs), etc. should be listed.

**Inspected By:** \_\_\_\_\_ **Date:** \_\_\_\_\_  
**Inspected By:** \_\_\_\_\_ **Date:** \_\_\_\_\_



# I. Hull

**WARNING** 

Any time the boat is started or is underway, the coxswain **MUST** have the lanyard of the engine kill switch clipped to his/her survival vest or PFD. A second engine kill switch activation clip and lanyard **MUST** be carried onboard to enable remaining crewmembers to operate the boat in the event the coxswain is ejected.

ITEM	SAT	UNSAT	REMARKS
Hull (Visible Surfaces)			
Collar			
Transom			
Depth Sounder Transducer Wiring			
Tie-Downs			
Outboard Engines			
Steering Actuator			
Zinc Anodes			
Lettering/Numbering/Decals			
Waterline			
Self-Bailing One-Way Scuppers			
Navigation Lights (Red/Green)			

**REMARKS:** \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_



## II. Deck

ITEM	SAT	UNSAT	REMARKS
Radar Pod Fittings and Hinge			
Lifting Eyes and Tie-Downs			
Heater Fuel Fill Station (Defender A Class Only)			
Deck Covering (Non-Skid)			
Heater Exhaust			
Heater Intake			
Forward Tow Bitt			
Aft Tow Bitt			
Gun Mounts (if installed)			
Ammunition Locker Shelves			
Anchor Locker			
EPIRB			
VHF Antennas			
Radar Pod			
Horn			
Radar Antenna			
GPS Antenna			
Blue Strobe Lights			
Loudhailer Speaker			
Floodlights			



Anchor Light			
<b>ITEM</b>	<b>SAT</b>	<b>UNSAT</b>	<b>REMARKS</b>
Towlight Mast (If Installed)			
Searchlight			
Cabin (Exterior)			
Cabin Door			
Windshield			
Side Windows and Doors			
Windshield Wipers			
Cuddy Cabin Door			
Electric Cabin Dewatering Pump Overboard Discharge			
Battery Vent(s)			

**REMARKS:** \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_



### III. Bilge

ITEM	SAT	UNSAT	REMARKS
Electric Cabin Dewatering Pump (Inside cabin, aft starboard corner seat box (Defender B Class). Inside cabin, centerline under aft cabin step (Defender A Class).)			

**REMARKS:** \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_



## IV. Aft Port and Starboard Storage Lockers

ITEM	SAT	UNSAT	REMARKS
12-VDC Negative Bus Bar			
12-VDC Negative Bus Bar Cover			
Primer Bulbs			
Fuel Tank Level Sensor			
Fuel Filters (Racor)			
Fuel Fill Cap			
Fuel Fill Line			
Fuel Vent(s)			
Lifting Eyes			
Scuppers			
Heater Fuel Fill Station (Defender B Class Only)			
Heater In-Line Fuel Filter			
Portable Fire Extinguisher			

**REMARKS:** \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_



## V. Outboard Engines and Steering Actuator

ITEM	SAT	UNSAT	REMARKS
Engine			
Engine Cover			
Oil Dipstick			
Oil Fill Cap			
Propeller			
Engine Attachment Points			
Cooling Water Flow Indicator			
Cooling Water Intakes			
Anodes			
Belts			
Hoses			
Water Separator Bowl			
Wiring			
Control Cables and Linkage			
Steering Actuator			
Actuator Shaft (Exposed Area)			
Cylinder			
Attaching Hardware			
Tie Bar			



Appendix C – Material Inspection Checklist



ITEM	SAT	UNSAT	REMARKS
Hydraulic Lines and Fittings			

**REMARKS:** \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_



## VI. Cabin (Interior)

ITEM	SAT	UNSAT	REMARKS
Crew Seats			
Battery Switches			
Batteries and Battery Box			
Ignition Panels (Start Keys, Engine Kill Switch Clips, and Lanyards)			
Communications/Navigation Equipment			
VHF Radios			
Radar			
Depth Sounders			
Microphones			
Engine Throttle Control			
Steering Wheel			
Helm Pump			
Power Panels and Switches			
Heater Control			
Searchlight Control			
Engine Gauges and Warning Lights			
Long Arms Stowage			
Fans			
Interior Lights			



ITEM	SAT	UNSAT	REMARKS
Windshield Wipers and Washer Controls			
Sliding Windows and Latches			
Portable Fire Extinguisher			
Towlight Mast (If Stowed)			

**REMARKS:** \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_



Appendix C – Material Inspection Checklist



## Appendix D. Disabling Casualties

---

**Introduction** This appendix contains disabling casualties for Defender Class boats. Refer to *Chapter 5.A* of this handbook for steps to follow if any of these casualties occur.

---

**In this appendix** This appendix contains the following information:

Topic	See Page
Engine Parameters	D-2
Engineering System Components	D-2
Electronics/Navigation	D-2
Safety	D-3
General Material	D-3

---



## Disabling Casualty List

### Engine Parameters

- 
- Engine Lube Oil Pressure:
    - Green Engine Oil Pressure Light extinguishes on ignition panel, engine RPM is automatically limited to 1800 RPM.
  - Engine Overheating:
    - Red overheating indicator illuminates on the ignition panel, engine speed is automatically reduced to 1800 RPM. If condition continues for another 20 seconds, the engine automatically shuts down.
- 

### Engineering System Components

- Engine fails to start.
  - Uncontrollable overheating.
  - Inoperable visual and audible alarms.
  - Metallic/non-metallic noise: metal-on-metal/fuel-knock/bearing/clicking.
  - Excessive engine vibration.
  - Any fuel or lube oil leak.
  - Engine oil level empty (no oil on the dipstick).
  - Any engine wiring insulation damaged or chaffed resulting in an exposed conductor
  - Engine surging (over 50 RPM).
  - Engine over speed (over 6000 RPM).
  - Loss of engine control.
  - Continuous electrical breaker trip.
  - Continuous failure of outboard engine fuses.
  - Steering system inoperative.
  - Engine mount hardware loose or missing.
  - Loose/missing propeller coupling nut.
  - Loose/disconnected engine control hardware.
  - Loose/disconnected steering actuator hardware.
  - Missing fuel cap.
- 

### Electronics/Navigation

- No electronic means of signaling distress (i.e., no radio, EPIRB not installed or unserviceable, etc.).
  - 12-Volt system will not energize.
-



---

**Safety**

- Truck and complete hitch system (hitch, ball mount, and ball) not rated at 10,000 lbs or greater, rating must be marked by manufacturers sticker or stamp.
- Electrical arcing and sparking.
- Odor of insulation overheating.
- No portable fire extinguishers (unserviceable).
- Missing kill switch lanyard.
- Radar pod securing hardware loose/missing.

---

**General  
Material**

- Hull/transom plate breach below the waterline.
  - Crack in transom plate perimeter weld (excluding the weld along the top of the transom plate).
  - Collar damage exceeding that described in the restrictive and major discrepancy lists.
-



Appendix D – Disabling Casualties





## Appendix E. Restrictive and Major Discrepancies

---

**Introduction** This appendix contains restrictive and major discrepancies for Defender Class boats. Refer to *Chapter 5* of this handbook for steps to follow if any of these casualties occur.

---

**In this appendix** This appendix contains the following information:

Topic	See Page
Restrictive Discrepancies	E-2
Major Discrepancies	E-4

---



## Restrictive Discrepancies

### Engine and Boat Systems

- 
- Engine performance:
    - Minimum RPM of 4500 for two minutes.
    - Overheating indicator illuminates, alarm sounds.
  - Any leaks
    - Outboard cooling water components.
    - Outboard engine lubrication system components.
    - Steering actuator help pump, hoses or fittings.
    - Diesel fuel.
  - Inoperable tilt/trim system.
  - Inoperable fuel gauge.
  - Missing taff rail.
  - Missing anchor.
- 

### Engineering System Components

- Electric cabin dewatering pump is inoperative.
  - Emulsified oil in lower unit.
- 

### Electronics/Navigation

- Navigation lights inoperative or displaying improper characteristics.
  - Depth sounder inoperative.
  - GPS inoperative.
  - Radar inoperative.
  - Electronic compass deviation greater than 5 degrees and unit unable to calibrate compass.
  - Magnetic compass missing/deviation table missing.
  - Electronics:
    - One VHF transceiver inoperative.
  - Both loudhailer and horn inoperable.
-



---

**General  
Material and  
Safety**

- Watertight integrity:
    - Holes/cracks in the hull/transom plate above the waterline.
    - Damage to collar that removes the polyurethane coating or exposes interior foam.
  - Crack in two or more transom support gusset welds.
  - One portable fire extinguisher missing or unserviceable.
  - Navigation/anchor lights extinguished (Defender A Class).
  - Navigation/anchor lights with one or more extinguished LEDs (Defender B Class).
  - Missing non-skid section (8 ½ x11”).
  - Missing boat crew survival vest.
  - Collar de-lamination - separation of the polyurethane coating from the interior foam.
- 

**Trailer**

- Damage or disfigurement of the wheel rim flange which results in exposure of the tire bead (sealing surface) and/or damage or disfigurement which warps the circular shape of the rim.
  - Tire air pressure below 20 PSI.
  - Three or more tires with air pressure below 40 PSI.
  - Tire tread depth less than 4/32” (1/8”).
  - Brake/tail light incandescent bulb extinguished (Defender A Class).
  - Brake/tail light with one or more extinguished LEDs (Defender B Class).
  - Missing lug nut.
  - Missing or flat, improper size, damaged or worn tire(s).
  - Trailer running lights inoperative or wrong characteristic.
  - Brake actuator or back up solenoid inoperative or no fluid.
  - Wheel bearings or brakes have excessive noise or play.
  - Structural cracks.
  - Missing safety chains or breakaway brake actuator safety chain.
  - Emergency brake latch fails to operate.
  - Missing tie down straps (6 required/not including winch strap).
-



## Major Discrepancies

### Engine and Boat Systems

- 
- Electric cabin dewatering hose missing hose clamp.
  - Loose/missing fittings, nuts, bolts, brackets, etc.:
  - Loose/missing hardware on the engines used for attaching accessories and sensors.
  - Battery terminal loose or corroded.
  - Engine control cables loose.
  - Fluid levels below minimum required.
  - Charging system faulty or inoperative.
  - Any engine wiring insulation damaged or chaffed, without an exposed conductor.
  - Damaged/inoperable door and window locks.
  - Inoperable engine cover latch.
  - Any standard boat machinery, with the exception of those listed on the disabling or restrictive list, not operating properly.
- 

### Boat Outfit

- Life ring and/or distress lights (missing/unserviceable).
  - Missing/chaffed seat belts.
  - Missing trailer screen (Defender B Class only).
  - Missing mooring lines.
  - Missing fenders.
  - Missing/inoperable skiff hook.
  - Missing/inoperable hand bilge pump.
  - Missing/damaged lightning rod (Defender B Class only).
  - Fire Extinguisher PMS not recorded on equipment tag or improperly completed.
- 

### Electronics/Navigation

- Compass light inoperative.
  - Expired deviation table.
  - Any standard boat electronics, with the exception of those listed on the restrictive list, not operating properly.
- 

### General Material and Safety

- Watertight integrity:
- Improperly repaired damage to hull or collar.
  - Damage to folding radar pod.
  - Loose/missing/improper fittings, nuts, bolts, brackets, etc.
  - Missing/improperly outfitted first aid kit.
  - Separation (gapping) of the plates along the top horizontal edge of the transom.
  - Separation (gapping) of the plates in the scupper cut out.
  - A crack in the weld joining the engine well plate to the forward transom plate.
  - Crack in one transom support gusset weld.
  - Extinguished deck illumination light (interior or exterior).
-



- 
- Any standard boat machinery or system, with the exception of those listed on the disabling or restrictive lists, not operating properly.
- 

**Trailer**

- Lose, missing, or improper hardware.
  - Brake fluid level low.
  - Nonstandard type tie-down straps.
  - Missing/damaged E/Z jack.
  - Missing section of DOT reflective tape.
  - Tire air pressure 20-39 PSI.
  - Tire air pressure above 50 PSI.
  - Clearance light extinguished (Defender A Class)
  - Clearance light with one or more extinguished LEDs (Defender B Class)
  - Bearing lubricator damaged or missing.
  - Damage or disfigurement of the wheel rim flange which does not result in exposure of the tire bead (sealing surface).
-



Appendix E – Restrictive and Major Discrepancies



## Appendix F. Defender Class Underway Trial

---

**Introduction** This appendix contains the underway trial requirements for the Defender Class boat to ensure that the boat operates to prescribed standards.

---

**In this appendix** This appendix contains the following information:

Topic	See Page
Defender Class Underway Trial	F-2

---



---

**Pre-U/W Trial** Back the boat down into the water. While boat is still on the trailer, lower the outboards into the water and start-up, check overboard discharge. Check the operation of all the gauges and throttle control, note results. Pull kill switches, outboards should shutdown. Place the kill switch(s) back on and place throttles into gear. Attempt to start while in gear. Engines should not start while in gear. Restart the engines and energize all equipment and ensure the following: satisfactory radio checks, GPS lock on, depth finder operates, and radar transmits.

---

**Underway Trial** After all disabling casualties and restrictive discrepancies have been corrected or waived; the boat may get underway for a power trial.

Get the boat underway, trim engines all the way down and bring it to a location where it can run for two (2) minutes on a relatively straight course. Bring the engines up to min 4500 rpm. Check the boat for any vibrations. Have the operator remove both hands from the helm and see how the boat reacts. It should hold a relatively straight heading. Check the throttle handles to see if they hold 4500 rpm or creep back. If they creep back, have the operator hold the throttles at 4500 rpm for the two (2) minute period and note the discrepancy. On the return trip to the station, check full power, noting engine speed and rpm. Engine cannot run above 6000 rpm. If the engines exceed 6000 rpm's, it is considered a **Disabling Casualty**. Once back at the pier, check the engines, fuel system, and steering system for evidence of leaks. While U/W compare electronic compass with GPS. If there is more than 5 degrees difference between electronic compass and GPS, electronic compass deviation can be determined by steering on a fixed range and known course. While steering on known course, compare course with electronic compass. If deviation is greater than 5 degrees the electronic compass will need to be calibrated. After compass has been calibrated, complete a new test. If compass is unable to be calibrated to within 5 degrees, it is considered a **Restrictive Discrepancy**.





## Appendix G. List of Acronyms

---

**Introduction** This appendix contains a list of acronyms used throughout the handbook.

---

**In this appendix** This appendix contains the following information:

Topic	See Page
List of Acronyms	G-2

---



<b>ACRONYM</b>	<b>DEFINITION</b>
AC	Aircraft
ATF	Automatic Transmission Fluid
BCRB	Bow Collar Reinforcement Bracket
CASREP	Casualty Report
CO	Commanding Officer
COLREGS	Collision Regulations
DBN	Double-Braided Nylon
DES	Digital Encryption Standard
DGPS	Differential Global Positioning System
DIW	Dead-in-the-Water
DO	Defense Operations
DSC	Digital Selective Calling
EC	Engineering Change
ECM	Engine Control Module
ELC	Engineering Logistics Center
ELT	Enforcement of Laws and Treaties
EMI	Electro-Magnetic Interference
EPIRB	Emergency Position Indicating Radio Beacon
GPH	Gallons Per Hour
GPS	Global Positioning System
HPA	Helm Pump Assembly
LED	Light Emitting Diode
MARPA	Mini Automatic Radar Plotting Aid
MEP	Marine Environmental Protection
MICA	Management Information, Configuration, and Allowances
MIG	Metal Inert Gas
MOB	Man Overboard



<b>ACRONYM</b>	<b>DEFINITION</b>
MSO	Marine Safety Office
MSS	Marine Safety and Security
MSST	Marine Safety and Security Team
NM	Nautical Mile
NSN	National Stock Number
OHIP	Overhead Hinged Instrument Panel
OIC	Officer-in-Charge
PFD	Personal Flotation Device
PGM-FI	Programmed Fuel Injection
PMS	Preventive Maintenance System
PPE	Personal Protective Equipment
PSS	Port Safety and Security
RBS	Recreational Boating Safety
RFO	Ready for Operation
SAFE	Secured Around Flotation Equipped
SAR	Search and Rescue
SINS	Scalable Integrated Navigation System
SOP	Standard Operating Procedure
TIG	Tungsten Inert Gas
UHMW	Ultra High Molecular Weight
UV	Ultraviolet
VDC	Volts Direct Current
WAAS	Wide Area Augmentation System
XO	Executive Officer
XPO	Executive Petty Officer
XTE	Cross Track Error



Appendix G-List of Acronyms



# INDEX

## A

ACG, 5-10  
 alternator, 3-15, 3-57, 5-10, 5-11, 5-13, 7-21, E-3, E-5  
 ammunition, 2-9, 2-33, 3-91, 6-23, 6-24, C-7  
 ammunition stowage, 3-91  
 anchor, 2-5, 2-9, 2-13, 2-28, 2-30, 2-33, 3-50, 3-52, 3-83, 3-87, 3-90, 3-91, 6-21, A-3, A-5, C-7  
 anchor/ammunition locker, 2-33, 6-24  
 anchoring, 2-30, 3-44, 3-53, 6-1, 6-21  
 angular momentum, 6-22  
 anode, 3-4, 3-5, 3-14, C-5, C-13  
 antenna, 3-39, 3-40, 3-41, 3-42, 3-48, 3-49, 3-51, 3-52, C-7

## B

batteries, 3-57, 3-58, 3-59, 3-60, C-15, D-3  
 battery, 3-8, 3-57, 3-58, 3-59, 3-60, 3-61, 3-63, 3-111, 6-23, 6-24, C-8, C-15, E-5  
 battery box vent, 3-59  
 battery isolator, 3-61  
 battery switch, 3-60, 6-23, 6-24, C-15  
 BCRB, 3-25, F-3  
 beaching plate, 3-17, 3-18  
 boat characteristic, 2-1  
 boat davit operation, 6-1, 6-3  
 boat system, 2-1, 2-3, 3-1, E-3, E-6  
 bow collar reinforcement bracket, 3-25, F-3  
 bow eye, 2-21  
 bow post, 2-3  
 breaker, 3-61, 3-62, 3-72, D-3  
 bulkhead, 2-15  
 buoyancy, 2-3, 3-17, 5-8, 6-17

## C

cabin, 2-3, 2-5, 2-9, 2-13, 2-14, 2-16, 2-17, 2-18, 2-19, 2-24, 2-26, 2-29, 2-33, 2-34, 3-19, 3-21, 3-22, 3-39, 3-40, 3-44, 3-45, 3-47, 3-48, 3-49, 3-54, 3-56, 3-58, 3-60, 3-61, 3-62, 3-65, 3-66, 3-67, 3-68, 3-71, 3-74, 3-83, 3-84, 3-85, 3-86, 3-89, 3-91, 3-93, 3-95, 3-96, 3-99, 3-100, 3-104, 3-107, 3-108, 3-110, 3-111, 4-9, 6-6, 6-24, 6-26, 6-29, 6-30, 6-32, A-3, A-4, A-5, A-6, C-1, C-8, C-9, C-15, E-3, E-5  
 cabin dewatering pump, 2-19, 3-61, C-8, C-9, E-3  
 cabin dome light, 3-110  
 cabin fan, 3-53, 3-62, 3-107, 3-108

cabin roof light, 3-99  
 cabin windows, 2-16  
 capsizing, 7-3, 7-5  
 CASREP, 5-3, 5-6, F-3  
 casualty report, 5-3, 5-6, F-3  
 certified crew, 4-3, 4-7  
 circuit overload protection, 3-61  
 CO, 4-5, 4-7, 5-3, 5-4, 5-5, 5-6, F-3  
 collar, 2-3, 2-5, 2-21, 3-1, 3-17, 3-25, 3-26, 7-9, 7-19, C-5, E-4, E-6, F-3  
 collar system, 3-1, 3-25  
 collision regulations, 3-99, F-3  
 COLREGS, 3-99, F-3  
 communication, 6-11, 7-1, 7-21  
 compass, 3-43, 3-44, 3-53, 3-54, E-3, E-5  
 configuration control, 1-9  
 control panel indicator, 5-10, 5-11  
 cooling, 3-6, 5-10, 6-5, 6-6, 7-16, C-13, D-3, E-3, E-5  
 coxswain, 3-10, 3-11, 3-39, 3-43, 3-52, 3-53, 4-1, 4-3, 4-5, 4-7, 4-9, 5-4, 5-5, 5-9, 6-6, 6-7, 6-9, 6-18, 7-8, 7-10, 7-12, 7-15, 7-17, 7-19  
 crew member, 4-3, 4-7  
 crew requirements, 4-1

## D

damage to collar, 7-19, E-4  
 davit, 6-3  
 dead-in-the-water, 2-5, F-3  
 deck, 2-3, 2-9, 2-18, 2-19, 2-25, 2-26, 2-27, 2-33, 2-34, 2-35, 3-21, 3-22, 3-23, 3-24, 3-33, 3-62, 3-73, 3-86, 3-88, 3-96, 3-100, 3-103, 3-109, 3-111, 3-112, 5-9, 6-7, 6-23, 6-24, 7-4, 7-6, C-1, C-7, A-6, A-7, A-11  
 deck drain, 2-3, 3-21, 3-22, 3-23  
 deck edge light, 3-103  
 deck lighting, 2-9, 2-26  
 deck locker, 2-33, 2-34, 3-74, 3-109, 6-24, A-6, A-11  
 defense operations, 2-4, F-3  
 depth sounder, 3-42, 3-43, 3-62, C-5, C-15, E-3  
 DES, 3-39, 3-48, F-3  
 DGPS, 3-47, 3-51, 3-53, 3-62, 7-21, F-3  
 diagonal stiffener, 3-19  
 diesel fuel tank, 2-18, 2-34, 3-34, 3-73  
 digital compass, 3-43  
 digital encryption standard, 3-39, 3-48, F-3  
 digital select calling, 3-40, 3-49, F-3  
 disabling casualties, 5-3, D-1  
 distribution panel, 3-62, 3-63  
 DIW, 2-5, F-3



DO, 2-4, F-3  
DSC, 3-40, 3-49, F-3

## E

EC, 1-7, B-1, B-3, C-3, F-3  
effects of wind, 6-13, 6-18  
ELC, ii, F-3  
electrical system, 2-34, 3-1, 3-57, 3-72  
electro-magnetic interference, F-3  
ELT, 2-4, F-3  
emergency position indicating radio beacon, 3-111,  
A-4, F-3  
emergency procedure, 1-1, 4-1, 7-1  
EMI, F-3  
enforcement of laws and treaties, 2-4, F-3  
engine, 3-4, 3-5, 3-6, 3-7, 3-8, 3-9, 3-10, 3-11, 3-12,  
3-13, 3-14, 3-16, 3-29, 3-37, 3-57, 3-60, 5-7, 5-9,  
5-11, 5-12, 5-13, 6-5, 6-6, 6-7, 7-2, 7-7, 7-9, 7-11,  
7-13, 7-15, 7-17, C-13, C-15, D-1, D-3, D-4, E-3,  
E-5, F-3  
engine cooling system, 3-6  
engine fuel system, 3-7  
engine high water temperature, 7-17  
engine key switch panels, 3-10  
engine starting, 3-10, 3-60  
engineering change, 1-7, B-1, B-3, C-3, F-3  
engineering logistics center, ii, F-3  
EPIRB, 3-111, 3-112, A-6, C-7, D-3, F-3  
exterior light, 3-95, 3-99  
e-z jack, 3-81

## F

facility manager, 1-1, 1-5, 1-7  
fire extinguisher, 2-18, 2-34, 3-109, A-3, A-5, A-7,  
A-8, C-11, C-16, D-4, E-4  
first aid kit, 3-108, A-3, A-5  
flo-torq, 3-16  
flo-torq II system, 3-16  
following sea, 5-8, 6-17  
forward battery vent, 3-60  
fuel, 2-5, 2-9, 2-18, 2-33, 3-6, 3-7, 3-17, 3-33, 3-34,  
3-35, 3-36, 3-38, 3-71, 3-74, 5-7, 5-12, 6-5, 6-23,  
6-24, 7-2, 7-9, A-4, A-6, C-7, C-11, D-3, E-3, E-5  
fuel consumption, 5-7, 5-12  
fuel filter, 2-18, 2-33, 3-6, 3-36, 3-74, 6-5, 7-9  
fuel pressure, 7-13  
fuel priming bulb, 3-7  
fuel system, 3-7, 3-33, A-4, A-6  
fuel tank, 2-5, 2-9, 2-18, 2-33, 3-17, 3-33, 3-34, 3-35,  
3-38, 3-74, 5-7, 6-5, 6-23, 6-24, 7-13, C-11  
fuel tank fill, 3-34, 3-35, 3-38, C-11  
fuel tank vent, 3-33, 3-34

fuel totalizer, 5-12  
fuse panel, 3-15

## G

global positioning system, 3-42, 3-51, 3-102, 7-17,  
A-4, A-6, C-7, E-3, F-3  
going alongside, 6-1, 6-9  
GPS, 3-41, 3-42, 3-111, 7-21, A-6, A-11, C-7, E-3,  
F-3  
GPS receiver/antenna, 3-42, 3-51, 3-52  
ground, 3-43, 3-63

## H

handling characteristic, 6-1, 6-13  
handrail, 2-24  
head seas, 6-13, 6-16  
heater, 2-3, 2-18, 2-33, 2-34, 3-58, 3-62, 3-71, 3-72,  
3-73, 3-74, 3-109, 6-23, C-7, C-11, C-15  
heater diesel fuel tank, 3-73, 3-74  
heater exhaust, 3-58, 3-71, 3-72, C-7  
heater intake, 3-71, 3-72, C-7  
heater thermostat, 3-72  
heating system, 3-1, 3-71  
helicopter, 6-20  
helm dash panel, 5-12, 5-13  
helm pump, 3-29, 3-31, 3-32, 7-9, C-15, F-3  
helm pump assembly, 3-29, F-3  
horn, 3-41, 3-47, 3-62, 3-111, C-7  
hose, 3-38, E-5  
HPA, 3-29, F-3  
hull, 2-1, 2-3, 2-5, 2-6, 2-7, 2-9, 3-1, 3-7, 3-17, 3-19,  
3-20, 3-21, 3-25, 3-32, 3-33, 3-63, 3-83, 3-85, 3-  
89, 3-91, 5-8, 6-5, 6-15, 6-24, 7-4, 7-8, C-1, C-3,  
C-5, D-4, E-3, E-5  
hull access plug, 3-19  
hull construction, 2-7, 3-20  
hull exterior lighting, 3-1, 3-95, 3-99  
hull reference point, 2-6  
hull system, 3-1, 3-17  
hydraulic fluid, 3-29  
hydraulic steering cylinder, 3-29

## I

ignition, 3-8, 3-10, 3-11, 3-12, 3-15, 3-71, 7-15, 7-17,  
D-3  
ignition system, 3-8, 3-71  
inboard profile, 2-12  
inspection guideline, C-3  
inspection standard, C-3

**K**

key switch panel, 3-10, 3-11

**L**

law enforcement light, 3-96, 3-100, 3-103  
 LED, 2-26, F-3  
 lifting eye, 2-28, 2-34, C-7  
 lifting strake, 3-17, 3-18  
 light switch panel, 3-96, 3-97, 3-100, 3-101  
 loading, 3-16, 3-81, 6-1, 6-24, 6-26, 6-27, 6-28, 6-29,  
 6-30, 6-31, 6-32  
 loss of control of engine RPM, 7-11, 7-13  
 loss of lube oil pressure, 7-15  
 loudhailer, 3-41, 3-47  
 lubrication, 3-6, E-3, E-5  
 lubrication system, 3-6, E-3

**M**

magnetic compass, 3-44, 3-53  
 main deck, 2-1, 2-21, 2-33, 3-19, A-3, A-5  
 main deck equipment, 2-1, 2-21  
 main deck stowage, 2-1, 2-33  
 major discrepancies, 5-4, 5-5, E-1  
 man overboard, 3-41, 3-50, F-3  
 management information, configuration, and  
 allowances, A-1, F-3  
 maneuverability, 6-18  
 manual relief valve, 3-5, 3-13  
 manufacturer, 2-3, 3-8, C-3  
 marine environmental protection, 2-4, F-3  
 marine safety and security, 2-4, F-3  
 marine safety office, F-3  
 MARPA, 3-41, F-3  
 material inspection checklist, C-1, C-3  
 MEP, 2-4, F-3  
 metal inert gas, 2-3, F-3  
 MICA, A-1, F-3  
 MIG, 2-3, F-3  
 mini automatic radar plotting aid, 3-41, F-3  
 minimum crew, 4-3  
 minor discrepancies, 5-4, 5-5  
 mission, 3-95, 3-99, 3-111, 4-3, 4-5, 4-7, 5-1, 5-4, 5-  
 5, 6-1, 6-5, 6-11, 6-23, 7-1, A-1, C-1  
 mission performance, 6-1  
 MOB, 3-41, 3-50, F-3  
 motorola, 3-39, 3-48, 3-62  
 MSO, F-3  
 MSS, 2-4, F-3

**N**

national stock number, F-4  
 navigation equipment, 3-39, 3-47, 4-7, 7-21, C-15

navigation light, 2-29, 3-96, 3-97, 3-100, 3-102, 3-  
 103, C-5, D-4, E3  
 NM, 2-5, 3-41, 3-50, 3-51, 3-111, 5-7, F-4  
 non-skid, 2-3, 2-25  
 NSN, F-4

**O**

OHIP, 2-9, 2-26, 3-40, 3-42, 3-43, 3-49, 3-57, 3-94,  
 3-95, 3-96, 3-98, 3-99, 3-100, 3-107, 3-111, 5-13,  
 6-24, F-4  
 oil pressure, 5-9, 5-11, 7-15, E-3  
 operating parameter, 5-1, 5-3  
 operating with helicopters, 6-1, 6-20  
 operational guideline, 5-1  
 outboard engine, 2-18, 2-34, 3-3, 3-4, 3-5, 3-7, 3-8,  
 3-15, 3-33, 3-36, 3-57, 6-5, 7-15, C-1, C-5, C-13,  
 D-3, E-3, E-5  
 outboard profile, 2-10, 2-11  
 overhead hinged instrument panel, 2-9, F-4

**P**

passenger, 2-5, 2-19  
 pedestal, 3-83  
 performance fin, 3-17, 3-18  
 personal flotation device, 3-10, 3-11, F-4  
 personal protective equipment, 4-11, 6-6, F-4  
 personal protective gear, 6-7  
 PFD, 3-10, 3-11, F-4  
 PGM-FI, 5-10, F-4  
 PMS, 5-3, E-5, F-4  
 port navigation light, 2-29, 3-96, 3-100, 3-102  
 port safety and security, 2-4, F-4  
 power tilt switch, 3-4, 3-12  
 PPE, 4-11, 6-6, F-4  
 pre-start, 6-5  
 preventive maintenance system, 5-3, E-5, F-4  
 primer bulb, 2-18, 2-33, 3-37, 6-5  
 programmed fuel injection, 5-10, 5-11, F-4  
 propellers, 2-5, 3-15, 3-16, 5-7  
 propulsion, 3-3, 3-33, 3-34, 5-10  
 propulsion fuel system, 3-1, 3-33  
 propulsion system, 3-1, 3-3  
 PSS, 2-4, F-4  
 pump, 2-19, 2-34, 3-6, 3-7, 3-29, 3-71, A-4, A-6  
 pump stowage, 2-34

**Q**

quartering the sea, 6-18

**R**

radar, 2-3, 2-24, 2-30, 3-41, 3-42, 3-45, 3-47, 3-50, 3-51, 3-52, 3-56, 3-62, 3-87, 3-96, 3-100, 3-104, 3-111, 6-25, 6-29, 6-32, 7-17, C-7, C-15, D-3, E-3, E-5, F-3  
radar/GPS, 3-42  
radome antenna, 3-41, 3-51  
raymarine, 3-40, 3-41, 3-47, 3-48, 3-49, 3-62  
raymarine 215 VHF transceiver, 3-40, 3-49  
raymarine 430 loudhailer, 3-41, 3-47, 3-48  
raytheon, 3-41, 3-42  
raytheon RL80CRC radar, 3-41  
RBS, 2-4, F-4  
ready for operation, 5-3, F-4  
recreational boating safety, 2-4, F-4  
repair and removal, 3-27  
restrictive discrepancies, 5-3, 5-6  
restrictive discrepancy, 5-5  
RFO, 5-3, F-4  
rig tube, 2-18, 2-33, 2-34, 3-19  
ring buoy, 2-30

**S**

SAFE, 2-3, 2-28, 3-25, 3-27, F-4  
safety equipment, 4-1, 4-11  
SAR, 2-4, 3-111, F-4  
scupper, 3-22, 3-23  
seakeeping, 3-17, 5-9  
search and rescue, 2-4, 3-111, F-4  
searchlight, 3-95, 3-96, 3-99, 3-100, 6-24, 6-25, 6-29, 6-32, C-8, C-15  
searchlight control, 3-96, 3-100, C-15  
seat, 2-18, 2-19, 3-43, 3-58, 3-65, 3-66, 3-67, 3-68, 3-69, A-3, A-5, C-9  
seating system, 3-1, 3-65, 3-67  
secured around flotation equipped, 2-3, 2-28, 3-25, 3-27, F-4  
sliding cabin door, 2-15  
SOP, 6-9, 6-11, F-4  
sound insulation, 3-17  
speed, 2-5, 3-9, 3-41, 3-50, 3-52, 3-57, 3-107, 5-9, 5-11, 5-12, 6-9, 6-10, 6-11, 6-15, 6-17, D-3  
spotter window, 2-9, 2-17  
ST60 digital compass, 3-43  
stability, 3-17, 3-25, 3-29, 3-44, 3-53, 5-9  
standard cleat, 2-22  
standard operating procedure, 6-9, 6-11, F-4  
standby/magnetic compass, 3-44

starboard navigation light, 2-29, 3-100, 3-103  
starter, 3-8, 3-15  
starting procedure, 6-1, 6-5  
station keeping, 6-13, 6-19  
steering actuator, 7-9, C-1, C-5, C-13, D-3, E-3, E-5  
steering casualty, 7-9  
steering cylinder, 3-29, 3-31, 3-32  
steering system, 3-1, 3-29, 3-30, 6-5, 7-9, D-3  
steering wheel, 3-31, 3-32, 3-72, C-15  
stern-to, 6-19  
storage locker, 3-22  
stowage, 3-92, 3-111, A-1, A-3, A-4, A-5, A-6, C-15

**T**

tachometer, 5-11  
thermostat, 3-12  
throttle control, 3-9, 3-10, 5-10, C-15  
tie bar, 3-29, 3-31, C-13  
tie bar assembly, 3-29  
TIG, 2-3, F-4  
tilt lock lever, 3-4, 3-13, 3-14  
tow bitt, 2-22, 2-23, 3-91, C-7  
tow post, 2-3  
towing, 2-5, 2-30, 3-79, 3-80, 3-86, 3-87, 3-89, 3-104, 6-1, 6-22, A-4, A-6  
towlight, 3-103, 3-104, C-8, C-16  
towline reel, 2-30, 2-31, 2-32  
trailer, 2-5, 2-25, 3-1, 3-45, 3-56, 3-77, 3-78, 3-79, 3-80, 3-81, 3-82, 3-83, 3-84, 6-24, 6-26, 6-29, 6-30, 6-32  
trailer hitch, 3-79, 6-38  
trailer system, 3-1, 3-77  
transceiver, 3-39, 3-40, 3-48, 3-49, E-3  
transom eye, 2-25  
trim tilt indicator, 5-11  
tungsten inert gas, 2-3, F-4  
turning, 3-12, 3-13, 3-17, 6-15  
turning and pivoting, 6-13, 6-15

**U**

UHMW, 3-25, F-4  
ultra high molecular weight, 3-25, F-4  
ultraviolet, 2-3, 3-25, F-4  
underway, 3-89, 3-109, 4-1, 4-5, 5-3, 5-4, 5-5, 5-6, 6-1, 6-6, 6-7, 6-13, 7-1  
unloading, 3-81, 6-1, 6-24, 6-26, 6-27, 6-32  
UV, 2-3, 3-25, F-4

**V**

VHF-FM, 3-39, 3-48  
voltmeter, 3-57, 5-13, 7-21





## W

WAAS, 3-47, 3-51, 3-52, F-4  
walking surface, 2-3  
water separator, 3-7, 3-8, 3-36, C-13  
weapons mounting/stowage, 3-1, 3-83  
weather-tight door, 2-9, 2-15, 2-16, 2-18  
wide area augmentation system, 3-47, 3-51, 3-52, F-4  
window, 2-14, 2-15, 2-18, 3-75  
window defroster, 3-75  
windshield wiper motor, 3-107, 3-108  
windshield wiper switch, 3-1, 3-108  
windshield wipers and washer, 3-107, 3-108, C-16





Index