Getting the MPL to Display Data Again

I.   Purpose:

To describe the procedure to be performed to get the data program to display when the MPL computer is displaying the workspace shell.

II.   Cautions and Hazards:

None.

III.   Requirements:

None.

IV.   Procedure:

A.   Steps:

1.   Place one finger on the CTRL key. Press the ESC key once.

2.   The Window List should appear in the middle of the screen.

3.   Highlight the entry that reads 'mpl.exe'.

4.   Press ENTER.

5.   The data program should reappear.

V.   References:

None.

VI.   Attachments:

None.