MPLHR Shutdown and Restart

I.   Purpose:

To describe the procedure for turning the MPLHR off and back on again along with how to turn off the Lidar and Laser power supplies.

II.   Cautions and Hazards:

None.

III.   Requirements:

None.

IV.   Procedure:

A.   MPLHR Power OFF:

1.   Press CTRL-ESC at the same time. You will see a blue background and a window list.

2.   Move the cursor out into the blue area.

3.   Press the right mouse button. A menu will appear.

4.   Select Shutdown. Answer YES or OK until you get the message "Press CTRL-ALT-DEL to restart the system."

5.   Press the CTRL, ALT and DEL keys at the same time. This will reboot the system.

B.   Turning OFF the Lidar Power Supply and the Laser Power Supply:

1.   Perform 1-4 steps above.

2.   Turn OFF the Main and Monitor toggle switches located to the right of the monitor.

3.   Turn OFF the toggle switch on the Lidar Power Supply.

4.   Turn OFF the key on the Laser Power Supply.

C.   To Turn Power Back ON:

1.   Turn ON the key on the Laser Power Supply.

2.   Turn ON the toggle switch on the Lidar Power Supply.

3.   Turn ON the monitor switch located to the right of the monitor.

4.   Turn ON the Main switch located to the right of the monitor.

- If you see "Workspace Shell" and no graphs, look for the MPL.EXE icon. Double click this icon and the graphs will reappear.

V. References:

None.

VI. Attachments:

None.