MWR Reboot

I.   Purpose:

This procedure is used to reboot the MWR when instructed to do so by TWP.

II.   Cautions and Hazards:

None

III.   Requirements:

None

IV.   Procedure:

A.   Steps:

1.   Go to the MWR laptop in the D-van.

2.   Click "Restart" on the laptop.

3.   Report your actions on the Daily Rounds report.

V.   References:

None

VI.   Attachments:

None