Department of Defense

be paid to the Contractor in the final payment under the contract.

(3) The retained percentage will be paid in accordance with the Payments to Contractor clause of this contract.

(f) The Contracting Officer shall determine the value and suitability of the construction plant, equipment, materials, structures and facilities. The Contracting Officer's determinations are not subject to appeal.

(End of clause)

[56 FR 36479, July 31, 1991, as amended at 62 FR 2614, Jan. 17, 1997]

252.236–7004 Payment for mobilization and demobilization.

As prescribed in 236.570(b)(2), use the following clause:

PAYMENT FOR MOBILIZATION AND DEMOBILIZATION (DEC 1991)

(a) The Government will pay all costs for the mobilization and demobilization of all of the Contractor's plant and equipment at the contract lump sum price for this item.

(1) _____ percent of the lump sum price upon completion of the contractor's mobilization at the work site.

(2) The remaining _____ percent upon completion of demobilization.

(b) The Contracting Officer may require the Contractor to furnish cost data to justify this portion of the bid if the Contracting Officer believes that the percentages in paragraphs (a) (1) and (2) of this clause do not bear a reasonable relation to the cost of the work in this contract.

(1) Failure to justify such price to the satisfaction of the Contracting Officer will result in payment, as determined by the Contracting Officer, of—

(i) Actual mobilization costs at completion of mobilization;

(ii) Actual demobilization costs at completion of demobilization; and

(iii) The remainder of this item in the final payment under this contract.

(2) The Contracting Officer's determination of the actual costs in paragraph (b)(1) of this clause is not subject to appeal.

(End of clause)

252.236–7005 Airfield safety precautions.

As prescribed in 236.570(b)(3), use the following clause. At some airfields, the width of the primary surface is 1,500 feet (750 feet on each side of the runway centerline). In such instances, substitute the proper width in the clause.

AIRFIELD SAFETY PRECAUTIONS (DEC 1991)

252.236-7005

AIRFIELD SAFETY PRECAUTIONS (DEC 1991)

(a) Definitions. As used in this clause-

(1) Landing areas means—

(i) The primary surfaces, comprising the surface of the runway, runway shoulders, and lateral safety zones. The length of each primary surface is the same as the runway length. The width of each primary surface is 2,000 feet (1,000 feet on each side of the runway centerline);

(ii) The *clear zone* beyond the ends of each runway, i.e., the extension of the primary surface for a distance of 1,000 feet beyond each end of each runway;

(iii) All taxiways, plus the lateral clearance zones along each side for the length of the taxiways (the outer edge of each lateral clearance zone is laterally 250 feet from the far or opposite edge of the taxiway, e.g., a 75foot-wide taxiway would have a combined width of taxiway and lateral clearance zones of 425 feet); and

(iv) All aircraft parking aprons, plus the area 125 feet in width extending beyond each edge all around the aprons.

(2) Safety precaution areas means those portions of approach-departure clearance zones and transitional zones where placement of objects incident to contract performance might result in vertical projections at or above the approach-departure clearance, or the transitional surface.

(i) The approach-departure clearance surface is an extension of the primary surface and the clear zone at each end of each runway, for a distance of 50,000 feet, first along an inclined (glide angle) and then along a horizontal plane, both flaring symmetrically about the runway centerline extended.

(A) The inclined plane (glide angle) begins in the clear zone 200 feet past the end of the runway (and primary surface) at the same elevation as the end of the runway. It continues upward at a slope of 50:1 (1 foot vertically for each 50 feet horizontally) to an elevation of 500 feet above the established airfield elevation. At that point the plane becomes horizontal, continuing at that same uniform elevation to a point 50,000 feet longitudinally from the beginning of the inclined plane (glide angle) and ending there.

(B) The width of the surface at the beginning of the inclined plane (glide angle) is the same as the width of the clear zone. It then flares uniformly, reaching the maximum width of 16,000 feet at the end.

(ii) The *approach-departure clearance zone* is the ground area under the approach-departure clearance surface.

(iii) The *transitional surface* is a sideways extension of all primary surfaces, clear zones, and approach-departure clearance surfaces along inclined planes.

(A) The inclined plane in each case begins at the edge of the surface.