Environmental Protection Agency

emissions equations or factors, provided they allow estimation of both wet-out area and oven organic HAP emissions, where necessary, and have been approved by your permitting authority. If a previously established equation or factor is specific to the wet-out area only, or to the oven only, then you must develop the corresponding uncontrolled or controlled equation or factor for the other organic HAP emissions source.

- (2) For uncontrolled (controlled) organic HAP emissions estimates, you may use controlled (uncontrolled) organic HAP emissions estimates and control device destruction efficiency to calculate your uncontrolled (controlled) organic HAP emissions provided the control device destruction efficiency was calculated at the same you collected the data to develop your facility's controlled (uncontrolled) organic HAP emissions estimation equations and factors.
- (c) Assign to each formula an uncontrolled organic HAP emissions estimation equation or factor based on the end product/thickness combination for which that formula is used.
- (d)(1) To calculate your annual uncontrolled organic HAP emissions from wet-out areas that do not have any capture and control and from wet-out areas that are captured by an enclosure but are vented to the atmosphere and not to a control device, multiply each formula's annual usage by its appropriate organic HAP emissions estimation equation or factor and sum the individual results.
- (2) To calculate your annual uncontrolled organic HAP emissions that escape from the enclosure on the wet-out area, multiply each formula's annual usage by its appropriate uncontrolled organic HAP emissions estimation equation or factor, sum the individual results, and multiply the summation by 1 minus the percent capture (expressed as a fraction).
- (3) To calculate your annual uncontrolled oven organic HAP emissions, multiply each formula's annual usage by its appropriate uncontrolled organic HAP emissions estimation equation or factor and sum the individual results.
- (4) To calculate your annual controlled organic HAP emissions, mul-

tiply each formula's annual usage by its appropriate organic HAP emissions estimation equation or factor and sum the individual results to obtain total annual controlled organic HAP emissions.

(e) Where a facility is calculating both uncontrolled and controlled organic HAP emissions estimation equations and factors, you must test the same formulae. In addition, you must develop both sets of equations and factors from the same tests.

§ 63.5875 How do I determine the capture efficiency of the enclosure on my wet-out area and the capture efficiency of my oven(s) for continuous lamination/casting operations?

- (a) The capture efficiency of a wetout area enclosure is assumed to be 100 percent if it meets the design and operation requirements for a permanent total enclosure (PTE) specified in EPA Method 204 of appendix M to 40 CFR part 51. If a PTE does not exist, then a temporary total enclosure must be constructed and verified using EPA Method 204, and capture efficiency testing must be determined using EPA Methods 204B through E of appendix M to 40 CFR part 51.
- (b) The capture efficiency of an oven is to be considered 100 percent, provided the oven is operated under negative pressure.

§ 63.5880 How do I determine how much neat resin plus is applied to the line and how much neat gel coat plus is applied to the line for continuous lamination/casting operations?

Use the following procedures to determine how much neat resin plus and neat gel coat plus is applied to the line each year.

- (a) Track formula usage by end product/thickness combinations.
- (b) Use in-house records to show usage. This may be either from automated systems or manual records.
- (c) Record daily the usage of each formula/end product combination on each line. This is to be recorded at the end of each run (*i.e.*, when a changeover in formula or product is made) and at the end of each shift.
- (d) Sum the amounts from the daily records to calculate annual usage of

§ 63.5885

each formula/end product combination by line.

§63.5885 How do I calculate percent reduction to demonstrate compliance for continuous lamination/ casting operations?

You may calculate percent reduction using any of the methods in paragraphs (a) through (d) of this section.

(a) Compliant line option. If all of your wet-out areas have PTE that meet the requirements of EPA Method 204 of appendix M of 40 CFR part 51, and all of your wet-out area organic HAP emissions and oven organic HAP emissions are vented to an add-on control device, use Equation 1 of this section to demonstrate compliance. In all other situations, use Equation 2 of this section to demonstrate compliance.

$$PR = \frac{(Inlet) - (Outlet)}{(Inlet)} \times 100 \quad (Eq. 1)$$

Where:

PR=percent reduction;

Inlet+HAP emissions entering the control device, lbs per year; Outlet=HAP emissions existing the control

device to the atmosphere, lbs per year.

$$PR = \frac{(WAE_{ci} + O_{ci}) - (WAE_{co} + O_{co})}{(WAE_{ci} + WAE_{u} + O_{ci} + O_{u})} \times 100$$
 (Eq. 2)

Where:

PR=percent reduction;

WAEici=wet-out area organic HAP emissions, lbs per year, vented to a control device;

WAEi_u=wet-out area organic HAP emissions, lbs per year, not vented to a control de-

Oju=oven organic HAP emissions, lbs per year, not vented to a control device;

Ojci=oven organic HAP emissions, lbs per year, vented to a control device; WAEi_{co}=wet-out area organic HAP emissions,

lbs per year, from the control device out-

 Oj_{co} =oven organic HAP emissions, lbs per year, from the control device outlet.

(b) Averaging option. Use Equation 3 of this section to calculate percent reduction.

$$PR = \frac{\left(\sum_{i=1}^{m} WAEi_{ci} + \sum_{j=1}^{n} Oj_{ci}\right) - \left(\sum_{i=1}^{m} WAEi_{co} + \sum_{j=1}^{n} Oj_{co}\right)}{\left(\sum_{i=1}^{m} WAEi_{ci} + \sum_{j=1}^{n} Oj_{ci} + \sum_{i=1}^{m} WAEi_{u} + \sum_{j=1}^{n} Oj_{u}\right)} \times 100$$
 (Eq. 3)

Where:

PR=percent reduction;

WAEici=wet-out area organic HAP emissions from wet-out area i, lbs per year, sent to a control device;

WAEi_u=wet-out area organic HAP emissions from wet-out area i, lbs per year, not sent to a control device;

WAEico=wet-out area organic HAP emissions from wet-out area i, lbs per year, at the outlet of a control device;

 Oj_u =organic HAP emissions from oven j, lbs per year, not sent to a control device;

Ojci=organic HAP emissions from oven j, lbs per year, sent to a control device;