

(4) How often the person offering the flight conducts such flights;

(5) The route of the flight;

(6) The inclusion of sightseeing flights as part of any travel arrangement package;

(7) Whether the flight in question would have been canceled based on poor visibility of the surface below the route of the flight; and

(8) Any other factors that the FAA considers appropriate.

*Commercial Air Tour operator* means any person who conducts a commercial air tour.

*Life preserver* means a flotation device used by an aircraft occupant if the aircraft ditches in water. If an inflatable device, it must be uninflated and ready for its intended use once inflated. In evaluating whether a non-inflatable life preserver is acceptable to the FAA, the operator must demonstrate to the FAA that such a preserver can be used during an evacuation and will allow all passengers to exit the aircraft without blocking the exit. Each occupant must have the physical capacity to wear and inflate the type of device used once briefed by the commercial air tour operator. Seat cushions do not meet this definition.

*Raw terrain* means any area on the surface, including water, devoid of any person, structure, vehicle, or vessel.

*Shoreline* means that area of the land adjacent to the water of an ocean, sea, lake, pond, river or tidal basin that is above the high water mark and excludes land areas unsuitable for landing such as vertical cliffs or land intermittently under water during the particular flight.

*Suitable landing area for helicopters* means an area that provides the operator reasonable capability to land without damage to equipment or injury to persons. Suitable landing areas must be site-specific, designated by the operator, and accepted by the FAA. These site-specific areas would provide an emergency landing area for a single-engine helicopter or a multiengine helicopter that does not have the capability to reach a safe landing area after an engine power loss.

(e) In an in-flight emergency requiring immediate action, the pilot in command may deviate from any rule of

this subpart to the extent required to meet that emergency.

### § 136.3 Letters of Authorization.

Operators subject to this subpart who have Letters of Authorization may use the procedures described in 14 CFR 119.51 to amend or have the FAA reconsider those Letters of Authorization.

### § 136.5 Additional requirements for Hawaii.

No person may conduct a commercial air tour in the State of Hawaii unless they comply with the additional requirements and restrictions in appendix A to part 136.

### § 136.7 Passenger briefings.

(a) Before takeoff each pilot in command shall ensure that each passenger has been briefed on the following:

(1) Procedures for fastening and unfastening seatbelts;

(2) Prohibition on smoking; and

(3) Procedures for opening exits and exiting the aircraft.

(b) For flight segments over water beyond the shoreline, briefings must also include:

(1) Procedures for water ditching;

(2) Use of required life preservers; and

(3) Procedures for emergency exit from the aircraft in the event of a water landing.

### § 136.9 Life preservers for over water.

(a) Except as provided in paragraphs (b) or (c) of this section, the operator and pilot in command of commercial air tours over water beyond the shoreline must ensure that each occupant is wearing a life preserver from before takeoff until flight is no longer over water.

(b) The operator and pilot in command of a commercial air tour over water beyond the shoreline must ensure that a life preserver is readily available for its intended use and easily accessible to each occupant if:

(1) The aircraft is equipped with floats; or

(2) The airplane is within power-off gliding distance to the shoreline for the duration of the time that the flight is over water.