

Table of Contents

CHAPTER 1. INTRODUCTION	1
1. General.....	1
2. Background.....	1
3. Limitations to NDT.....	2
CHAPTER 2. DESCRIPTION OF NDT PROCESS	3
4. General.....	3
5. Pavement Stiffness and Sensor Response.....	3
6. Deflection Basin.	4
7. Use of NDT Data.	6
CHAPTER 3. NONDESTRUCTIVE TESTING EQUIPMENT	7
8. General.....	7
9. Categories of Equipment.....	7
10. General Requirements for NDT Equipment.	10
11. Static Devices.	11
12. Vibratory Devices.	12
13. Impulse Devices.....	13
14. Use of Historical Data.....	17
CHAPTER 4. REQUIREMENTS FOR NONDESTRUCTIVE TESTING EQUIPMENT	19
15. General.....	19
16. Need for Standardization.	19
17. FAA Sensitivity Study.....	20
18. Summary of FAA Policy.	22
CHAPTER 5. TEST PLANNING	23
19. General.....	23
20. Justification for NDT.....	23
21. NDT Test Objectives.	24
22. NDT Test Types.....	24
23. Test Locations and Spacing.....	25
24. NDT Test Sketches.....	27
25. Special Considerations.....	29
CHAPTER 6. TEST PROCEDURES	31
26. General.....	31
27. Equipment Mobilization.	31
28. Startup Operations.	32
29. Data Collection.	32
30. Special Test Conditions.	34
31. Onsite Review of Data.....	35
CHAPTER 7. DEFLECTION DATA ANALYSES	37
32. General.....	37
33. Overview of Process.....	37
34. Process Raw Deflection Data.....	39
35. Back-Calculation Analysis.....	43
36. PCC Joint Analysis.....	62
37. PCC Void Analysis.....	65
38. PCC Durability Analysis.	67

39.	Summary.....	69
CHAPTER 8. NDT-BASED EVALUATION AND DESIGN INPUTS		71
40.	General.....	71
41.	Statistically Derived Inputs.....	71
42.	Using NDT Results in FAA Analysis Programs.....	75
43.	PCC Loss of Support.	77
44.	Summary.....	78

List of Figures

Figure 1.	Impulse Load Created by FWD.....	4
Figure 2.	Sensors Spaced Radially from the Load Plate.....	4
Figure 3.	Schematic of Deflection Basin.....	5
Figure 4.	Comparison of Deflection Basin of Three Pavements.....	6
Figure 5.	Static and Dynamic Force Components for Vibratory NDT.....	7
Figure 6.	Time to Peak Load for Impulse-Based NDT Equipment.....	8
Figure 7.	Benkleman Beam.....	11
Figure 8.	Dynalect Deflection Trailer.....	12
Figure 9.	Road Rater.....	13
Figure 10.	Kuab FWD.....	15
Figure 11.	Dynatest FWD.....	15
Figure 12.	Carl Bro FWD/HWD and LWD Trailer, Van-Integrated or Portable.....	16
Figure 13.	JILS HWD.....	17
Figure 14.	Evaluation of HWD Force Linearity in Terms of ISM.....	22
Figure 15.	Evaluation of HWD Force Linearity in Terms of Subgrade Elastic Modulus.....	22
Figure 16.	NDT Test Locations within a PCC Slab.....	24
Figure 17.	Load Transfer across A PCC Joint.....	25
Figure 18.	Example Runway or Taxiway Sketch When Centerline Lies on Slab Joint.....	27
Figure 19.	Example Runway or Taxiway Sketch When Centerline Does Not Lie on Slab Joint.....	27
Figure 20.	Example Runway or Taxiway Sketch for HMA Pavements.....	28
Figure 21.	Thermal Curling in PCC Slab from Temperature Changes.....	29
Figure 22.	Location of Additional Sensors for Corner and Joint Testing.....	34
Figure 23.	NDT Data Analysis And Design Flowchart.....	37
Figure 24.	ISM Plot to Identify Pavement Section Breaks.....	40
Figure 25.	Normalized Deflection Plot Used to Identify Pavement Section Breaks.....	41
Figure 26.	Normalized Subgrade Deflection Plot Used to Identify Pavement Sections.....	42
Figure 27.	Process for Data Preparation and Back-Calculation Method Selection.....	44
Figure 28.	Flowchart for Closed-Form Back-Calculation Using Area Method.....	46
Figure 29.	Basin Area for SHRP Four-Sensor Configuration.....	47
Figure 30.	Comparison of Measured and Calculated Deflection Basins.....	55
Figure 31.	Back-Calculation Procedures for an Elastic Layer Based Analysis.....	60
Figure 32.	Initial BAKFAA Run for Example 2.....	61
Figure 33.	Second BAKFAA Run for Example 2.....	61
Figure 34.	Output From Second BAKFAA Run for Example 2.....	62
Figure 35.	Deflection vs. Stress LTE Relationship for 12 Inch (30 cm) Diameter Load Plate.....	64
Figure 36.	Example Plot of Transverse Joint LTE Δ for a 10,000 Ft (3,000 m) Taxiway.....	65
Figure 37.	Void Detection Beneath PCC Slabs.....	66
Figure 38.	Example Plot of Transverse Joint Voids for a 10,000 Ft (3,000 m) Taxiway.....	67
Figure 39.	Example Plot of ISM _{ratio} for Transverse Joint for HMA Overlaid PCC.....	69
Figure 40.	Histogram of ISM Values for Section 3 in Figure 24.....	72

List of Tables

Table 1. Summary of Nondestructive Testing Measuring Equipment.....	9
Table 2. Detailed Specifications for Selected FWDs and HWDs	14
Table 3. ASTM Standards for Deflection Measuring Equipment.....	19
Table 4. Common Sensor Configurations.....	21
Table 5. Typical Runway and Taxiway Test Locations and Spacing, Feet (m)	26
Table 6. Typical Apron Test Locations and Frequency	26
Table 7. FAA Software Tools for Pavement Analysis, Evaluation, And Design	38
Table 8. Theoretical Basis of FAA Software Tools	39
Table 9. Required Sensor Distance (Inch) From Load Plate with 12 Inch (30 cm) Diameter	42
Table 10. Area-Based Constants for Equation 8.....	43
Table 11. Type of Back-Calculation Software Tool Required for Each Load Scenario.....	45
Table 12. Constants for D, (Equation 11)	52
Table 13. Typical Modulus Values and Ranges for Paving Materials.....	52
Table 14. Typical Poisson's Ratios for Paving Materials	53
Table 15. Linear Analysis Back- Calculation Programs.....	54
Table 16. Nonlinear Analysis Back-Calculation Programs	58
Table 17. Seed Modulus and Poisson's Ratios for Example Problem 2.....	59
Table 18. Pavement Joint Performance Ratings	60
Table 19. Statistical Summary of ISM Values for Each Section in Figure 24.....	64
Table 20. Required FAA Advisory Circular Evaluation and Design Inputs.....	74
Table 21. Allowable Modulus Values for FAARFIELD (AC 150/5320-6), psi (MPa).....	75
Table 22. HMA Pavement Base and Subbase Modulus and Equivalency Factor Inputs.....	76
Table 23. Recommended Reduced Values for Loss of Support Conditions	78