



Homeowner's Guide to Retrofitting

Six Ways to Protect Your Home From Flooding

FEMA P-312, 3rd Edition / June 2014



FEMA



Homeowner's Guide to Retrofitting

Six Ways to Protect Your Home From Flooding

FEMA P-312, 3rd Edition / June 2014



FEMA



Preface

The Federal Emergency Management Agency (FEMA) has prepared this guide specifically for homeowners who want to know how to help protect their homes from flooding. As a homeowner, you need clear information about the options available to you and straightforward guidance that will help you make decisions. This guide gives you both, in a form designed for readers who have little or no experience with flood protection methods or building construction techniques.



Acknowledgments

Third Edition Authors and Key Contributors

Seth Frost-Tift, URS Group, Inc.
Amit Mahadevia, URS Group, Inc.
Deborah Mills, Dewberry
Adam Reeder, Atkins
Adrienne Sheldon, URS Group, Inc.
John Squerciati, Dewberry

Third Edition Reviewers and Contributors

Daniel Bass, FEMA Headquarters
William Coulbourne, URS Group, Inc.
Franki Coons, FEMA Headquarters
Jhun de la Cruz, FEMA Headquarters
John Grace, FEMA Region I
Karolyn Kiss, FEMA Headquarters
John Ingargiola, FEMA Headquarters
John “Bud” Plisich, FEMA Region IV
Steven VanDyke, FEMA Headquarters
Gregory Wilson, FEMA Headquarters
Wallace Wilson, URS Group, Inc.

Third Edition Technical Editing, Layout, and Illustration

Young Cho, URS Group, Inc.
Julie Liptak, Stantec
Lee-Ann Lyons, URS Group, Inc.
Susan Patton, URS Group, Inc.
Ivy Porpotage, URS Group, Inc.
Billy Ruppert, URS Group, Inc.
Amy Siegel, URS Group, Inc.



Table of Contents

Preface.....	i
Acknowledgments.....	iii
Acronyms.....	xiii
1.0 About this Guide	1-1
1.1 Who This Guide Is For.....	1-1
1.2 How This Guide Can Help You.....	1-2
1.3 How To Use This Guide	1-2
2.0 Introduction to Retrofitting	2-1
2.1 What Is Retrofitting?	2-3
2.2 Types of Flooding.....	2-3
2.3 How Flooding Can Damage Your Home.....	2-5
2.3.1 Depth/Elevation of Flooding.....	2-5
2.3.2 Flow Velocity.....	2-8
2.3.3 Flood Frequency	2-9
2.3.4 Rates of Rise and Fall.....	2-10
2.3.5 Duration.....	2-11
2.3.6 Debris Impact.....	2-11
2.4 Other Hazards	2-11
2.5 Federal, State, and Local Regulations	2-12
2.5.1 The Community Rating System.....	2-13
2.5.2 Flood Insurance Rate Maps.....	2-14
2.6 Financial Assistance for Retrofitting	2-16
2.6.1 Federal Programs.....	2-16
2.6.2 Non-Federal Help	2-20

TABLE OF CONTENTS

3.0	An Overview of the Retrofitting Methods	3-1
3.1	Cautions	3-2
3.1.1	Substantial Improvement / Substantial Damage	3-2
3.1.2	Basements	3-3
3.1.3	Flood Protection Elevation and Risk	3-3
3.1.4	Freeboard and Flood Mapping Uncertainties	3-6
3.1.5	Human Intervention	3-8
3.1.6	Other Considerations	3-9
3.2	Construction Terminology	3-10
3.2.1	Construction Type	3-10
3.2.2	Foundation Type.....	3-11
3.3	Retrofitting Methods and Costs	3-12
3.3.1	Elevation	3-12
3.3.2	Relocation and Demolition	3-20
3.4	Floodproofing	3-25
3.4.1	Wet Floodproofing.....	3-25
3.4.2	Dry Floodproofing	3-28
3.4.3	Barrier Systems	3-31
3.5	Summary	3-36
4.0	Deciding Which Method Is Right for Your Home.....	4-1
4.1	Making Your Decision.....	4-2
4.1.1	Step 1 – Determine the Hazards to Your Home.....	4-2
4.1.2	Step 2 – Inspect Your Home	4-3
4.1.3	Step 3 – Check with Your Local Officials	4-11
4.1.4	Step 4 – Consult a Design Professional and Retrofitting Contractor	4-12
4.2	Decision-Making Matrices	4-15
4.2.1	Evaluation Factors	4-15
4.2.2	Substantial Improvement / Substantial Damage Matrix.....	4-17
4.2.3	NOT Substantial Improvement / NOT Substantial Damage Matrix	4-18
5.0	Elevating Your Home.....	5-1
5.1	Considerations.....	5-2
5.1.1	Amount of Elevation	5-2
5.1.2	Existing Foundation	5-4
5.1.3	Hazards	5-5
5.1.4	Access	5-5
5.1.5	Home Size, Design, and Shape	5-6
5.1.6	Service Equipment	5-6

5.2	The Elevation Techniques	5-6
5.2.1	Elevating on Extended Foundation Walls	5-6
5.2.2	Alternative Elevation Techniques for Masonry Homes on Slab-on-Grade Foundations	5-15
5.2.3	Elevating on an Open Foundation	5-20
6.0	Relocation and Demolition	6-1
6.1	Relocation	6-1
6.1.1	Considerations	6-2
6.1.2	The Relocation Process	6-3
6.2	Demolition	6-9
6.2.1	Considerations	6-10
6.2.2	The Demolition Process	6-11
7.0	Floodproofing	7-1
7.1	Wet Floodproofing	7-1
7.1.1	Design Flood Elevation	7-2
7.1.2	Hazards	7-2
7.1.3	Post-Flood Cleanup	7-3
7.1.4	Modifications Required for Wet Floodproofing	7-5
7.1.5	Installing Openings	7-5
7.1.6	Protecting the Underside of Elevated Buildings	7-7
7.1.7	Using Flood Damage-Resistant Materials	7-8
7.1.8	Protecting Service Equipment	7-9
7.2	Dry Floodproofing	7-9
7.2.1	Considerations	7-10
7.2.2	Modifications Required for Dry Floodproofing	7-12
8.0	Barriers	8-1
8.1	Levees	8-2
8.2	Floodwalls	8-3
8.3	Temporary Barriers	8-3
8.4	Technical Considerations	8-4
8.4.1	Height of Barrier	8-4
8.4.2	Basement Foundations	8-5
8.4.3	Soil Conditions	8-5
8.4.4	Duration of Flooding	8-5
8.5	Additional Considerations	8-6
8.5.1	Annual Maintenance	8-6
8.5.2	Housing of Occupants	8-6
8.5.3	Access to Structure	8-6

TABLE OF CONTENTS

8.5.4	Human Intervention	8-6
8.5.5	Interior Drainage.....	8-7
9.0	Protecting Service Equipment	9-1
9.1	Elevation.....	9-2
9.1.1	Maintaining Horizontal and Vertical Clearances	9-4
9.1.2	Venting Considerations	9-5
9.1.3	Unions, Fittings, and Valves.....	9-5
9.2	Relocation	9-5
9.2.1	Electrical Panels.....	9-5
9.2.2	Electric Meters.....	9-6
9.2.3	Electrical Wiring.....	9-6
9.2.4	Mechanical Systems	9-6
9.2.5	Water Heaters.....	9-7
9.2.6	Washer/Dryer Units.....	9-7
9.3	Protection in Place.....	9-7
9.3.1	Floodwalls and Shields.....	9-8
9.3.2	Anchors and Tiedowns.....	9-8
9.3.3	Backflow Valves	9-10

Appendices

Appendix A	Bibliography and Sources of Information
Appendix B	Glossary
Appendix C	FEMA Regional Offices
Appendix D	NFIP State Coordinating Agencies
Appendix E	State Historic Preservation Offices
Appendix F	Professional Organizations
Appendix G	Retrofitting Checklist

Figures

Figure 2-1.	This home in New Orleans was inundated by 4 feet of water during Hurricane Katrina.	2-1
Figure 2-2.	This home, from Figure 2-1, was elevated in a manner that added to both its appearance and its value. As a result of its elevation, the home avoided major damage from Hurricane Isaac in 2012.	2-2
Figure 2-3.	These homes in Gays Mills, WI, were inundated by riverine flooding during the Midwest floods of 2008.....	2-4
Figure 2-4.	The extreme impact of large, fast-moving waves, combined with the removal of supporting soil by erosion and scour, can have devastating effects on buildings exposed to coastal flooding. Hurricane Floyd destroyed this home along the coast of North Carolina in 1999.	2-4

Figure 2-5. In this example, the 1-percent-annual-chance flood elevation is 391.6 feet (10.1 feet above the benchmark elevation of 381.5 feet), and the elevation of the lowest floor of the home is 389.3 feet (7.8 feet above the same benchmark). The flood depth above the lowest floor is therefore equal to 391.6 feet – 389.3 feet, or 2.3 feet during the 1-percent-annual-chance flood.....2-6

Figure 2-6. Hydrostatic pressure acts on walls and concrete slab floors. The weight of saturated soils adds to the pressure on basement walls. Figure 2-6a shows a home with a concrete slab floor. Figure 2-6b shows a home with a basement.....2-7

Figure 2-7. The walls of this basement in Wisconsin failed because of the pressure exerted by water and saturated soil.2-7

Figure 2-8. Once water enters the home, hydrostatic pressure is equalized. Figure 2-8a shows a home with a concrete slab floor. Figure 2-8b shows a home with a basement.....2-8

Figure 2-9. Moving water acts on the front, sides, and back of a home.....2-9

Figure 2-10. Water moving at high velocity destroyed the wall of this home and caused the building to shift on its foundation.....2-9

Figure 2-11. Wind forces on a sealed building are less than wind forces on a building with an opening.2-12

Figure 2-12. Earthquake forces act in both horizontal and vertical directions.....2-12

Figure 2-13. This FIRM for riverine flooding shows the SFHA (Zone AE), floodway (hatch-marked Zone AE along centerline of river channel), and areas outside the SFHA (Zone X). The area between the limits of the base flood and 0.2-percent-annual-chance flood are delineated by shaded Zone X. Areas above the 0.2-percent-annual-chance flood are delineated by unshaded Zone X.....2-15

Figure 3-1. This graph shows the relationship between flood recurrence intervals and the probability of an event occurring within a 30-year period.....3-6

Figure 3-2. Portion of a paper FIRM showing coastal flood insurance rate zones. The icons on the right indicate the associated flood hazard zones for design and construction purposes. The LiMWA is not shown on older FIRMs, but is shown on newer FIRMs.....3-7

Figure 3-3. Typical transect perpendicular to the shoreline showing the delineations between Zone V, the MoWA area, the LiMWA, Zone A, and the MiWA area.3-8

Figure 3-4. Typical cross-sections of three common construction types: frame, masonry veneer, and masonry. The foundation shown here for all three construction types consists of concrete blocks and a concrete footing. The same construction types are also found on basement and slab-on-grade foundations.....3-11

Figure 3-5. Home foundation types.....3-12

Figure 3-6. Typical cross-section of home elevated on continuous foundation walls.....3-14

Figure 3-7. Before (left) and after (right) photos of a retrofitted home elevated on extended continuous foundation walls.....3-14

Figure 3-8. Home elevated on reinforced concrete piers.3-15

Figure 3-9. Home elevated on posts3-16

Figure 3-10. Home elevated on piles.3-17

TABLE OF CONTENTS

Figure 3-11. Example of well-elevated and embedded pile foundation tested by Hurricane Katrina. Note adjacent building failures (Dauphin Island, AL, 2005).	3-17
Figure 3-12. The owner of this flood-prone home in south Florida decided to build a new wood-framed second story on top of the masonry first story. The new second story is well above the BFE.....	3-18
Figure 3-13. Many homes in the Town of Prattsville, NY, were slated for demolition during the recovery effort following Hurricane Irene.	3-23
Figure 3-14. A home with a wet floodproofed subgrade basement.	3-26
Figure 3-15. A home with a wet floodproofed enclosure.	3-27
Figure 3-16. A typical dry floodproofed home.	3-30
Figure 3-17. A home protected by a levee (left) and a floodwall (right).	3-33
Figure 3-18. A home protected by a levee.	3-33
Figure 3-19. A home protected by a floodwall designed as a landscaping feature.....	3-36
Figure 3-20. Example of floodwall and levee dimensions.	3-37
Figure 4-1. Peak gust wind speeds in the United States. Source: Minimum Design Loads for Buildings and Other Structures, ASCE/SEI 7-10. Used with permission from ASCE.	4-4
Figure 4-2. Seismic Design Categories Map of the United States for low-rise Occupancy Category I and II structures located on sites with average alluvial soil conditions.....	4-6
Figure 4-3. Difference between flood level and lowest floor in homes on crawlspace and basement foundations.	4-10
Figure 5-1. As shown in the cutaway view, the lowest floor is above the flood level. When at least 1 foot of freeboard is provided, only the foundation is exposed to flooding.	5-3
Figure 5-2. This home in Cedar Falls, IA, was elevated one full story. The garage and storage area are at the home's original elevation.	5-4
Figure 5-3. With attention to detail and planning, homeowners have created attractive retrofitted homes.....	5-5
Figure 5-4a through 5-4d. Elevating a basement or crawlspace foundation home on extended foundation walls.	5-8
Figure 5-5. Cross-section view of slab-on-grade foundation variations.	5-10
Figure 5-6. Building a new foundation for a slab-on-grade home.	5-11
Figure 5-7. Elevating a slab-on-grade home without the slab.	5-11
Figure 5-8. House in Zone A was detached from its slab foundation (which remains) and elevated on masonry piers. The floor system is supported by new wood joists (Mandeville, LA).....	5-12
Figure 5-9a through 5-9d. Elevating a slab-on-grade home with the slab attached.	5-13
Figure 5-10a through 5-10c. Elevating by extending the walls of a solid masonry home.....	5-16
Figure 5-11. Elevation of the floor levels in a row house to maximize living area above the BFE in Zone A. ...	5-18
Figure 5-12a through 5-12c. Home elevated by adding a new second story over an abandoned lowest floor. ...	5-18
Figure 5-13a through 5-13d. Elevating a basement or crawlspace foundation home on piers.	5-21

Figure 5-14. Home elevated on post or column foundations.....5-22

Figure 5-15. Home elevated on piles.5-23

Figure 6-1. New foundation is being prepared.....6-4

Figure 6-2. Clearing pathways beneath the structure for lifting supports.6-5

Figure 6-3. Pathways for lifting beams.....6-6

Figure 6-4. Beams supported by cribbing are placed at critical lift points.6-6

Figure 6-5. Hydraulic jacks lift the structure, and the home is separated from existing foundation.6-7

Figure 6-6. Trailer wheel sets are placed beneath the lifting beams.6-7

Figure 6-7. The move to the new site begins.....6-8

Figure 6-8. House is lowered and connected to the foundation after the foundation is fully constructed.6-8

Figure 6-9. Typical mitigation reconstruction project.....6-12

Figure 7-1. Typical wet floodproofing.....7-3

Figure 7-2. Wall openings must allow floodwaters not only to enter the home, but also to rise and fall at the same rate as floodwaters outside the home.....7-6

Figure 7-3. Sketch of foundation plan of home with multiple enclosed areas, each with flood openings. Typical enclosures with flood openings (Left). Flood opening in typical crawlspace foundation (Right).7-6

Figure 7-4. The lateral and buoyancy force resulting from the same depth of flooding is much less on a home without a basement (a) than on a home with a basement (b). The pressure on basement walls is caused by water and saturated soils.....7-11

Figure 7-5. Example of an exterior application of a spray-applied asphalt membrane (left) and an interior application of a fiber reinforced polymer wrap (right).7-13

Figure 7-6. A way to seal an existing brick-faced wall is to add an additional layer of brick with a seal in between. Please note that weep holes (drainage) and wick drains are moved up to prevent moisture from getting inside the walls.....7-13

Figure 7-7. In the “wrapped home” method, the lower portion of the home is protected with a temporary layer of polyethylene film. As shown, a temporary drainage line is also required.....7-14

Figure 7-8. Heavy-gauge metal shield over sliding glass door opening.7-16

Figure 7-9. Light-gauge metal shield held in place by permanently installed tracks.7-16

Figure 7-10. Low window raised approximately 2 feet and original opening filled with brick.7-17

Figure 7-11. Drainage system for a dry floodproofed home.7-18

Figure 8-1. Structure protected by levee (on left) and floodwall (on right).8-1

Figure 8-2. Levee construction.....8-2

Figure 8-3. Structure protected by a floodwall with decorative stone finish.8-3

Figure 8-4. Two-foot-high water-filled temporary barrier protecting a residence from flooding.8-4

TABLE OF CONTENTS

Figure 8-5.	The City of Boulder, CO, installed a “pop up” closure to this floodwall at a City office building subject to flash floods. The closure floats up into place automatically when the site is flooded.	8-7
Figure 8-6.	Small patio floodwall with sump pump.....	8-7
Figure 9-1.	Air conditioning/heat pump compressor mounted on a brick pedestal outside an elevated home.....	9-3
Figure 9-2.	Air conditioning/heat pump compressor mounted on a cantilevered platform attached to a home elevated on an open foundation.....	9-3
Figure 9-3.	Water heater and furnace protected by a concrete floodwall with opening and gasketed shield.....	9-8
Figure 9-4.	Anchoring a fuel storage tank with a concrete slab.....	9-9
Figure 9-5.	Example of an exterior backflow valve installed in a valve pit.....	9-10

Tables

Table 2-1.	Eligible Retrofit Activities by Program.....	2-19
Table 3-1.	Advantages and Disadvantages of Elevation	3-19
Table 3-2.	Relative Costs of Elevating a Home.....	3-20
Table 3-3.	Advantages and Disadvantages of Relocation.....	3-22
Table 3-4.	Relative Costs of Relocation	3-22
Table 3-5.	Relative Costs of Demolition and Rebuilding	3-24
Table 3-6.	Advantages and Disadvantages of Wet Floodproofing	3-28
Table 3-7.	Relative Costs of Wet Floodproofing.....	3-29
Table 3-8.	Advantages and Disadvantages of Dry Floodproofing	3-31
Table 3-9.	Relative Costs of Dry Floodproofing.....	3-32
Table 3-10.	Advantages and Disadvantages of Levees and Floodwalls.....	3-35
Table 3-11.	Relative Costs of Levees and Floodwalls	3-36
Table 3-12.	Relative Costs of Various Retrofit Measures.....	3-38
Table 4-1.	Requirements for Design Professional and Contractor Services.....	4-13
Table 4-2.	Retrofitting Methods for Substantially Improved or Substantially Damaged Homes.....	4-17
Table 4-3.	Retrofitting Methods for Homes That are NOT Substantially Improved or Damaged.....	4-18
Table 7-1.	Flood Damage-Resistant Materials.....	7-9
Table 8-1.	Considerations for Using Barriers	8-2



Acronyms

ASCE	American Society of Civil Engineers
ASFPM	Association of State Floodplain Managers
AST	aboveground storage tank
BFE	base flood elevation
CDC	Centers for Disease Control
CMU	concrete masonry unit
CRS	Community Rating System
DFE	design flood elevation
DHS	U.S. Department of Homeland Security
DRC	Disaster Recovery Center
FEMA	Federal Emergency Management Agency
FIRM	Flood Insurance Rate Map
FIS	Flood Insurance Study
FMA	Flood Mitigation Assistance
fps	feet per second
HMA	Hazard Mitigation Assistance
HMGP	Hazard Mitigation Grant Program
HUD	U.S. Department of Housing and Urban Development
HVAC	heating, ventilation, and air conditioning
IBC	International Building Code
ICC	Increased Cost of Compliance
IEBC	International Existing Building Code
IRC	International Residential Code

ACRONYMS

LAG	lowest adjacent grade
LiMWA	limit of moderate wave action
LOMA	Letter of Map Amendment
MEP	mechanical, electrical, and plumbing
MiWA	Minimal Wave Action
MoWA	Moderate Wave Action
mph	miles per hour
MSC	Map Service Center
msl	mean sea level
NAVD	North American Vertical Datum
NFIA	National Flood Insurance Act
NFIP	National Flood Insurance Program
NGVD	National Geodetic Vertical Datum
NRCS	National Resources Conservation Service
OSHA	Occupational Safety and Health Administration
OSB	oriented-strand board
PDM	Pre-Disaster Mitigation
PNP	private non-profit
RFC	Repetitive Flood Claims
SBA	Small Business Administration
SFHA	Special Flood Hazard Area
SFIP	Standard Flood Insurance Policy
SHMO	State Hazard Mitigation Officer
SHPO	State Historic Preservation Office
SRL	Severe Repetitive Loss
UL	Underwriters Laboratories
USACE	U. S. Army Corps of Engineers
U.S.C.	United States Code
USDA	U.S. Department of Agriculture
UST	underground storage tank