# **BBSS** Reboot

### I. Purpose:

This procedure is used to reboot the BBSS when instructed to do so by TWP.

## II. Cautions and Hazards:

None

## **III.** Requirements:

None

#### IV. Procedure:

#### A. Steps:

- 1. Go to the BBSS laptop in the E-van.
- 2. Click "Restart" on the laptop.
- 3. Report your actions on the Daily Rounds report.

## V. References:

None.

## VI. Attachments:

None