Rebooting MMCR Via ADaM

I. Purpose:

To describe the process for rebooting the MMCR via the ADaM system.

II. Cautions and Hazards:

None.

III. Requirements:

None.

IV. Procedure:

    A. Steps:
    Note: This procedure will reboot the MMCR by turning everything off, including the small UPS and then bring the system back up.

        1. Login to adam via the X-Terminal as adamoper.

        2. Type the following commands:

- su \<use the root password when the system asks you for a password>
- cd /files0/ADaM
- ./shutdown_mmcr.csh BOTH
- exit \<this exits you from root>
- exit \<this logs you off adam>

V. References:

None.

VI. Attachments:

None.