

ARCS PROCEDURE: Author: W. Porch	RSR SPARE PARTS/TOOLS LISTING	PRO(RSR)-002.001 September 10, 1998 Page 1 of 2
-----------------------------------------	-------------------------------	-----------------------------------------------------------

RSR Spare Parts/Tools Listing

I. Purpose:

This document lists the recommended RSR spare parts to be taken to the ARCS sites by the RESET team.

II. Cautions and Hazards:

- None.

III. Requirements:

Tools

- Band shaping tool (get five; parts have a way of disappearing).
- Aluminum cap (used during installation to protect sensor head from possible damage). Also, get several of these.
- I/C removal tool.
- I/C pin tool.
- Voltmeter.
- Red plastic caps.

Spares

- Specially designed box to transport filter heads (EPS Model 1300).
- Desiccant bags (for inside datalogger).
- Heater fuse (3 amps).
- Spare screws for the leveling pad (1/4 –20 x 1.5 inch).
- CPU board (1.5 amp fuse).
- Battery fuse (6 amp fuse).
- Logger board.

IV. Procedure:

N/A.

V. References:

None.

ARCS PROCEDURE: Author: W. Porch	RSR SPARE PARTS/TOOLS LISTING	PRO(RSR)-002.001 September 10, 1998 Page 2 of 2
------------------------------------------------	--------------------------------------	------------------------------------------------------------------

VI. Attachments:

None.