

nShield Security Policy CIPHER™

MiniHSM in FIPS 140-2 level 3 mode



Version: 2.2.3

Date: 2 April 2008

© Copyright 2008 nCipher Corporation Limited, Cambridge, United Kingdom.

Reproduction is authorised provided the document is copied in its entirety without modification and including this copyright notice.

nCipher™, nForce™, nShield™, nCore™, KeySafe™, CipherTools™, CodeSafe™, SEE™ and the SEE logo are trademarks of nCipher Corporation Limited.

nFast® and the nCipher logo are registered trademarks of nCipher Corporation Limited.

All other trademarks are the property of the respective trademark holders.

nCipher Corporation Limited makes no warranty of any kind with regard to this information, including, but not limited to, the implied warranties of merchantability and fitness to a particular purpose. nCipher Corporation Limited shall not be liable for errors contained herein or for incidental or consequential damages concerned with the furnishing, performance or use of this material.

Patents

UK Patent GB9714757.3. Corresponding patents/applications in USA, Canada, South Africa, Japan and International Patent Application PCT/GB98/00142.

Chapter 1: Purpose	5
Introduction	5
Module Ports and Interfaces	8
Excluded Components	9
Roles	10
Unauthorised	10
User	10
nCipher Security Officer	10
Junior Security Officer	11
Services available to each role	12
Keys	28
Security Officer's key	28
Junior Security Officer's key	28
Long term signing key	29
Module signing key	29
Module keys	29
Logical tokens	29
Share Key	30
Impath keys	30
Key objects	31
Session keys	31
Archiving keys	32
Certificate signing keys	32
Firmware Integrity Key	32
Firmware Confidentiality Key	33
nCipher Master Feature Enable Key	33
Rules	34
Identification and authentication	34
Procedures to initialise a module to comply with FIPS 140-2 Level 3	36
Procedures to initialise a module to comply with FIPS 140-2 Level 2	37
Operating a level 2 module in FIPS mode	38
To return a module to factory state	38
To create a new user	38
To authorize the user to create keys	39
To authorize a user to act as a Junior Security Officer	39
To authenticate a user to use a stored key	40
To authenticate a user to create a new key	40
Physical security	41
Checking the module	41

Strength of functions	42
Attacking Object IDs	42
Attacking Tokens	42
Key Blobs	43
Impaths	43
KDP key provisioning	43
Derived Keys	43
Self Tests	44
Supported Algorithms	45
FIPS approved algorithms:	45
Non-FIPS approved algorithms	46
nCipher addresses	48

Introduction

MiniHSM tamper resistant Hardware Security Modules are multi-tasking hardware modules that are optimized for performing modular arithmetic on very large integers. The modules also offer a complete set of key management protocols.

The MiniHSM provides the security for the nCipher's TSMC products.

The MiniHSM Hardware Security Modules are defined as multi-chip embedded cryptographic modules as defined by FIPS PUB 140-2.

Unit ID	Model Number	RTC NVRAM	SEE	Potting	EMC	Crypto Accelerator	Overall level
nCipher MiniHSM	nC4031Z-10	Yes	Optional	Yes	B	none	3

In order to comply with EU ROHS directive, nCipher revalidated the MiniHSM. This validation applies to the original version with leaded solder, build standard A , and to the lead free build standard, build standard B. The build standard is listed on the label on the top of the device.

nCipher also supply modules to third party OEM vendors for use in a range of security products.

The module runs firmware provided by nCipher. There is the facility for the administrator to upgrade this firmware. In order to determine that the module is running the correct version of firmware they should use the **NewEnquiry** service which reports the version of firmware currently loaded.

The validated firmware versions is 2.33.60.

The module can be initialised to comply with the requirements for Roles and Services at either level 2 or level 3

- When initialized in level 2 mode the firmware version is 2.33.60-2 (level 2 mode) and the level 2 certificate applies.
- When initialized in level 3 mode the firmware version is 2.33.60-3 (level 3 mode) and the level 3 certificate applies.

The initialization parameters are reported by the **NewEnquiry** and **SignModuleState** services. A user can determine which mode the module is operating in using the KeySafe GUI or the command line utilities supplied with the module, or their own code - these operate outside the security boundary.

The modules must be accessed by a custom written application. Full documentation for the nCore API can be downloaded from the nCipher web site: <http://www.nCipher.com>.

MinHSMs have on-board non-volatile memory. There are services that enable memory to be allocated as files. Files have Access Control Lists that determine what operations can be performed on their contents. nShield modules have on-board Real-time clock.

MiniHSMs include a technology called, the Secure Execution Environment (SEE). This enables users to load a SEE machine. A SEE machine is user written code that implements a specific Software Interrupt interface. This enables users to implement non-cryptographic code in a protected memory space on the module that is outside the logical security boundary.

SEE code is executed in a protected environment. Whenever the SEE machine is running the nCore kernel is locked. Whenever the nCore kernel is active the SEE machine is locked. The SEE machine is excluded from the requirements of FIPS PUB 140-2. While the SEE machine is active the module is running in a non-FIPS mode.

The SEE machine has no direct access to objects stored on the module. In order to use cryptographic functions it must submit a job to the nCore kernel using the nCore API. The testing shows that the interface between the nCore kernel and the SEE machine is secure and that a malicious SEE machine cannot gain access to objects protected by the nCore kernel.

Before a user can send commands to the SEE machine they must create an instance called a **SEE World**. A **SEE World** is treated as a separate user by the module and must present the correct authentication before they can submit commands to the nCore kernel.

MiniHSM are supplied with the SEE functions disabled. In order to use these functions the customer must purchase a feature-enable certificate enabling the functions for a specific module. The SEE feature is export controlled and therefore is not available in some territories.

The module can be connected to a computer running one of the following operating systems:

- Windows
- Solaris
- HP-UX
- AIX
- Linux x86

- FreeBSD x86

Windows XP Professional SP2 and a Debian Linux distribution with kernel version 2.2.26 were used to test the module for this validation.

Module Ports and Interfaces

The following table lists the logical interfaces to the module and how they map to physical interfaces.

Logical Interface	Physical Interface
Data In	serial bus, Serial Interface,
Data Out	serial bus, Serial Interface,
Control In	serial bus, Temperature SensorMode pins
Status Out	serial bus, LED pin
Power	power pins

Excluded Components

The following components are excluded from FIPS 140-2 validation:

- 4 pin serial interface (RTS, CTS, data, data_ground) used for commands
- 4 pin serial interface (RTS, CTS, data, data_ground) for connection to smart card reader.
- Mode pins
- Clear pin
- Reset pin
- Status LED pin
- SEE machine

The mode pins must be connected to an external three position switch, referred to elsewhere as the mode switch.

The clear pin must be connected to an external push to make button - referred to as the clear button. This enables a user to clear the module in a controlled manner which ensures communication on the host serial port is not disrupted.

The reset pin instantly clears the module - this will disrupt communication on the serial port, so should only be used if all components that communicate with the module are also being reset.

The LED pin is designed to be connected to the anode of an external LED, the cathode of which is connected to earth. Statuses are indicated by a change in voltage on this pin - which will cause an external LED to flash.

The smart card serial interface must be attached to an external 9-pin D-type connector to allow connection of an nCipher smart card reader.

Roles

The module defines the following roles:

Unauthorised

All connections are initially unauthorized. If the module is initialized in level 3 mode, an unauthorized user is restricted to status commands, and commands required to complete authorization protocol.

User

An operator enters the user role by providing the required authority to carry out a service. The exact accreditation required to perform each service is listed in the table of services.

In order to perform an operation on a stored key, the operator must first load the key blob. If the key blob is protected by a logical token, the operator must first load the logical token by loading shares from smart cards.

If the module is initialized in level 3 mode, the user role requires a certificate from the security officer to import or generate a new key. This certificate is linked to a token protected key.

Once an operator in the user role has loaded a key they can then use this key to perform cryptographic operations as defined by the Access Control List (ACL) stored with the key.

Each key blob contains an ACL that determines what services can be performed on that key. This ACL can require a certificate from a Security Officer authorizing the action. Some actions including writing tokens always require a certificate.

nCipher Security Officer

The nCipher Security Officer (NSO) is responsible for overall security of the module.

The nCipher Security Officer is identified by a key pair, referred to as K_{NSO} . The hash of the public half of this key is stored when the unit is initialized. Any operation involving a module key or writing a token requires a certificate signed by K_{NSO} .

The nCipher Security Officer is responsible for creating the authentication tokens (smart cards) for each user and ensuring that these tokens are physically handed to the correct person.

An operator assumes the role of NSO by loading the private half of K_{NSO} and presenting the **KeyID** for this key to authorize a command.

Junior Security Officer

Where the nCipher Security Officer want to delegate responsibility for authorizing an action they can create a key pair and give this to their delegate who becomes a Junior Security Officer (JSO). An ACL can then refer to this key, and the JSO is then empowered to sign the certificate authorizing the action. The JSO's keys should be stored on a key blob protected by a token that is not used for any other purpose.

In order to assume the role of JSO, the user loads the JSO key and presents the **KeyID** of this key, and if required the certificate signed by K_{NSO} that delegates authority to the key, to authorize a command.

A JSO can delegate portions of their authority to a new user in the same way. The new user will be a JSO if they have authority they can delegate, otherwise they will be a user.

Services available to each role

For more information on each of these services refer to the nCipher Developer's Guide and nCipher Developer's Reference.

The following services provide user authentication or cryptographic functionality. The functions available depend on whether the user is in the unauthenticated role, an authorized user including junior security officer (JSO), or the nCipher Security Officer (NSO). For each operation it lists the supported algorithms. Algorithms in square brackets are not under the operator's control. Algorithms used in optional portions of a service are listed in italics.

Note Algorithms marked with an asterisk are not approved by NIST. If the module is initialised in its level 3 mode, these algorithms are disabled. If module is initialized in level 2 mode, the algorithms are available. However, if you choose use them, the module is not operating in FIPS approved mode.

Key Access	Description
Create	Creates a in-memory object, but does not reveal value.
Erase	Erases the object from memory, smart card or non-volatile memory without revealing value
Export	Discloses a value, but does not allow value to be changed.
Report	Returns status information
Set	Changes a CSP to a given value
Use	Performs an operation with an existing CSP - without revealing or changing the CSP

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
Bignum Operation	Yes	Yes	Yes	Performs simple mathematical operations.	No access to keys or CSPs	
Change Share PIN	No	pass phrase	pass phrase	Updates the pass phrase used to encrypt a token share. The pass phrase supplied by the operator is not used directly, it is first hashed and then combined with the module key. To achieve this the command decrypts the existing share using the old share key derived from old pass phrase, module key and smart card identity. It then derives a new share key based on new pass phrase, module key and smart card identity, erases old share from smart card and writes a new share encrypted under the new share key.	<i>Sets</i> the pass phrase for a share, <i>uses</i> module key, <i>uses</i> share key, <i>uses</i> module key, <i>creates</i> share key, <i>uses</i> new share key, <i>exports</i> encrypted share, <i>erases</i> old share	[SHA-1 and AES or Triple DES]

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
Channel Open	No	handle, ACL	handle, ACL	Opens a communication channel which can be used for bulk encryption or decryption.	Uses a key object	AES, DES*, Triple DES, Arc Four*, Aria*, Camellia*, SEED*
Channel Update	No	handle	handle	Performs encryption / decryption on a previously opened channel. The operation and key are specified in ChannelOpen .	Uses a key object	AES, DES*, Triple DES, Arc Four*, Aria*, Camellia*, SEED*
CheckUserACL	No	handle	handle	Determines whether the ACL associated with a key object allows a specific user defined action.	Uses a key object	
Clear Unit	Yes	Yes	Yes	Zeroizes all loaded keys, tokens and shares. Clear Unit does not erase long term keys, such as module keys.	Zeroizes objects.	All
Create Buffer	No	cert [handle]	cert [handle]	Allocates an area of memory to load data. If the data is encrypted, this service specifies the encryption key and IV used. This service is feature enabled. The decrypt operation is performed by LoadBuffer	Uses a key object	AES, DES*, Triple DES, Arc Four*, Aria*, Camellia*, SEED*
Create SEE World	No	handle cert	handle cert	Creates a SEE World , passing in the initialization data stored in a buffer. This command checks the DSA signatures on the buffer using the public key provided. It also specifies whether debugging is allowed or not. Enabling debugging requires a certificate from the nCipher Security Officer.	No access to keys or CSPs	

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
Decrypt	No	handle, ACL	handle, ACL	Decrypts a cipher text with a stored key returning the plain text.	Uses a key object	AES, DES*, Triple DES, Arc Four*, Aria*, Camellia*, SEED*, Diffie-Hellman, ECDH, RSA*, ElGamal*, KCDSA*
Derive Key	No	handle, ACL	handle, ACL	The nCipher DeriveKey service provides functions that the FIPS 140-2 standard describes as key wrapping and split knowledge - it does not provide key derivation in the sense understood by FIPS 140-2. Creates a new key object from a variable number of other keys already stored on the module and returns a handle for the new key. This service can be used to split, or combine, encryption keys. This service is used to wrap keys according to the nCipher KDP so that a key server can distribute the wrapped key to micro-HSM devices.	Uses a key object, create a new key object.	AES, RSA, EC-DH, EC_MQV, Triple DES, PKCS #8*, TLS key derivation, XOR, DLIES (D/H plus Triple DES or D/H plus AES), Aria*, Arc Four*, Camellia*, DES*, SEED*,
Destroy	No	handle	handle	Removes an object, if an object has multiple handles as a result of RedeemTicket service, this removes the current handle.	Erases a Impath, SEWorld , logical token, or any key object.	All
Duplicate	No	handle, ACL	handle, ACL	Creates a second instance of a key object with the same ACL and returns a handle to the new instance.	Creates a new key object.	All
Encrypt	No	handle, ACL	handle, ACL	Encrypts a plain text with a stored key returning the cipher text.	Uses a key object	AES, DES*, Triple DES, RSA*, ElGamal*, Arc Four*, Aria*, Camellia*, SEED*, KCDSA*

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
Erase File	level 2 only	cert	yes	Removes a file, but not a logical token, from a smart card or software token.	No access to keys or CSPs	
Erase Share	level 2 only	cert	yes	Removes a share from a smart card or software token.	<i>Erases</i> a share	
Existing Client	yes	yes	yes	Starts a new connection as an existing client.	No access to keys or CSPs	
Export	No	handle, ACL	handle, ACL	If the unit is operating in FIPS mode this operation is only available for public keys - see Operating a level 2 module in FIPS mode on page 38. If the unit has been initialized to comply with FIPS 140-2 level 3 roles and services and key management, this service is only available for public keys.	<i>Exports</i> a [public] key object.	Level 2 mode - Any key type Level 3 mode - RSA, DSA, ECDSA, Diffie-Hellman, El-Gamal and ECDH public keys
Feature Enable	No	cert	cert	Enables a service. This requires a certificate signed by the nCipher Master Feature Enable key.	<i>Uses</i> the public half of the nCipher Master Feature Enable Key	[DSA]
Firmware Authenticate	yes	yes	yes	Reports firmware version. Performs a zero knowledge challenge response protocol based on HMAC that enables a operator to ensure that the firmware in the module matches the firmware supplied by nCipher. The protocol generates a random value to use as the HMAC key.	No access to keys or CSPs	HMAC
Foreign Token Command (Bypass)	No	handle	handle	Sends an ISO-7816 command to a smart card over the channel opened by ForeignTokenOpen .	<i>Uses</i> a bypass channel.	
Foreign Token Open (Bypass)	No	FE, cert	FE	Opens a channel to foreign smart card that accepts ISO-7816 commands. This service cannot be used if the smart card has been formatted using FormatToken . The channel is closed when the card is removed from the reader, or if the handle is destroyed. This service is feature enabled.	<i>Creates</i> a bypass channel.	

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
FormatToken	level 2 only	cert	yes	Formats a smart card or software token ready for use.	May use a module key to create challenge response value	[AES, Triple DES]
Generate Key	level 2 only	cert	yes	Generates a symmetric key of a given type with a specified ACL and returns a handle. Optionally returns a certificate containing the ACL.	Creates a new symmetric key object. Sets the ACL and Application data for that object. Optionally uses module signing key and exports the key generation certificate.	AES, Triple DES, Arc Four*, Aria*, Camellia*, DES*, SEED*. [DSA]
Generate Key Pair	level 2 only	cert	yes	Generates a key pair of a given type with specified ACLs for each half or the pair. Performs a pair wise consistency check on the key pair. Returns two key handles. Optionally returns certificates containing the ACL.	Creates two new key objects. Sets the ACL and Application data for those objects. Optionally uses module signing key and exports two key generation certificates.	Diffie-Hellman, DSA, ECDSA, EC-DH, EC-MQV, RSA, ElGamal*, KCDSA* [DSA]
Generate KLF	No	FE	FE	Generates a new long term key.	Erases the module long term key, creates new module long term key.	[DSA]
Generate Logical Token	level 2 only	cert	yes	Creates a new logical token, which can then be written as shares to smart cards or software tokens	Uses module key. Creates a logical token.	[AES or Triple DES]
Get ACL	No	handle, ACL	handle, ACL	Returns the ACL for a given handle.	Exports the ACL for a key object.	

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
Get Application Data	No	handle, ACL	handle, ACL	Returns the application information stored with a key.	<i>Exports</i> the application data of a key object.	
Get Challenge	yes	yes	yes	Returns a random nonce that can be used in certificates	No access to keys or CSPs	
Get Key Info	No	handle	handle	Superseded by GetKeyInfoEx retained for compatibility.	<i>Exports</i> the SHA-1 hash of a key object	
Get Key Info Extended	No	handle	handle	Returns the hash of a key for use in ACLs	<i>Exports</i> the SHA-1 hash of a key object	
Get Logical Token Info	No	handle	handle	Superseded by GetLogicalTokenInfoEx retained for compatibility.	<i>Exports</i> the SHA-1 hash of a logical token.	[SHA-1]
Get Logical Token Info Extended	No	handle	handle	Returns the token hash and number of shares for a logical token	<i>Exports</i> the SHA-1 hash of a logical token.	[SHA-1]
Get Module Keys	yes	yes	yes	Returns a hashes of the Security Officer's key and all loaded module keys .	<i>Exports</i> the SHA-1 hash of KNSO and module keys.	[SHA-1]
Get Module Long Term Key	yes	yes	yes	Returns a handle to the public half of the module's signing key. this can be used to verify key generation certificates and to authenticate inter module paths.	<i>Exports</i> the public half of the module's long term key.	[DSA]
Get Module Signing Key	yes	yes	yes	Returns the public half of the module's signing key. This can be used to verify certificates signed with this key.	<i>Exports</i> the public half of the module's signing key.	[DSA]
Get RTC	yes	yes	yes	Reports the time according to the on-board real-time clock	No access to keys or CSPs	
Get Share ACL	yes	yes	yes	Returns the access control list for a share	<i>Exports</i> the ACL for a token share on a smart card.	

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
GetSlot Info	yes	yes	yes	Reports status of the physical token in a slot. Enables an operator to determine if the correct token is present before issuing a ReadShare command. If the token is formatted with a challenge response key, uses the module key to authenticate the smart card.	May use a module key.	[AES, Triple DES]
Get Slot List	yes	yes	yes	Reports the list of slots available from this module.	No access to keys or CSPs	
GetTicket	No	handle	handle	Gets a ticket - an invariant identifier - for a key. This can be passed to another client or to a SEE World which can redeem it using RedeemTicket to obtain a new handle to the object,	Uses a key object, logical token, Impath, SEEWorld .	
Get World Signers	No	handle	handle	Returns a list of the keys used to sign a SEEWorld identified by the key hash and the signing mechanism used. This command can only be called from inside the SEE world.	Uses a SEEWorld object.	
Hash	yes	yes	yes	Hashes a value.	No access to keys or CSPs	HSA-160*, MD5*, RIPEMD 160*, SHA-1, SHA-256, SHA-384, SHA-512
Impath Get Info	No	handle	handle	Reports status information about an impath	Uses an Impath, exports status information.	
Impath Key Exchange Begin	FE	FE	FE	Creates a new inter-module path and returns the key exchange parameters to send to the peer module.	Creates a set of Impath keys	[DSA and Diffie Hellman] AES, Triple-DES
Impath Key Exchange Finish	No	handle	handle	Completes an impath key exchange. Require the key exchange parameters from the remote module.	Creates a set of Impath keys.	[DSA and Diffie Hellman, AES, Triple-DES]
Impath Receive	No	handle	handle	Decrypts data with the Impath decryption. key.	Uses an Impath key.	[AES or Triple DES]

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
Impath Send	No	handle	handle	Encrypts data with the impath encryption key.	<i>Uses an Impath key.</i>	[AES or Triple DES]
Import	level 2 only	cert	yes	<p>Loads a key and ACL from the host and returns a handle.</p> <p>If the unit is operating in FIPS mode at level 2, this operation must only be used for public keys - see Operating a level 2 module in FIPS mode on page 38</p> <p>If the unit has been initialized to comply with FIPS 140-2 level 3 roles and services and key management, this service is only available for public keys.</p>	<i>Creates a new key object, sets the key value, ACL and App data.</i>	Level 2 mode - Any key type Level 3 mode - RSA, DSA, Diffie-Hellman, ECDSA or ECDH public keys
Initialise	init	init	init	<p>Initializes the module, returning it to the factory state. This clears all NVRAM files, all loaded keys and all module keys and the module signing key.</p> <p>It also generates a new KMO and module signing key.</p> <p>The only key that is not zeroized is the long term signing key. This key only serves to provide a cryptographic identity for a module that can be included in a PKI certificate chain. nCipher may issue such certificates to indicate that a module is a genuine nCipher module. This key is not used to encrypt any other data.</p>	<i>Erases keys, Creates KMO and KML</i>	[DSA]
Load Blob	No	handle	handle	Loads a key that has been stored in a key blob. The operator must first have loaded the token or key used to encrypt the blob.	<i>Uses module key, logical token, or archiving key, creates a new key object.</i>	AES, Triple DES or RSA and AES

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
Load Buffer	No	handle	handle	Loads signed data into a buffer. Several load buffer commands may be required to load all the data, in which case it is the responsibility of the client program to ensure they are supplied in the correct order. Requires the handle of a buffer created by CreateBuffer . On a MiniHSM this data can be read from flash rather than over the serial interface.	No access to keys or CSPs	
Load Logical Token	yes	yes	yes	Allocates space for a new logical token - the individual shares can then be assembled using ReadShare or ReceiveShare . Once assembled the token can be used in LoadBlob or MakeBlob commands.	Uses module key	[AES or Triple DES]
Load User Flash	monitor	monitor	monitor	Stores signed data in Flash memory. This data can be retrieved by the Load Buffer service to remove the requirement to repeatedly load the data over the serial interface.	No access to keys or CSPs	
Make Blob	No	handle, ACL	handle, ACL	Creates a key blob containing the key and returns it. The key object to be exported may be any algorithm.	Uses module key, logical token or archiving key, exports encrypted key object.	AES, Triple DES or RSA and AES
Mod Exp	yes	yes	yes	Performs a modular exponentiation on values supplied with the command.	No access to keys or CSPs	
Mod Exp CRT	yes	yes	yes	Performs a modular exponentiation on values, supplied with the command using Chinese Remainder Theorem.	No access to keys or CSPs	
Module Info	yes	yes	yes	Reports low level status information about the module. This service is designed for use in nCipher's test routines.	No access to keys or CSPs	

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
NewClient	yes	yes	yes	Returns a client id.	No access to keys or CSPs	
New Enquiry	yes	yes	yes	Reports status information.	No access to keys or CSPs	
No Operation	yes	yes	yes	Does nothing, can be used to determine that the module is responding to commands.	No access to keys or CSPs	
NVMem Allocate	No	cert	yes	Allocates an area of non-volatile memory as a file and sets the ACLs for this file. This command can now be used to write files protected by an ACL to a smart card	No access to keys or CSPs	
NVMem Free	No	cert	yes	Frees a file stored in non-volatile memory. This command can now be used to write files protected by an ACL to a smart card	No access to keys or CSPs	
NVMem List	yes	yes	yes	Reports a list of files stored in the non-volatile memory. This command can now be used to list files protected by an ACL on a smart card	No access to keys or CSPs	
NVMem Operation	No	cert, ACL	ACL	Performs an operation on a file stored in non-volatile memory. Operations include: read, write, increment, decrement, etc. This command can now be used to write files protected by an ACL to a smart card	No access to keys or CSPs	

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
Programming Begin Programming Begin Chunk Programming Load Block Programming End Chunk Programming End	monitor	monitor	monitor	<p>These commands are used in the firmware upgrade process. The administrator uses the LoadROM utility which issues the correct command sequence to load the new firmware.</p> <p>The module will only be operating in a FIPS approved mode if you install firmware that has been validated by NIST / CSE. Administrators who require FIPS validation should only upgrade firmware after NIST / CSE issue a new certificate.</p> <p>The monitor also checks that the Version Sequence Number (VSN) of the firmware is as high or higher than the VSN of the firmware currently installed.</p>	<p>Uses Firmware Integrity Key and Firmware Confidentiality Keys.</p> <p>Sets Firmware Integrity Key and Firmware Confidentiality Keys.</p>	[DSA, Triple DES]
Random Number	yes	yes	yes	<p>Generates a random number for use in a application using the on-board random number generator. There are separate services for generating keys.</p> <p>The random number services are designed to enable an application to access the random number source for its own purposes - for example an on-line casino may use GenerateRandom to drive its applications.</p>	No access to keys or CSPs	
Random Prime	yes	yes	yes	<p>Generates a random prime. This uses the same mechanism as is used for RSA and Diffie-Hellman key generation. The primality checking conforms to ANSI X9.31.</p>	No access to keys or CSPs	

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
Read File	level 2	cert	yes	<p>Reads a file, but not a logical token, from a smart card or software token.</p> <p>This command can only read files without ACLs.</p>	<p>Reads a file, but not a logical token, from a smart card or software token. This command can only read files without ACLs.</p> <p>No access to keys or CSPs</p>	
Read Share	yes	yes	yes	<p>Reads a share from a physical token.</p> <p>Once sufficient shares have been loaded recreates token- may require several ReadShare or ReceiveShare commands.</p>	<p><i>Uses</i> pass phrase, module key, <i>creates</i> share key, <i>uses</i> share key, <i>creates</i> a logical token.</p>	[SHA-1, AES or Triple DES]
Receive Share	No	handle, encrypted share	handle, encrypted share	<p>Takes a share encrypted with SendShare and a pass phrase and uses them to recreate the logical token. - may require several ReadShare or ReceiveShare commands</p>	<p><i>Uses</i> an Impath key, <i>uses</i> pass phrase, module key, <i>creates</i> share key, <i>uses</i> share key, <i>creates</i> a logical token</p>	[AES, Triple DES]
Redeem Ticket	No	ticket	ticket	<p>Gets a handle in the current name space for the object referred to by a ticket created by GetTicket.</p>	<p><i>Uses</i> a key object, logical token, Impath, or SEWorld</p>	
Remove KM	No	cert	yes	<p>Removes a loaded module key.</p>	<p><i>Erases</i> a module key</p>	
SEE Job	No	cert	yes	<p>Sends a command to a SEE World.</p>	<p>No access to keys or CSPs</p>	

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
Set ACL	No	handle, ACL	handle, ACL	Sets the ACL for an existing key. The existing ACL for the key must allow the operation.	<i>Sets the Access Control List for a key object</i>	
Set Application Data	No	handle, ACL	handle, ACL	Stores information with a key.	<i>Sets the application data stored with a key object</i>	
Set KM	No	cert	yes	Loads a key object as a module key.	<i>Uses a key object, sets a module key</i>	AES, Triple DES
Set NSO Perm	init	init	No	Loads a key hash as the nCipher Security Officer's Key and sets the security policy to be followed by the module. This can only be performed while the unit is in the initialisation state.	<i>Sets the nCipher Security officer's key hash.</i>	[SHA-1 hash of DSA key]
Set RTC	No	cert	yes	Sets the real-time clock.	No access to keys or CSPs	
Set SEE Machine	No	cert handle	handle	Loads the contents of a buffer (created by CreateBuffer / LoadBuffer) as the SEE machine for this module. This command checks the signatures on the buffer.	<i>Uses a public key provided in buffer</i>	DSA, Triple DES MAC, HMAC
Sign	No	handle, ACL	handle, ACL	Returns the digital signature or MAC of plain text using a stored key.	<i>Uses a key object</i>	RSA, DSA, ECDSA, Triple DES MAC, HMAC, KCDSA*
Sign Module State	No	handle, ACL	handle, ACL	Signs a certificate describing the modules security policy, as set by SetNSOPerm	<i>Uses the module signing key</i>	[DSA]
Send Share	No	handle, ACL	handle, ACL	Reads a logical token share and encrypts it under an impath key for transfer to another module where it can be loaded using ReceiveShare	<i>Uses an Impath key, exports encrypted share.</i>	[AES, Triple DES]
Statistics Enumerate Tree	yes	yes	yes	Reports the statistics available.	No access to keys or CSPs	

Command / Service	Role			Description	Key/CSP access	Key types
	Unauth	JSO / User	NSO			
Statistic Get Value	yes	yes	yes	Reports a particular statistic.	No access to keys or CSPs	
Trace SEE World	No	cert	yes	Reports debugging output from a SEE World .	No access to keys or CSPs	
Verify	No	handle, ACL	handle, ACL	Verifies a digital signature using a stored key.	Uses a key object.	RSA, DSA, ECDSA, Triple DES MAC, HMAC, KCDSA *
Write File	level 2	cert	yes	Writes a file, but not a logical token, to a smart card or software token. Note these files do not have an ACL, use the NVMEM commands to create files with an ACL.	No access to keys or CSPs	
Write Share	No	cert handle	handle	Writes a new share to a smart card or software token. The number of shares that can be created is specified when the token is created. All shares must be written before the token is destroyed.	Sets pass phrase, uses module key, creates share, uses pass phrase and module key, creates share key, uses module key, uses share key, exports encrypted share.	[AES, Triple DES, SHA-1]

Code	Description
No	The operator can not perform this service in this role.
yes	The operator can perform this service in this role without further authorization.

Code	Description
handle	<p>The operator can perform this service if they possess a valid handle for the resource: key, channel, impath, token, buffers, SEWorld.</p> <p>The handle is an arbitrary number generated when the object is created.</p> <p>The handle for an object is specific to the operator that created the object.</p> <p>The ticket services enable an operator to pass an ID for an object they have created to another operator or SEWorld.</p>
ACL	<p>The operator can only perform this service with a key if the ACL for the key permits this service. The ACL may require that the operator present a certificate signed by a Security Officer or another key.</p> <p>The ACL may specify that a certificate is required, in which case the module verifies the signature on the certificate before permitting the operation.</p>
pass phrase	<p>An operator can only load a share, or change the share PIN, if they possess the pass phrase used to encrypt the share. The module key with which the pass phrase was combined must also be present.</p>
cert	<p>An operator can only perform this service if they are in possession of a certificate from the nCipher Security Officer. This certificate will reference a key. The module verifies the signature on the certificate before permitting the operation.</p>
FE	<p>This service is not available on all modules. It must be enabled using the FeatureEnable service before it can be used.</p>
level 2 only	<p>These services are available to the unauthenticated operator only when the module is initialized in it FIPS 140-2 level 2 mode. The module can be initialized to comply with FIPS 140-2 level 3 roles and services and key management by setting the FIPS_level3_compliance flag. If this flag is set:</p> <ul style="list-style-type: none"> the Generate Key, Generate Key Pair and Import commands require authorization with a certificate signed by the nCipher Security Officer. the Import command fails if you attempt to import a key of a type that can be used to Sign or Decrypt messages. the GenerateKey, GenerateKeyPair, Import and DeriveKey operations will not allow you to create an ACL for a secret key that allows the key to be exported in plain text.
encrypted share	<p>The ReceiveShare command requires a logical token share encrypted using an Impath key. created by the SendShare command.</p>
ticket	<p>The RedeemTicket command requires the ticket generated by GetTicket.</p>
init	<p>These services are used to initialise the module. They are only available when the module is in the initialisation mode. To put the module into initialisation mode you must have physical access to the module and put the mode switch into the initialisation setting. In order to restore the module to operational mode you must put the mode switch back to the Operational setting.</p>
monitor	<p>These services are used to reprogram the module. They are only available when the module is in the monitor mode. To put the module into monitor mode you must have physical access to the module and put the mode switch into the monitor setting. In order to restore the module to operational mode you reinitialize the module and then return it to operational state.</p>

Keys

For each type of key used by the nShield and nCipher modules, the following section describes the access that a user has to the keys.

The nShield and nCipher modules refers to keys by their handle, an arbitrary number, or by its SHA-1 hash.

Security Officer's key

The nCipher Security officer's key must be set as part of the initialisation process. This is a public / private key pair that the nCipher Security Officer uses to sign certificates to authorize key management and other secure operations.

The SHA-1 hash of the public half of this key pair is stored in the module FRAM

The public half of this key is included as plain text in certificates.

The module treats anyone in possession of the private half of this key as the Security Officer.

If you use the standard tools supplied by nCipher to initialise the module, then this key is a DSA key stored as a key blob protected by a logical token on the Administrator Card Set. If a customer writes their own tools to initialise the module, they can choose between RSA, DSA or KDSA, and are responsible for ensuring the private half of this key is stored securely.

Junior Security Officer's key

Because the nCipher Security Officer's key has several properties, it is good practice to delegate authority to one or more Junior Security Officers, each with authority for defined operations.

To create a Junior Security Officer (JSO) the NSO creates a certificate signing key for use as their JSO key. This key must be protected by a logical token in the same manner as any other application key.

Then to delegate authority to the JSO, the nCipher Security Officer creates a certificate containing an Access Control List specifying the authority to be delegated and the hash of the JSO key to which the powers are to be delegated.

The JSO can then authorize the actions listed in the ACL - as if they were the NSO - by presenting the JSO key and the certificate. If the JSO key is created with the Sign permission in its ACL the JSO may delegate parts of their authority to another key, the holder of the delegate key will need to present the certificate signed by the NSO and the certificate signed by the JSO. If the JSO key only has **UseAsCertificate** permissions, then they cannot delegate authority.

If you use the standard tools supplied by nCipher to initialise the module, then this key is a DSA key stored as a key blob protected by a logical token on the Administrator Card Set. If a customer writes their own tools to initialise the module, they can choose between RSA, DSA or KDSA, and are responsible for ensuring the private half of this key is stored securely.

Long term signing key

The nShield and nCipher modules stores a 160 bit random number in the FRAM. This data is combined with a discrete log group stored in the module firmware to produce a DSA key.

This key can be reset to a new random value by the **GenerateKLF** service. It can be used to sign a module state certificate using the **SignModuleState** service and the public value retrieved by the non-cryptographic service **GetLongTermKey**.

This is the only key that is not zeroized when the module is initialized.

This key is not used to encrypt any other data. It only serves to provide a cryptographic identity for a module that can be included in a PKI certificate chain. nCipher may issue such certificates to indicate that a module is a genuine nCipher module.

Module signing key

When the nShield and nCipher modules is initialized it automatically generate a DSA key pair that it uses to sign certificates. The private half of this pair is stored internally in FRAM and never released. The public half is revealed in plaintext, or encrypted as a key blob under some other key. This key is only ever used to verify that a certificate was generated by a specified module.

Module keys

Module keys are AES or Triple DES used to protect tokens. The nShield and nCipher modules generates the first module key K_{M0} when it is initialized. This module key is guaranteed never to have been known outside this module. K_{M0} is an AES key. The Security Officer can load further module keys. These can be generated by the module or may be loaded from an external source. Setting a key as a module key stores the key in FRAM.

Module keys can not be exported once they have been assigned as module keys. They may only be exported on a key blob when they are initially generated.

Logical tokens

A logical token is an AES or Triple DES key used to protect key blobs. Logical tokens are associated with module keys. The key type depends on the key type of the module key.

When you create a logical token, you must specify parameters, including the total number of shares, and the number of shares required to recreate the token, the quorum. The total number can be any integer between 1 and 64 inclusive. The quorum can be any integer from 1 to the total number.

A logical token is always generated randomly, using the on-board random number generator.

While loaded in the module logical tokens are stored in the object store.

Token keys are never exported from the module, except on physical tokens or software tokens. When a module key is exported the logical token - the Triple DES key plus the token parameters - is first encrypted with a module key. Then the encrypted token is split into shares using the Shamir Threshold Sharing algorithm, even if the total number of shares is one. Each share is then encrypted using a share key and written to a physical token - a smart card - or a software token. Logical tokens can be shared between one or more physical token. The properties for a token define how many shares are required to recreate the logical token. Shares can only be generated when a token is created. The firmware prevents a specific share from being written more than once.

Share Key

A share key is used to protect a logical token share when they are written to a smart card or software token that is used for authentication. The share key is created by creating a message comprised of an nCipher secret prefix, Module key, Share number, smart card unique id and an optional 20 bytes supplied by the user (expected to be the SHA-1 hash of a pass phrase entered into the application), and using this as the input to the approved pRNG function to form a unique key used to encrypt the share - this is either an AES or Triple DES key depending on the key type of the logical token which is itself determined by the key type of the module key. This key is not stored on the module. It is recalculated every time share is loaded. The share data includes a MAC, if the MAC does not verify correctly the share is rejected.

The share key is not used directly to protect CSPs. The logical token needs to be reassembled from the shares using Shamir Threshold Sharing Scheme and then be decrypted using the module key. Only then can the logical token be used to decrypt application keys.

Impath keys

An impath is a secure channel between two modules.

To set up an impath two modules perform a validated key-exchange, currently using Diffie-Hellman.

The key exchange parameters are signed by the modules signing key. Once the modules have validated the signatures, the module derives four symmetric keys using a protocol based on SHA-1. Currently symmetric keys are Triple DES. The four keys are used for encryption, decryption, MAC creation, and MAC validation. The protocol ensures that the key Module 1 uses for encryption is used for decryption by module 2.

All in-path keys are stored as objects in the object store in DRAM.

Key objects

Keys used for encryption, decryption, signature verification, and digital signatures are stored in the module as objects in the object store in DRAM. All key objects are identified by a random identifier that is specific to the user and session.

All key objects are stored with an Access Control List or ACL. The ACL specifies what operations can be performed with this key. Whenever a user generates a key or imports a key in plain text, they must specify a valid ACL for that key type. The ACL can be changed using the **SetACL** service. The ACL can only be made more permissive if the original ACL includes the **ExpandACL** permission.

Key objects may be exported as key blobs if their ACL permits this service. Each blob stores a single key and an ACL. The ACL specifies what operations can be performed with this copy of the key. The ACL stored with the blob must be at least as restrictive as the ACL associated with the key object from which the blob was created. When you load a key blob, the new key object takes its ACL from the key blob. Working key blobs are encrypted under a logical token. Key objects may also be exported as key blobs under an archiving key. The key blob can be stored on the host disk or in the module NVRAM.

Key objects can only be exported in plain text if their ACL permits this operation. If the module has been initialized to comply with FIPS 140-2 level 3 roles and services and key management, the ACL for a private or secret key cannot include the export as plain service. A user may pass a key to another user - or to a SEE World - using the ticketing mechanism. The **GetTicket** mechanism takes a key identifier and returns a ticket. This ticket refers to the key identifier - it does not include any key data. A ticket can be passed as a byte block to the other user who can then use the **RedeemTicket** service to obtain a key identifier for the same object that is valid for their session. As the new identifier refers to the same object, the second user is still bound by the original ACL.

Session keys

Keys used for a single session are generated as required by the module. They are stored along with their ACL as objects in the object store. These may be of any supported algorithm.

Archiving keys

It is sometimes necessary to create an archive copy of a key, protected by another key. Keys may be archived using:

- Triple DES keys
- A combination of Triple DES and RSA keys.

In this case a random Triple DES key is created which is used to encrypt working key and then this key is wrapped by the RSA key.

- An integrated encryption scheme using Diffie-Hellman or RSA and AES or Triple DES.

When a key is archived in this way it is stored with its ACL

When you generate or import the archiving, you must specify the **UseAsBlobKey** option in the ACL. The archiving key is treated as any other key object.

When you generate or import the key that you want to archive you must specify the Archival options in the ACL. This options can specify the hash(es) of the allowed archiving key(s). If you specify a list of hashes, no other key may be used.

Certificate signing keys

The ACL associated with a key object can call for a certificate to be presented to authorize the action. The required key can either be the nCipher Security Officer's key or any other key. Keys are specified in the ACL by an identifying key SHA-1 hash. The key type is also specified in the ACL although DSA is standard, any signing algorithm may be used, all nCipher tools use DSA.

Certain services can require certificates signed by the nCipher Security Officer.

Firmware Integrity Key

All firmware is signed using a DSA key pair. A module only loads new firmware if the signature decrypts and verifies correctly.

The private half of this key is stored at nCipher.

The public half is included in all firmware. The firmware is stored in flash memory when the module is switched off, this is copied to DRAM as part of the start up procedure.

Firmware Confidentiality Key

All firmware is encrypted using Triple DES to prevent casual decompilation.

The encryption key is stored at nCipher's offices and is in the firmware.

The firmware is stored in flash memory when the module is switched off, this is copied to DRAM as part of the start up procedure.

nCipher Master Feature Enable Key

For commercial reasons not all nCipher modules offer all services. Certain services must be enabled separately. In order to enable a service the user presents a certificate signed by the nCipher Master Feature Enable Key. This causes the module to set the appropriate bit in the FRAM.

The nCipher Master Feature Enable Key is a DSA key pair, The private half of this key pair is stored at nCipher's offices. The public half of the key pair is included in the firmware. The firmware is stored in flash memory when the module is switched off, this is copied to DRAM as part of the start up procedure.

Rules

Identification and authentication

Communication with the nShield and nCipher modules is performed via a server program running on the host machine, using standard inter process communication, using sockets in UNIX operating system, named pipes under Windows NT.

In order to use the module the user must first log on to the host computer and start an nCipher enabled application. The application connects to the nCipher server, this connection is given a client ID, a 32-bit arbitrary number.

Before performing any service the user must present the correct authorization. Where several stages are required to assemble the authorization, all the steps must be performed on the same connection. The authorization required for each service is listed in the section [Services available to each role](#) on page 12. A user cannot access any service that accesses CSPs without first presenting a smart card, or software token.

The nShield and nCipher modules performs identity based authentication. Each individual user is given a smart card that holds their authentication data - the logical token share - in an encrypted form. All operations require the user to first load the logical token from their smart card.

Access Control

Keys are stored on the host computer's hard disk in an encrypted format, known as a key blob. In order to load a key the user must first load the token used to encrypt this blob.

Tokens can be divided into shares. Each share can be stored on a smart card or software token on the computer's hard disk. These shares are further protected by encryption with a pass phrase and a module key. Therefore a user can only load a key if they possess the physical smart cards containing sufficient shares in the token, the required pass phrases and the module key are loaded in the module.

Module keys are stored in FRAM in the module. They can only be loaded or removed by the nCipher Security Officer, who is identified by a public key pair created when the module is initialized. It is not possible to change the Security Officer's key without re initializing the module, which clears all the module keys, thus preventing access to all other keys.

The key blob also contains an Access Control List that specifies which services can be performed with this key, and the number of times these services can be performed. These can be hard limits or per authorization limits. If a hard limit is reached that service can no longer be performed on that key. If a per-authorization limit is reached the user must reauthorize the key by reloading the token.

All objects are referred to by handle. Handles are cross-referenced to **ClientIDs**. If a command refers to a handle that was issued to a different client, the command is refused. Services exist to pass a handle between **ClientIDs**.

Access Control List

All key objects have an Access Control List (ACL). The user must specify the ACL when they generate or import the key. The ACL lists every operation that can be performed with the key - if the operation is not in the ACL the module will not permit that operation. In particular the ACL can only be altered if the ACL includes the **SetACL** service. The ACL is stored with the key when it is stored as a blob and applies to the new key object created when you reload the blob.

The ACL can specify limits on operations - or groups of operations - these may be global limits or per authorization limits. If a global limit is exceeded then the key cannot be used for that operation again. If a per authorization limit is exceeded then the logical token protecting the key must be reloaded before the key can be reused.

An ACL can also specify a certifier for an operation. In this case the user must present a certificate signed by the key whose hash is in the ACL with the command in order to use the service.

An ACL can also list User Defined actions. These actions do not permit any operations within the module, but can be tested with the **CheckUserAction** service. This enables SEE programs to make use of the ACL system for their own purposes. For example payShield uses this feature to determine the role of a Triple-DES key within EMV.

An ACL can also specify a host service identifier. In which case the ACL is only met if the nCipher server appends the matching Service name. This feature is designed to provide a limited level of assurance and relies on the integrity of the host, it offers no security if the server is compromised or not used.

ACL design is complex - users will not normally need to write ACLs themselves. nCipher provide tools to generate keys with strong ACLs.

Object re-use

All objects stored in the module are referred to by a handle. The module's memory management functions ensure that a specific memory location can only be allocated to a single handle. The handle also identifies the object type, and all of the modules enforce strict type checking. When a handle is released the memory allocated to it is actively zeroed.

Error conditions

If the module cannot complete a command due to a temporary condition, the module returns a command block with no data and with the status word set to the appropriate value. The user can resubmit the command at a later time. The server program can record a log of all such failures.

If the module encounters an unrecoverable error it enters the error state. This is indicated by the change in voltage on the LED pin causing the LED connected to this pin to flash in the Morse pattern SOS. As soon as the unit enters the error state all processors stop processing commands and no further replies are returned. In the error state the unit does not respond to commands. The unit must be reset.

Security Boundary

The physical security boundary is the plastic jig that contains the potting on both sides of the PCB.

All cryptographic components are covered by potting.

There is also a logical security boundary between the nCore kernel and the SEE.

Some items are excluded from FIPS 140-2 validation as they are not security relevant see [Excluded Components](#) on page 9

Status information

The module has an LED pin that indicates the overall state of the module. This pin must be connected to an external LED.

The module also returns a status message in the reply to every command. This indicates the status of that command.

There are a number of services that report status information. Where the module is fitted inside an NetHSM this information can be displayed on the LCD on the NetHSM's front panel.

Procedures to initialise a module to comply with FIPS 140-2 Level 3

The nCipher enabled application must perform the following services, for more information refer to the nCipher Security Officer's Guide and Technical Reference Manual.

- 1 Put the mode switch into the initialisation position and restart the module

- 2 Use either the graphical user interface KeySafe or the command line tool new-world. Using either tool you must specify the number of cards in the Administrator Card Set and the encryption algorithm to use, Triple-DES or AES. To ensure that the module is in Level 3 mode you must
 - Using Keysafe select the option "**Strict FIPS 140 Mode**" = **Yes**.
 - Using new-world specify the **-F** flag in the command line
- 3 The tool prompts you to insert cards and to enter a pass phrase for each card.
- 4 When you have created all the cards, reset the mode switch into the operational position and restart the module.

If a module is initialised in level 3 mode

- Keysafe displays "Strict FIPS 140-2 Mode" = Yes in the information panel for that module.
- The command line tool Enquiry include **StrictFIPS** in the list of flags for the module

Procedures to initialise a module to comply with FIPS 140-2 Level 2

The nCipher enabled application must perform the following services, for more information refer to the nCipher Security Officer's Guide and Technical Reference Manual.

- 1 Put the mode switch into the initialisation position and restart the module
- 2 Use either the graphical user interface KeySafe or the command line tool new-world. Using either tool you must specify the number of cards in the Administrator Card Set and the encryption algorithm to use, Triple-DES or AES. To ensure that the module is in Level 2 mode you must
 - Using Keysafe select the option "**Strict FIPS 140 Mode**" = **No**
 - Using new-world do NOT specify the **-F** flag in the command line
- 3 The tool prompts you to insert cards and to enter a pass phrase for each card.
- 4 When you have created all the cards, reset the mode switch into the operational position and restart the module.

If a module is initialised in level 2 mode

- Keysafe displays "Strict FIPS 140-2 Mode" = No in the information panel for that module.

- The command line tool Enquiry does NOT include **StrictFIPS** in the list of flags for the module

Operating a level 2 module in FIPS mode

To be operating in Level 2 FIPS Mode, only FIPS Approved cryptography can be used in FIPS Mode. Use of any Non-FIPS Approved algorithms, except for those for which the CMVP allowed in FIPS Mode (See Supported Algorithms Section), means that the module would not be operating in FIPS Mode.

In order to comply with FIPS mode the user must not generate private or secret keys with the **ExportAsPlain** ACL entry; nor should they use the **Import** service to import such keys in plain text.

A user can verify that a key was generated correctly using the **nkmverify** utility supplied by nCipher. This utility checks the ACL stored in the key-generation certificate.

To return a module to factory state

This clears the Security Officer's key, the module signing key and any loaded module keys.

- 1 Fit the initialisation link and restart the module
- 2 Use the **Initialise** command to enter the Initialisation state.
- 3 Load a random value to use as the hash of the Security Officer's key.
- 4 Set Security Officer service to set the Security Officer's key and the operational policy of the module.
- 5 Remove the initialisation link and restart the module.
- 6 After this operation the module must be initialized correctly before it can be used in a FIPS approved mode.

nCipher supply a graphical user interface KeySafe and a command line tool new-world that automate these steps.

To create a new user

- 1 Create a logical token.
- 2 Write one or more shares of this token onto software tokens.

- 3 For each key the user will require, export the key as a key blob under this token.
- 4 Give the user any pass phrases used and the key blob.

nCipher supply a graphical user interface KeySafe and a command line tool new-world that automate these steps.

To authorize the user to create keys

- 1 Create a new key, with an ACL that only permits **UseAsSigningKey**.
- 2 Export this key as a key blob under the users token.
- 3 Create a certificate signed by the nCipher Security Officer's key that:
 - 4 includes the hash of this key as the certifier
 - 5 authorizes the action **GenerateKey** or **GenerateKeyPair** depending on the type of key required.
 - 6 if the user needs to store the keys, enables the action **MakeBlob**, limited to their token.
- 7 Give the user the key blob and certificate.

nCipher supply a graphical user interface KeySafe and a command line tool **new-world** that automate these steps.

To authorize a user to act as a Junior Security Officer

- 1 Generate a logical token to use to protect the Junior Security Officer's key.
- 2 Write one or more shares of this token onto software tokens
- 3 Create a new key pair,
- 4 Give the private half an ACL that permits **Sign** and **UseAsSigningKey**.
- 5 Give the public half an ACL that permits **ExportAsPlainText**
- 6 Export the private half of the Junior Security Officer's key as a key blob under this token.
- 7 Export the public half of the Junior Security Officer's key as plain text.
- 8 Create a certificate signed by the nCipher Security Officer's key includes the hash of this key as the certifier
- 9 authorizes the actions **GenerateKey**, **GenerateKeyPair**

10 authorizes the actions **GenerateLogicalToken**, **WriteShare** and **MakeBlob**, these may be limited to a particular module key.

11 Give the Junior Security Officer the software token, any pass phrases used, the key blob and certificate.

nCipher supply a graphical user interface KeySafe and a command line tool **new-world** that automate these steps.

To authenticate a user to use a stored key

- 1 Use the **LoadLogicalToken** service to create the space for a logical token.
- 2 Use the **ReadShare** service to read each share from the software token.
- 3 Use the **LoadBlob** service to load the key from the key blob.
- 4 The user can now perform the services specified in the ACL for this key.
- 5 To assume Security Officer role load the Security Officer's key using this procedure. The Security Officer's key can then be used in certificates authorising further operations.

nCipher supply a graphical user interface KeySafe and a command line tool **new-world** that automate these steps.

To authenticate a user to create a new key

- 1 If you have not already loaded your user token, load it as above.
- 2 Use the **LoadBlob** service to load the authorization key from the key blob.
- 3 Use the **KeyId** returned to build a signing key certificate.
- 4 Present this certificate with the certificate supplied by the Security Officer with the **GenerateKey**, **GenerateKeyPair** or **MakeBlob** command.

nCipher supply a graphical user interface KeySafe and a command line tool **new-world** that automate these steps.

Physical security

All security critical components of the module are covered by epoxy resin.

The module has a clear button. Pressing this button put the module into the self-test state, clearing all stored key objects, logical tokens and impath keys and running all self-tests. The long term security critical parameters, module keys, module signing key and Security Officer's key can be cleared by returning the module to the factory state, as described above.

Checking the module

To ensure physical security, make the following checks regularly:

- Examine the epoxy resin security coating for obvious signs of damage.
- The smart card reader is directly plugged into the port provided by the appliance in which the module is integrated and the cable has not been tampered with.

Strength of functions

Attacking Object IDs

Connections are identified by a **ClientID**, a random 32 bit number.

Objects are identified by a **KeyID** - this should be renamed **ObjectID** as it can now be used for more than just keys but retains its old name for code compatibility reasons. Again this is a random 32 bit number.

In order to randomly gain access to a key loaded by another user you would need to guess two random 32 bit numbers. The module can process about 2^{16} commands per minute - therefore the chance of succeeding within a minute is $2^{16} / 2^{64} = 2^{-48}$ which is significantly less than the required chance of 1 in 1,000,000 ($\sim 2^{-20}$)

Attacking Tokens

If a user chooses to use a logical token with only one share, no pass phrase and leaves the smart card containing the share in the slot than another user could load the logical token. The module does not have any idea as to which user inserted the smart card. This can be prevented by:

- not leaving the smart card in the reader

if the smart card is not in the reader, they can only access the logical token by correctly guessing the **ClientID** and **ObjectID** for the token.

- requiring a pass phrase

when loading a share requiring a pass phrase the user must supply the SHA-1 hash of the pass phrase. The hash is combined with a module key, share number and smart card id to recreate the key used to encrypt the share. If the attacker has no knowledge of the pass phrase they would need to make 2^{80} attempts to load the share. The module enforces a five seconds delay between failed attempts to load a share.

- requiring more than one share

If a logical token requires shares from more than one smart card the attacker would have to repeat the attack for each share required.

Logical tokens are either 168-bit Triple DES keys or 256-bit AES keys. Shares are encrypted under a combination of a module key, share number and card ID. If you could construct a logical token share of the correct form without knowledge of the module key and the exact mechanism used to derive the share key the chance that it would randomly decrypt into a valid token are 2^{-168} or 2^{-256} .

Key Blobs

Key blobs are used to protect keys outside the module. There are two formats of blob - indirect and direct. Direct blobs are used for token and module key protected blobs. indirect blobs are used by the nCipher Security World for key-recovery and for pass-phrase recovery.

Direct blobs use a Integrated encryption scheme, which takes a 168 or 256 bit key and a nonce and uses SHA-1 to derive a triple-DES or AES encryption key, used for encryption and a HMAC key, used for integrity. Indirect key, take the public half of a 1024-bit RSA key and a none as the input, and derive the keys from this. Both forms provide at least 80-bits of security.

Impaths

Impaths protect the transfer of encrypted shares between modules.

When negotiating an Impath, the module verifies a 1024-bit DSA signatures to verify the identity of the other module. It then uses 1024-bit Diffie-Hellman key exchange to negotiate a 168-bit triple-DES encryption keys used to protect the channel. This provides a minimum of 80-bits of security for the encrypted channel.

Note The shares sent over the channel are still encrypted using their share key, decryption only takes place on the receiving module.

KDP key provisioning

The KDP protocol used to transfer keys from a module to a micro HSM uses 1024-bit DSA signatures to identify the end point and a 2048-bit Diffie-Hellman key exchange to negotiate the Triple-DES or AES keys used to encrypt the keys in transit providing a minimum of 100-bits of security for the encrypted channel.

Derived Keys

The nCore API provides a range of key derivation and wrapping options that a user can choose to make use of in their protocols. The user must ensure that they select suitable algorithms that are found in Annex D of FIPS PUB 140-2 and implemented according to NIST Special Publication 800-56A and that the key strength provides at a minimum 80 bits of encryption strength. Refer to NIST Special Publication 800-57 for minimum key strengths.

If the module is initialized in its level 3 mode all non-approved key wrapping and key establishment mechanisms are disabled.

Self Tests

When power is applied to the module it enters the self test state. The module also enters the self test state whenever the unit is reset, by pressing the clear button.

In the self test state the module clears the main RAM, thus ensuring any loaded keys or authorization information is removed and then performs its self test sequence, which includes:

- An operational test on hardware components
- An integrity check on the firmware, verification of a SHA-1 hash.
- A statistical check on the random number generator
- Known answer and pair-wise consistency checks on all algorithms and pRNG
- Verification of a MAC on EEPROM contents to ensure it is correctly initialized.

This sequence takes a few seconds after which the module enters the Pre-Maintenance, Pre-Initialisation, Uninitialised or Operational state; depending on the position of the mode switch and the validity of the the EEPROM contents.

While it is powered on, the module continuously monitors the temperature recorded by its internal temperature sensor. If the temperature is outside the operational range it enters the error state.

The module also continuously monitors the hardware RNG and the approved SHA-1 based pRNG. If either fail it enters the error state.

When firmware is updated, the module verifies a DSA signature on the new firmware image before it is written to flash.

In the error state, the module's LED repeatedly flashes the Morse pattern SOS, followed by a status code indicating the error. All other inputs and outputs are disabled.

Supported Algorithms

FIPS approved algorithms:

- AES
 - Certificate #685, ECB, CBC and CMAC modes
 - GCM Mode Vendor Affirmed
- Triple DES
 - Certificate #625
 - Double and triple length keys
 - Approved for Federal Government Use - Modes are CBC and ECB
- Triple DES MAC
 - Triple-DES Certificate #625
- DSA
 - Certificate #259
- ECDSA
 - Certificate #76
- RSA
 - Certificate #320
- SHA-1, SHA-224, SHA-256, SHA-384 and SHA-512
 - Certificate #713
- HMAC SHA-1, HMAC SHA-224, HMAC SHA-256, HMAC SHA-384 and HMAC SHA-512
 - Certificate #364
- Random Number Generator
 - (FIPS 186-2 Change Notice 1 SHA-1 and FIPS 186-2 RNG General Purpose RNG)
 - Certificate #399

Non-FIPS approved algorithms

Note Algorithms marked with an asterisk are not approved by NIST. If the module is initialised in its level 3 mode, these algorithms are disabled. If module is initialized in level 2 mode, the algorithms are available. However, if you choose to use them, the module is not operating in FIPS approved mode.

Symmetric

- Aria*
- Arc Four (compatible with RC4)*
- Camellia*
- CAST 6 (RFC2612)*
- DES*

Note Non-compliant due to CAVP DES transition policy.

- SEED (Korean Data Encryption Standard) - requires Feature Enable activation*

Asymmetric

- Diffie-Hellman (key agreement, key establishment methodology provides between 80 and 256 bits of encryption strength)
- El Gamal* (encryption using Diffie-Helman keys)
- Elliptic Curve Diffie-Hellman (key agreement, key establishment methodology provides 192-bits of encryption strength);
- RSA (key wrapping, key establishment methodology provides between 80 and 256 bits of encryption strength)
- KCDSA - requires Feature Enable activation*
- EC-MQV (key establishment methodology provides between 80 and 256 of encryption strength)

Hash

- HAS-160 - requires Feature Enable activation*
- MD5 - requires Feature Enable activation*

- RIPEMD 160*
- Tiger*

MAC

- HMAC (MD5, RIPEMD160, Tiger)*

Other

- SSL*/TLS master key derivation
- PKCS #8 key wrapping*

Note TLS key derivation is approved for use by FIPS 140-2 validated modules - though there is as yet no validation test. MD5 may be used within TLS key derivation.

nCipher Corporation Ltd.

Cambridge, UK

Jupiter House
Station Road
Cambridge
CB1 2JD
UK

Tel: +44 (0) 1223 723600

Fax: +44 (0) 1223 723601

E-mail: sales@ncipher.com**nCipher Inc.**

Boston Metro Region, USA

92 Montvale Avenue, Suite 4500
Stoneham, MA 02180
USATel: 800-NCIPHER
800-6247437
+1 (781) 994 4000

Fax: +1 (781) 994 4001

E-mail: sales@us.ncipher.com**Internet addresses**Web Site: <http://www.ncipher.com/>
Support: <http://www.ncipher.com/support/>
Online Documentation: <http://active.ncipher.com/documentation/>

Note nCipher also maintain international sales offices. Please contact the UK, or the US, head office for details of your nearest nCipher representative.

