SUBCHAPTER K-METAL AND NONMETAL MINE SAFETY AND HEALTH

56.4331 Firefighting drills. PART 56—SAFETY AND HEALTH STANDARDS—SURFACE METAL FLAMMABLE AND COMBUSTIBLE LIQUIDS AND AND NONMETAL MINES GASES 56 4400 Use restrictions. Subpart A—General 56.4401 Storage tank foundations. 56.4402 Safety can use 56.4430 Storage facilities. 56.1 Purpose and scope. 56.2 Definitions. INSTALLATION/CONSTRUCTION/MAINTENANCE PROCEDURES 56 4500 Heat sources. 56.4501 Fuel lines. 56.1000 Notification of commencement of 56.4502 Battery-charging stations. operations and closing of mines. 56.4503 Conveyor belt slippage. 56.4530 Exits. Subpart B—Ground Control 56.4531 Flammable or combustible liquid 56.3000 Definitions. storage buildings or rooms. MINING METHODS WELDING/CUTTING/COMPRESSED GASES 56.3130 Wall, bank, and slope stability. 56.4600 Extinguishing equipment. 56.3131 Pit or quarry wall perimeter. 56.4601 Oxygen cylinder storage. 56.4602 Gauges and regulators. SCALING AND SUPPORT 56.4603 Closure of valves. 56.3200 Correction of hazardous conditions. 56.4604 Preparation of pipelines or con-56.3201 Location for performing scaling. tainers. Scaling tools. APPENDIX I TO SUBPART C-NATIONAL CON-56.3203 Rock fixtures. SENSUS STANDARDS PRECAUTIONS Subpart D—Air Quality and Physical 56.3400 Secondary breakage. **Agents** 56.3401 Examination of ground conditions. Activity between machinery AIR QUALITY equipment and the highwall or bank. 56.5001 Exposure limits for airborne contaminants. Subpart C—Fire Prevention and Control 56.5002 Exposure monitoring. 56.4000 Definitions. 56.5005 Control of exposure to airborne con-56.4011 Abandoned electric circuits. taminants 56.5006 Restricted use of chemicals. PROHIBITIONS/PRECAUTIONS/HOUSEKEEPING **Subpart E—Explosives** 56.4100 Smoking and use of open flames. Warning signs. 56.4101 56.6000 Definitions. 56.4102 Spillage and leakage. 56.4103 Fueling internal combustion en-STORAGE gines. 56.4104 Combustible waste. 56.6100 Separation of stored explosive mate-56.4130 Electric substations and liquid storrial. age facilities. 56.6101 Areas around explosive material storage facilities. FIREFIGHTING EQUIPMENT 56.6102 Explosive material storage practices. 56.4200 General requirements. 56.6130 Explosive material storage facilities. 56.4201

56.6131 Location of explosive material stor-

Transportation 56.6200 Delivery to storage or blast site

age facilities.

areas.

56.6133 Powder chests.

56.6132 Magazine requirements.

Inspection.

56.4230 Self-propelled equipment.

56.4203 Extinguisher recharging or replace-

FIREFIGHTING PROCEDURES/ALARMS/DRILLS

56.4330 Firefighting, evacuation, and rescue

56.4202 Fire hydrants.

procedures.

30 CFR Ch. I (7-1-06 Edition)

Pt. 56	30 CFR Ch. I (7-1-06 Edition)
56.6201 Separation of transported explosive material.	56.6904 Smoking and open flames. 57.6905 Protection of explosive material.
56.6202 Vehicles. 56.6203 Locomotives.	Subpart F—Drilling and Rotary Jet Piercing
56.6204 Hoists. 56.6205 Conveying explosives by hand.	Drilling
USE 56.6300 Control of blasting operations.	56.7002 Equipment defects. 56.7003 Drill area inspection. 56.7004 Drill mast.
56.6301 Blasthole obstruction check. 56.6302 Separation of explosive material. 56.6303 Initiation preparation.	56.7005 Augers and drill stems. 56.7008 Moving the drill. 56.7009 Drill helpers.
56.6304 Primer protection. 56.6305 Unused explosive material. 56.6306 Loading, blasting, and security.	56.7010 Power failures. 56.7011 Straightening crossed cables. 56.7012 Tending drills in operation.
56.6307 Drill stem loading. 56.6308 Initiation systems. 56.6309 Fuel oil requirements for ANFO.	56.7013 Covering or guarding drill holes. 56.7018 Hand clearance. 56.7050 Tool and drill steel racks.
56.6310 Misfire waiting period. 56.6311 Handling of misfires. 56.6312 Secondary blasting.	56.7051 Loose objects on the mast or drill platform.
ELECTRIC BLASTING	56.7052 Drilling positions. 56.7053 Moving hand-held drills. 56.7055 Intersecting holes.
56.6400 Compatibility of electric detonators. 56.6401 Shunting. 56.6402 Deenergized circuits near deto-	56.7056 Collaring in bootlegs. ROTARY JET PIERCING
nators. 56.6403 Branch circuits. 56.6404 Separation of blasting circuits from power source.	56.7801 Jet drills. 56.7802 Oxygen hose lines. 56.7803 Lighting the burner. 56.7804 Refueling.
56.6405 Firing devices. 56.6406 Duration of current flow. 56.6407 Circuit testing.	56.7805 Smoking and open flames. 56.7806 Oxygen intake coupling. 56.7807 Flushing the combustion chamber.
NONELECTRIC BLASTING	Subpart G [Reserved]
56.6500 Damaged initiating material. 56.6501 Nonelectric initiation systems. 56.6502 Safety fuse.	Subpart H—Loading, Hauling, and Dumping
EXTRANEOUS ELECTRICITY	TRAFFIC SAFETY
56.6600 Loading practices. 56.6601 Grounding. 56.6602 Static electricity dissipation during	56.9100 Traffic control. 56.9101 Operating speeds and control of equipment.
loading. 56.6603 Air gap. 56.6604 Precautions during storms. 56.6605 Isolation of blasting circuits.	56.9102 Movement of independently operating rail equipment. 56.9103 Clearance on adjacent tracks.
EQUIPMENT/TOOLS	56.9104 Railroad crossings. Transportation of Persons and Materials
56.6700 Nonsparking tools. 56.6701 Tamping and loading pole requirements.	56.9200 Transporting persons. 56.9201 Loading, hauling, and unloading of
MAINTENANCE	equipment or supplies. 56.9202 Loading and hauling large rocks.
56.6800 Storage facilities. 56.6801 Vehicle repair. 56.6802 Bulk delivery vehicles.	SAFETY DEVICES, PROVISIONS, AND PROCE- DURES FOR ROADWAYS, RAILROADS, AND LOADING AND DUMPING SITES
56.6803 Blasting lines.	56.9300 Berms or guardrails. 56.9301 Dump site restraints.
GENERAL REQUIREMENTS 56.6900 Damaged or deteriorated explosive material. 56.6901 Black powder. 56.6902 Excessive temperatures. 56.6903 Burning explosive material.	 56.9302 Protection against moving or runaway railroad equipment. 56.9303 Construction of ramps and dumping facilities. 56.9304 Unstable ground. 56.9305 Truck spotters.

Mine Safety and Health Admin., Labor

OF Duration of manner and all the

Pt. 56

56.9306 Warning devices for restricted clearances.

56.9307 Design, installation, and maintenance of railroads.

56.9308 Switch throws.

56.9309 Chute design.

56.9310 Chute hazards.

56.9311 Anchoring stationary sizing devices.

56.9312 Working around drawholes.

56.9313 Roadway maintenance.

56.9314 Trimming stockpile and muckpile faces.

56.9315 Dust control.

56.9316 Notifying the equipment operator.

56.9317 Suspended loads.

56.9318 Getting on or off moving equipment. 56.9319 Going over, under, or between rail-

56.9319 Going over, under, or between rail cars.

56.9330 Clearance for surface equipment.

Subpart I—Aerial Tramways

56.10001 Filling buckets.

56.10002 Inspection and maintenance.

56.10003 Correction of defects.

56.10004 Brakes.

56.10005 Track cable connections.

56.10006 Tower guards.

56.10007 Falling object protection. 56.10008 Riding tramways.

56.10009 Riding loaded buckets.

56.10010 Starting precautions.

Subpart J—Travelways

56.11001 Safe access.

56.11002 Handrails and toeboards.

56.11003 Construction and maintenance of ladders.

56.11004 Portable rigid ladders.

56.11005 Fixed ladder anchorage and toe clearance.

56.11006 Fixed ladder landings.

56.11007 Wooden components of ladders.

56.11008 Restricted clearance.

56.11009 Walkways along conveyors.

56.11010 Stairstep clearance.

56.11011 Use of ladders.

56.11012 Protection for openings around travelways.

56.11013 Conveyor crossovers.

56.11014 Crossing moving conveyors.

56.11016 Snow and ice on walkways and travelways.

56.11017 Inclined fixed ladders.

56.11025 Railed landings, backguards, and other protection for fixed ladders.

56.11026 Protection for inclined fixed ladders.

56.11027 Scaffolds and working platforms.

Subpart K—Electricity

56.12001 Circuit overload protection.

56.12002 Controls and switches.

56.12003 Trailing cable overload protection.

56.12004 Electrical conductors.

56.12005 Protection of power conductors

from mobile equipment. 56.12006 Distribution boxes.

56.12007 Junction box connection procedures.

56.12008 Insulation and fittings for power wires and cables.

56.12010 Isolation or insulation of communication conductors.

56.12011 High-potential electrical conductors.

56.12012 Bare signal wires.

56.12013 Splices and repairs of power cables.

56.12014 Handling energized power cables.

56.12016 Work on electrically-powered equipment.

56.12017 Work on power circuits.

56.12018 Identification of power switches.

56.12019 Access to stationary electrical equipment or switchgear.

56.12020 Protection of persons at switchgear.

56.12021 Danger signs.

56.12022 Authorized persons at major electrical installations.

56.12023 Guarding electrical connections and resistor grids.

56.12025 Grounding circuit enclosures.

56.12026 Grounding transformer and switchgear enclosures.

56.12027 Grounding mobile equipment. 56.12028 Testing grounding systems.

56.12030 Correction of dangerous conditions.

56.12032 Inspection and cover plates.

56.12033 Hand-held electric tools.

56.12034 Guarding around lights. 56.12035 Weatherproof lamp sockets.

56.12036 Fuse removal or replacement.

56.12037 Fuses in high-potential circuits.

56.12038 Attachment of trailing cables.

56.12039 Protection of surplus trailing cables.

56.12040 Installation of operating controls.

56.12041 Design of switches and starting boxes.

56.12042 Track bonding.

56.12045 Overhead powerlines.

56.12047 Guy wires.

56.12048 Communication conductors on power poles.

56.12050 Installation of trolley wires.

56.12053 Circuits powered from trolley wires.

56.12065 Short circuit and lightning protection.

56.12066 Guarding trolley wires and bare powerlines.

56.12067 Installation of transformers.

56.12068 Locking transformer enclosures.

56.12069 Lightning protection for telephone wires and ungrounded conductors.

56.12071 Movement or operation of equipment near high-voltage power lines.

Subpart L—Compressed Air and Boilers

56.13001 General requirements for boilers and pressure vessels.

Pt. 56 30 CFR Ch. I (7-1-06 Edition) 56.14213 Ventilation and shielding for weld-56.13010 Reciprocating-type air compressors. 56.13011 Air receiver tanks. ing. 56.14214 56.13012 Compressor air intakes. Train warnings. 56.13015 Inspection of compressed-air receiv-56.14215 Coupling or uncoupling cars. ers and other unfired pressure vessels. 56.14216 Backpoling. 56.13017 Compressor discharge pipes. 56.14217 Securing parked railcars. 56.13019 Pressure system repairs. 56.14218 Movement of equipment on adja-56.13020 Use of compressed air. cent tracks. 56.13021 High-pressure hose connections. 56.14219 Brakeman signals. 56.13030 Boilers. APPENDIX I TO SUBPART M-NATIONAL CON-SENSUS STANDARDS Subpart M—Machinery and Equipment **Subpart N—Personal Protection** 56.14000 Definitions. First aid materials. 56.15001 SAFETY DEVICES AND MAINTENANCE 56.15002 Hard hats. REQUIREMENTS 56.15003 Protective footwear. 56.14100 Safety defects: examination, cor-56.15004 Eye protection. Safety belts and lines. 56.15005 rection and records. 56.14101 Brakes. 56.15006 Protective equipment and clothing for hazards and irritants. 56.14102 Brakes for rail equipment. 56.15007 Protective equipment or clothing 56.14103 Operators' stations. for welding, cutting, or working with 56.14104 Tire repairs. 56.14105 Procedures during repairs or mainmolten metal. 56.15014 Eye protection when operating tenance grinding wheels. 56.14106 Falling object protection. 56.15020 Life jackets and belts. 56.14107 Moving machine parts 56.14108 Overhead drive belts. Subpart O-Materials Storage and 56.14109 Unguarded conveyors with adjacent travelways. Handling 56.14110 Flying or falling materials. 56.16001 Stacking and storage of materials. 56.14111 Slusher, backlash guards and secur-56.16002 Bins, hoppers, silos, tanks, and surge piles. 56.14112 Construction and maintenance of 56.16003 Storage of hazardous materials. guards. 56.16004 Containers for hazardous materials. 56.14113 Inclined conveyors: backstops or 56.16005 Securing gas cylinders. brakes. 56.16006 Protection of gas cylinder valves. 56.14114 Air valves for pneumatic equip-56.16007 Taglines, hitches, and slings. ment. 56.16009 Suspended loads. 56.14115 Stationary grinding machines. 56.16010 Dropping materials from overhead. 56.14116 Hand-held power tools. 56.16011 Riding hoisted loads or on the hoist 56.14130 Roll-over protective structures hook. (ROPS) and seat belts. 56.16012 Storage of incompatible substances. 56.14131 Seat belts for haulage trucks. 56.16013 Working with molten metal. 56.14132 Horns and back-up alarms. 56.16014 Operator-carrying overhead cranes.

SAFETY PRACTICES AND OPERATIONAL PROCEDURES

56.14200 Warnings prior to starting or moving equipment.

56.14201 Conveyor start-up warnings.

56.14202 Manual cleaning of conveyor pul-

leys.

56.14203 Application of belt dressing.

56.14204 Machinery lubrication.

56.14205 Machinery, equipment, and tools.

56.14206 Securing movable parts.

56.14207 Parking procedures for unattended equipment.

56.14208 Warning devices.

56.14209 Safety procedures for towing.

56.14210 Movement of dippers, buckets, loading booms, or suspended loads.

56.14211 Blocking equipment in a raised position.

56.14212 Chains, ropes, and drive belts.

56.16015 Work or travel on overhead crane bridges.

56.16016 Lift trucks.

Subpart P—Illumination

56.17001 Illumination of surface working

Subpart Q—Safety Programs

56.18002 Examination of working places.

56.18006 New employees.

56.18009 Designation of person in charge.

56.18010 First aid.

56.18012 Emergency telephone numbers.

56.18013 Emergency communications system.

56.18014 Emergency medical assistance and transportation.

56.18020 Working alone.

Subpart R—Personnel Hoisting	56.19069 Entering and leaving conveyances.
56.19000 Application.	56.19070 Closing cage doors or gates. 56.19071 Riding in skips or buckets.
Hoists	56.19072 Skips and cages in same compart-
 56.19001 Rated capacities. 56.19002 Anchoring. 56.19003 Driving mechanism connections. 	ment. 56.19073 Hoisting during shift changes. 56.19074 Riding the bail, rim, bonnet, or crosshead.
56.19004 Brakes. 56.19005 Locking mechanism for clutch. 56.19006 Automatic hoist braking devices. 56.19007 Overtravel and overspeed devices.	 56.19075 Use of open hooks. 56.19076 Maximum speeds for hoisting persons in buckets. 56.19077 Lowering buckets.
56.19008 Friction hoist synchronizing mechanisms.	56.19078 Hoisting buckets from the shaft bottom.
56.19009 Position indicator. 56.19010 Location of hoist controls. 56.19011 Drum flanges. 56.19012 Grooved drums.	 56.19079 Blocking mine cars. 56.19080 Hoisting tools, timbers, and other materials. 56.19081 Conveyances not in use.
56.19013 Diesel- and other fuel-injection- powered hoists.	56.19083 Overtravel backout device.
56.19014 Friction hoist overtravel protection.	SIGNALING 56.19090 Dual signaling systems.
56.19017 Emergency braking for electric hoists.	56.19091 Signaling instructions to hoist operator.
56.19018 Overtravel by-pass switches. WIRE ROPES	56.19092 Signaling from conveyances.56.19093 Standard signal code.
56.19021 Minimum rope strength. 56.19022 Initial measurement.	56.19094 Posting signal code. 56.19095 Location of signal devices. 56.19096 Familiarity with signal code.
56.19023 Examinations. 56.19024 Retirement criteria.	SHAFTS
56.19025 Load end attachments. 56.19026 Drum end attachment.	56.19100 Shaft landing gates. 56.19101 Stopblocks and derail switches.
56.19027 End attachment retermination. 56.19028 End attachment replacement. 56.19030 Safety device attachments.	56.19102 Shaft guides. 56.19103 Dumping facilities and loading pockets.
HEADFRAMES AND SHEAVES	56.19104 Clearance at shaft stations. 56.19105 Landings with more than one shaft
56.19035 Headframe design. 56.19036 Headframe height. 56.19037 Fleet angles.	entrance. 56.19106 Shaft sets. 56.19107 Precautions for work in compart-
56.19038 Platforms around elevated head sheaves.	ment affected by hoisting operation. 56.19108 Posting warning signs during shaft work.
CONVEYANCES 56.19045 Metal bonnets.	56.19109 Shaft inspection and repair. 56.19110 Overhead protection for shaft deepening work.
56.19049 Hoisting persons in buckets. 56.19050 Bucket requirements.	56.191111 Shaft-sinking ladders.
56.19054 Rope guides.	INSPECTION AND MAINTENANCE 56.19120 Procedures for inspection, testing,
HOISTING PROCEDURES 56.19055 Availability of hoist operator for	and maintenance. 56.19121 Recordkeeping.
manual hoists. 56.19056 Availability of hoist operator for automatic hoists.	56.19121 Recordaceping. 56.19122 Replacement parts. 56.19129 Examinations and tests at beginning of shift.
56.19057 Hoist operator's physical fitness. 56.19058 Experienced hoist operators. 56.19061 Maximum hoisting speeds. 56.19062 Maximum acceleration and deceleration.	56.19130 Conveyance shaft test. 56.19131 Hoist conveyance connections. 56.19132 Safety catches. 56.19133 Shaft. 56.19134 Sheaves.
56.19063 Persons allowed in hoist room. 56.19065 Lowering conveyances by the	56.19135 Rollers in inclined shafts.
brakes. 56.19066 Maximum riders in a conveyance.	Subpart S—Miscellaneous
56.19067 Trips during shift changes. 56.19068 Orderly conduct in conveyances.	56.20001 Intoxicating beverages and nar- cotics.

§ 56.1

56.20002 Potable water.
56.20003 Housekeeping.
56.20005 Carbon tetrachloride.
56.20008 Toilet facilities.
56.20009 Tests for explosive dusts.

56.20010 Retaining dams.56.20011 Barricades and warning signs.

56.20013 Waste receptacles.

56.20014 Prohibited areas for food and beverages.

AUTHORITY: 30 U.S.C. 811.

SOURCE: 50 FR 4054, Jan. 29, 1985, unless otherwise noted.

Subpart A—General

§56.1 Purpose and scope.

This part 56 sets forth mandatory safety and health standards for each surface metal or nonmetal mine, including open pit mines, subject to the Federal Mine Safety and Health Act of 1977. The purpose of these standards is the protection of life, the promotion of health and safety, and the prevention of accidents.

§ 56.2 Definitions.

The following definitions apply in this part. In addition definitions contained in any subpart of part 56 apply in that subpart. If inconsistent with the general definitions in this section, the definition in the subpart will apply in that subpart:

American Table of Distances means the current edition of "The American Table of Distances for Storage of Explosives" published by the Institute of Makers of Explosives.

Approved means tested and accepted for a specific purpose by a nationally recognized agency.

Attended means presence of an individual or continuous monitoring to prevent unauthorized entry or access.

Authorized person means a person approved or assigned by mine management to perform a specific type of duty or duties or to be at a specific location or locations in the mine.

Barricaded means obstructed to prevent the passage of persons, vehicles, or flying materials.

Barrier means a material object, or objects that separates, keeps apart, or demarcates in a conspicuous manner such as cones, a warning sign, or tape. Berm means a pile or mound of material along an elevated roadway capable of moderating or limiting the force of a vehicle in order to impede the vehicle's passage over the bank of the roadway.

Blast area means the area in which concussion (shock wave), flying material, or gases from an explosion may cause injury to persons. In determining the blast area, the following factors shall be considered:

- (1) Geology or material to be blasted.
- (2) Blast pattern.
- (3) Burden, depth, diameter, and angle of the holes.
 - (4) Blasting experience of the mine.
- (5) Delay system, powder factor, and pounds per delay.
- (6) Type and amount of explosive material.
 - (7) Type and amount of stemming.

Blast site means the area where explosive material is handled during loading, including the perimeter formed by the loaded blastholes and 50 feet (15.2 meters) in all directions from loaded holes. A minimum distance of 30 feet (9.1 meters) may replace the 50-foot (15.2-meter) requirement if the perimeter of loaded holes is demarcated with a barrier. The 50-foot (15.2-meter) and alternative 30-foot (9.1-meter) requirement also apply in all directions along the full depth of the hole.

Blasting agent means any substance classified as a blasting agent by the Department of Transportation in 49 CFR 173.114(a) (44 FR 31182, May 31, 1979) which is incorporated by reference. This document is available for inspection at each Metal and Nonmetal Safety and Health District Office of the Mine Safety and Health Administration, and may be obtained from the U.S. Government Printing Office, Washington, DC 20402.

Blasting area means the area near the blasting operations in which concussion or flying material can reasonably be expected to cause injury.

Blasting cap means a detonator which is initiated by a safety fuse.

Blasting circuit means the electrical circuit used to fire one or more electric blasting caps.

Blasting switch means a switch used to connect a power source to a blasting circuit.