

- (2) This test must subject each ordnance sample to the qualification environmental test level. For ordnance that is internal to a safe-and-arm device, the test level must be no less than the actual environment that the ordnance experiences when installed and the safe-and-arm device is subjected to its qualification environment.
- (3) A lot will have an initial service-life of five years if it passes this test and all the required tests. A lot will have an initial service-life of one year if it passes all the required tests, but does not undergo this test.
- (4) The same 21 sample components, from the same production lot, must undergo each test designated with an X. For a test designated with a quantity of less than 21, each component sample tested must be one of the original 21 samples.