## § 121.287

## § 121.287 Carriage of cargo in cargo compartments.

When cargo is carried in cargo compartments that are designed to require the physical entry of a crewmember to extinguish any fire that may occur during flight, the cargo must be loaded so as to allow a crewmember to effectively reach all parts of the compartment with the contents of a hand fire extinguisher.

## § 121.289 Landing gear: Aural warning device.

- (a) Except for airplanes that comply with the requirements of §25.729 of this chapter on or after January 6, 1992, each airplane must have a landing gear aural warning device that functions continuously under the following conditions:
- (1) For airplanes with an established approach wing-flap position, whenever the wing flaps are extended beyond the maximum certificated approach climb configuration position in the Airplane Flight Manual and the landing gear is not fully extended and locked.
- (2) For airplanes without an established approach climb wing-flap position, whenever the wing flaps are extended beyond the position at which landing gear extension is normally performed and the landing gear is not fully extended and locked.
- (b) The warning system required by paragraph (a) of this section—
- (1) May not have a manual shutoff;
- (2) Must be in addition to the throttle-actuated device installed under the type certification airworthiness requirements; and
- (3) May utilize any part of the throttle-actuated system including the aural warning device.
- (c) The flap position sensing unit may be installed at any suitable place in the airplane.

[Doc. No. 6258, 29 FR 19202, Dec. 31, 1964, as amended by Amdt. 121–3, 30 FR 3638, Mar. 19, 1965; Amdt. 121–130, 41 FR 47229, Oct. 28, 1976; Amdt. 121–227, 56 FR 63762, Dec. 5, 1991; Amdt. 121–251, 60 FR 65929, Dec. 20, 1995]

## § 121.291 Demonstration of emergency evacuation procedures.

(a) Except as provided in paragraph (a)(1) of this section, each certificate holder must conduct an actual dem-

- onstration of emergency evacuation procedures in accordance with paragraph (a) of appendix D to this part to show that each type and model of airplane with a seating capacity of more than 44 passengers to be used in its passenger-carrying operations allows the evacuation of the full capacity, including crewmembers, in 90 seconds or less.
- (1) An actual demonstration need not be conducted if that airplane type and model has been shown to be in compliance with this paragraph in effect on or after October 24, 1967, or, if during type certification, with §25.803 of this chapter in effect on or after December 1, 1978.
- (2) Any actual demonstration conducted after September 27, 1993, must be in accordance with paragraph (a) of appendix D to this part in effect on or after that date or with §25.803 in effect on or after that date.
- (b) Each certificate holder conducting operations with airplanes with a seating capacity of more than 44 passengers must conduct a partial demonstration of emergency evacuation procedures in accordance with paragraph (c) of this section upon:
- (1) Initial introduction of a type and model of airplane into passenger-carrying operation;
- (2) Changing the number, location, or emergency evacuation duties or procedures of flight attendants who are required by §121.391; or
- (3) Changing the number, location, type of emergency exits, or type of opening mechanism on emergency exits available for evacuation.
- (c) In conducting the partial demonstration required by paragraph (b) of this section, each certificate holder must:
- (1) Demonstrate the effectiveness of its crewmember emergency training and evacuation procedures by conducting a demonstration, not requiring passengers and observed by the Administrator, in which the flight attendants for that type and model of airplane, using that operator's line operating procedures, open 50 percent of the required floor-level emergency exits and 50 percent of the required non-floor-level emergency exits whose opening by a flight attendant is defined as an emergency evacuation duty under