

TABLE 132.220—CARRIAGE OF PORTABLE AND SEMI-PORTABLE FIRE EXTINGUISHERS—Continued

Space	Classification (see § 132.210)	Number and placement
Safety areas: Communicating passageways	A-II	1. In each main passageway, not more than 45.7 meters (150 feet) apart (permissible in stairways).
Pilothouse	C-I	2. In vicinity of exit.
Service spaces: Galleys	B-II or C-11	1. For each 230 square meters (2,500 feet ²) or fraction thereof, suitable for hazards involved.
Paint lockers	B-II	1. Outside space, in vicinity of exit.
Accessible baggage and storerooms	A-II	1. For each 230 square meters (2,500 feet ²) or fraction thereof, located in vicinity of exits, either inside or outside spaces.
Work shops and similar spaces	A-II	1. Outside space in vicinity of exit.
Machinery spaces: Internal-combustion propulsion-machinery.	B-II	1. For each 1,000 brake horsepower, but not fewer than 2 nor more than 6.
Electric propulsion motors or generators of open type.	B-III	1. Required. ⁽¹⁾ , ⁽²⁾
Auxiliary spaces: Internal combustion	C-II	1. For each propulsion motor or generator unit.
Electric motors and emergency generators.	B-II	1. Outside space in vicinity of exit. ⁽²⁾
	C-II	1. Outside space in vicinity of exit. ⁽²⁾

⁽¹⁾ Not required where a fixed gaseous fire-extinguishing system is installed.
⁽²⁾ Not required on vessels of less than 300 gross tons.

(b) Each semiportable fire extinguisher must be mounted or otherwise placed in the open so as to be readily visible.

(c) Except as provided by paragraph (d) of this section, each portable fire extinguisher must be mounted or otherwise placed in the open or behind glass so as to be readily visible.

(d) A portable fire extinguisher may be mounted or otherwise placed in an enclosure together with the fire hose, if the enclosure is marked in compliance with § 131.830 of this subchapter.

(e) Each portable fire extinguisher and its station must be numbered to comply with § 131.835 of this subchapter.

(f) No portable or semiportable fire extinguisher with a nameplate indicating that it needs protection from freezing may be mounted or otherwise placed where freezing temperatures are foreseeable.

§ 132.230 Spare charges.

(a) Except as provided by paragraph (b) or (c) of this section, each vessel must carry spare charges for 50 percent of the portable fire extinguishers required by § 132.220 of this subpart.

(b) Rather than comply with paragraph (a) of this section, a vessel may carry one extra portable extinguisher of the same classification.

(c) If extinguishers of a particular classification cannot be readily re-

charged by crew members, a vessel must—rather than comply with paragraph (a) of this section—carry one more extinguisher of that classification.

(d) Each spare charge must be packaged so as to minimize the hazards to personnel recharging the extinguishers.

§ 132.240 Stowage of semiportable fire extinguishers.

The frame or support of each semiportable fire extinguisher of size III, IV, or V must be secured to prevent the extinguisher from shifting in heavy weather.

Subpart C—Miscellaneous

§ 132.310 Fixed fire-extinguishing systems for paint lockers.

(a) Except as provided by paragraph (b) of this section, a fixed gaseous fire-extinguishing system or another approved fixed fire-extinguishing system must be installed in each paint locker.

(b) No fixed fire-extinguishing system need be installed in a paint locker that is—

(1) Less than 1.7 cubic meters (60 cubic feet) in volume;

(2) Accessible only from the weather deck; and

(3) Not adjacent to a tank for flammable or combustible liquid.

(c) Each fixed fire-extinguishing system installed must comply with part 95