	Pressure Transducer Installation, Removal	No.: SOP-5227	Page 1 of 1
	and Maintenance	Revision: 0	Effective Date: October 29, 2008

ATTACHMENT 2			
SOP-5227-2 Manufacturer Operating Manuals	Records Use Only		

- 1. In Situ Operations Manuals for Pressure Transducers
- 2. MiniTROLL Operator's Manual for MiniTROLL Model SSP-100
- 3. WinSitu 4.0 User's Guide
- 4. Hermit 3000 Data Logger Operator's Manual
- 5. In-Situ Inc. Data Manager Software Operator Manual
- 6. Solinst Level Logger Manual