


# NASA 528 Painting Guide

## Engine Nacelle & Wing Detail Left wing & engine (right side similar)

### Inboard View - Both Engines



Black under engine nacelle starts at engine intake to top of De-icer Boot. Extend aft to flap hinge line. Inboard half only.




De-icer Boot

Paint wing leading edge Black from De-icer Boot to engine nacelle

### Underside View - both sides

Carry black aft to flap hinge line to include inboard gear door



De-icer Boot