Environmental Protection Agency

of the leather product do change, whichever is sooner.

[67 FR 9162, Feb. 27, 2002, as amended at 70 FR 6360, Feb. 7, 2005]

§63.5355 How do I monitor and collect data to demonstrate continuous compliance?

- (a) You must monitor and collect data according to this section.
- (b) You must collect data at all required intervals as specified in your plan for demonstrating compliance as specified at §63.5325.
- (c) For emission control devices, except for monitor malfunctions, associated repairs, and required quality assurance or control activities (including, as applicable, calibration checks and required zero and span adjustments), you must monitor continuously (or collect data at all required intervals) at all times that the affected source is operating.
- (d) You may not use data recorded during monitoring malfunctions, associated repairs, and required quality assurance or control activities in data averages and calculations used to report emission or operating levels, nor may such data be used in fulfilling a minimum data availability requirement, if applicable. You must use all the data collected during all other periods in assessing the compliance ratio, and, if an emission control device is used, in assessing the operation of the control device

§ 63.5360 How do I demonstrate continuous compliance with the emission standards?

- (a) You must demonstrate continuous compliance with the emission standards in §63.5305 by following the requirements in paragraphs (a)(1) and (2) of this section:
- (1) You must collect and monitor data according to the procedures in your plan for demonstrating compliance as specified in §63.5325.
- (2) If you use an emission control device, you must collect the monitoring data according to 40 CFR part 63, subpart SS.
- (3) You must maintain your compliance ratio less than or equal to 1.00, as specified at §63.5330.

- (b) You must report each instance in which you did not meet the emission standards in §63.5305. This includes periods of startup, shutdown, and malfunction. These deviations must be reported according to the requirements in §63.5420(b).
- (c) You must conduct the initial compliance demonstration before the compliance date that is specified for your source in §63.5295.

TESTING AND INITIAL COMPLIANCE REQUIREMENTS

§ 63.5375 When must I conduct a performance test or initial compliance demonstration?

You must conduct performance tests after the installation of any emission control device that reduces HAP emissions and can be used to comply with the HAP emission requirements of this subpart. You must complete your performance tests not later than 60 calendar days before the end of the 12-month period used in the initial compliance determination.

§ 63.5380 How do I conduct performance tests?

- (a) Each performance test must be conducted according to the requirements in §63.7(e) and the procedures of §63.997(e)(1) and (2).
- (b) You may not conduct performance tests during periods of startup, shutdown, or malfunction, as specified in §63.7(e)(1).
- (c) You must conduct three separate test runs for each performance test required in this section, as specified in §63.7(e)(3). Each test run must last at least 1 hour.

§ 63.5385 How do I measure the quantity of finish applied to the leather?

- (a) To determine the amount of finish applied to the leather, you must measure the mass, or density, and volume of each applied finish.
- (b) Determine the mass of each applied finish with a scale calibrated to an accuracy of at least 5 percent of the amount measured. The quantity of all finishes used for finishing operations must be weighed or have a predetermined weight.
- (c) Determine the density and volume of each applied finish according to the