§ 119.445

- (9) Baffle plates, where required in metal tanks, must be of the same material and not less than the minimum thickness required in the tank walls and must be connected to the tank walls by welding or brazing. Limber holes at the bottom and air holes at the top of all baffles must be provided.
- (10) Iron or steel diesel fuel tanks must not be galvanized on the interior. Galvanizing, paint, or other suitable coating must be used to protect the outside of iron and steel diesel fuel tanks.
- (b) Location and installation. Independent fuel tanks must be located and installed in compliance with the requirements of this paragraph.
- (1) Fuel tanks must be located in, or as close as practicable to, machinery spaces.
- (2) Fuel tanks and fittings must be so installed as to permit examination, testing, or removal for cleaning with minimum disturbance to the hull structure.
- (3) Fuel tanks must be adequately supported and braced to prevent movement. The supports and braces must be insulated from contact with the tank surfaces with a nonabrasive and nonabsorbent material.
- (4) All fuel tanks must be electrically bonded to a common ground.
- (c) Tests. Independent fuel tanks must be tested in compliance with the requirements of this part prior to being used to carry fuel.
- (1) Prior to installation, tanks vented to the atmosphere must be hydrostatically tested to, and must withstand, a pressure of 35 kPa (5 psig) or 1.5 times the maximum pressure head to which they may be subjected in service, whichever is greater. A standpipe of 3.5 meters (11.5 feet) in height attached to the tank may be filled with water to accomplish the 35 kPa (5 psig) test. Permanent deformation of the tank will not be cause for rejection unless accompanied by leakage.
- (2) After installation of the fuel tank on a vessel, the complete installation must be tested in the presence of a marine inspector, or an individual specified by the cognizant OCMI, to a head not less than that to which the tank may be subjected in service. Fuel may be used as the testing medium.

(3) All tanks not vented to the atmosphere must be constructed and tested in accordance with §119.330 of this part.

[CGD 85-080, 61 FR 922, Jan. 10, 1996, as amended by USCG 1999-5151, 64 FR 67183, Dec. 1, 1999]

§ 119.445 Fill and sounding pipes for fuel tanks.

- (a) Fill pipes for fuel tanks must be not less than 40 millimeters (1.5 inches) nominal pipe size.
- (b) There must be a means of accurately determining the amount of fuel in each fuel tank either by sounding, through a separate sounding pipe or a fill pipe, or by an installed marine type fuel gauge.
- (c) Where sounding pipes are used, each opening must be at least as high as the opening of the fill pipe and they must be kept closed at all times except during sounding.
- (d) Fill pipes and sounding pipes must be so arranged that overflow of liquid or vapor cannot escape to the inside of the vessel.
- (e) Fill pipes and sounding pipes must run as directly as possible, preferably in a straight line, from the deck connection to the top of the tank. Such pipes must terminate on the weather deck and must be fitted with shutoff valves, watertight deck plates, or screw caps, suitably marked for identification. Diesel fill pipes and sounding pipes may terminate at the top of the tank.
- (f) Where a flexible fill pipe section is necessary, suitable flexible tubing or hose having high resistance to salt water, petroleum oils, heat and vibration, may be used. Such hose must overlap metallic pipe ends at least 1.5 times the pipe diameter and must be secured at each end by clamps. The flexible section must be accessible and as near the upper end of the fill pipe as practicable. When the flexible section is a nonconductor of electricity, the metallic sections of the fill pipe separated thereby must be joined by a conductor for protection against generation of a static charge when filling with fuel.

[CGD 85-080, 61 FR 922, Jan. 10, 1996; 61 FR 20556, May 7, 1996]