


## HOW TO SET UP A AZDEN WIRELESS SYSTEM



1. Remove the hotshoe tab at the top of the camera.

(Wireless receiver)



2. Check and/or replace 9 volt batteries in both the wireless receiver and microphone, then mount the wireless receiver to the hotshoe. (Pictured above)



3. The "EXT MIC" input is located below the hotshoe. Now, plug the wireless receiver into the "EXT MIC" input. Switch on the wireless receiver, and set it to F1. The red light indicates that the wireless microphone is not turned on.



4. Switch on your wireless microphone, and set it to F1. After that, the red light on the wireless receiver will have turned green and the wireless setup is complete.