

- (2) This test must subject each ordnance sample to the qualification environmental test level. For ordnance that is internal to a safe-and-arm device, the test level must be no less than the actual environment that the ordnance experiences when installed and the safe-and-arm device is subjected to its qualification environment.
- (3) For each column, the quantity of sample components required at the top of the column must be from the same production lot and must undergo each test designated with an X. For a test designated with a lesser quantity, each component tested must be one of the original samples for that column.
- (4) Five ordnance samples from the same lot must undergo the tests required by this column to extend the service-life of the remaining ordnance from the same lot for one year.
- (5) Ten ordnance samples from the same lot must undergo the tests required by this column to extend the service-life of the remaining ordnance from the same lot for five years.