

LIGHT VEHICLE PM SERVICE

DAILY SAFETY CHECKLIST

- WALK AROUND VEHICLE
- CHECK FOR BODY DAMAGE
- CHECK TIRE WEAR AND INFLATION
- VIEW UNDER VEHICLE FOR WET SPOTS CAUSED BY A POSSIBLE FLUID LEAK
- CHECK FLUID LEVELS TO INCLUDE ENGINE OIL, COOLANT RESERVOIR LEVEL, AND WINDSHIELD WASHER FLUID LEVEL
- REVIEW AND CHECK THE VEHICLE OWNER'S OPERATION MANUAL FOR DIRECTIONS ON SPECIFIC VEHICLE OPERATIONS AND MAINTENANCE ITEMS

A PM SERVICE CHECKLIST PERFORMED EVERY 5000 MILES OR ONE YEAR

- REPLACE ENGINE OIL AND FILTER
- CHECK/CLEAN BATTERY TERMINALS
- LUBRICATE/GREASE ALL GREASE FITTINGS-INCLUDING ALL U-JOINTS
- CHECK ALL FLUID LEVELS AND FILL AS NECESSARY
 - BATTERY
 - RADIATOR
 - POWER STEERING RESERVOIR
 - WINDSHIELD WASHER
 - MASTER CYLINDER
 - TRANSMISSION
 - TRANSFER CASE
 - DIFFERENTIAL
- CHECK ALL LIGHTS FOR PROPER OPERATION
- CHECK ALL TIRES
- CHECK/REPLACE BELTS
- CHECK AIR FILTER; REPLACE IF NECESSARY
- DIESEL PICKUPS CHANGE FUEL FILTER ANNUALLY (PREFER FALL)

B PM SERVICE CHECKLIST PERFORMED EVERY 10,000 MILES

- PERFORM ALL ITEMS LISTED ON "A" PM CHECKLIST PLUS
- ROTATE TIRES ON ALL LIGHT VEHICLES (UNDER 10-000 LBS. GVWR)

C PM SERVICE CHECKLIST (EXCEPT GROUP 2 SEDANS)

- MINI PASSENGER VANS 40,000 MILES ONLY
- GROUP 3 AND GROUP 7 VEHICLES AT 30,000 AND 60,000 MILES
- GROUP 4 AT 30,000; 60,000 AND 90,000 MILES
- GROUP 9 AND 13 VEHICLES AT 30,000 MILES ONLY
- PERFORM ALL ITEMS INCLUDED IN AN "A" AND "B" PM SERVICE PLUS
- PACK FRONT WHEEL BEARINGS IF APPLICABLE
- DRAIN AND REFILL AUTOMATIC TRANSMISSION FLUID-REPLACE FILTER
- REPLACE FUEL FILTER, IF IN LINE
- (DODGE CHARGER HEMI ENGINE) REPLACE SPARK PLUGS WITH PLATINUM PLUGS AT 30,000 MILES ONLY

D PM SERVICE CHECKLIST PERFORMED EVERY 5000 MILES OR ONE YEAR (ALL HIGHWAY PATROL UNITS)

- REPLACE ENGINE OIL AND FILTER
- CHECK/CLEAN BATTERY TERMINALS
- LUBRICATE/GREASE ALL GREASE FITTINGS-INCLUDING ALL U-JOINTS
- CHECK ALL FLUID LEVELS AND FILL AS NECESSARY
- BATTERY
- RADIATOR
- POWER STEERING RESERVOIR
- WINDSHIELD WASHER
- MASTER CYLINDER
- TRANSMISSION
- TRANSFER CASE
- DIFFERENTIAL
- CHECK ALL LIGHTS FOR PROPER OPERATION
- CHECK ALL TIRES
- CHECK/REPLACE BELTS
- CHECK AIR FILTER, REPLACE IF NECESSARY

E PM SERVICE CHECKLIST (ALL HIGHWAY PATROL UNITS AT 10,000 MILE INTERVALS)

- PERFORM ALL ITEMS LISTED ON "D" PM CHECKLIST PLUS
- ROTATE TIRES, IF NECESSARY

F PM SERVICE CHECKLIST PERFORMED EVERY 2500 MILES OR ONE YEAR (GROUP 12 FACILITY UNITS)

- REPLACE ENGINE OIL AND FILTER
- CHECK/CLEAN BATTERY TERMINALS
- LUBRICATE/GREASE ALL GREASE FITTINGS-INCLUDING ALL U-JOINTS
- CHECK ALL FLUID LEVELS AND FILL AS NECESSARY
- BATTERY
- RADIATOR
- POWER STEERING RESERVOIR
- WINDSHIELD WASHER
- MASTER CYLINDER
- TRANSMISSION
- TRANSFER CASE
- DIFFERENTIAL
- CHECK ALL LIGHTS FOR PROPER OPERATION
- CHECK ALL TIRES
- CHECK/REPLACE BELTS
- CHECK AIR FILTER, REPLACE IF NECESSARY

G PM SERVICE CHECKLIST PERFORMED EVERY 5 YEARS (GROUP 12 FACILITY UNITS)

- DRAIN AND REFILL AUTOMATIC TRANSMISSION FLUID-REPLACE FILTER
- REPLACE ENGINE COOLANT