

SPAWNING GRAVELS

PROFILE VIEW

IMPORTED GRAVEL PLACEMENT FOR SPAWNING
AT GLIDES AND UPSTREAM HEAD OF RIFFLES.

WATER SURFACE

RIFFLE

RUN

POOL

GLIDE

RIFFLE

RUN

POOL

GLIDE

RIFFLE

PLAN VIEW

FLOW 

