



Bend setbacks are based on the angle of deflection of the centerline of the AlVWV channel. The width and length of the setbacks are based on how sharp the turn or bend is. The length of the setback is measured down the channel along the centerline starting at the bend. The width is measured from the near edge of the channel.