

Figure 5. — PDP-CVS Calibration Configuration