

Figure 6. — CFV-CVS Calibration Configuration