

ARCS PROCEDURE:	SWAPPING OUT ULTRA 10's AT MANUS SITE	PRO(ADAM)-047.000
Author: P. McDaniel		23 May 2001 Page 1 of 2

Swapping Out Ultra 10's at Manus Site

I. Purpose:

The purpose of this procedure is to provide instruction on how to swap out the Ultra 10's at Manus ARCS-1.

II. Cautions and Hazards:

None.

III. Requirements:

None.

IV. Procedure:

A. Steps:

1. Power off ADaM and disconnect the main power cable from the back of the ADaM/Artecon Case.
2. Disconnect the RJ45 network connection on the back of the ADaM/Artecon Case.
3. Disconnect the monitor plug on the back of the Ultra 10 in the ADaM/Artecon Case.
4. Disconnect the keyboard cable from the front of the ADaM/Artecon Case.
5. Remove the front panel screws that are holding the ADaM/Artecon Case in the rack
6. Slide the Artecon Case that holds ADaM1 out of the Rack far enough to where you can get to the remaining cables on the back of the unit.. You should be able to leave everything sitting on the slides and not have to remove the ADaM/Artecon assembly from the slides.
7. Disconnect the remaining cables from the back of the Ultra 10 making note of where they were plugged in so that you can re-plug them into the new Ultra 10
8. Removing two screws from the top-sides of the Artecon case.
9. Removing the top cover.
10. Swap out the ADaM1 Ultra 10 with the replacement Ultra 10
11. Reverse the Previous Steps.

ARCS PROCEDURE:	SWAPPING OUT ULTRA 10's AT MANUS SITE	PRO(ADAM)-047.000 23 May 2001 Page 2 of 2
Author: P. McDaniel		

V. References:

None.

VI. Attachments:

None.