

ARCS PROCEDURE:	OPERATIONS WITHOUT A MONITOR	PRO(BBSS)-014.000
Author: D. Morrison		October 20, 2000 Page 1 of 2

Operations Without a Monitor

I. Purpose:

This procedure provides a sequence of keystrokes that can be used to run the BBSS program when the BBSS laptop monitor screen is out.

II. Cautions and Hazards:

None

III. Requirements:

None

IV. Procedure:

A. Steps:

1. Reboot the computer each time you start.
 - a. While holding down the CTRL key, press the ESC key (this is like pressing the START button).
 - b. Press the UP ARROW once.
 - c. Press ENTER.
 - d. While holding down the ALT key, press the R key.
 - e. Press ENTER (this allows you to restart the computer).
 - f. Wait until the hard disk light stops flashing before continuing. This is to make sure the computer is fully booted.
2. Run the Balloon Launch program.
 - a. While holding down the CTRL key, press the ESC key.
 - b. Press the UP ARROW three times, and press ENTER.
 - c. Type C:\windows\desktop\launch balloon.pif
 - d. Press ENTER (this will run the program).
 - e. Wait 5 seconds to make sure the program is started.
 - f. Press ENTER (this is the first part of the program where it asks if the data is ok).
 - g. After the launch is over, don't forget to press the ESC key, and press Y to close the program. It may be difficult to tell when the launch is over since the laptop screen is not working. You will

ARCS PROCEDURE: Author: D. Morrison	OPERATIONS WITHOUT A MONITOR	PRO(BBSS)-014.000 October 20, 2000 Page 2 of 2
---	---	---

have to go by the Digi-Cora display to tell when the launch is over.

- If the binary file count goes up in the health and status after each launch, it means it is working.

V. References:

None.

VI. Attachments:

None.