

ARCS PROCEDURE	CLEANING IRT GOLD MIRROR	PRO(IRT)-008.000
Author: C. Long		26 November 2002 Page 1 of 1

Cleaning IRT Gold Mirror

I. Purpose:

This document describes the procedure for cleaning the IRT gold mirrors. The cleaning should take place daily as part of Daily Rounds activities.

II. Cautions and Hazards:

- DO NOT wipe the mirrors.
- Use bottled, tap, or A/C unit condensate water to cleaning the mirrors.

III. Requirements:

- None.

IV. Procedure:

A. Cleaning IRT Gold Mirrors

1. Dowse the gold mirror with a generous amount of water.
2. Wait for 1 minute.
3. Repeat steps 1 and 2 twice (total of three times), or until the mirror is free of dust or dirty spots.
4. Total amount of water used for three dowsing processes should be about 12 to 16 Oz, or 1/3 to 1/2 liter.
5. Let the mirror air-dry; DO NOT wipe it.

V. References:

1. IRT Replacement, PRO(IRT)-003.

VI. Attachments:

None.