

The RESET Site Conditions Report is intended to record the site conditions upon arrival of the RESET team, giving us a chance to monitor what has happened at the site since the last RESET visit. It is a way to capture your general observations on how the site is holding up and how it is being taken care of. It could be carried out like a daily round, checking everything that the observers would check.

1. Check the vans and site in general, are they clean?
2. Check the domes and windows of the instruments, are they clean and not damaged?
3. Check whether the instruments are level.
4. Check the desiccant in those instruments that use them.
5. Check the condition of cables and connections.
6. Check the storage of spares and supplies.

Item	Notes
Cleaning tapes	Had nine in tape containers, eight boxes in bookcase, shipped another ten boxes.
Sky cam	OFF
TV/VCR	Appears broken.
HVAC	D-Van AC screens on side very rusty on both units; same for E-Van and I-Van.
Dataloggers	No baskets over them.
GNDRAD	PIR: needs desiccant change.
GNDRAD	PSP: needs more cleaning after a wasps nest was cleared away.
GNDRAD	NET: cloudy, has condensation in it.
SKYRAD	IRT: lens has water spots, white flakes and generally looks bad; shutter cover shows signs of rust.
SKYRAD	Ventilator on Brusag PIR seems nonfunctional.
SKYRAD	PSP: desiccant is purple.
SMET	Need to change desiccant on logger barometer.
MWR	Fan is ON, but the heater light was not lit.
Vans	Dark due to burned out light bulbs.
Security shed	Has no roof.
Balloon barn	Helium tanks are not secured to the wall.