

Pavement Preservation

Checklist Series

12

Cold In-Place

Asphalt Recycling

Application Checklist



U.S. Department
of Transportation
Federal Highway
Administration



CIR Application Checklist

This checklist is one of a series created to guide State and local highway maintenance and inspection staff in the use of innovative pavement preservation processes. The series is provided through the joint efforts of the Pavement Preservation Program of the Federal Highway Administration (FHWA), the Foundation for Pavement Preservation (FP²) and the Asphalt Recycling & Reclaiming Association (ARRA).

FHWA uses its partnerships with FP², ARRA, the American Association of State Highway and Transportation Officials, and State and local transportation agencies to promote pavement preservation.

To obtain other checklists or to find out more about pavement preservation, contact the FP² (www.fp2.org), National Center for Pavement Preservation (NCP) (www.pavementpreservation.org), ARRA (www.arra.org) or the FHWA website at www.fhwa.dot.gov/pavement.

Quality Assurance Notice

The Federal Highway Administration provides high-quality information to serve Government, industry, and the public in a manner that promotes public understanding. Standards and policies are used to ensure and maximize the quality, objectivity, utility, and integrity of its information. FHWA periodically reviews quality issues and adjusts its programs and processes to ensure continuous quality improvement.

Preliminary Responsibilities

This section includes documents and information that should be available prior to any construction activities.

Document Review

- Project specifications
- Mix design
- Structural Pavement Design
- Construction manual
- Traffic control plan
- Owner/Agency requirements
- Additive manufacturers' instructions
- Safety Data Sheets (SDSs)
- Health and Safety Plan and Job Hazard Analysis

Project Review

- Note the types and causes of existing pavement distresses.
- Identify if there are any weak or unstable mixes in the existing cross section or weak subgrades.
- Verify that previous testing has not detected the presence of weak areas underlying the pavement, confirming that pavement failures do not result from base or subgrade failure.

- Visually examine the current surface and subsurface drainage conditions and confirm they are sufficient to prevent surface deterioration and softening of the subgrade and will enable long-term performance of the pavement after cold in-place recycling (CIR) treatment.
- Verify that both center and edge pavement cores have been obtained at various locations along the length of the project, and use cores to confirm the thickness of the bituminous layer.
- Verify from the cores that there is sufficient thickness of the bituminous material in place to perform the CIR process.
- Verify that existing appurtenant structures, e.g., guardrails, curbs, and bridge clearances, do not impose limitations on potential variations of the existing pavement geometry.
- Determine whether paving fabric is present within any of the layers to be recycled and if it could affect construction operations.
- Verify that the project is a good candidate for CIR based on the preliminary project review.

Materials Checks

- A sufficient number of cores/samples are obtained for mix design.
- Samples are evaluated for consistency over the length of the project.
- The recycling agent is compatible with the materials and processes.
The recycling agent may be:
 - Emulsified asphalt
 - Foamed (expanded) asphalt
- Recycling additives can be added in small amounts to improve mix properties, if indicated by the mix design. Recycling additives may be lime, hydraulic cement or new aggregates.

Preconstruction Inspection Responsibilities

This section identifies activities that should be performed before proceeding with construction activities.

Preconstruction Meeting

- Ensure that all necessary contractor and agency personnel attend the preconstruction meeting.

Surface Preparation

- Ensure that structural pavement distresses have been addressed.
- Identify and correct any subsurface drainage problems.
- Ensure that pre-milling, if required, was performed satisfactorily.

Equipment Inspections

This section identifies equipment inspections. For CIR processing either a multi-unit train or a single unit train can be used.

Multi-Unit Trains

Milling Machine

- Verify that the milling drum is the correct width.
- Verify that the milling machine has sufficient weight and horsepower to cut to the depth and tolerances

specified in the contract documents.

- Verify that the cutting teeth are all in place and in adequate condition.
- Verify that the spray bar and nozzles are working properly and not clogged.

Screening and Crushing Units

- Verify that the opening size of the screen deck meets the specifications/contract documents and is in good working condition.
- Verify that all oversize material will be routed through the crusher and re-screened.
- Verify that the crushing unit is working properly.

Pugmill

- Verify that all paddles within the pugmill are present and in good condition.
- Verify that the clearance between the paddles and the wall of the pugmill does not exceed that specified in the contract documents.
- Verify that the pugmill wall is not greatly worn and does not have holes.
- Verify that the spray bars and recycling agent supply lines are not clogged.

Recycling Agent and Additive Systems (Water, Foamed Asphalt/Emulsified Asphalt, Other)

- Verify that the mixing unit is properly calibrated and is capable of accurately dispensing the required quantity of recycling agent and additives, if required.
- Verify that the on-board recycling agent/additive system is equipped with a meter capable of recording the rate of flow and total amount of each liquid being added to the recycled material.
- Verify that the on-board foam generating system includes a foamed asphalt sampling valve when foamed asphalt is being used as the recycling agent.
- Verify that the on-board recycling agent system has a positive interlock system linked to the forward speed of the train so that the amount of liquid recycling agent being added will change according to the operational speed of the train.
- Verify that the correct amount of water is being added to achieve a homogenous mixture and achieve specified percent compaction.

Single-Unit Trains

- Verify that the cutting drum is the correct width.
- Verify that the single-unit train has sufficient weight and horsepower to cut to the depth and tolerances specified within the contract documents.
- Verify that the cutting teeth are all in place and in adequate condition.
- Verify that the spray bar and nozzles are working properly and not clogged.
- Verify that the on-board recycling agent system is equipped with a meter capable of recording the rate of flow and total amount of each liquid being added to the recycled material.
- Verify that the single-unit train is equipped with an on-board foam generating system including a foamed asphalt sampling valve when foamed asphalt is being used as the recycling agent.
- Verify that the on-board recycling agent system has a positive interlock system linked to the forward speed of the single-unit train so that the amount of liquid recycling agent being added will change according to the operational speed of the train.
- Verify that the correct amount of water is being added to achieve a homogenous mixture and achieve specified percent compaction.

All Trains

Nurse Trucks

- Verify that the interior of the nurse tank is not contaminated and that the trailer is dedicated to transporting only the specific material used.
- Verify that the flexible hose used to convey material from the nurse trailer to the pugmill/recycling unit is clean and not contaminated.

Paver and Pickup Machine

- Verify that the paver and pickup machine, if required, have adequate horsepower.
- Verify that the paver hopper is adequately sized for the project to prevent material spillover.
- Verify that the automatic grade and cross-slope controls are functioning properly.

Compaction Rollers

- Verify that the rollers proposed for use by the contractor are in accordance with those specified in the contract documents. Typically, at least one pneumatic-tired roller and one vibratory, double-steel drum roller are required.
- Verify that the rollers proposed for use by the contractor meet the size, width, and weight requirements of the contract documents.

- Verify that the number of rollers used is consistent with the rate of material being processed and placed.
- Verify that the tire pressures on pneumatic-tired rollers are consistent with the tire pressures specified in the contract documents.
- Verify that working water systems are installed on all rollers as required by the contract documents.
- Verify that working scrapers are in place on all rollers as required by the contract documents.

Weather Requirements

- Verify that the ambient air temperature (in the shade) meets contract specification requirements, typically a minimum of 50 °F (10 °C).
- Consider that variations in temperature, humidity, and wind conditions will all affect breaking and curing times..
- Verify that no significant precipitation is predicted during construction operations, in accordance with contract specifications.

Mix Design

- Verify that a mix design has been performed and that the resulting mixture meets the specifications in the contract documents.

- Verify that any special instructions included with the mix design are incorporated into the contractor's preparations for construction operations.
- Verify that the contractor has submitted the final mix design for review and acceptance prior to initiation of construction operations.

Traffic Control

- Verify that the traffic control plan complies with the contract documents and the Manual on Uniform Traffic Control Devices (Federal Highway Administration, 2009).
- Verify that signs and devices erected on the roadway match the traffic control plan contained in the contract documents.
- Ensure that flaggers do not hold traffic for extended periods of time.
- Ensure that flaggers do not hold traffic stopped on freshly treated material.
- Ensure that signs are removed or covered when they no longer apply.
- Ensure that an appropriate action plan is developed and implemented for emergency vehicles passing through the project.
- Ensure that any unsafe conditions are reported to a supervisor or the appropriate law enforcement officials.

Project Inspection Responsibilities

This section identifies activities that should be performed during the construction process.

Milling, Crushing, and Mixing

- Ensure that all grass and soil are removed from the pavement surface, especially along the edges of the pavement, prior to recycling.
- Ensure that the depth and width being milled are in accordance with contract documents.
- Verify that the width of milling overlaps with the previous pass by a margin of at least 4 inches (100 mm).
- Verify that the maximum size of the RAP is less than or equal to the maximum permitted by the mix design, typically, 1.0 to 1.5 inches (25 to 38 mm).
- Verify that paving fabric incorporated into the recycled mix has a maximum dimension as per contract documents. Typically, maximum dimension is not greater than 2 inches (50 mm). Obvious oversized material should be removed from the recycled mixture.

Pickup Machine and Paver

- When processed material is being windrowed, ensure that the pickup machine is the correct distance behind the pugmill. (Note: Contract documents may specify a maximum separation, either in units of distance or time.)
- Ensure the screed on the paver is not heated.
- Ensure that the paving machine places processed material to grade and slope or crown in accordance with contract documents.
- Ensure that both the transverse and longitudinal joints are constructed in accordance with contract documents.
- Ensure that a continuous flow of material is deposited into the paver hopper. Material should not overfill the hopper and spill over the sidewalls, nor should the hopper be under filled such that the drag slats in the bottom of the hopper are exposed.

Rolling Procedure

- Develop a rolling pattern at the beginning of construction so that the number of passes required using the specified rollers will result in the maximum achievable density (using a nuclear density gauge) in accordance with contract documents.
- Ensure that there is no damage from potential over rolling.

- Communicate daily with the roller operators to review the developed rolling pattern.
- Ensure that compaction tests are performed, as required by the contract documents and that the test results meet the specification requirements.
- Ensure that stops, starts, and turns are gradual.
- Ensure that finish rolling is completed within the time specified in the contract documents.
- Ensure that water is lightly sprayed onto the roller drums and tires to prevent pickup. Under no circumstances should diesel or other solvents be used to prevent pickup.
- If a wetting agent is utilized, verify compatibility with the recycling agent.

Quality Assurance

- Verify that recycling agent, water, and additives are added at the rates specified by the mix design in accordance with contract documents.
- Visually inspect the mixture for uniformity and homogeneity as it is discharged, whether onto the pavement and windrowed or directly into the paver hopper.
- Obtain samples of the mixture and component recycling agents and

additives in accordance with the quality assurance requirements of the contract documents.

- Verify that the mixture and component recycling agents and additives comply with the requirements of the contract documents.

Opening to Traffic

- Ensure that the material in the recently completed mat meets the requirements for compaction density and length of initial cure time as presented in the contract documents.
- Apply a fog seal, typically 0.05 to 0.15 lbs. /yd², to minimize raveling prior to opening to traffic, as required by the contract documents. Apply blotter, sand uniformly, typically 2 to 3 lbs. / yd² to absorb excess fog seal and to prevent pick-up by traffic. Take extra care to not over sand the pavement surface.
- Ensure that temporary pavement markings required by the contract documents are in place prior to opening the surface to traffic.

Curing

- Allow the completed CIR mat to cure as per contract documents for emulsified asphalt.

- Perform secondary compaction to remove minor consolidation in the wheel paths, when required by the contract documents, at the end of the curing period and prior to placing the surface course.

Surface Course

- After curing and secondary compaction, when required, apply a surface course (seal coat or HMA overlay) as specified by the contract documents.
- Apply a tack coat for an HMA overlay in accordance with the contract requirements to promote a good bond between the CIR layer and the surface course.

Common Problems and Solutions

(Problem: Solution)

- **Base Layer Aggregate or Subgrade Soils in the CIR:**
 1. Inspect milling depth.
 2. Ensure sufficient bituminous layer thickness.
- **Oversize material or chunks in the recycled mat:**

1. Check the screen deck for correct size or holes (multi-unit train).
2. Check for chunks in the pugmill: ensure paddle clearance; remove chunks before compaction.
3. Check forward speed of the CIR machine and breaker bar (single-unit train)

- **Nonhomogeneous mixture:**

1. Check for sufficient moisture content.
2. Check for sufficient recycling agent.
3. Check recycling agent temperature for extremes.
4. Check correct operation of the pugmill/mixing chamber.

- **Segregation:**

1. Inspect the top size versus the depth being placed.
2. If the wings of the hopper are being used, make sure segregated material is not being introduced in this way.
3. Identify systematic segregation areas and make corrections, such as around a gear box.
4. If the screed is extended, look for segregation in the extensions.

- **Drag marks in uncompacted mixture:**

1. Ensure that the screed is clean.

2. Ensure that the screed is unheated.

- **Insufficient compaction:**

1. Ensure rolling is started at the correct time.
2. Ensure roller patterns have been adequately established, are understood, and are being followed.
3. Ensure the correct type, number, and size of the rollers are being used.
4. Ensure the rollers are not moving too fast.
5. Re-establish the rolling pattern as necessary

- **Raveling:**

1. Ensure the water system is working on the rollers.
2. Check if traffic may be on the compacted CIR too soon.
3. Check for sufficient recycling agent content.
4. Ensure ambient conditions are not too cool.

- **Flushing:**

1. Ensure there is not too much pre-wet water or recycling agent being added (total fluids).

Acknowledgements

We would like to thank Lee Gallivan of FHWA for his feedback and support in revising and publishing this pocket guide.

Sources

Information in this checklist is based on or refers to the following sources:

- Basic Asphalt Recycling Manual, Second Edition, 2014.* Annapolis, MD: Asphalt Recycling & Reclaiming Association. Available at www.arr.org.
- Manual on Uniform Traffic Control Devices.* 2009. Washington, DC: Federal Highway Administration. Available at <http://mutcd.fhwa.dot.gov>.

For more information on the Pavement Preservation Checklist Series, contact:

Federal Highway Administration, HIAP-1
Office of Asset Management, Pavement and Construction, Room E75-340
1200 New Jersey Ave, SE
Washington, DC 20590
www.fhwa.dot.gov/pavement

National Center for Pavement Preservation
Michigan State University
2857 Jolly Road
Okemos, MI 48864
E-mail: ncpp@egr.msu.edu
Telephone: 517-432-8220
www.pavementpreservation.org/

FP2, Inc.
8100 West Court
Austin, TX 78754
E-mail: jimmoulthrop@gmail.com
Telephone: 512-977-1854
www.fp2.org

Asphalt Recycling & Reclaiming Association
#3 Church Circle – PMB 250
Annapolis, Maryland 21401
Telephone: 410-267-0023
Fax: 410-267-7546
E-mail krissoff@arra.org; www.arra.org/

Publication No. FHWA-HIF-13-062

