# NATURAL RESOURCES CONSERVATION SERVICE CONSERVATION PRACTICE STANDARD

# PRECISION LAND FORMING

(Ac.)

## **CODE 462**

#### **DEFINITION**

Precision Land Forming is reshaping the surface of land to planned grades.

#### **PURPOSE**

This practice improves surface drainage and controls erosion.

## **CONDITIONS WHERE PRACTICE APPLIES**

This practice applies to all land where soils will be of sufficient depth and of suitable textures so that after completing precision land forming, an adequate root zone remains to permit the planned use of the land and the application of proper conservation measures, soil amendments, and fertilizer.

This standard does not apply to areas needing Conservation Practice Land Smoothing (466) or Conservation Practice Irrigation Land Leveling (464).

#### **CRITERIA**

Plan all precision land forming as an integral part of an overall system to facilitate the conservative use of soil and water resources.

Design and installation must be based on adequate engineering surveys and investigations. If the land is to be formed for more than one purpose, it must be formed to meet the requirements of the most restrictive purpose or crop.

All forming work must be designed within the slope limits required for the proposed use and provide for the removal of excess surface water. If other conservation practices such as

grassed waterways, surface field ditches, and filter strips are needed to accomplish the stated

purpose, they must be included in the plans for improvement.

**Slope Requirements.** Slope may be uniform in the direction of flow or may increase or decrease.

Reverse grades in the direction of planned water flow must not be permitted. Short level sections are permissible to meet field conditions. Depending on cultural practices, cross slopes must be such that water can be contained within the furrows to prevent breakthroughs from rainfall runoff.

Slope to Control Erosion Caused by Runoff from Rainfall. Design field grades must be such that erosion caused by runoff from rainfall can be controlled within the limits permissible for conservation farming. When benching between land-formed plots exceeds 1 foot, a permanent grassed area or border ridge must be left between the plots to reduce the possibility of gully erosion.

**Surface Drainage.** All precision land-forming systems must include plans for removing or otherwise providing for control of excess water.

Designs must provide field elevations and field grades that will permit proper functioning of the planned drainage facilities.

Borrow Computations. Excavation and fill material required for or obtained from such structures as ditches, ditch pads, and roadways must be considered part of the precision landforming design, and the appropriate yardage must be included when balancing cuts and fills and determining borrow requirements.

NRCS, NHCP September 2014

# **CONSIDERATIONS**

Effects on the water budget, especially on volumes and rates of runoff, infiltration, deep percolation, and evaporation should be considered.

Short-term and construction effects of installation on downstream water resources should be minimized.

Potential for earth moving to uncover or redistribute toxic materials, such as saline soils, and make them available to water or plants should be addressed.

Consider effects on wetland hydrology and/or wetland wildlife habitat.

Address potential impacts to existing utilities by relocating and avoiding all utilities.

Consider effects on soil loss due to increased wind erosion potential and subsequent deposition.

#### PLANS AND SPECIFICATIONS

Plans and specifications for land smoothing must be in keeping with this standard and must describe the requirements for applying the practice to achieve its intended purpose. Plans and specifications must include construction plans, drawings, job sheets or other similar documents. These documents must specify the requirements for installing the practice.

## **OPERATION AND MAINTENANCE**

An Operation and Maintenance (O&M) plan must be prepared for and reviewed with the landowner or operator. Actions must be carried out to insure that this practice functions as intended. Such action must include performing maintenance when needed to insure that surface irregularities are maintained at the degree of smoothness required. The plan must specify that the treated areas and associated practices be inspected annually and after significant storm events to identify repair and maintenance needs.

## **REFERENCES**

- U.S. Department of Agriculture, Natural Resources Conservation Service, Engineering Field Handbook, Chapter 1. Surveying. National Engineering Handbook, Part 650.01, Washington, DC.
- U.S. Department of Agriculture, Natural Resources Conservation Service, Engineering Field Handbook, Chapter 4. Elementary Soils Engineering. National Engineering Handbook, Part 650.04, Washington, DC.
- U.S. Department of Agriculture, Natural Resources Conservation Service, Irrigation Land Leveling. Section 15, Chapter 12. National Engineering Handbook, Part 623.12. Washington, DC.
- U.S. Department of Agriculture, Natural Resources Conservation Service, Engineering Field Handbook, Chapter 14. Water Management (Drainage). National Engineering Handbook, Part 650.14, Washington, DC.