

LECTURE #6


CHANNEL ROUTING IN HSPF



LEARNING OBJECTIVES

- Develop a familiarity with **organization and linkages** in HSPF related to RCHRES
- Learn the **key processes** simulated and parameters used in flow routing simulation in HSPF


RCHRES STRUCTURE CHART



STREAM HYDRAULICS (HYDR)


- **Assumptions**
 - Completely mixed reach (single layer)
 - Unidirectional flow
 - Flow routing by kinematic wave or storage-routing method (i.e., conservation of momentum not considered)
- **Requires function table (FTable) for depth-volume-discharge relationship for each reach.**
- **Precipitation/evaporation accommodated**
- **Calculates outflow, depth, volume, surface area, and selected auxiliary variables (velocity, cross-sectional area, bed shear velocity/stress)**

FLOW AND CONSTITUENT SOURCES OUTFLOW/GATES




- Inflows:**
 - Tributaries
 - Point sources
 - Nonpoint source
- Spillways**
- Withdrawal**

FLOW DIAGRAM FOR HYDR SECTION OF RCHRES



CHANNEL GEOMETRY



FTABLES

VARIABLE

DEFINITION

NROWS

Number of rows in the FTABLE. There must be at least one row in the table.

NCOL

Number of columns in the FTABLE. NCOLS must be between 3 and 8. NROWS*NCOLS must not exceed 100.

DEPTH

Depth of reach (m or ft). The depth must not decrease as the row number increases.

SURFACE AREA

Surface area of the reach (ha or acres).

VOLUME

Volume of reach (Mm³ or acre-feet). The volume must not decrease as the row number increases.

DISCHARGE

Discharge from reach (m³/sec or ft³/sec). There may be up to five discharge columns.

EXAMPLE

```
FTABLE      103
ROWS COLS ***
  3     5
  DEPTH      AREA      VOLUME  outflow1  outflow2 ***
  (FT)      (ACRES)    (AC-FT)   (CFS)     (CFS) ***
    0.0         0.0         0.0        0.0        0.0
    5.0        10.0        25.0       20.5       10.2
   20.0       120.0       1000.0     995.0      200.1
END FTABLE 103
```


FLOW ROUTING EQUATIONS I

CONTINUITY

$$VOLE = VOLS + \text{sum IVOL} - \text{sum OVOL} + PR - EVAP$$

VOLE = volume at end of time step


VOLS = volume at start of time step

OVOL = outflow volumes

IVOL = inflow volumes

PR = volume of precipitation

EVAP = volume of evaporation



$$\text{let } OVOL = \Delta t (KS * OS + (1.0 - KS) * OE)$$

KS = weighting factor (0.0 - 0.5)

OS = outflow at start of time step

OE = outflow at end of time step

unknown

unknown

$$\text{then } VOLE = (VOLS + \text{sum IVOL} + PR - EVAP) - \Delta t \{KS * OS + (1 - KS) * OE\}$$

OUTFLOW FROM REACHES

- User needs to specify each outflow as one of the following:
 - Case 1. Outflow = $f(\text{storage volume})$
 - *Open channels and unregulated reservoirs*
 - Case 2. Outflow = $f(\text{time})$
 - *Reservoir withdrawal for irrigation or water supply, and wastewater discharge*
 - Case 3. Outflow = $f(\text{storage volume, time})$
 - *Both unregulated outflow and a withdrawal*

OUTFLOW FROM REACHES (CONT.)

- **Case 4.** Outflow = Min[f(storage volume,time)]
 - *Irrigation demand is a function of time (season), but pump capacity is limited by water level*
- **Case 5.** Outflow = Max[f(storage volume,time)]
 - *If the reservoir level is high, emergency spillway used, else seasonal release schedule for low flow*

FLOW ROUTING EQUATIONS II

OUTFLOW DEMANDS

$$OE = f(VOLE)$$

open channels and unregulated reservoirs
use rating table or table (FTABLE in HSPF)

$$OE = f(\text{time})$$

diversions into or out of a channel or reservoir
such reservoir withdrawal for irrigation or waste water
treatment plant discharge (time series on WDM file)

$$OE = f(VOLE) + f(\text{time})$$

both unregulated outflow and a diversion

$$OE = \text{MIN} [f(VOLE), f(\text{time})]$$

irrigation demand is a function of time(season),
but pump capacity limited by water level

$$OE = \text{MAX} [f(VOLE), f(\text{time})]$$

if reservoir level is high, emergency spillway used,
else seasonal release schedule for low flow

DISCHARGE OPTION

ODFVFG - volume component (each exit)

- 0 - exit is not f(vol)
- > 0 - use column in FTABLE
- < 0 - absolute value is column in COLIND array
(which is read from time-series data set)

ODGTFG - time component (each exit)

- 0 - exit is not f(time)
- > 0 - column in OUTDGT array
(which is read from time-series data set)

FUNCT - combination rule (each exit)

- 1 - $\min(f(\text{vol}), f(\text{time}))$
- 2 - $\max(f(\text{vol}), f(\text{time}))$
- 3 - $f(\text{vol}) + f(\text{time})$

DISCHARGE EXAMPLES

```

HYDR-PARM1
#      # VC A1 A2 A3 ODFVFG      ODGTFG      FUNCT
      FG FG FG FG   1 2      1 2      1 2
1      0 1      4      0
2      0 1      -1     0
3      0 1      4 5     1      1
END HYDR-PARM1
    
```

Reach 1 - Simple stream reach with constant stage-discharge relationship

```

FTABLE 1
Depth      Area      Volume      Disch1      Disch2 ***
(ft)      (acres)    (ac-ft)    (cfs)      (cfs) ***
0.0       0.0         0.0        0.0        0.0
3.0       1.0         2.0        5.0        3.0
10.0      10.0        50.0       25.0       18.0
END FTABLE 1
    
```

No time series required.

Reach 2 - Stream reach with seasonally variable stage-discharge relationship

Same FTABLE as above.

COLIND(1) specifies discharge column(s)
 For example: 4.0 4.1 4.2 4.5 5.0 4.9 4.8 4.6 ...


Reach 3 - Reservoir with gate and spillway

```

FTABLE 3
Depth      Area      Volume      Disch1      Disch2 ***
(ft)      (acres)    (ac-ft)    (cfs)      (cfs) ***
0.0       0.0         0.0        0.0        0.0
20.0      50.0        500.0      100.0       0.0
40.0      500.0       7000.0     300.0       10.0
50.0      900.0       12000.0    350.0       200.0
END FTABLE 3
    
```

OUTDGT(1) specifies the outflow demand
 For example: 75.0 80.0 100.0 120.0 90.0 85.0 ...

WinHSPF FTABLE GENERATION



Import From Cross-Section

Cross-Section Files

Open 1 Save

FTABLE 25

Variable	Description	Value
L	Length (ft)	1
Ym	Mean Depth (ft)	3.5
W/m	Mean Width (ft)	42.5
n	Mannings Roughness Coefficient	0.02
S	Longitudinal Slope	0.0007
m32	Side Slope of Upper Flood Plain Left	0.4
m22	Side Slope of Lower Flood Plain Left	0.4
W12	Zero Slope Flood Plain Width Left (ft)	0.01
m12	Side Slope of Channel Left	0.4
m11	Side Slope of Channel Right	0.4
W11	Zero Slope Flood Plain Width Right (ft)	0.01
m21	Side Slope Lower Flood Plain Right	0.4
m31	Side Slope Upper Flood Plain Right	0.4
Yc	Channel Depth (ft)	5
Y11	Flood Side Slope Change at Depth (ft)	15
Y12	Maximum Depth (ft)	16

OK Cancel Help

CREATING FTABLES FOR RESERVOIRS BASINS TECHNICAL NOTE 1

- Obtain data tables or graphs describing the depth-area and depth-volume relationships from reservoir management agency
- Alternatively, create a bathymetric map of the lake
 - Determine surface area at different depths from planimetry
 - Calculate volume of lake at given depths
- Obtain reservoir release data from reservoir management agency or USGS gage data

BATHYMETRY WITHIN GIS

Incrementally increase Stage and
calculate Surface Area and Volume

Calculate Q using
appropriate Weir
Equation

Spillway

