

Intersection of Runway 17-35 and Taxiways
Brayo and Charlie



Taxiway Alpha Adjacent to the Military Ramp



Runway 17-35, Runway 4-22

Airport Operations: (913) 782-5335 Air Traffic Control: (913) 782-9216 Hours of Operation: Airport - 24 hours

Tower - 0600-2200 local

Latitude: 38 degrees 49' 86" Longitude: 94 degrees 53' 42"

Elevation: 1087 ft

Variation: 4.5 E degrees

From City: Southwest, Olathe 4 miles

Sectional Chart: Kansas City

Control Tower: Yes

ARTCC: Kansas City Center

FSS: Columbia. 1-800-992-7433

NOTAM Facility: Columbia FSS

Wind Indicator: Yes
Beacon: Yes
Fire and Rescue: Yes
Airline Operations: No
Customs: No
UNICOM 122.95
CTAF 133.0
ATIS N/A

IXD Ground: 124.3 IXD Tower 133.0 Clearance Delivery: 124.3 Approach Control: 118.9 ASOS: 135.325 VOR (@OJC): 113.0

RCO: N/A

Emergency: N/A



RUNWAY SAFETY
Everyone's Responsibility
STAY ALERT!

FEDERAL AVIATION ADMINISTRATION Central Region Runway Safety Program http://www.faa.gov/runwaysafety

Information Only - Not for Navigational Purposes [⊥] 38°50.5′N -[⊥] T HANGARS ELEV HANGAR **HANGAR** 1085\ \ \ \ \ \ \ \ \ FBO HANGAR **FIELD** HANGAR **HANGAR ELEV** 1087 175.6° CONTROL TOWER 38°50.0'N **FBO HANGARS** HANGAR 1085 7339 X 190 CAUTION: During times when the Sun is at low angles, i.e. early morning, late afternoon and evening, Hold Position Markings on East-West taxiways can become obscured due to glare. 1051 TT350 0.1° W

HOT SPOTS

1. Use caution when operating near the complex intersection of Runway 17-35, Taxiway Bravo, and Taxiway Charlie. Be alert to vehicles and aircraft operating in the area.

Taxiing aircraft transitioning from Taxiway Charlie to Taxiway Alpha MUST first hold short of Runway 17-35 at Charlie as the "turn" is inside the Runway Safety Area. SEE INSET BELOW

- 2. Use caution when taxiing on Taxiway Alpha on the northwest side of the airport to ensure wingtip clearance from security fence and aircraft parked on the military ramp.
- **3**. Aircraft landing Runway 17-35; DO NOT confuse Runway 4-22 as the taxiway to either the main ramp to the West, or the General Aviation ramp to the Northeast.

DO NOT enter Runway 4-22 without ATC authorization when the tower is operational. Use caution at this intersection as aircraft may be operating on both runways when tower is closed.

Pilots are strongly encouraged to broadcast position and intentions while operating on the airport surface and in the pattern on CTAF (Common Traffic Advisory Frequency), 133.0, during the hours when the IXD tower is closed.