

Runway 17/35, Runway 32 and Taxiway N



Runway 32 Approach Hold Line is Located ON Taxiway A.



Runway 17/35 and Taxiway A

Air Traffic Control: (402) 458-2423 Air Traffic Control: (402) 474-3011 Hours of Operation: Airport 24 hours

Tower 0530L-0000L(midnight)

Latitude: N40°-51-06 Longitude: W96°-45-56 Airfield Elevation: 1219 feet. Variation: 5.8° E

From City: 4 miles NW Sectional Chart: Omaha

Control Tower: Yes

ARTCC: Minneapolis

FSS: OLU - 866-288-3448

NOTAM Facility: Columbus (OLU)

Wind Indicator: Yes Yes Beacon: Fire and Rescue: Yes Airline Operations: Yes Customs: No UNICOM: 122.95 ATIS: 118.05 LNK Ground: 121.9 LNK Tower: 118.5 Clearance Delivery: 120.7

Approach Control: 124.0 (170° -349°)


124.8 (350° -169°)


ASOS: (402) 474-9214

VOR: 116.1

RCO: 122.65 Columbus

Emergency: 121.5 Not available at Tower





HOT SPOTS

- 1. RUNWAY 17L/35R AND TAXIWAY N. Pay particular attention when crossing runway 17/35 from the east ramp. To clear Runway 17/35 safety area the appropriate stop point is at the hold sign for Runway 32
- 2. RUNWAY 32 APPROACH HOLD LINE ON SOUTH TAXIWAY A. Pilots will be instructed to hold short at the "32 APCH" sign when Runway 32 is in use. In that case, aircraft should not proceed beyond the "32 APCH" sign without ATCT clearance.
- **3**. RUNWAY 35 AND TAXIWAY A. When landing Runway 35 use caution not to mistake Taxiway A for Runway 35. REILS are located on Runway 35.
- 4. RUNWAY 18, 14 AND TAXIWAYS E, D, J. Use extreme caution when operating near this complex intersection.
- 5. DO NOT CONFUSE RUNWAY 35 FOR RUNWAY 36. Runway 36 is the larger North/South Runway west of Runway 35 and West of the Air Traffic Tower.

