



Taxiway F crosses Runway 14R-32L.



Taxiway C crosses Runways 14R-32L and 18-36.



Taxiway A crosses Runway 18-36.

Airport Operations: (402) 422-6821 Air Traffic Control: (402) 346-6752 Hours of Operation: Airport - 24 hours

Tower - 24 hours

Latitude: N41°-18-16
Longitude: W95°-53-63
Airfield Elevation: 984 feet.

Variation: 5.1° E

From City: 4 miles NE
Sectional Chart: Omaha
Control Tower: Yes

ARTCC: Minneapolis

FSS: OLU - 866-288-3448

NOTAM Facility: Columbus (OLU)

Wind Indicator: No
Beacon: Yes
Fire and Rescue: Yes
Airline Operations: Yes

Customs: Yes - ADCUS AVBL

UNICOM 122.95
ATIS 120.4
OMA Ground: 121.9
OMA Tower 132.1

256.9

Clearance Delivery: 119.9 Approach Control: 124.5 E

120.1 W


ASOS: (402) 344-0324 VOR: 116.3 chan 110


OMA RCO: 122.35 Fort Dodge 122.1R

116.3 T

Emergency: 121.5 Not available on airport

243.0 Not available on airport





HOT SPOTS

Use EXTREME CAUTION while near the center of the airport. The intersections of Taxiways A, C, and F with Runways 14R/32L: and Runway 18/36 create a very complex intersection and great potential for confusion.

- 1. Taxiway F crosses Runway 14R/32L
- 2. Taxiway C crosses the complex intersection of both Runway 14R/32L and Runway 18/36
- **3**. Taxiway A crosses Runway 18/36
- Runway 18 and Taxiway U. Use extreme caution when taxied into take-off position and hold on Runway 18 at Taxiway Uniform. The Hold-Short Position for the intersecting Runway 14L/32R is just immediately south of Taxiway Uniform. Be sure to hold short of Runway 14L/32R when taxied into position on Runway 18.

CAUTION

If unfamiliar with the airport or taxi routes, request progressive taxi instructions from ATC. If in doubt, ASK! Ground Control Frequency is 121.9.

READ BACK ALL HOLD SHORT INSTRUCTIONS!