



Center for Transportation Analysis
Research Brief
Oak Ridge National Laboratory

Aviation Visualization and Analysis

Center for Transportation Analysis (CTA) Research Areas

Aviation Visualization and Analysis
Data, Statistical Analysis
Geo-Spatial Information Tools
Defense Transportation
Energy Policy Analysis
Environmental Policy Analysis
Highway Safety
Intelligent Transportation Systems
Logistics Management
Supply Chain Management
Modeling and Simulation
Transportation Operations
Planning and Systems Analysis
Transportation Security

Understanding Flight Interactions


An ORNL team is supporting the Federal Aviation Administration Flight Standards Certification and Surveillance Division to identify safety-related aviation events using an integrated visualization and analysis tool.



ornl AUSTIN DIGITAL, INC.

The Austin Digital Inc. Flight Operations Quality Assurance (FOQA) tool, Event Measurement System (EMS), was developed to allow user-configured analysis of data from digital flight data recorders. An enhanced EMS, with highly efficient processing of visualization and analysis functions, is used to study radar tracks and airline data to identify flight interactions and so help identify precursors of safety significance.


Radar Approach Control (TRACON) and Los Angeles Center (ZLA) facilities is used. The radar analysis complements analysis from airline partner's Flight Data Analysis (FDA) programs. (*Airline partners are users of the EMS FOQA tool.*)



Analysis of radar data provides additional information for in-flight interactions of partner aircraft, including coordinated maneuvers and Traffic Alert and Collision Avoidance System Resolution Advisories (TCAS RAs).

Identifying a Partner Aircraft in SNA Traffic Interactions

Departures from Santa Ana/John Wayne Airport (SNA) shown as blue tracks, and General Aviation traffic (yellow tracks) are displayed at an altitude of ~3,000 feet traveling level between the San Diego, Los Angeles, and Burbank regions. TCAS events occur ~8,000 feet. Some events are not apparent in radar data, but are identified in airline partner data.




A 3-month period (July to Sep 2004) of radar data for the Southern California Consolidated Terminal

Oak Ridge National Laboratory is managed by UT-Battelle, LLC, for the U.S. Department of Energy under Contract number DE-AC05-00OR22725




SNA Traffic Interactions



Demonstrate Measure


Two interacting aircraft are shown below: an E135 (Embraer Regional Jet 135) and a PA30 (Piper Twin Comanche PA-30) near Tandy Three arrival fix into in Santa Ana/John Wayne Airport (SNA). The aircraft on left responds to a TCAS RA with a climb to increase its separation from the other aircraft. At the shortest duration in separation for these aircraft ~12.2 s is the lateral closure time. (Minimum vertical separation for aircraft ~300 feet and Minimum Lateral Separation ~0.5 nm. These events occur at different times in the sequence).

Tandy Three Arrival into SNA: E135 Interacting with a PA30



Visualization of Flight Pairs

SNA departures are used to show visualization of flight pairs. Flights (with tails) shown in pink are SNA departures, and flights shown in red are close flights that approach closeness in separation.



Summary

- Radar data from Southern California are used to study flight interactions including coordinated maneuvers and Traffic Alert and Collision Avoidance System Resolution Advisories (TCAS RAs).
- The visualization and analysis tool can identify where mid-air collisions are possible in order to determine what preventive measures may be taken to avoid these low-frequency events.
- The ability to dynamically measure flight interactions is applicable to a variety of initiatives, including risk assessment, airspace characterization/management, and interaction analysis of airline data.
- The tool offers benefits for airspace management as well as safety analysis.



For more information regarding this research contact Simon Rose, Center for Transportation Analysis, Oak Ridge National Laboratory, phone (865) 946-1253 or email rosesd@ornl.gov.