

| | | |
|--|------------------------------|--|
| ARCS PROCEDURE: Author: C. Flynn | MPL HANDSET PROCEDURE | PRO(MPL)-017.000 June 1, 1999 Page 1 of 3 |
|--|------------------------------|--|

MPL Handset Procedure

I. Purpose:

This procedure deals with the MPL handset. This is the information that Connor Flynn would want whenever there is a problem with the MPL.

II. Cautions and Hazards:

None

III. Requirements:

None.

IV. Procedure:

A. Steps:

1. One of the following worksheets is for when the MPL green light is ON.
2. The second worksheet is for when the green light is OFF.

V. References:

None.

VI. Attachments:

1. Green Light On Worksheet
2. Green Light Off Worksheet

Attachment 1: Green Light On Work Sheet

GREEN LIGHT ON

Date: _____ Time: _____

1. When you turn on the MPL; 1) does the green light come on automatically, or 2) do you have to press any buttons to get the green light appear? _____
2. On the hand-held unit, is the word **EMISSION** lit? _____
3. On the hand-held unit, is the light above the word **PULSE** lit? _____
4. What is on the computer screen? _____
5. Is the clock updating on the computer screen? _____
6. On the hand-held unit, perform the following steps:
 - a) Press the * key until the word **WATTS** is lit.
 - b) What is the value displayed? _____
 - c) Press the * key until the word **PRF** is lit.
 - d) What is the value displayed? _____
 - e) Press the * key until the word **STATUS** is lit.
 - f) Press the down arrow on the right-hand side.
 - g) You will see text that is shown in Column 1.
 - h) Press the down arrow again.
 - i) Fill in what you see displayed on the hand-held unit in Column 2
 - j) Press the down arrow and you are back at step a).
 - k) Continue steps f) through j) until you get to the bottom of Column 1.

| Column 1 | Column 2 |
|----------|----------|
| HRS1 | |
| PWR1 | |
| CUR1 | |
| TMP1 | |
| MODE | |
| GPIB | |
| SYNC | |
| FDBK | |
| BAUD | |
| PRTY | |
| DBIT | |
| SBIT | |
| FLBD | |
| PWRT | |

Attachment 2: Green Light Off Work Sheet

GREEN LIGHT OFF

Date: _____ Time: _____

1. On the hand-held unit, is the word EMISSION lit? _____
2. On the hand-held unit, is the light above the word PULSE lit? _____
3. What is on the computer screen? _____
4. Is the clock updating on the computer screen? _____
5. On the hand-held unit, perform the following steps:
 - a) Press the * key until the word **WATTS** is lit.
 - b) What is the value displayed? _____
 - c) Press the * key until the word **PRF** is lit.
 - d) What is the value displayed? _____
 - e) Press the * key until the word **STATUS** is lit.
 - f) Press the down arrow on the right-hand side.
 - g) You will see text that is shown in Column 1.
 - h) Press the down arrow again.
 - i) Fill in what you see displayed on the hand-held unit in Column 2
 - j) Press the down arrow and you are back at step a).
 - k) Continue steps f) through j) until you get to the bottom of Column 1.

| Column 1 | Column 2 |
|----------|----------|
| HRS1 | |
| PWR1 | |
| CUR1 | |
| TMP1 | |
| MODE | |
| GPIB | |
| SYNC | |
| FDBK | |
| BAUD | |
| PRTY | |
| DBIT | |
| SBIT | |
| FLBD | |
| PWRT | |