Microchannel Reactors for Automotive Fuel Processors

<u>Sean Fitzgerald</u>, Anna Lee Tonkovich, Dave VanderWiel, Jennifer Zilka, Yong Wang, Michael Lamont, Robert Wegeng

Pacific Northwest National Laboratory Operated by Battelle for the U.S. DOE


Richland, WA 99352, U.S.A.

This work was supported by the EE-OTT (Office of Transportation Technology) of the U.S. Department of Energy

Presentation Synopsis

- Compact Fuel Processor
 - Gasoline Vaporizer
 - Water Gas Shift Reaction
- Compact Processes require microtechnology
- Process Commercialization

Compact Fuel Processor: Gasoline vaporizer



- <u>Size</u>: 8 cm by 10 cm by 4 cm
- Capacity: Vaporized gasoline for 50-kW_e fuel processing system (~ 300 mL/min)
- Implications: Complete fuel processor system = 8 Liters

Patent pending

Compact processes need microtechnology

■ Parallel processing of matter

- Reduce heat transfer resistance
- Reduce mass transfer resistance

■ Component efficiency


- Microtechnology ~ 90% or better
- Conventional technology < microtechnology

■ Fuel Processor size (50 kW_e)

- Microchannel reactor ~ 8 Liters
- Conventional ~ 10x to 100x larger

Compact Processes:Highly effective Heat Transfer

Reduce heat transfer resistance using microchannels




Battelle

High surface area to volume ratio

Low pressure drop through channels


Compact Processes:Highly effective Mass Transfer

Reduce mass transfer resistance with novel catalysts



- Reduce transport distances
- High effectiveness factor

Compact fuel processor: Automotive power



■ Efficiency: 50% vs. 20% for IC engine

■ <u>Issues</u>: Size and cost

■ **Impact**: 58% reduction in CO₂ per mile traveled


Components: Compact 50kW_e fuel processor

Microtechnology:


~ 8 liters

Current technology:

> 300 liters




Microchannel Gasoline Vaporizer: Compact 50-kW_e Fuel Processor




- Attributes: Four parallel cells
- <u>Size</u>: 8 cm by 10 cm by 4 cm
- Capacity: Gasoline (~ 300 mL/min)
- Implications: Complete fuel processor system = 8 Liters
- Fabrication: Laminate process
- Pressure drop: ∆P < 2psi (through microchannels at ~ 1400 SLPM)</p>

Microchannel Gasoline Vaporizer




Microchannel Vaporizer





Compact Gasoline Vaporizer: Full-scale Performance



Gasoline vaporized: ~ 300 mL/min

Feed gas (anode effluent + air: ~ 1400 SLPM

Battell

Automotive fuel processor: Compact water gas shift reactor

$$CO + H_2O \Rightarrow CO_2 + H_2$$
 (desired)
 $\Rightarrow CH_4$, $C(s)$ (undesired)

Conventional technology:


- $\tau = 1 \sec$
- 300 500 C

Compact microtechnology:

Patent pending

- $\tau = 25 \text{ msec}$
- 300 500 C

Compact Water Gas Shift Reaction Performance data




Fast kinetics required for compact process

Non-equilibrium products favored at short contact times

Compact Water Gas Shift Reaction Performance data

At 25 ms, Conversion > 99%, Selectivity ~ 100%





Compact 50-kW_e Fuel Processor

Components

- Vaporizer
- Primary Conversion
- WGS
- CO Cleanup

■ System

- Total ~ 8 L
- Less than 3 laptops

Power density


- U.S. target: 0.5 kW_e/L
- PNNL expectation: 6.5 kW_e/L



Commercializing compact processes


Laminate Sheet Architecture

- Multiple microcomponents per sheet enables scale-up
- Each sheet performs one or more unit operations
- U.S. # 5,611,214 (issued 3/18/97)
- U.S.# 5,811,062 (issued 6/11/98)
- Others pending (U.S. and foreign)




Pacific Northwest National Laboratory

Commercializing compact processes: Laminate fabrication



Economy of mass production, not economy of scale



Battelle: Leading the way in compact process development

- Demonstrated compact microreactors
- Developing other applications
- Building a portfolio of intellectual property
 - Enabling sheet architecture
 - Catalysts
 - Components & systems
 - Low cost manufacturing methods
- Interested in deploying technology with commercialization partners