

*The indicator monitors temperature exposure, not product quality*

## Vaccine Temperature Management

A 3M MonitorMark™ Time Temperature Indicator has been packaged with this shipment by McKesson to assure that the enclosed vaccines have been shipped under manufacturer-recommended conditions.

## Receiver Instructions

Immediately upon shipment receipt:

- Remove the 3M MonitorMark Time Temperature Indicator from the shipment container
- Store vaccines as instructed below
- Follow instructions on reverse side to utilize the 3M MonitorMark Time Temperature Indicator properly

## Vaccine Storage Requirements

- Take the product out of the shipment container immediately upon shipment receipt
- If damage is evident, contact your Project Point of Contact (PPOC) within 2 hours of shipment receipt
- Remove the product from the zippered plastic bag
- Refrigerate immediately
- Store at 35° to 46°F (2° to 8°C)
- Do not freeze or expose to freezing temperatures

## McKesson Specialty

## How to Read

Immediately upon shipment receipt, remove the 3M MonitorMark Time Temperature Indicator and check the Index.

### For MMR vaccines:

- If the Index color is 0-1, store the products as instructed and begin use.



- If the Index color is 2-5, store the product as instructed and contact your PPOC for further instruction prior to using.



### For all other vaccines:

- If the Index color is 0-2, store the products as instructed and begin use.



- If the Index color is 3-5, store the product as instructed and contact your PPOC for further instruction prior to using.



## 3M MonitorMark Time Temperature Indicator decision table:

Indicator Color	Vaccine Type	
	MMR	All Other Vaccines
0-1	Begin using vaccines	
2	Contact PPOC	Begin using vaccines
3-5	Contact PPOC	

This document can be found on the CDC website at:

<http://www.cdc.gov/vaccines/programs/vmbip/downloads/newsletters/ipc-3m-monitor.pdf>