

Sec. 2.23. Weights

A. Application

A.1. This code applies to commercial weights; that is, weights used in connection with commercial weighing devices.

A.2. This code does not apply to test weights or to other "standards" of mass.

A.3. See also General Code requirements.

S. Specifications

S.1. Material. - The material used for weights shall be as follows:

- (a) Weights of 6 g or 100 gr and larger shall be made of a metal, or a metal alloy, not softer than brass.
- (b) Weights of less than 6 g or 100 gr may be made of aluminum, but shall not be made of iron or of unplated steel, except stainless steel.

S.2. Design.

S.2.1. Surface. - The surface of a weight shall be smooth and shall not be coated with thick, soft, or brittle material. A weight of more than 2 g or 30 gr or shall not have sharp edges, points, or corners.

S.2.2. Ring. - A ring on a weight shall not be split or removable.

S.3. Adjusting Material. - Adjusting material shall be securely positioned and shall not project beyond the surface of the weight.

S.4. Marking Requirements.

S.4.1. General. - A weight shall be marked to show clearly its nominal value, which shall include identification of the unit; however, the nominal value of a weight of 30 gr or 2 g, or less, may be designated by dots, lines, figures, distinctive shape, or other appropriate means.

S.4.2. Apothecaries' Weights. - On apothecaries' dram, ounce, and pound weights, the letters "ap" shall be used

in combination with the nominal value and the appropriate abbreviation of or symbol for the unit.

S.4.3. Troy Weights. - On troy ounce and pound weights, the letter "t" shall be used in combination with the nominal value and the appropriate symbol of the unit.

S.4.4. Metric Weights. - On metric weights, the symbols "kg," "g," and "mg" shall be used in combination with the nominal value of kilograms, grams, and milligrams, respectively.

S.4.5. Carat Weights. - On carat weights, the letter "c" shall be used in combination with the nominal value.

S.4.6. Counterpoise Weight. - A counterpoise weight shall be marked to show clearly both its nominal value and the value it represents when used on the multiplying-lever scale for which it is intended.

N. Notes

N.1. Testing Procedures. - Commercial weights should be tested on a precision balance using standard weights, the errors of which, when used without correction, do not exceed 1/3 of the smallest tolerance to be applied. (See Appendix A; Fundamental Considerations paragraphs 3.2. and 3.3.)

T. Tolerances

T.1. In Excess and in Deficiency. - The tolerances hereinafter prescribed shall be applied equally to errors in excess and errors in deficiency.

T.2. On Avoirdupois Weights. - The maintenance tolerances shall be as shown in Table 1. Acceptance tolerances shall be one-half the maintenance tolerances.

T.3. On Metric Weights. - The maintenance tolerances shall be as shown in Table 2. Acceptance tolerances shall be one-half the maintenance tolerances.

T.4. On Carat Weights. - The maintenance tolerances shall be as shown in Table 2. Acceptance tolerances shall be one-half the maintenance tolerances.

2.23. Weights

T.5. On Apothecaries' and Troy Weights. - The maintenance tolerances shall be as shown in Table 3. Acceptance tolerances shall be one-half the maintenance tolerances.

| Table 1. Maintenance Tolerance for Avoirdupois Weights | | | | | | |
|---|-------------------|------|---|------|---|-----|
| Maintenance Tolerance | | | | | | |
| Nominal Value | Equal-Arm Weights | | Counterpoise Weights | | | |
| | | | For scales with multiples of less than 1000 | | For scales with multiples of 1000 or over | |
| oz | grains | mg | grains | mg | grains | mg |
| 1/64 | 0.1 | 6 | | | | |
| 1/32 | 0.3 | 19 | | | | |
| 1/16 | 0.4 | 26 | | | | |
| 1/8 | 0.5 | 32 | | | | |
| 1/4 | 1.0 | 65 | | | | |
| 1/2 | 1.5 | 97 | 1.0 | 65 | | |
| 1 | 1.7 | 110 | 1.0 | 65 | | |
| 2 | 2.0 | 130 | 1.0 | 65 | | |
| 3 | 2.0 | 130 | 1.5 | 97 | | |
| 4 | 3.0 | 190 | 1.5 | 97 | 1.0 | 65 |
| 5 | 3.5 | 230 | 1.5 | 97 | 1.0 | 65 |
| 6 | 3.5 | 230 | 1.5 | 97 | | |
| 8 | 4.0 | 260 | 2.0 | 130 | 1.5 | 97 |
| 10 | 4.0 | 260 | 2.5 | 160 | 2.0 | 130 |
| 12 | 5.0 | 320 | 2.5 | 160 | 2.0 | 130 |
| lb | grains | mg | grains | mg | grains | mg |
| 1 | 5.0 | 320 | 3.0 | 190 | 2.5 | 160 |
| 2 | 7.0 | 450 | 6.0 | 390 | 4.0 | 260 |
| 3 | 9.0 | 580 | 9.0 | 580 | 5.0 | 320 |
| 4 | 11.0 | 710 | 11.0 | 710 | 6.0 | 390 |
| 5 | 15 | 970 | 12.0 | 780 | 6.5 | 420 |
| 6 | 17 | 1190 | | | | |
| 7 | 19 | 1200 | | | | |
| 8 | 21 | 1400 | 15.0 | 970 | 9.0 | 580 |
| 9 | 23 | 1500 | | | | |
| 10 | 25 | 1600 | 18.0 | 1160 | 10.0 | 650 |
| 15 | 28 | 1800 | | | | |
| 20 | 30 | 1900 | | | | |
| 25 | 35 | 2300 | | | | |
| 30 | 40 | 2600 | | | | |
| 40 | 45 | 2900 | | | | |
| 50 | 50 | 3200 | | | | |

| Table 2. Maintenance Tolerances for Metric Weights | | | |
|---|-------------------------------|-----------------------------------|-------------------------------|
| Nominal Value (mg) | Maintenance Tolerance (mg) | Nominal Value (g) | Maintenance Tolerance (mg) |
| 5 or less | 0.1 | 1 | 4 |
| 10 | 0.3 | 2 | 6 |
| 20 | 0.4 | 3 | 8 |
| 30 | 0.6 | 5 | 10 |
| 50 | 0.8 | 10 | 15 |
| 100 | 1.0 | 20 | 20 |
| 200 | 1.5 | 30 | 30 |
| 300 | 2.0 | 50 | 40 |
| 500 | 3.0 | 100 | 70 |
| | | 200 | 100 |
| | | 300 | 150 |
| | | 500 | 175 |
| Nominal Value (kg) | Maintenance Tolerance (mg) | Nominal Value (carats) | Maintenance Tolerance (mg) |
| 1 | 250 | 0.25* | 0.6 |
| 2 | 400 | 0.5** | 1.0 |
| 3 | 500 | 1.0 | 1.5 |
| 5 | 800 | 2.0 | 2.0 |
| 10 | 1000 | 3.0 | 3.0 |
| 20 | 1500 | 5.0 | 4.0 |
| | | 10.0 | 6.0 |
| | | 20.0 | 10.0 |
| | | 30.0 | 12.0 |
| | | 50.0 | 15.0 |
| | | 100.0 | 25.0 |
| | | *25 points or less **50 points | |

2.23. Weights

| <p align="center">Table 3. Maintenance Tolerances For Apothecaries' and Troy Weights</p> | | | | | |
|---|-----------------------|------|---------------|-----------------------|--------|
| Nominal Value | Maintenance Tolerance | | Nominal Value | Maintenance Tolerance | |
| | grains | mg | | grains | mg |
| 1 | 0.01 | 0.6 | 1 | 0.4 | 25.0 |
| 2 | 0.02 | 1.3 | 2 | 0.6 | 40.0 |
| 3 | 0.03 | 2.0 | 3 | 1.0 | 65.0 |
| 5 | 0.03 | 2.0 | 4 | 1.5 | 100.0 |
| 10 | 0.04 | 2.5 | 5 | 1.6 | 105.0 |
| 20 | 0.06 | 4.0 | | | |
| scruples | grains | mg | oz | grains | mg |
| 1 | 0.06 | 4.0 | 6 | 1.8 | 115.0 |
| 2 | 0.10 | 6.5 | 7 | 1.9 | 125.0 |
| | | | 8 | 2.0 | 130.0 |
| | | | 9 | 2.1 | 135.0 |
| | | | 10 | 2.2 | 145.0 |
| dr | grains | mg | oz | grains | mg |
| 0.5 | 0.07 | 4.5 | 11 | 2.4 | 155.0 |
| 1.0 | 0.10 | 6.5 | 12 | 2.5 | 160.0 |
| 2.0 | 0.20 | 13.0 | 20 | 2.9 | 190.0 |
| 3.0 | 0.30 | 20.0 | 30 | 3.7 | 240.0 |
| 4.0 | 0.40 | 25.0 | 50 | 5.4 | 350.0 |
| 5.0 | 0.50 | 30.0 | | | |
| 6.0 | 0.60 | 40.0 | | | |
| dwt | grains | mg | oz | grains | mg |
| 1 | 0.06 | 4.0 | 100 | 7.7 | 500.0 |
| 2 | 0.10 | 6.5 | 200 | 12.3 | 800.0 |
| 3 | 0.15 | 10.0 | 300 | 15.4 | 1000.0 |
| 4 | 0.20 | 13.0 | 500 | 23.1 | 1500.0 |
| 5 | 0.30 | 20.0 | 1000 | 38.6 | 2500.0 |
| 10 | 0.40 | 25.0 | | | |