The Thief Process for Mercury Removal from Flue Gas





Evan J. Granite, Mark C. Freeman, Richard A. Hargis, William J. O'Dowd, Henry W. Pennline NETL and Brian S. Higgins Mobotec USA

United States Department of Energy National Energy Technology Laboratory Mercury Control Technology Conference Pittsburgh, PA December 2006





Thief Process

- Alternative to activated carbon injection (ACI)
- Extraction of partially combusted coal from furnace & re-injection downstream of preheater
- Recent results show similar removals to ACI
- Licensed to Mobotec USA May 2005
- Further development through collaborative research efforts
- Utility pilot tests shortly



Regulatory Drivers

- EPA Announcement March 15, 2005
- Clean Air Mercury Rule
- Several States Requiring Stricter Reductions
- 70-90% Removal Requirement
- Phased in Over Several Years





Fossil Energy Program Goals

Develop more effective mercury control options


- Cost-effective and high level of mercury removal
- Meet long-term IEP program goal of 90% mercury reduction at cost reduction of 25-50%






Technical Challenges *Mercury is Difficult to Capture*

- Low concentration
- Can exist as Hg⁰
- Harsh conditions of coalderived flue gas
- Competitive adsorption / poisoning
- Low sorbent reactivity
- Hg is semi-noble metal





NETL BENCH-SCALE PACKED BED REACTOR







Bench-Scale Packed Bed Reactor

- ¹/₂-inch OD by 12-inch long quartz tube
- 100 mg of sorbent
- Temperature: 280°F 320°F
- Gas Composition: slipstream of PRB or PRB/Bituminous particulate-free flue gas
- Flow-rate: 8 liters/min
- Sir Galahad CEM: inlet/outlet mercury









Lab Results: Commercial Carbons

<u>Sorbent</u>	Capacity (mg/g)	<u>Temp (°F)</u>
FluePac AC	0.89	280
Darco AC	1.60	280
Insul AC	1.96	280
Insul AC	0.19	400
S-AC-1	1.55	280
S-AC-2	1.39	280

Physical Adsorption Favored By Low Temperature

- Unpromoted carbons display good capacity
- Sulfur promotion does not increase capacity

Cost of sulfur addition is not justified

Lab Results: Thief Sorbents

<u>Sorbent</u>	Capacity (mg/g)	Temp (°F)
Thief-1	2.19	280
Thief-2	1.80	280
Thief-3	1.38	280

Promising Carbon Sorbents

- Cheaper than activated carbons
- Large removals displayed in lab and pilot tests
- Partially combusted coal, produced in-situ
- Removal from furnace via lance ("Thief")

Initial Bench-Scale Results

<u>Sorbent</u>	5% Breakthrough (min)	
Darco AC	120	
Thief	60	
Thief-HCI	90	
Fly Ash	≤ 10	





Coal: Activated Carbon Precursor

- Contains Numerous Reactive Moieties
- Enormous Concentration Relative to Hg
- Conventional AC Manufacture Harsh
- High Temperature and Long Residence Time
- High Surface Area
- Lose or Passivate Reactive Species
- O, S, Se, Te, Cl, Br, I, and Metal Oxides
- Likely Retained on Surface for Thief Carbons




Norit Darco Versus Thief Sample (50 micron)








Initial Mercury Removal Results - Darco FGD versus Thief Sorbent





Mercury Removal Results - Darco FGD versus Thief Sorbent



Heat Rate Penalties

- Heating Value Extracted Solids & Gas
- Sensible Heat Loss When Cooling Solids & Gas
- Heat Transfer from Furnace Gas to Small High Temperature Thief Probe

Can Be Minimized by Use of Heat Exchanger



Parasitic Power Requirements

- Fan Power for Extraction of Sorbent & Gas
- Fan Power for Reinjection of Sorbent
- Pneumatic Injection if Thief Sorbent Stored
- Pulverizer Power for Make-up Coal
- Circulation of Any Heat Exchanger Fluids
- Incremental ID Fan Requirements for Additional Flue Gas Associated With Make-up Coal



Thief Carbons

- High BET Surface Areas
- Large Iodine Numbers
- Between 80-250 m²/g
- Approaching SA of Commercial AC
- Cheaper than Commercial AC
- Comparable Mercury Capacity/Reactivity
 <u>Cost Estimate for Thief Carbons</u>
- \$90-\$200/ton
- \$500-\$3000/ton for AC



Conclusions: Thief Process Thief sorbents exhibit high capacity

- Lab, bench, & pilot-scale tests
- Capacities comparable to AC
- Lower cost carbon
- Small parasitic power requirements
- Minor heat rate penalties
- Commercial potential
- Further development by Mobotec USA



Application 2: Thief Carbon Catalysts

Simple Strategy → Oxidation of Hg

- Enhance Capture in Scrubbers
- Improve Capture in Particulate Control Device

ESP or Baghouse



Thief Carbon Catalysts

Advantages

- Cheaper than Precious Metals or Activated Carbons
- Easy to Impregnate
- Cheap Enough to Be Throw-Away Catalyst
- Bench-Scale Results



Results: Thief Catalyst

NETL 500-lb/hr Pilot Combustion Facility

- Catalyst: HCI-Treated Thief Carbon
- Mass: 100 mg
- Mercury Concentration: 10 µg/Nm³ Total
- Mercury Concentration: 8 µg/Nm³ Elemental
- 6 hrs On-Line
- 75% Oxidation of Mercury
- Level of Oxidation Increases With Time
- High Level of Oxidation Demonstrated

