



U.S. Department of Energy
Office of Civilian Radioactive Waste Management



Oxygen Electro-reduction on C22 and C276 Nickel Metal Alloy

Stephen P. Rogers*, Dominic Gervasio
Arizona State University, Tempe, AZ

&

Joe H. Payer
Case Western Reserve University, Cleveland, OH

210th ECS Meeting
Cancun, Mexico
Nov. 1, 2006

Acknowledgement and Disclaimer

- **Support of the Science and Technology Program of the Office of the Chief Scientist (OCS), Office of Civilian Radioactive Waste Management (OCRWM), U.S. Department of Energy (DOE) is gratefully acknowledged. The work was performed under the Corrosion and Materials Performance Cooperative, DOE Cooperative Agreement Number: DE-FC28-04RW12252.**
- **The views, opinions, findings, and conclusions or recommendations of authors expressed herein do not necessarily state or reflect those of the DOE/OCRWM/OCS.**



- **Objective: determine if O_2 is reduced on C22 and C276 in 1M KOH**
- **Materials and methods**
 - **C22 and C276 surface preparation**
 - **O_2 reduction by CPRM method: standardized to Au disc – Au ring**
 - **O_2 reduction by CPRM method for C22 and C276**
- **Estimate of rate constants for O_2 reduction on C22 and C276**
- **Future Research**
 - **FTIR of C22 and C276 surface oxides**
 - **O_2 reduction in presence of nitrates and chloride**
- **Additional Acknowledgments**



Oxygen Electro-reduction on C22 and C276 Nickel Metal Alloy

- **Project Objective:**

- To establish if O_2 reduction occurs on alloys C22 and C276 in aqueous alkaline electrolyte.
- Determine conditions and extent (kinetics) of O_2 reduction on C22 and C276.
 - Determine the sustained O_2 reduction potential(s) on hastelloys in alkaline media
 - Identify products of O_2 reduction and their rates of formation
 - Provide experimental results in a form suitable for inputting to computational methods for predicting alloy corrosion processes

- **Approach:**

- Measure electrochemical behavior of fresh and aged alloys in aqueous alkaline (KOH) electrolyte in the presence or absence of O_2 , with and without additives (KNO_3 , Cl^- , particles) at various temperatures.
 - Voltammetry with electrode in still solution
 - Rotating ring-disc electrode (RRDE)
 - Electrochemical impedance spectroscopy (EIS)
 - Electrochemical Fourier Transform Infrared (Echem-FTIR)




Nickel Metal Alloy wt% Compositions

Alloy Designation	UNS#	C	Co	Cr	Cu	Fe	Mn	Mo	Ni	P	S	Si	V	W
Hastelloy(R) C276	N10276	4e-3	1.45	15.74	n/a	5.58	0.50	15.53	57.55	0.008	0.003	0.02	0.163	3.45
Hastelloy(R) C22	N06022	4e-3	0.72	21.00	n/a	3.90	0.23	13.30	57.90	0.011	0.004	0.026	0.013	2.90
Hastelloy(R) C2000	N06200	1e-3	0.05	22.71	1.54	0.65	0.23	15.64	59.12	0.003	0.004	0.043	n/a	n/a

n/a – not reported on analysis certificate.



Approach



- **Planarized electrode** – Allied HiTech 8" polishing table: wet 800, 1200, 2400 grit SiC; wet 5um, 3um, 0.5um alumina
- **Mirror surface finish** – Hand polishing fixture: wet felt 1um, 0.3um, and 0.05um alumina slurry
- **Prior to Echem** – Random hand polish: wet felt 0.05um alumina slurry; rinse in 95% EtOH, then 18.2 MΩ H₂O

Apparatus:

- Pine rotator (in blue)
- Jacketed Pyrex 5-neck cell
- Configured with bridged SCE reference
- Spectroscopic graphite auxiliary electrode
- RRDE (Au ring, hastelloy disc)
- Sparging tube
- PAR VMP2 controller w/ ver. 9.13 software
- Circulating glycol-H₂O (thermostat control: ±1° C)



The Cyclic Potential Ring Measurement (CPRM) Method

Rotating Ring Disc Electrode (RRDE) technique:

- Continuously cycle the ring over a small potential range for oxidation;
- Concurrently, step potentiostatically the disc in a range for reduction.

Reproducible, “clean” ring surface for quantitative ring electrode detection; background subtraction for low level detection, and does not underestimate the role of H₂O₂ production.

N. R. K. Vilambi and E. J. Taylor,

J. Electroanal. Chem., **270** (1989) 61-77;

Electrochimica Acta., **34**, no. 10, (1989) 1449-1454.

- **Quantitative description of peroxide formation during oxygen reduction on Au and Pt in alkaline media.**

D. Gervasio, J. H. Payer,



in “*Fundamental Understanding of Electrode Processes, in Memory of Professor Ernest B. Yeager*”, Proceeding of the Electrochemical Society, Orlando, FL, J. Prakash, D. Scherson, M. Enayetullah and In-Tae Bae, Editors, (2003) 58–70.

- **Kinetics of oxygen electro-reduction on steel by CPRM in alkaline media were investigated.**



Cyclic Voltammetry Potential Range Surveys for CPRM Method


(Ar de-aerated 1M KOH @ 30°C, pH = 14, 500mV/s scan rate, 4900 rpm, 6th cycle)



- Little to no slope around 0 mA shows good RRDE configuration.
- C22 & C276 have very similar responses w/ C276 having less metal oxide formation and reduction than C22.




Cyclic Potential Ring Measurement (CPRM) Method – Timing for Au-Au RRDE



Cyclic Potential Ring Measurement (CPRM) Method

Series Reduction of O_2 on Au in 1M KOH @ 30° C, pH = 14

Current work at ASU




CPRM Plots

Au Ring (0.126 cm²) currents
(averaged from 0.5V to 0.6V on 14th cycle; scan: -0.25V to 0.7V @ 500mV/s)

Au disc (0.283 cm²) currents

Taken from Vilambi and Taylor, *J. Electroanal. Chem.*, **270** (1989) 61-77



- Our findings are very similar to those of Vilambi's work, calibrating our methodology.




Cyclic Potential Ring Measurement (CPRM) Method


for O_2 Reduction to H_2O_2 in 1M KOH @ 30° C, pH = 14

Levich Plots

Au Disc (0.283 cm²)



Au Ring (0.126 cm²)




- As the rotation rate increase, the limiting currents increase linearly with the square root of the rotational speed in accordance with Levich's equation.



Cyclic Potential Ring Measurement (CPRM) Method

for O₂ Reduction to H₂O₂ in 1M KOH @ 30° C, pH = 14




- Our CPRM experiment repeats Vilambi's findings of 100% current collection in the potential range (-0.4V to -0.8V) for the first reduction in the series mechanism for O₂ on Au, and validates our methodology.



Cyclic Potential Ring Measurement (CPRM) Method – Timing for Au-Ni RRDE


Au ring potential cycled from -0.25V to 0.7V at 500mV/s;
ring currents evaluated during anodic scan at cycle 14



Cyclic Potential Ring Measurement (CPRM) Method


Series Reduction of O_2 on Hastelloys in 1M KOH @ 30° C, pH = 14

CPRM Plots



Au Ring (0.126 cm²) currents
(averaged from 0.5V to 0.6V on 14th cycle; scan: -0.25V to 0.7V @ 500mV/s)

Ni disc (0.283 cm²) currents
(averaged over 30s during the Au ring cyclic voltammetry)




- A difference of ~ 0.1 V for H_2O_2 formation between C22 & C276.



Cyclic Potential Ring Measurement (CPRM) Method

C276 Ni; 1M KOH @ 30° C, pH = 14; 2500 rpm



Disc currents on C276 in 1M KOH equilibrated with:

- Ar,
- O_2 ,
- H_2O_2 under Ar

• O_2 reduction occurs in two waves (-0.5 to -1; -1 to -1.4);


• H_2O_2 reduction occurs in one wave (-1 to -1.4);

• Indicates a 2-step series reduction path for O_2 reduction to H_2O :

- first: $O_2 \rightarrow H_2O_2$
- second: $H_2O_2 \rightarrow H_2O$.



Rate Constant Evaluation



Assumptions:

- 1st order dependence on $[O_2]$
- $[O_2] = 0.00022 \text{ mol/l @ } 30^\circ \text{ C}$
- no catalytic decomposition of H_2O_2

H. S. Wroblowa, Y. D. Pan, and G. Razumney
 , *J. Electroanal. Chem.*, **60**, (1976) 195.

S. Zecevic, D. Drazic and S. Gojkovic, *J. Electroanal. Chem.*, **265**, (1989) 179.

CPRM data applied to

$$j_{\text{kinetic}} = j_L j / (j_L - j)$$

$$j_{\text{kinetic}} = k_{\text{exp}} n [O_2]^1$$




Estimated rate constants k_2 & k_3



Estimated Rate constants for O₂ Reduction on C22 & C276 in 1M KOH @ 30° C; pH =14

- Assuming a series mechanism; &
- Using CPRM disc data & the relations $j_{kinetic} = j_L j / (j_L - j)$, $j_{kinetic} = k_{exp} n [O_2]$.



- The estimated rate constants for H₂O₂, k_2 , and H₂O, k_3 , formation are greater for C276 than C22 for the same potential.




- Standardized and calibrated RRDE approach for O₂ reduction kinetics on hastelloy discs using the CPRM method of Vilambi & Taylor that used Au ring – Au disc;
- Oxygen reduction on C22 & C276 in alkaline water to peroxide onsets at about -0.6V; continues to -1.4V; maximizes at -1.1V (on C22) and -1.0V (on C276) vs. SCE;
- The H₂O₂ → H₂O onset at -1V vs. SCE; the limiting H₂O₂ current was ill-defined due to overlap with H₂ generation at more negative potentials;
- Estimated rate constants, k_2 and k_3 , from CPRM data for:

	C22	C276	
i) O ₂ → H ₂ O ₂ @ -0.7V	0.001	0.013	(cm/s)
ii) H ₂ O ₂ → H ₂ O @ -1.2V	0.193	0.232	(cm/s)



EChem-FTIR



Gas inlet/diffusion tube


PEEK plunger

FTIR box mount w/ rotation, tilt, vertical & horizontal positioning

Pt counter electrode wire; 1mm OD, coiled

Working electrode material; 18mm OD

Reference electrode reservoir to Luggin tip



- Standard window size (32mm OD x 2mm thick) is easily exchanged;
- Can be completely disassembled



Additional Acknowledgements

Design and fabrication assistance on the EChem-FTIR cell was provided by scientific glassware designer **Janice Kyle**, Dept. of Chemistry & Biochemistry at Arizona State University and by Sr. designer & instrument maker **Zoltan Farkas**, Dept. of Physics at Arizona State University.

