

# Small-Particle Plasma Spray (SPPS) Thermal Barrier Coatings

K. Faber, J. Mawdsley, J. Su and R. Trice  
Department of Materials Science And Engineering

and

T. Bernecki

Advanced Coatings Technology Group  
Northwestern University, Evanston, IL

Research supported by the USDOE's FETC under a  
cooperative agreement DE-FC21-92MC24061 with SCERDC  
under subcontract No. 96-01-SR047,  
Lawrence Golan, Technical Representative


# Sample Fabrication

- Used Small Particle Plasma-Spray (SPPS) powder injection technology:


Allows small particles to be placed into the plasma in a more controlled manner

- Reduces powder vaporization
- Less open porosity in coatings

- U.S. Patent No. 5,744,777



# TBC Studies Using SPPS



# The Current Work:


Understand the properties of SPPS coatings through:

- I. Characterization of coatings as a function of spraying conditions.
- II. Development of a mechanical test to assess elastic properties and damage mechanisms.


# I. Comparison of Microstructure, Thermal Conductivity and Damage Tolerance for Two Spraying Conditions

	<b>“COOLER” Conditions</b>	<b>“HOTTER” Conditions</b>
<b>Power</b>	25 kW	40 kW
<b>% Hydrogen</b>	10%	20%
<b>Total Gas Flow</b>	50 SLM	40 SLM
<b>Spray Distance</b>	6 cm	6 cm
<b>Injector Offset</b>	11 mm	11 mm
<b>Injector Angle</b>	30°	30°

# Splat Morphology




COOLER Conditions




HOTTER Conditions

# Coating Microstructure: Polished Top Surfaces



Cooler Conditions



*91% dense*



Hotter Conditions

*92.2% dense*

# Small-Angle X-Ray Scattering




- SAXS is sensitive to changes in electron density which can be caused by porosity.
- With this setup, pores in the range of 20 - 400 nm are detected.
- Pattern can be analyzed to get scattering area to volume ratio.

# SAXS, Conductivity and Hardness

	<b>Hotter Conditions</b> (92.2% dense)	<b>Cooler Conditions</b> (91% dense)
<b>As Sprayed:</b> S/V Conductivity Hardness	$62 \pm 8 \text{ cm}^2/\text{cm}^3$ $1.7 \pm 0.1 \text{ W/m K}$ $6.5 \pm 0.2 \text{ GPa}$	$122 \pm 21 \text{ cm}^2/\text{cm}^3$ $2.1 \pm 0.1 \text{ W/mK}$ $7.5 \pm 0.3 \text{ GPa}$
<b>1200°C/600 hr:</b> S/V	$17 \pm 1 \text{ cm}^2/\text{cm}^3$	$23 \pm 3 \text{ cm}^2/\text{cm}^3$


# Four-Point Bend Testing Setup





- Sensors: DECI model SE 150-m, 7 cm apart
- Monitoring System: Vallen AMS-3
- Coating Thickness: 100  $\mu\text{m}$

# Tension Bending Fatigue with AE

- Fatigue cycle: 0.3 Hz 125-310 MPa




- Waveforms showed that hits >55 dB were very short duration
  - Characteristic of through-crack formation





# Compression Bending Fatigue with AE


- Fatigue cycle: 0.3 Hz 125-310 MPa



- Very good results, no visible damage
- Overall, samples indistinguishable from one another





## II. New Mechanical Test for Coatings to Establish Coating Properties: Stand Alone Coating Test (SACT)



- Need to measure strain very accurately
- Need to balance the load distribution

- Gages bonded with epoxy
- Typical 0-5% difference between gage responses

# Preparing SACT Samples



Side View


1. Plasma-spray alumina on aluminum coated tubes of alumina
2. Cut up 12" tube into 1" tubes and machine ends
3. Soak tubes in Water/HCl for 3 days to dissolve aluminum
4. Wash coatings/dry/physical measurements

## Advantages of this Tube Geometry

Generate 9-10 specimens per 12" tube

Typical coating is only 200  $\mu\text{m}$  thick\*


# Common Mechanical Response: Hysteresis



- Hysteresis loops beyond 25 MPa


- Hysteresis loops widened with increasing stress

# Common Mechanical Response: Decreasing Modulus with Cyclic Loading




- Modulus decreases with increased stress in cyclic loading

# Failure Mechanism: Damage Accumulation via Crack Growth?




- Strain over time with constant stress
- Real change in strain response over time

# Coating Deformation Mechanisms




Cross-Sectional View



Brightfield TEM


- Extremely complex microstructure (lamella are not planar)
- Extremely defective microstructure
  - bimodal porosity distribution
  - large porosity distribution at the interface
  - unmelted particles
  - quench cracks
- Sliding of the adjacent lamellae has been suggested

# TEM Investigation of Deformation Mechanisms




Cross-Sectional View

Fractured Sample (400 MPa)




Brightfield TEM



- No evidence of lamella slipping in any sample

# Summary of Deformation Process

- Intrinsic defects (quench cracks and porosity) in the microstructure react with compressive stress
- Cracks emanate from these defects, turning parallel with the compressive stress
- Likely that cracks follow lamella boundaries
- Ultimately, small cracks grow to long axial cracks and split
- Crack growth mechanism observed in fatigue\*



Sample fractured at 400 MPa

\*E.F. Rejda, Fat. Fract. Engng Mater. Struct. 20 [7] 1043-50 1991)