## **PWD Calibration Check Sheet**

	Command	Response	Reference
1	Complete the cleaning of the lenses		pg 84 of manual
2 3 4	type <b>CLEAN</b> type <b>STA</b> "Backscatter Change" receiver "Backscatter Change" transmitter		pg 85 of manual
5	Complete the cleaning of the RAINCAP		
6	Insert blocking plate into receiver hood		pg 86 of manual
7	type <b>ZERO</b>		<u> </u>
8 9 10	Remove blocking plate Insert calibrator plates Signal Value of Calibrator Plates	532	pg 87 of manual
11	type CHEC		
		100.0	
12	Is the CHEC value within 5% of Signal Value		Hit "ESC" to teminate
13	Is the CHEC value within 20% of Signal Value		Hit "ESC" to teminate
14	type <b>CAL</b> <u>532</u>		pg 88 of manual
15	type CHEC		Hit "ESC" to terminate

FM(PWD)-001.000 Last revised March 2006